


# L-force 9400 Servo Drives



**9400 HighLine V01.37**  
*Parameter setting & configuration*

## **Copyright**

© 2006 Lenze Drive Systems GmbH. All rights reserved.

## **Imprint**

Lenze Drive Systems GmbH

Postfach 10 13 52, 31763 Hameln, Germany

Phone: ++49 (0)5154 / 82-0

Fax: ++49 (0)5154 / 82-2111

E-mail: [Lenze@Lenze.de](mailto:Lenze@Lenze.de)

## **Copyright information**

All texts, photos and graphics contained in this documentation are subject to copyright protection. No part of this documentation may be copied or made available to third parties without the explicit written approval of Lenze Drive Systems GmbH.

## **Liability**

All information given in this documentation has been carefully selected and tested for compliance with the hardware and software described. Nevertheless, discrepancies cannot be ruled out. We do not accept any responsibility or liability for any damage that may occur. Required correction will be included in updates of this documentation.

Depending on the software version of the controller, the screenshots in this documentation may differ from the »Engineer« representation.

## Contents

<b>1</b>	<b>About this Manual</b> .....	<b>16</b>
1.1	Conventions used .....	16
1.2	Terminology used .....	17
1.3	Definition of notes used .....	18
<b>2</b>	<b>Introduction</b> .....	<b>19</b>
2.1	Parameter setting, configuring or programming? .....	19
2.1.1	Technology applications .....	20
2.1.2	Basic functionalities .....	20
2.2	Communicating with the controller .....	21
2.2.1	Going online via diagnostic adapter .....	21
2.2.2	Going online via system bus (CAN on board) .....	24
2.2.3	Use of other communication interfaces .....	24
2.3	Signal types & scaling .....	25
<b>3</b>	<b>Commissioning</b> .....	<b>26</b>
3.1	Notes on commissioning using the keypad .....	27
3.2	Test commissioning .....	28
3.3	Initial commissioning .....	29
3.4	Standard set-up .....	31
3.5	Controller replacement .....	32
3.6	Motor replacement .....	33
<b>4</b>	<b>Drive interface</b> .....	<b>34</b>
4.1	LED status displays .....	34
4.2	Parameter setting .....	35
4.2.1	Machine parameters .....	35
4.2.1.1	Mains voltage .....	36
4.2.1.2	Gearbox ratio .....	37
4.2.1.3	Motor mounting direction .....	38
4.2.1.4	Configuration feedback .....	38
4.2.1.5	Unit/application unit .....	39
4.2.1.6	Traversing range .....	40
4.2.1.7	Feed constant .....	42
4.2.2	Monitoring of the device utilisation .....	43
4.2.3	Parameter for status display .....	43
4.3	Monitoring of external events .....	44
4.4	Set/remove controller inhibit .....	44

4.5	Device states.....	45
4.5.1	Status "initialisation active".....	46
4.5.2	Status "Safe torque off active".....	46
4.5.3	State "Device is ready to switch on".....	47
4.5.4	State "Device is switched on".....	48
4.5.5	State "Operation".....	49
4.5.6	State "Warning active".....	49
4.5.7	State "Warning locked active".....	49
4.5.8	State "Quick stop by trouble".....	50
4.5.9	Status "Trouble active".....	50
4.5.10	State "Fault active".....	50
4.5.11	State "System fault active".....	51
4.6	Controller commands.....	52
4.6.1	Overview of device commands.....	53
4.6.2	Status display for device command.....	54
4.6.3	Start/stop application.....	56
4.6.4	Load Lenze setting.....	56
4.6.5	Save parameter set.....	57
4.6.6	Load parameter set.....	57
4.6.7	Activate application.....	58
4.6.8	Save selected application.....	58
4.6.9	Activate/archive parameter set.....	59
4.7	System block "LS_DriveInterface".....	60
4.7.1	Status signals.....	63
<b>5</b>	<b>Motor interface.....</b>	<b>64</b>
5.1	Initial commissioning.....	65
5.1.1	Read the motor data out of the controller.....	66
5.1.2	Select motor in the »Engineer« motor catalog.....	66
5.1.3	Display/edit motor data in the »Engineer«.....	67
5.1.4	Accept/adapt route data.....	69
5.1.5	Parameterise motor encoder.....	70
5.1.6	Set rotor displacement angle.....	71
5.1.7	Optimise the switching performance of the inverter.....	73
5.1.8	Set motor parameters.....	75
5.1.9	Define currents and speed limits.....	78
5.1.10	Select switching frequency.....	79
5.1.11	Optimise current controller.....	81
5.1.11.1	Correction of the leakage inductance via saturation characteristic.....	82
5.1.11.2	Example for determining the saturation characteristic.....	84

5.2	Extended commissioning .....	87
5.2.1	Optimise speed controller .....	88
5.2.2	Set current setpoint filter .....	90
5.2.3	Optimise phase controller .....	92
5.2.4	Optimise the response to setpoint changes by means of the torque feedforward control .....	93
5.3	Signal flow .....	95
5.4	Parameter setting .....	97
5.4.1	Motor monitoring (I <sup>2</sup> t) .....	98
5.4.1.1	Example for entry of the characteristic for asynchronous servo motor	101
5.4.1.2	Example for entry of the characteristic for synchronous servo motor	102
5.4.2	Special characteristic for motor temperature sensor .....	103
5.4.3	Motor temperature monitoring .....	103
5.5	System block "LS_MotorInterface" .....	104
<b>6</b>	<b>Encoder evaluation .....</b>	<b>108</b>
6.1	Signal flow .....	109
6.2	Parameter setting .....	110
6.2.1	Controller configuration .....	111
6.2.2	System with motor encoder .....	112
6.2.3	System with motor encoder and position encoder .....	113
6.2.4	Use external position encoder. ....	114
6.3	System block "LS_Feedback" .....	115
<b>7</b>	<b>I/O terminals .....</b>	<b>116</b>
7.1	Overview .....	116
7.2	Analog inputs .....	117
7.2.1	Terminal assignment/electrical data .....	117
7.2.2	Parameter setting .....	118
7.2.3	Reconfiguring analog input 1 as a current input .....	118
7.2.4	System block "LS_AnalogInput" .....	119
7.3	Analog outputs .....	120
7.3.1	Terminal assignment/electrical data .....	120
7.3.2	Parameter setting .....	121
7.3.3	System block "LS_AnalogOutput" .....	122
7.4	Digital inputs .....	123
7.4.1	Terminal assignment/electrical data .....	123
7.4.2	Parameter setting .....	123
7.4.3	System block "LS_DigitalInput" .....	124

7.5	Digital outputs.....	125
7.5.1	Terminal assignment/electrical data.....	125
7.5.2	Parameter setting .....	125
7.5.3	System block "LS_DigitalOutput" .....	126
7.6	Monitoring function "State bus" .....	127
7.6.1	Detecting the current status .....	128
7.6.2	Setting the state bus to the status "Error" .....	128
7.7	Touch probe detection.....	129
7.7.1	Actual value interpolation (principle) .....	130
7.7.2	Dead time compensation .....	131
7.7.3	System block "LS_TouchProbe1...8" .....	132
7.7.4	System block "LS_TouchProbeMotor" .....	133
7.7.5	System block "LS_TouchProbeLoad".....	133
7.8	System bus "CAN on board".....	134
<b>8</b>	<b>Safety engineering .....</b>	<b>135</b>
8.1	Integration into the application.....	136
8.2	Selecting the required safety module.....	136
8.3	Control word of the safety module SM3xx.....	137
8.4	Status information of the SM3xx safety module .....	138
8.5	System block "LS_SafetyModule".....	139
<b>9</b>	<b>Basic drive functions .....</b>	<b>140</b>
9.1	General information .....	140
9.1.1	Conditions for the use of the basic functions .....	140
9.1.2	Internal state machine.....	141
9.1.2.1	"Initialisation" status.....	142
9.1.2.2	Status "Controller not ready" .....	142
9.1.2.3	Status "drive in standstill" .....	142
9.1.2.4	Status "Drive is stopped" .....	143
9.1.2.5	Status "Manual jog active" .....	143
9.1.2.6	Status "Homing active".....	143
9.1.2.7	Status "Positioning active" .....	143
9.1.2.8	Status "Setpoint follower active".....	144
9.1.2.9	Status "Quick stop active" .....	144
9.1.2.10	Status "Error".....	144
9.1.2.11	Interrupting/replacing states.....	145
9.1.2.12	Priorities .....	145
9.1.3	Requesting control via a basic function .....	146

9.2	Standard stop	148
9.2.1	Parameter setting	149
9.2.2	Behaviour of the function (example)	150
9.2.3	System block "LS_Stop"	151
9.3	Quick stop	152
9.3.1	Parameter setting	152
9.3.2	Activating/Deactivating quick stop	154
9.3.3	System block "LS_quick stop"	155
9.4	Manual jog	156
9.4.1	Parameter setting	156
9.4.1.1	Smooth start and quick stop of the drive	157
9.4.1.2	Second manual speed	157
9.4.2	Executing manual jog	158
9.4.2.1	Manual jog in positive/negative direction	159
9.4.2.2	Manual jog to limit position	160
9.4.2.3	Retracting of an activated limit switch	161
9.4.3	System block "LS_ManualJog"	162
9.5	Homing	164
9.5.1	Parameter setting	165
9.5.1.1	Homing mode	165
9.5.1.2	Home position & target position	169
9.5.1.3	Second homing speed	170
9.5.1.4	Homing to end stop	171
9.5.1.5	Connection of reference switch	171
9.5.1.6	Touch probe interface configuration	171
9.5.2	Executing homing	172
9.5.2.1	Setting reference search/setting reference directly	173
9.5.2.2	Loading home position via input	173
9.5.2.3	Resetting home position	173
9.5.3	System block "LS_Homing"	174
9.6	Positioning	176
9.6.1	Parameter setting	176
9.6.2	Carrying out positioning	177
9.6.2.1	Starting positioning	178
9.6.2.2	Aborting/interrupting positioning	178
9.6.2.3	Continuing an interrupted positioning process	178
9.6.2.4	Activating override	179
9.6.3	System block "LS_Positioner"	180

9.7	Position follower .....	183
9.7.1	Signal flow .....	184
9.7.2	Parameter setting .....	186
9.7.2.1	Setpoint interpolation .....	187
9.7.2.2	Inversion of the direction of rotation .....	187
9.7.3	Activating setpoint interface .....	188
9.7.4	System block "LS_PositionFollower" .....	189
9.8	Speed follower .....	190
9.8.1	Signal flow .....	191
9.8.2	Parameter setting .....	192
9.8.2.1	Setpoint interpolation .....	193
9.8.2.2	Inversion of the direction of rotation .....	193
9.8.3	Activating setpoint interface .....	194
9.8.4	System block "LS_SpeedFollower" .....	195
9.9	Torque follower .....	196
9.9.1	Signal flow .....	196
9.9.2	Parameter setting .....	197
9.9.2.1	Setpoint interpolation .....	197
9.9.2.2	Inversion of the direction of rotation .....	197
9.9.3	Activating setpoint interface .....	198
9.9.4	System block "LS_TorqueFollower" .....	199
9.10	Limiter .....	200
9.10.1	Parameter setting .....	201
9.10.1.1	Software limit positions .....	202
9.10.1.2	Hardware limit positions (limit switch) .....	204
9.10.1.3	Limitations .....	205
9.10.1.4	Limited speed .....	207
9.10.2	Control word of the safety module .....	208
9.10.3	System block "LS_Limiter" .....	209



9.11	Brake control .....	211
9.11.1	Parameter setting .....	212
9.11.1.1	Operating mode .....	213
9.11.1.2	Signal configuration .....	213
9.11.1.3	Standstill monitoring .....	214
9.11.1.4	Brake activation in automatic operation .....	215
9.11.1.5	Brake time response .....	217
9.11.1.6	Torque feedforward control .....	219
9.11.2	Mode 0: Brake control is switched off .....	222
9.11.3	Mode 1/11: Direct control of the brake .....	222
9.11.4	Mode 2/12: Automatic control of the brake .....	223
9.11.4.1	Behaviour at pulse inhibit .....	224
9.11.4.2	Process when brake is released .....	225
9.11.4.3	Process when brake is closed .....	226
9.11.5	Grinding the brake .....	227
9.11.6	Carry out brake test .....	229
9.11.7	System block "LS_Brake" .....	231
<b>10</b>	<b>Technology applications (TAs) .....</b>	<b>233</b>
10.1	Overview .....	233
10.2	Commissioning using the »Engineer« .....	235
10.2.1	Parameterise application .....	236
10.2.2	Parameterise signal combinations .....	237
10.2.3	Configure application .....	239
10.2.4	Networking via standardised ports .....	240

<b>11</b>	<b>Standard TAs</b>	<b>241</b>
11.1	Introduction	242
11.1.1	Application examples	242
11.2	TA "Actuator – speed"	244
11.2.1	Basic signal flow	245
11.2.2	Assignment of the I/O terminals	246
11.2.2.1	Setpoint and control signals	246
11.2.2.2	Actual value and status signals	247
11.2.3	Machine parameters	249
11.2.4	Speed setpoint conditioning	250
11.2.4.1	Change-over to fixed setpoint	251
11.2.4.2	Setpoint inversion	252
11.2.4.3	Speed ramp generator	253
11.2.5	Speed follower	255
11.2.6	Manual jog	256
11.2.7	Quick stop	257
11.2.8	Limiter	258
11.2.9	Brake control	259
11.2.10	Signal configuration of drive and motor interface	261
11.2.11	Signal configuration of the output ports	262
11.2.12	Application error messages	264
11.3	TA "Actuator – torque"	265
11.3.1	Basic signal flow	266
11.3.2	Assignment of the I/O terminals	267
11.3.2.1	Setpoint and control signals	267
11.3.2.2	Actual value and status signals	268
11.3.3	Machine parameters	270
11.3.4	Torque setpoint conditioning	271
11.3.4.1	Setpoint inversion	272
11.3.4.2	Ramp generator	272
11.3.5	Speed limit value conditioning	273
11.3.5.1	Change-over to fixed setpoint	274
11.3.5.2	Speed ramp generator	275
11.3.6	Torque follower	277
11.3.7	Manual jog	278
11.3.8	Quick stop	279
11.3.9	Limiter	280
11.3.10	Brake control	281
11.3.11	Signal configuration of drive and motor interface	283
11.3.12	Signal configuration of the output ports	284
11.3.13	Application error messages	286

<b>12</b>	<b>TAs for interconnection via electrical shaft</b>	<b>287</b>
12.1	Introduction	288
12.1.1	Synchronisation of the drives via a master angle	288
12.1.2	Virtual master/real master	289
12.1.3	Transmission of the master angle	290
12.1.4	Speed or angular synchronism?	291
12.1.5	Rail or cascade structure?	291
12.1.6	Master or actual value transfer?	291
12.1.7	Absolute or relative master angle processing?	292
12.1.8	Functions with synchronisation via the electrical shaft.	292
12.1.9	Application examples	293
12.2	TA "Electronic gearbox"	297
12.2.1	Basic signal flow	298
12.2.2	Assignment of the I/O terminals	299
12.2.2.1	Setpoint and control signals	299
12.2.2.2	Actual value and status signals	300
12.2.3	Machine parameters	301
12.2.3.1	Master axis (master shaft)	302
12.2.3.2	Slave axis (machine axis)	303
12.2.4	Selection of master value source and output	305
12.2.4.1	Master value source: Virtual master	306
12.2.4.2	Master value source: Digital frequency input	307
12.2.4.3	Master value source: Bus system	307
12.2.5	Operating mode "Electronic gearbox"	308
12.2.5.1	Master value processing	309
12.2.5.2	Virtual clutch	310
12.2.5.3	Master value trimming	311
12.2.5.4	Setpoint conditioning	312
12.2.6	"Homing" mode	313
12.2.7	"Manual jog" mode	315
12.2.8	"Positioning" mode	316
12.2.9	Following error monitoring	318
12.2.10	Quick stop	319
12.2.11	Limiter	320
12.2.12	Brake control	322
12.2.13	Signal configuration of drive and motor interface	324
12.2.14	Signal configuration of the output ports	325
12.2.15	Application error messages	327
12.2.16	Step by step: Electrical shaft via system bus (CAN)	328

12.3	TA "Synchronism with mark synchronisation" .....	332
12.3.1	Basic signal flow .....	334
12.3.2	Assignment of the I/O terminals .....	335
12.3.2.1	Setpoint and control signals .....	335
12.3.2.2	Actual value and status signals .....	336
12.3.3	Machine parameters .....	337
12.3.3.1	Master axis (master shaft) .....	338
12.3.3.2	Slave axis (machine axis) .....	339
12.3.4	Selection of master value source and output .....	341
12.3.4.1	Master value source: Virtual master .....	342
12.3.4.2	Master value source: Digital frequency input .....	343
12.3.4.3	Master value source: Bus system .....	343
12.3.5	"Synchronism" mode" .....	344
12.3.5.1	Master value processing .....	345
12.3.5.2	Mark synchronisation (master value) .....	346
12.3.5.3	Virtual clutch .....	348
12.3.5.4	Master value trimming .....	349
12.3.5.5	Setpoint conditioning .....	350
12.3.5.6	Mark synchronisation (setpoint) .....	351
12.3.6	"Homing" mode .....	353
12.3.7	"Manual jog" mode .....	355
12.3.8	"Positioning" mode" .....	356
12.3.9	Quick stop .....	358
12.3.10	Limiter .....	359
12.3.11	Brake control .....	361
12.3.12	Signal configuration of drive and motor interface .....	363
12.3.13	Signal configuration of the output ports .....	364
12.3.14	Application error messages .....	366

<b>13</b>	<b>TAs for positioning tasks</b>	<b>367</b>
13.1	Introduction	368
13.1.1	Application examples	369
13.2	TA "Multi-purpose positioning"	371
13.2.1	Basic signal flow	372
13.2.2	Assignment of the I/O terminals	373
13.2.2.1	Setpoint and control signals	373
13.2.2.2	Actual value and status signals	374
13.2.3	Basic settings	375
13.2.3.1	Machine parameters	375
13.2.3.2	Traversing range	376
13.2.3.3	Position control	377
13.2.4	Program flow	378
13.2.4.1	Overview of action types	379
13.2.4.2	Action type "Homing"	382
13.2.4.3	Action type "Positioning"	384
13.2.4.4	Action type "Variable branching"	385
13.2.4.5	Sequencer inputs	386
13.2.4.6	Sequencer outputs	386
13.2.4.7	Parameter setting of the program flow in the Engineer	388
13.2.4.8	Control of the sequence table	389
13.2.5	Profile data management	390
13.2.5.1	Profile parameters	390
13.2.5.2	Variable tables	393
13.2.5.3	Positioning modes	395
13.2.5.4	Touch probe positioning	397
13.2.5.5	"Teach" function	398
13.2.6	Speed/acceleration override	399
13.2.7	Following error monitoring	400
13.2.8	Manual jog	401
13.2.9	Quick stop	402
13.2.10	Limiter	403
13.2.11	Brake control	405
13.2.12	Signal configuration of drive and motor interface	407
13.2.13	Signal configuration of the output ports	408
13.2.14	Application error messages	410

13.3	TA "Table positioning" .....	411
13.3.1	Basic signal flow .....	412
13.3.2	Assignment of the I/O terminals .....	413
13.3.2.1	Setpoint and control signals .....	413
13.3.2.2	Actual value and status signals .....	414
13.3.3	Control of the program flow via predefined ports .....	415
<b>14</b>	<b>Oscilloscope .....</b>	<b>416</b>
14.1	Technical data .....	416
14.2	Function description .....	417
14.3	User interface .....	418
14.3.1	Oscilloscope toolbar .....	418
14.3.2	Oscilloscope function bar .....	419
14.3.3	Oscillograph .....	419
14.3.4	Vertical settings .....	419
14.3.5	Status bar .....	419
14.3.6	Trigger/cursor settings .....	420
14.3.7	Horizontal settings .....	420
14.3.8	Recording settings .....	420
14.4	Operation .....	421
14.4.1	Selecting the variables to be recorded .....	421
14.4.2	Selecting the recording time/sample rate .....	422
14.4.3	Selecting the trigger condition .....	422
14.4.4	Starting recording .....	424
14.4.5	Adjusting the representation .....	424
14.4.6	Reading individual measured values .....	426
14.5	Data records .....	427
14.5.1	Saving/exporting a data record .....	427
14.5.2	Loading/importing a data record .....	428
14.5.3	Deleting data record in the project .....	429
14.5.4	Overlay function .....	429
14.5.5	Copying data record to clipboard .....	430
14.6	Variables of the motor control (oscilloscope signals) .....	431

<b>15</b>	<b>Diagnostics &amp; error analysis</b> .....	<b>433</b>
15.1	Drive diagnostics with the »Engineer« .....	433
15.2	Drive diagnostics via keypad/bus system .....	434
15.3	Logbook .....	436
15.3.1	Function description .....	437
15.3.2	Filtering logbook entries .....	437
15.3.3	Reading logbook entries .....	438
15.4	Monitoring .....	439
15.4.1	Setting the error response .....	439
15.5	Maloperation of the drive .....	442
15.6	Error messages of the operating system .....	443
15.6.1	Format of the error numbers saved in the fault memory .....	443
15.6.1.1	Response .....	444
15.6.1.2	Instance-ID .....	444
15.6.1.3	Module ID .....	445
15.6.1.4	Error ID .....	445
15.6.1.5	Example for bit coding of the error number .....	446
15.6.2	Reset of error message .....	447
15.6.3	Error list .....	448
<b>16</b>	<b>Parameter reference</b> .....	<b>537</b>
16.1	Structure of the parameter descriptions .....	537
16.1.1	Data type .....	537
16.1.2	Parameters with read-only access .....	538
16.1.3	Parameters with write access .....	539
16.1.3.1	Parameters with setting range .....	539
16.1.3.2	Parameters with selection list .....	539
16.1.3.3	Parameters with bit-code setting .....	540
16.1.3.4	Parameters with subcodes .....	541
16.1.4	Parameter attributes .....	542
16.2	Abbreviations used in parameter & selection texts .....	543
16.3	Parameter list .....	543
16.4	Attribute table .....	648
<b>17</b>	<b>Index</b> .....	<b>658</b>
	<i>Your opinion is important to us</i> .....	679

## 1 About this Manual

This Manual contains information about the parameterisation & configuration of the 9400 HighLine controller by means of the L-force »Engineer« and the keypad.



### Note!

The Manual supplements the **Mounting Instructions** attached to the controller and the **Manual** for the 9400 HighLine controller.

**The Mounting Instructions contain safety information which must be observed!**

The information in this Manual applies to the following "9400 Servo Drives":

Type	Type designation	As of hardware version	As of software version
9400 HighLine (Single Drive & Multi Drive)	E94AxHExxxx	PD	1.37.00

### 1.1 Conventions used

This Manual uses the following conventions to distinguish between different types of information:

Type of information	Writing	Examples/notes
Variable identifier	<i>Italics</i>	By setting <i>bEnable</i> to TRUE...
Window range		The <i>Message window...</i> / The <i>Options</i> dialog box...
Control element	<b>Bold</b>	The <b>OK</b> button... / The <b>Copy</b> command... / The <b>Properties</b> index card... / The <b>Name</b> input field...
Sequence of menu commands		If the execution of a function requires several commands, the individual commands are separated by an arrow: Select <b>File→Open</b> to...
Shortcut	<b>&lt;Bold&gt;</b>	Use <b>&lt;F1&gt;</b> to open the online help.  If a command requires a combination of keys, a "+" is placed between the key symbols: Use <b>&lt;Shift&gt;+&lt;ESC&gt;</b> to...
Program code	Courier	<b>IF</b> var1 < var2 <b>THEN</b> a = a + 1 <b>END IF</b>
Keyword	<b>Courier bold</b>	
Hyperlink	<u>Underlined</u>	A hyperlink is an optically highlighted reference which is activated with a mouse click.
Step-by-step instruction		Like safety information, step-by-step instructions are indicated by a pictograph.



## 1.2 Terminology used

Term	Meaning
»Engineer«	Lenze software which supports you throughout the whole machine life cycle - from planning to maintenance.
Code	"Container" for one or several parameters used for controller parameter setting or monitoring.
Subcode	If a code contains several parameters, the individual parameters are stored under "subcodes". This Manual uses a slash "/" as a separator between code and subcode (e.g. "C00118/3").
Function block editor	Graphical interconnection tool which is provided for controllers in the MotionControl HighLevel and TopLevel license level in the »Engineer« on the <b>FB editor</b> tab and by means of which the technology applications supplied can also be reconfigured and extended by individual functions.
Function block	A function block (FB) can be compared with an integrated circuit that contains a certain control logic and delivers one or several values when being executed. <ul style="list-style-type: none"> <li>• An entity (reproduction, copy) of the function block is always inserted in the circuit.</li> <li>• It is also possible to insert several instances of a function block in a circuit.</li> <li>• Each entity has an unequivocal identifier (the entity name) and a processing number which defines the position the function block is calculated during the task cycle.</li> </ul>
System block	System blocks provide interfaces for basic functions and hardware of the controller in the function block editor of the »Engineer« (e.g. to the digital inputs). <ul style="list-style-type: none"> <li>• System blocks cannot be instanced in contrast to function blocks.</li> </ul>
DIS code	Parameter that displays the current status or value of an input/output of a system block.
TA	Abbreviation for "Technology Application". Technology applications are applications prepared by Lenze which form the basis of solving typical applications.

## 1.3 Definition of notes used

The following signal words and symbols are used in this documentation to indicate dangers and important information:

### Safety instructions

Structure of safety instructions:



#### **Pictograph and signal word!**

(characterise the type and severity of danger)

#### **Note**

(describes the danger and suggests how to avoid the danger)

Pictograph	Signal word	Meaning
	Danger!	<b>Danger of personal injury through dangerous electrical voltage</b> Indicates an impending danger that may lead to death or severe personal injury if the corresponding measures are not taken.
	Danger!	<b>Danger of personal injury through a general source of danger</b> Indicates an impending danger that may lead to death or severe personal injury if the corresponding measures are not taken.
	Stop!	<b>Danger of material damage</b> Reference to a possible danger that may result in property damage if the corresponding measures are not taken.

### Application notes

Pictograph	Signal word	Meaning
	Note!	Important note for trouble-free operation
	Tip!	Useful tip for simple handling

## 2 Introduction

The basis of every **L-force** application is an easy and quick parameter setting of prepared technology applications and solutions\*.


This chapter contains basic information on the runtime software model of **L-force** and how you can establish very easily an online connection between PC and controller for parameter setting with the »Engineer«.

At the end of this chapter you will find an overview of the different signal types & scalings which serve to process physical values (e.g. speed or position) within the application.

\* In preparation!

### 2.1 Parameter setting, configuring or programming?

The graded runtime software model of **L-force** provides a simple and universal solution for motion and process tasks as well as for complex machine functions.



**Programming\***

#### **Configuring**

The HighLevel and TopLevel licenses enable you to extend the provided technology applications by individual functions using the graphic function block editor of the »Engineer«. Here, you can access the comprehensive function libraries of Lenze which contain, among other things, process controllers, arithmetic functions, logic blocks, as well as ramp generators and integrators.

#### **Parameter setting**


The StateLevel license includes a range of technology which can be put into operation easily with a keypad or via dialogs in the »Engineer«.

\* In preparation!

#### 2.1.1 Technology applications

Technology applications (TAs) are applications prepared by Lenze which form the basis of solving typical applications.

- ▶ The technology applications available for the 9400 Servo Drives can be selected in the »Engineer« form the application catalog.



The screenshot shows a window titled "Runtime software" with a "Technology level" section. It lists three levels of motion control with their respective technology applications:


- Motion Control TopLevel**
  - [TA "Multi-purpose positioning"](#)
  - TA "Electronic cam" \*
  - TA "Register control" \*
  - TA "Winding technology" \*
- Motion Control HighLevel**
  - [TA "Electronic gearbox"](#)
  - [TA "Synchronism with mark synchronisation"](#)
- Motion Control StateLevel**
  - [TA "Actuator – speed"](#)
  - [TA "Actuator – torque"](#)
  - [TA "Table positioning"](#)

Each higher license contains additional technology applications for further application fields.

\* In preparation!

#### 2.1.2 Basic functionalities

Important basic drive functions and other basic functionalities are implemented in the firmware of the controller and are always available irrespective of the prevailing runtime software license.



The screenshot shows a window titled "Firmware" with two columns of basic functionalities:

- Motion Control basic drive functions**
  - [Standard stop](#)
  - [Quick stop](#)
  - [Manual jog](#)
  - [Homing](#)
  - [Positioning](#)
  - [Position follower](#)
  - [Speed follower](#)
  - [Torque follower](#)
  - [Limiter](#)
  - [Brake control](#)
- Further basic functionalities**
  - [Drive interface](#)
  - [Motor interface](#)
  - [Encoder evaluation](#)
  - [I/O terminals](#)
  - [Safety engineering](#)
  - [Logbook](#)
  - [Oscilloscope](#)

## 2.2 Communicating with the controller

The following interfaces/communication modules can be used to build up communication between PC and controller:

- ▶ Diagnostic interface X6/[Going online via diagnostic adapter](#)
- ▶ CAN on-board interface/[Going online via system bus \(CAN on board\)](#) (📖 24)
- ▶ Optional interfaces provided by corresponding communication modules in the module receptacles MXI1/MXI2 of the controller.



### Note!

For communication with the controller, at least the control electronics of the controller must be supplied with 24 V low voltage via plug X2. For detailed information, please see the Mounting Instructions for the controller.




### Tip!

Detailed information about the individual interfaces can be found in the corresponding Communication Manuals.

### 2.2.1 Going online via diagnostic adapter

For the initial commissioning of the controller, you can use, for instance, the diagnostic adapter offered by Lenze:



### Note!

Please observe the documentation for the diagnostic adapter!


#### Preconditions:


- ▶ The diagnostic adapter is connected to diagnostic interface X6 on the controller and to a free USB port on the PC.
- ▶ The driver required for the diagnostic adapter is installed.
- ▶ The control electronics of the controller is supplied with 24 V low voltage via plug X2.




#### How to build up an online connection via the diagnostic adapter:

1. Select the 9400 HighLine controller to which you want to build up an online connection in the *Project view* of the »Engineer«:




2. Click the  icon or select the command **Online→Go online**.
  - If no online connection has been configured for the selected controller so far, the *Assignment of offline controllers* dialog box will be displayed:






- The dialog box also appears if the online connection is built up via the command **Online→Go online** instead of using the *toolbar* icon.
3. Select the entry "Diagnostic adapter" from the **Bus connection** list field.

4. Click **Find controller path** to find the controller in the selected bus system.
  - The *Address assignment* dialog box appears:



5. Select the corresponding controller from the **Identified field devices** list field.
6. Click **OK**.
  - The *Address assignment* dialog box is closed and the selected **Controller access path** (e.g. "DDCMP:/") is indicated in the *Assignment of offline controllers* dialog box.
7. Click **Connect**.
  - The dialog box is closed and the online connection with the controller is built up.
  - In the *Project view*, a yellow icon indicates the online connection with the controller:



Now you can use the icons  and  to easily build up and end a connection with the controller. The communication settings are only required when communication with a controller is built up for the first time.

- ▶ If you want to change the existing configuration, select the command **Online→Go online** to open the *Assignment of offline controllers* dialog box and change the settings.
- ▶ With an online connection, the »Engineer« displays the current parameter settings of the controller with a yellow background colour.



### Stop!

If you change parameters in the »Engineer« while the controller is connected online, the changes will be directly accepted by the controller!

#### 2.2.2 Going online via system bus (CAN on board)

As an alternative to the diagnostic adapter, you can use the integrated system bus interface (CAN on-board, terminal X1) of the controller for communication.

► Lenze offers the following communication accessories for connection to the PC:

Communication accessories	PC interface
<b>PC system bus adapter 2173</b> incl. connection cable and voltage supply adapter <ul style="list-style-type: none"><li>• for DIN keyboard connection (EMF2173IB)</li><li>• for PS/2 keyboard connection (EMF2173IBV002)</li><li>• for PS/2 keyboard connection with electrical isolation (EMF2173IBV003)</li></ul>	Parallel interface (LPT port)
<b>PC system bus adapter 2177</b> incl. connection cable (EMF2177IB)	USB (Universal Serial Bus)



#### Note!

- For detailed information about the PC system bus adapter, please see the "CAN Communication Manual".
- Please observe the documentation for the PC system bus adapter!
- The online connection is built up as described in the previous chapter [Going online via diagnostic adapter](#), only select the entry "CAN system bus" in the *Assignment of offline controllers* dialog box from the **Bus connection** list field. [\(p. 22\)](#)

#### 2.2.3 Use of other communication interfaces

The controller can be extended by further communication interfaces, if required, e.g. Ethernet TCP/IP, Ethernet Powerlink or PROFIBUS-DP.

- For this purpose the controller is provided with the module receptacles MX11 and MX12 to plug in communication modules.
- Detailed information on this subject can be found in the Hardware Manual and Communication Manual for the corresponding communication system.



## 2.3 Signal types & scaling

It is very helpful for the parameter setting & configuration of the controller to know the signal types and their scaling listed in the following table, which serve to process physical sizes (e.g. a speed or position) in a function block configuration.

Signal type	Unit	Connection symbol in the FB editor	Resolution	Scaling external $\equiv$ internal	Range	Number of decimal positions	Identifier suffix
Position	Increments	◀/▶	32 bits	1 motor revolution $\equiv 2^{16}$ increments	$-2^{31} \dots 2^{31}-1$ increments	3	_p
Speed	rpm	◀/▶	16 bits	15000 rpm $\equiv 2^{14} \equiv 16384$	$\pm 30000.0$ rpm	1	_v
		◆	32 bits	15000 rpm $\equiv 2^{26} \equiv 67108864$	$\pm 480000.0$ rpm	1	_s
Speed variation/time	rpm/s	◇	32 bits	15000000 rpm/s $\equiv 2^{22} \equiv 4194304$	$\pm 7.69 * 10^9$ rpm/s	3	_x
Scaled signal	%	●	32 bits	100 % $\equiv 2^{30} \equiv 1073741824$	$\pm 200.00$ %	2	_n
		○	16 bits	100 % $\equiv 2^{14} \equiv 16384$	$\pm 199.99$ %	2	_a
Control/status signal		□	1 bit	0 $\equiv$ FALSE; 1 $\equiv$ TRUE	0 / 1	0	
Time	s	■	28 bits		0 ... 268435.456 s	3	
Status word		■	32 bits		-2147483648 ... 2147483647 (0000 0000 <sub>hex</sub> ... FFFF FFFF <sub>hex</sub> )	0	
Not standardised		■					



### Tip!

Only inputs/outputs of the same signal type (with the same connection symbol) can be connected in the function block editor of the »Engineer«.

Non-standardised inputs/outputs can be connected if the input and output have the same resolution.

### 3 Commissioning

This documentation contains detailed information on parameter setting and configuration of the controller. Sequential reading is not required.

In order to get the information relevant for an initial commissioning, this chapter describes different commissioning scenarios which can also be used as a guide through this Manual:

A. [Test commissioning](#) (📖 28)

- **Target:** Rotating the motor with as few settings as possible in best time.

B. [Initial commissioning](#) (📖 29)

- **Target:** Adapting the controller to electromechanics and control.

C. [Standard set-up](#) (📖 31)

- **Target:** Taking over the application and parameter set of an already preconfigured "Engineer" project in several controllers.

D. [Controller replacement](#) (📖 32)

- **Target:** Replacing a controller which has failed in a running system by a replacement device using the "old" memory module.

E. [Motor replacement](#) (📖 33)

- **Target:** Replacing a motor which has failed in a running system.

## 3.1 Notes on commissioning using the keypad

### For motor with electronic nameplate (ENP)

- ▶ A display of the route data offered by ENP via keypad is not provided. The route data must be edited and optimised individually.
- ▶ In order that the motor does not start unintentionally without adjusting the route data, the maximum current in the Lenze setting is set to "0 A" in [C00022](#).
- ▶ After setting the route data these motor data and the ones read out of the ENP must be stored with mains failure protection on the memory module of the controller ([C00002](#) = "11").


### For motor without electronic nameplate (ENP)

- ▶ The motor and route data must be edited and set individually.
- ▶ In order that the motor does not start unintentionally without adjusting the route data, the maximum current is set to "0 A" in [C00022](#) as factory adjustment.
- ▶ After the motor and route data are set, they must be stored with mains failure protection on the memory module of the controller ([C00002](#) = "11").


### Commissioning of the application

- ▶ The application must already be stored on the memory module of the controller. Otherwise, commissioning with keypad only is not possible.
- ▶ All application parameters which deviated from the factory adjustment, must be edited individually. For this purpose, the project planner must provide a corresponding list (including the motor and route data) for the commissioner.
- ▶ In case of a standard set-up the rotor position must be adjusted for synchronous motors of a third-party manufacturer and Lenze synchronous motors with Stegmann absolute value encoder.
- ▶ After the parameters are set, they must be stored with mains failure protection on the memory module of the controller ([C00002](#) = "11").

## 3.2 Test commissioning


Worksteps	
<b>Initial commissioning of motor/controller:</b>	
1.	<a href="#">Select motor in the »Engineer« motor catalog.</a> (📖 66) <ul style="list-style-type: none"><li>When the motor connected to the motor has an electronic nameplate (ENP), all motor data are automatically read out of the ENP and a selection from the motor catalog is not required. ▶ <a href="#">Read the motor data out of the controller</a> (📖 66)</li></ul>
2.	<a href="#">Accept/adapt route data.</a> (📖 69)
3.	<a href="#">Parameterise motor encoder.</a> (📖 70)
<b>Save project and parameter set:</b>	
1.	<a href="#">Save parameter set.</a> (📖 57)
2.	Save »Engineer« project.
<b>Commissioning of the application:</b>	
	<b>Note:</b> <p>The following steps require that the technology application "actuator – speed" has been selected in the »Engineer« application catalog. See chapter <a href="#">Technology applications (TAs)</a>: ▶ <a href="#">Commissioning using the »Engineer«</a> (📖 235) ▶ <a href="#">TA "Actuator – speed"</a> (📖 244)</p>
1.	Enable controller via terminal RFR.
2.	Enable setpoint follower via digital input DI2.
3.	Define speed setpoint via analog input 1 (terminal AI1+/AI1-).
4.	If required, the direction of rotation can be inverted via the digital input DI3.
5.	Check further <a href="#">Basic drive functions</a> of the applications: <ul style="list-style-type: none"><li>A quick stop can be activated via the digital input DI1. ▶ <a href="#">Quick stop</a> (📖 152)</li><li>A manual control is available for the setting-up operation. ▶ <a href="#">Manual jog</a> (📖 156)<ul style="list-style-type: none"><li>The enable is executed via the digital input DI6.</li><li>The digital inputs DI7 and DI8 activate parameterisable setpoints for both directions of rotation.</li></ul></li></ul>

## 3.3 Initial commissioning

Worksteps	
<b>Adapt the motor to the controller:</b>	
1.	<a href="#">Select motor in the »Engineer« motor catalog.</a> (📖 66) <ul style="list-style-type: none"> <li>When the motor connected to the motor has an electronic nameplate (ENP), all motor data are automatically read out of the ENP and a selection from the motor catalog is not required. ▶ <a href="#">Read the motor data out of the controller</a> (📖 66)</li> </ul>
2.	<a href="#">Accept/adapt route data.</a> (📖 69)
3.	<a href="#">Parameterise motor encoder.</a> (📖 70)
	When an external motor is operated on a controller: <ul style="list-style-type: none"> <li>Only in case of a synchronous motor: <a href="#">Set rotor displacement angle.</a> (📖 71)</li> <li>Only in case of unknown motor parameters:               <ul style="list-style-type: none"> <li>– <a href="#">Optimise the switching performance of the inverter.</a> (📖 73)</li> <li>– <a href="#">Set motor parameters.</a> (📖 75)</li> </ul> </li> </ul>
4.	<a href="#">Define currents and speed limits.</a> (📖 78)
5.	<a href="#">Select switching frequency.</a> (📖 79)
6.	<a href="#">Optimise current controller.</a> (📖 81) <ul style="list-style-type: none"> <li>Required since the controller parameters depend on the maximum switching frequency needed. The default values of the motor catalog only represent theoretically calculated approximate values.</li> </ul>
<b>Parameterise/configure application:</b>	
1.	Load & parameterise technology application. See chapter <a href="#">Technology applications (TAs)</a> : <ul style="list-style-type: none"> <li>▶ <a href="#">Commissioning using the »Engineer«</a> (📖 235)</li> <li>▶ <a href="#">TA "Actuator – speed"</a> (📖 244)</li> </ul>
2.	If required, reconfigure the circuit of the technology application with the function block editor.
<b>Optimise speed control loop:</b>	
1.	<a href="#">Optimise speed controller.</a> (📖 88) <ul style="list-style-type: none"> <li>Via traversing profile from the application and oscilloscope</li> </ul>
2.	<a href="#">Set current setpoint filter.</a> (📖 90) <ul style="list-style-type: none"> <li>In order to suppress or damp (mechanical) resonant frequencies, two current setpoint filters are integrated in the speed control loop of the controller which are switched off in the default setting but can be parameterised accordingly, if required.</li> </ul>
<b>Save project and parameter set:</b>	
1.	<a href="#">Save parameter set.</a> (📖 57)
2.	Save »Engineer« project.
<b>Establish network:</b>	
1.	Insert network and machine application into the »Engineer« project.
2.	Interconnect the ports conveniently inside the machine application.
3.	Configure the network (set addresses, baud rates and process data channels sensibly).
4.	Establish communication with the control.
5.	Establish communication with other drive components (e.g. HMIs, I/O extension and other controllers).

Worksteps	
<b>Check &amp; optimise application /DC-bus operation:</b>	
1.	Traverse axis in manual operation. <ul style="list-style-type: none"><li>• See chapter <a href="#">Basic drive functions</a> ▶ <a href="#">Manual jog</a> (📖 156)</li></ul>
2.	Check area boundaries (travel, speed, torque).
3.	Traverse axis in automatic operation with set-up speed, possibly together with coupled axes.
4.	Check coupling with other motions (master-/slave axes, tools, ...).
5.	Optimisation of the process at higher speeds.
6.	Recording of signal characteristics using the oscilloscope function for the documentation. <ul style="list-style-type: none"><li>• See chapter <a href="#">Oscilloscope</a> (📖 416)</li></ul>
<b>Save &amp; archive project and parameter set:</b>	
1.	<a href="#">Save parameter set.</a> (📖 57)
2.	Save »Engineer« project.
3.	Deposit a safety copy of the »Engineer« project e.g. on CD ROM in the control cabinet.

## 3.4 Standard set-up

Worksteps	
<b>Transfer application and parameter set to the controller:</b>	
1.	Transfer the application preconfigured in the »Engineer« and the corresponding parameter set to the memory module of the controller.
2.	<a href="#">Save parameter set.</a> (📖 57)
<b>For a motor with an electronic nameplate (ENP):</b>	
1.	Restart controller with connected motor to read out the motor data from the electronic nameplate (ENP). <ul style="list-style-type: none"> <li>Restart the controller either by switching off and on again the voltage supply or by the device command "Restart controller" (<code>C00002</code> = "11000").</li> <li>See chapter <a href="#">Motor interface</a> ▶ <a href="#">Read the motor data out of the controller</a> (📖 66)</li> </ul>
2.	<a href="#">Save parameter set.</a> (📖 57)
<b>For a motor without an electronic nameplate (ENP):</b>	
	<b>Note:</b> Here, the motor is operated with the motor and route data detected during the initial commissioning. In contrast to the operation of a motor with ENP no resolver errors are compensated and a uniform saturation characteristic is considered only. <ul style="list-style-type: none"> <li>See chapter <a href="#">Motor interface</a> ▶ <a href="#">Initial commissioning</a> (📖 65)</li> </ul>
1.	If required, detect rotor displacement angle. ▶ <a href="#">Set rotor displacement angle</a> (📖 71) <ul style="list-style-type: none"> <li>Required for synchronous motors of an original equipment manufacturer and Lenze synchronous motors with Stegmann absolute value encoder.</li> </ul>
2.	<a href="#">Save parameter set.</a> (📖 57)

## 3.5 Controller replacement

Scenario: The controller has failed in a running system.



### Note!

For the following procedure described we assume that the memory module and possibly available extension modules in the controller and the motor are not affected by the failure.

#### Worksteps

##### Replacement of the controller:

1. Replace controller.  
**See Mounting Instructions for the controller!**
2. Insert the memory module of the failed controller into the replacement device.
3. If further extension modules are plugged into the failed controller, these must be inserted into the replacement device as well.

Further steps are not required since all data needed are on the memory module.



## 3.6 Motor replacement

Scenario: The motor has failed in a running system.

**Note!**

In the following procedure described we assume that the controller is not affected by the failure.

**Worksteps****Replacement of the motor:**

1. Replace the motor.  
See [Mounting Instructions for the controller!](#)

**Note:**

The motor connection at the controller can be accessed without pulling the basic device out of the installation backplane.

**For a motor with an electronic nameplate (ENP):**

1. Restart controller with connected motor to read out the motor data from the electronic nameplate.
  - Restart the controller either by switching off and on again the voltage supply or by the device command "Restart controller" ([C00002](#) = "11000").
  - See chapter [Motor interface](#) ▶ [Read the motor data out of the controller](#) (📖 66)
2. [Save parameter set.](#) (📖 57)

**For a motor without an electronic nameplate (ENP):****Note:**

The motor is operated with the motor and route data that are stored on the memory module.

- See chapter [Motor interface](#) ▶ [Initial commissioning](#) (📖 65)

1. If required, detect rotor displacement angle. ▶ [Set rotor displacement angle](#) (📖 71)
  - Required for synchronous motors of an original equipment manufacturer and Lenze synchronous motors with Stegmann absolute value encoder.
2. [Save parameter set.](#) (📖 57)

## 4 Drive interface

This chapter describes the drive interface which serves to set the controller to different states and query different status information of the controller. Moreover, the machine constants for the motor end can be entered via this drive interface.

### 4.1 LED status displays

The control of the "DRIVE READY" and "DRIVE ERROR" LED on the front of the controller depends on the device status. ▶ [Device states](#) (45)



DRIVE READY	DRIVE ERROR	Meaning
OFF	OFF	<a href="#">Status "initialisation active"</a>
	OFF	<a href="#">Status "Safe torque off active"</a> Consider LED on the safety module!
	OFF	<a href="#">State "Device is ready to switch on"</a>
	OFF	<a href="#">State "Device is switched on"</a>
	OFF	<a href="#">State "Operation"</a>
		<a href="#">State "Warning active"</a> or <a href="#">State "Warning locked active"</a> The controller is ready to start, switched on or the operation is enabled and a warning is indicated.
		<a href="#">State "Quick stop by trouble"</a>
OFF		<a href="#">Status "Trouble active"</a>
OFF		<a href="#">State "Fault active"</a>
OFF		<a href="#">State "System fault active"</a>

#### Legend

Meaning of the symbols used to describe the LED states:

	LED flashes once approx. every three seconds ( <i>slow flash</i> )
	LED flashes twice approx. every 1.25 seconds ( <i>flash</i> )
	LED flashes twice approx. every 1.25 seconds ( <i>double flash</i> )
	LED blinks every second
	LED is permanently on



**Tip!**

The current device state is also displayed in [C00183](#).

## 4.2 Parameter setting

### 4.2.1 Machine parameters

The global machine constants ("machine parameters") are set in the »Engineer« on the **Application parameters** tab in the *Overview* → *Drive interface* → *Machine parameters* dialog level:



**Tip!**

Detailed information on the different machine parameters can be obtained from the following subchapters.

## 4.2.1.1 Mains voltage

Via the **Mains voltage** list field ([C00173](#)) the mains voltage for the drive controller is set.

- ▶ If you set a mains voltage with adjustable threshold for undervoltage ("LU adjustable"), this undervoltage threshold can be set in the **Undervoltage threshold (LU)** input field ([C00174](#)).
- ▶ In the **Resp. to DC bus overvoltage** list field ([C00600](#)) the response to the DC-bus overvoltage can be selected.



### Note!

Changing the setting in [C00173](#) also affects the permissible device utilisation!




### Tip!

The chapter "Rated data" in the Hardware Manual informs which device type has which permissible device utilisation at which mains voltage and switching frequency.

See also: ▶ [Monitoring of the device utilisation](#) (📖 43)

## 4.2.1.2 Gearbox ratio

The gearbox ratio specifies the number of revolutions of the motor axis needed for one rotation of the load axis (e.g. spindle or drive roll).




[4-1] Schematic diagram - gearbox ratio

- ▶ In the example shown in figure [4-1] 58.667 revolutions of the motor axis result in one revolution of the spindle.

### Selection of the gearbox ratio

- ▶ The gearbox ratio must be defined in the form of a quotient (numerator/denominator). The required data is included in the technical gearbox data.



[4-2] Example: Technical data gearbox data (from the gearbox catalog)

- ▶ Example calculation on the basis of the technical gearbox data:

Gearbox numerator	factor	$= z2 \times z4 = 88 \times 72$	= 6336	→ <a href="#">C02520</a>
Gearbox denominator	factor	$= z1 \times z3 = 12 \times 9$	= 108	→ <a href="#">C02521</a>



**Tip!**

The resulting gearbox factor is displayed in [C02531/1](#).


## 4.2.1.3 Motor mounting direction

Via the **motor mounting direction** list field ([C02527](#)) the direction of rotation can be inverted depending on the motor mounting position, if required:

- ▶ [C02527](#) = "0": Clockwise motor  $\equiv$  positive machine direction.
- ▶ [C02527](#) = "1": Counter-clockwise motor  $\equiv$  positive machine direction.

## 4.2.1.4 Configuration feedback

In the most cases, the system only has one motor encoder, i.e. no separate position encoder is installed on the load side. Motor position (angle of rotation) and motor speed are detected via the motor encoder selected in [C00495](#) and converted with regard to the load side.



[4-3] Schematic diagram - feedback with position encoder = motor encoder

The actual position and speed values on the machine side result from the conversion via the [Gearbox ratio](#) on the motor side and the [Feed constant](#).



### Tip!

Detailed information on parameter setting of the feedback systems for the motor control can be found in chapter "[Encoder evaluation](#)". ([108](#))

#### 4.2.1.5 Unit/application unit

Using these machine parameters you define the real unit of the machine in which the feed constant and the parameters for a travel profile must be specified (e.g. position, speed, acceleration, and deceleration).

- ▶ If you set, for instance, the "mm" unit for a linear axis, the position must be specified in [mm] and the speed in [mm/s].
- ▶ By means of the freely definable "application unit" the significant production units as e.g. "bottles" can be set.
  - For this, select the entry "User-defined" as unit in [C02525](#) and enter the desired application unit in [C02526](#).



#### Note!

In this documentation, the term "unit" in the parameter unit data only serves as a wildcard for the real unit of a machine.

#### Display parameters

Parameters	Information
<a href="#">C02533</a>	Time unit
<a href="#">C02534</a>	User-defined time unit
<a href="#">C02535</a>	User-defined unit
<a href="#">C02537</a>	Unit of speed
<a href="#">C02538</a>	Unit of acceleration

Highlighted in grey = display parameter

## 4.2.1.6 Traversing range

The selection of the traversing range ("Unlimited", "Limited" or "Modulo") in the **Traversing range** list field ([C02528](#)) serves to define the machine measuring system.




### Note!

A change-over of the traversing range results in a loss of the reference information!

### "Unlimited" traversing range"

The drive can rotate continuously in one direction.

- ▶ By referencing and activating the software limit positions the traversing range can be limited.
- ▶ For positioning with absolute travel command the home position must be known.




[4-4] Example: Unlimited traversing range - "feed control tape"

### "Limited" traversing range"

The travel range is limited by positive and negative position limits (mechanical limits/travel range limit switches/software limit positions). ▶ [Limiter](#) (□ 200)

- ▶ After a defined distance the drive must travel in the opposite direction.
- ▶ For positioning with absolute travel command the home position must be known.
- ▶ Basically the software limit positions are monitored with regard to the internally maximally value range to be displayed ( $\pm 2^{31}$  increments) even if the monitoring mode has been deactivated via [C02700](#).
- ▶ An overflow of the value range results in a loss of the reference information.




[4-5] Example: Limited traversing range - "spindle drive" (linear axis)



## "Modulo" traversing range

The measuring system is repeated.

- ▶ If the cycle set in [C02536](#) is exceeded, a defined overflow occurs. The cycle typically corresponds to a rotation or tool distance in a rotative system.
- ▶ For positioning with absolute travel command the home position must be known.
- ▶ Software limit positions are not effective.
- ▶ Absolute targets can be approached by exceeding the measuring system limit, e.g. from 10° to 350°.




[4-6] Example: Modulo traversing range - "rotary table"

## Dependencies - traversing range/basic drive functions


- ▶ The following table lists the different dependencies between the traversing range selected and basic drive functions.

Basic drive function	Traversing range		
	Unlimited	Limited	Modulo
Position data for <a href="#">Encoder evaluation</a>	continuously	continuously	clocked
Position data for <a href="#">Position follower</a>	absolute	absolute	absolute (in time)
Positioning modes for <a href="#">Positioning</a>	1, 2, 5, 6, 7, 8	1, 2, 5, 6, 7, 8	5, 6, 11 ... 16
Restrictions for <a href="#">Homing</a>	None	None	Home position must be in time
Limit positions ( <a href="#">Limiter</a> )	permitted	permitted	not permitted



- ① Reference setting
- ② Position in the machine measuring system
- ③ Position in the motor measuring system

[4-7] Example: Unlimited/limited position display




- ① Cycle
- ② Position in the machine measuring system
- ③ Position in the motor measuring system

[4-8] Example: Modulo position display

## 4.2.1.7 Feed constant

The feed constant corresponds to the motion of the machine at one revolution of the gearbox output shaft.


- ▶ The input in the **Feed constant** field ([C02524](#)) is made in the unit defined in [C02525](#) regarding one revolution.
- ▶ In case of a conveyor drive the feed constant results from the circumference of the drive roll which is calculated in the following example based on the diameter given:



$$\text{Feed constant} = \pi \cdot d \frac{[\text{Unit}]}{\text{Revolution}} = \pi \cdot 200 \frac{\text{mm}}{\text{Revolution}} = 628.3185 \frac{\text{mm}}{\text{Revolution}}$$

[4-9] Schematic diagram: Feed constant in case of a conveyor drive

- ▶ In case of a spindle drive (linear axis) the speed constant results from the leadscrew pitch. The feed constant indicates which way the slide travels at one revolution of the spindle (in the following example 5.023 mm).



[4-10] Schematic diagram: Feed constant in case of a spindle drive

- ▶ In case of a rotary table and defined as an angle the feed constant is = 360°.

#### 4.2.2 Monitoring of the device utilisation

In [C00064](#) the device utilisation (i x t) is displayed over the last 180 seconds in [%].

- ▶ If the value displayed in [C00064](#) exceeds the warning threshold set in [C00123](#), the fault message "device utilisation Ixt > C00123" is output and the fault response set in [C00604](#) occurs (default setting: "Warning").
- ▶ If the value displayed in [C00064](#) exceeds 100 %, the fault message "device utilisation Ixt > 100 %" is output and the fault response "Fault" occurs.
  - The fault can only be reset if the value displayed in [C00064](#) is < 95 % again.

#### 4.2.3 Parameter for status display

Parameters	Information
<a href="#">C00003</a>	Controller command status
<a href="#">C00007</a>	Active application
<a href="#">C00150</a>	Status word 1
<a href="#">C00155</a>	Status word 2
<a href="#">C00183</a>	Device state
<a href="#">C02530</a>	Active function state

Highlighted in grey = display parameter

## 4.3 Monitoring of external events

Use the input *DI\_bSetExternError* of the system block [LS DriveInterface](#) to monitor external events by means of corresponding logic operations and activate the error message "External error" in the controller.

### Parameterising a response to an external error

The controller response to the error message "External error" can be selected under [C00581](#).

### Activation of error message "External error".

The error message "External error" is activated by setting the input *DI\_bSetExternError* to TRUE.

- ▶ After this, the error number for the error message "External error" "[0x20750000](#)" (when "Fault" has been selected as response) will be stored in the internal fault memory ([C00168](#)).

### Reset of error message

The error message "External error" and other active error messages are reset by setting the input *DI\_bResetError* to TRUE.

- ▶ If the input *DI\_bSetExternError* is still set to TRUE, the reset will not be carried out.
- ▶ Error messages can only be reset if the cause of the error has been eliminated.


## 4.4 Set/remove controller inhibit

Setting the controller inhibit inhibits the power stages in the controller and resets the speed/current and position controller of the motor control.

- ▶ When the controller is inhibited, the status output *DI\_bCInhActive* of the system block [LS DriveInterface](#) is set to TRUE.
- ▶ The controller can be inhibited by different sources, e.g. using the digital input RFR, the input *DI\_bSetCInh* of the system block [LS DriveInterface](#) or via the device command "Inhibit controller" ([C00002](#) = "41").
- ▶ The bit code under [C00158](#) shows the source that inhibited the controller.

4.5 Device states

The state control of the drive is internally controlled via a state machine which can adopt the following "device states":



[4-11] Device states of the state machine for the device control



**Note!**

The device states of the controller must not be confused with the function states of the [Basic drive functions](#). (140)

- The current device status is displayed in [C00183](#).
- In the "Operation" device state, the [Basic drive functions](#) specify the motion control of the drive.


## 4.5.1 Status "initialisation active"

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
OFF	OFF	10: Initialisation active

The controller is in this device state directly after switching on the supply voltage.

- ▶ In this device status the operating system is initialised.
- ▶ The application is not yet processed.
- ▶ The monitoring mode is not yet active.
- ▶ Communication is not possible yet.
- ▶ The controller cannot be parameterised yet and no device commands can be executed.
- ▶ When the device initialisation is completed, the device state is automatically changed to "Safe torque off active".

## 4.5.2 Status "Safe torque off active"

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
	OFF	101: Safe torque off active

This device state becomes active when the controller receives the request "Safe torque off".


- ▶ "Drive is torqueless" (0x00750003) is entered in the logbook.
- ▶ If there is no request by the safety module, it is changed into the next state "Device is ready to switch on".



### Note!

The "Safe torque off active" state is also passed through after errors have been acknowledged (see fig. [\[4-11\]](#)).

## 4.5.3 State "Device is ready to switch on"


LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
	OFF	141: Device is ready to switch on

The controller is in this device state directly after the initialisation is completed and no DC-bus voltage is applied yet.

- ▶ The bus systems are running and the terminals and encoders are evaluated.
- ▶ The monitoring modes are active.
- ▶ The controller can be parameterised and device commands can be executed in a limited way.
- ▶ The application is basically executable.
- ▶ The function of the user task can be used.
  - Condition: The application has started (status display in [C02108](#)).
- ▶ The basic drive functions cannot be used yet.
- ▶ There are two options for a change from the "Device is ready to switch on" state to the "Device is switched on" state:
  - Auto restart enabled after mains connection ([C00142](#) = "1").
  - Auto restart inhibited after mains connection ([C00142](#) = "0") and controller inhibited.

### Auto start option 1: Auto restart enabled after mains connection


- ▶ The following figure shows the status change for the automatic start option 1 (Lenze setting) as a function of the controller inhibit:



[4-12] State change when auto restart is enabled (C00142 = "1")

## Auto-start option 0: Auto restart inhibited after mains connection

- ▶ When the automatic start option 0 has been selected, the controller inhibit must be explicitly reset after the mains is switched on so that the controller status changes from "Device is ready to switch on" to "Device is switched on":



[4-13] State change when the auto restart is inhibited (C00142 = "0")

### 4.5.4 State "Device is switched on"


LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
	OFF	90: Device is ready to switch on.

The drive is in this device state when the DC-bus voltage is applied and the controller is still inhibited by the user (controller inhibit).

- ▶ The bus systems are running and the terminals and encoders are evaluated.
- ▶ The monitoring modes are active.
- ▶ The controller can be parameterised yet and device commands can be executed in a limited way.
- ▶ The application is basically executable.
- ▶ The function of the user task can be used.
  - Condition: The application has started (status display in [C02108](#)).
- ▶ The basic drive functions cannot be used yet.
- ▶ When the controller is inhibited, the motor creates a torque.





## 4.5.5 State "Operation"

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
	OFF	0: Operation



In this device state the motor follows its setpoint according to the selected basic drive function.

## 4.5.6 State "Warning active"

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
		1: Operation/warning active



This state can occur parallel to the device states "Device is ready to switch on", "Device is switched on" and "Operation", if a monitoring is activated, the fault response "Warning" has been parameterised for.

## 4.5.7 State "Warning locked active"

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
		2: Operation/Warning locked active

This state can occur parallel to the device states "Device is ready to switch on", "Device is switched on" and "Operation", if a monitoring is activated which the fault response "Warning locked" has been parameterised for.


## 4.5.8 State "Quick stop by trouble"

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
		151: Quick stop by trouble active

This device state becomes active as soon as a monitoring mode responds for which the error response "Quick stop in case of trouble" has been parameterised.

- ▶ The drive is decelerated to standstill with torque within the parameterised deceleration time independent of the defined setpoint and can be kept there.
- ▶ The device state can only be abandoned by acknowledging the error if the error cause is removed.
- ▶ When the controller is inhibited, it can be jumped to the "Operation" state even during the error status since the controller inhibit has a higher priority. As long as the error is pending and has not been acknowledged, it is changed back to the "Quick stop by trouble active" when the controller is enabled afterwards.


## 4.5.9 Status "Trouble active"

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
OFF		104: Trouble active

This device state becomes active as soon as a monitoring mode responds for which the error response "Trouble" has been parameterised.


- ▶ The motor has no torque (is coasting).
- ▶ The device state is automatically abandoned if the error cause is removed:
  - "Trouble active" state < 500 ms: Return to the original device state.
  - "Trouble active" > state 500 ms: Return via the device state "Safe torque off active".

## 4.5.10 State "Fault active"

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
OFF		102: Fault active

This device state becomes active as soon as a monitoring mode responds for which the error response "Fault" has been parameterised.

#### 4.5.11 State "System fault active"

LED DRIVE READY	LED DRIVE ERROR	Display in <a href="#">C00183</a>
OFF		20: System fault active

This device state becomes active if a system error occurs.

- ▶ The device state can only be abandoned by mains switching.

## 4.6 Controller commands

Different controller commands are available for project management within the controller. They can be activated under code [C00002](#).

- ▶ The following subsections describe the most important controller commands for project management and parameter set management in the controller.
- ▶ With an online connection, the controller commands can be activated from the »Engineer« by selecting the corresponding command in the **Parameters** tab under [C00002](#). As an alternative, the controller commands can be activated via the keypad.
- ▶ In [C00003](#) the number and the status of the device command executed last is indicated. ▶ [Status display for device command](#) (📖 54)



### Note!

Before the supply voltage is switched off after a device command has been transmitted via [C00002](#), it must be checked via [C00003](#) if the device command has been completed successfully!

- The "0x00" status in the lower 16 bits of [C00003](#) means that the device command has been executed successfully.



### Tip!

Many frequently required controller commands (e.g. "Save start parameters") can be executed via the *toolbar* icons of the »Engineers«.



### Note!

Controller commands that can be executed via the toolbar of the »Engineers« always affect the element currently selected in the *Project view* including all subelements.

- If no controller, but a system module is selected in the *Project view*, the corresponding controller command will be activated in all lower-level controllers having an online connection with the »Engineer«.

For the commands described in the following subsections, the controller must be selected in the *Project view*.

## 4.6.1 Overview of device commands

Controller command	Information	Status*
0 Load Lenze setting	▶ <a href="#">Load Lenze setting</a> (☞ 56)	●
1 Load start parameter	▶ <a href="#">Load parameter set</a> (☞ 57)	●
5 Activate application	▶ <a href="#">Activate application</a> (☞ 58)	●
7 Save application selection	▶ <a href="#">Save selected application</a> (☞ 58)	●
11 Save start parameter	▶ <a href="#">Save parameter set</a> (☞ 57)	●
20 Delete logbook	▶ <a href="#">Logbook</a> (☞ 436)	●
21 Archive logbook		●
31 Start application	▶ <a href="#">Start/stop application</a> (☞ 56)	●
32 Stop application		●
33 Reset program		●
34 Restart program		●
35 Delete program		●
36 Reset runtime measurement		●
41 Inhibit controller	▶ <a href="#">Set/remove controller inhibit</a> (☞ 44)	-
42 Enable controller		-
43 Reset error	▶ <a href="#">Reset of error message</a> (☞ 447)	-
45 Activate quick stop	▶ <a href="#">Quick stop</a> (☞ 152)	-
46 Exit quick stop		-
51 Determine rotor displacement angle	▶ <a href="#">Set rotor displacement angle</a> (☞ 71)	●
71 Detect inverter characteristic	▶ <a href="#">Optimise the switching performance of the inverter</a> (☞ 73)	●
72 Determine motor parameter	▶ <a href="#">Set motor parameters</a> (☞ 75)	●
91 CAN on board: Reset node	See Communication Manual "System bus (CANopen)".	●
92 CAN module: Reset node		●
93 CAN on board: Pred.Connect.Set		●
94 CAN module: Pred.Connect.Set		●
95 CAN on board: Identify node		●
96 CAN module: Identify node		●
101 Ethernet module MXI1 unbind/bind	See Communication Manual "Ethernet".	●
102 Ethernet module MXI2 unbind/bind		●
201 Activate parameter set 1	▶ <a href="#">Activate/archive parameter set</a> (☞ 59)	●
202 Activate parameter set 2		●
203 Activate parameter set 3		●
204 Activate parameter set 4		●
301 Archive parameter set 1		●
302 Archive parameter set 2		●
303 Archive parameter set 3		●
304 Archive parameter set 4		●

The device command status is displayed in [C00003](#). ▶ [Status display for device command](#)

Controller command		Information	Status*
1021	Export parameter to file	Export current parameter set to file.	●
1030	Format file system	Format file system of the memory module.	●
1040	Restore file system		-
10000	Prepare firmware update		●
11000	Restart controller		●

The device command status is displayed in [C00003](#). ▶ [Status display for device command](#)

## 4.6.2 Status display for device command

[C00003](#) indicates the number and the status of the last executed controller command. The number of the controller command is indicated in the upper 16 bits and the execution status in the lower 16 bits.

C00003	
Bit 16 ... 31	Bit 0 ... 15
Device command executed last	Status of the last executed controller command

- ▶ The following table lists the most important status messages according to the degree of probability of their occurrence.

Bit 0 ... 15	Status	Concerns device command
0x0000	Execution ok.	All
0x0001	General fault.	All
0x8404	File could not be opened.	201, 202, 203, 204, 301, 302, 303, 304
0x841D	Fault while reading out of a file.	201, 202, 203, 204, 301, 302, 303, 304
0x841E	Fault while writing into a file.	11, 201, 202, 203, 204, 301, 302, 303, 304
0x841F	Invalid file type.	201, 202, 203, 204,
0x8420	Unexpected file end.	201, 202, 203, 204, 301, 302, 303, 304
0x8422	Checksum error	201, 202, 203, 204
0x842B	Fault while reading the parameter set partition.	1
0x842C	Fault while writing the parameter set partition.	11
0x842E	No memory module available.	1, 11
0x8502	Processing of the device command is still active.	All
0x9Axx	CAN fault	0, 1, 5, 91, 92, 201, 202, 203, 204
0x9B07	Rotor position adjustment cannot be executed because of the wrong motor type (asynchronous motor).	51
0x9B08	Rotor position adjustment has been aborted.	51
0x9B09	Rotor position adjustment cannot be executed since another identification is active already.	51
0x9B0A	Rotor position adjustment cannot be executed since the V/f-test mode is active.	51

Bit 0 ... 15	Status	Concerns device command
0x9B0B	Rotor position adjustment cannot be executed since the current controller test mode is active.	51
0x9B12	Motor identification cannot be started since the current controller test mode is active.	71, 72
0x9B13	Motor identification cannot be started since the V/f test mode is active.	71, 72
0x9B14	Motor identification cannot be started since the rotor position adjustment is active.	71, 72
0x9B15	Motor identification has been aborted.	71, 72
0x9B16	Motor identification has been aborted by fault.	71, 72
0xA001	Access to file has been denied since the file is already accessed from another position	11, 201, 202, 203, 204, 301, 302, 303, 304
0xA005	I/O fault when accessing the file system.	11, 201, 202, 203, 204, 301, 302, 303, 304
0xA00C	RAM memory is full.	11, 201, 202, 203, 204, 301, 302, 303, 304
0xA00D	Access authorisation denied.	11, 201, 202, 203, 204, 301, 302, 303, 304
0xA01C	No free memory on the memory module.	11, 201, 202, 203, 204, 301, 302, 303, 304

## 4.6.3 Start/stop application

With an online connection, these controller commands can be executed via the corresponding *toolbar* icons of the »Engineers«.

- ▶ Alternatively, the controller commands can also be activated with the parameter settings listed in the "Controller command" column (e.g. via the keypad).

Symbol	Function	Controller command
	Start application in controller	<a href="#">C00002</a> = "31"
	Stop application in controller	<a href="#">C00002</a> = "32"



### Note!

If the drive is stopped during operation, the drive is braked to standstill via the basic function "Stop".

- ▶ [Standard stop](#) (148)



## 4.6.4 Load Lenze setting

This controller command resets the parameter settings to the Lenze setting. All parameter changes get lost.

- ▶ Only possible when the application has stopped and the controller is inhibited.
- ▶ This controller command only affects the settings of the operating system, application and module parameters, the active application and the configuration selected with the function block editor remain unchanged.



### How to load the Lenze setting:

1. Click the  icon to stop the current controller program.
2. Click the  icon to set the controller inhibit.
3. Execute the controller command "Load Lenze setting" with [C00002](#) = "0".



#### 4.6.5 Save parameter set

Controller parameter changes made via the »Engineer« or keypad will get lost after mains switching of the controller or loading of another application unless the settings have been explicitly saved with the corresponding controller command in the memory module of the controller.



##### **How to save the starting parameters safe against mains failure in the memory module:**

Execute the controller command "Save starting parameter" with [C00002](#) = "11".



#### 4.6.6 Load parameter set

Activation of this controller command reloads the parameter set of the active application from the memory module into the controller. All parameter changes made since the parameter set has been saved last will get lost.

- ▶ Only possible when the application program has stopped and the controller is inhibited.



##### **How to reload the starting parameters from the memory module:**

1. Click the  icon to stop the current controller program.
2. Click the  icon to set the controller inhibit.
3. Execute the controller command "Load starting parameter" with [C00002](#) = "1".


## 4.6.7 Activate application

If the memory module contains several applications, you can use this controller command to activate a different application in the controller.

- ▶ After mains switching, the preset application will be loaded into the controller.
- ▶ If after mains switching another application than the one preset by Lenze is to be loaded, it must be activated first and then the application selection must be saved. ▶ [Save selected application](#)



### How to activate a different application:

1. Click the  icon to stop the current controller program.
2. Select the number of the application to be activated under [C00005](#).
3. Execute the controller command "Activate application" with [C00002](#) = "5".
  - The application with the number set in [C00005](#) is activated. If it is started immediately depends on the automatic start setting selected in [C02104](#).



### Note!

When the application is activated, the corresponding parameter set 1 is loaded automatically and parameter settings executed before will get lost unless the parameter set was saved before!

## 4.6.8 Save selected application

After mains switching, the controller always loads the preset application, even if a different application has been active before.

Use the controller command "Save selected application" to select the active application as presetting, i.e. the memory module will load this application into the controller after every mains switching.

- ▶ When the controller command is executed, the parameter set is saved automatically.



Execute the controller command "Save selected application" with [C00002](#) = "7" to select the active application as presetting.

## 4.6.9 Activate/archive parameter set


In addition to the current parameter set, it is possible to store up to four additional parameter sets (PS 1 ... PS 4) for each project in the memory module.

Using the corresponding controller commands, you can archive the current parameter set settings in parameter sets PS 1 ... PS 4 and reactivate them, if required.

- ▶ This allows you to define different controller settings for an application, which can easily be loaded by means of the corresponding controller command, if required.


### Activate parameter set

The following figure shows the controller commands which activate a parameter set on the memory module (MM):



### Archive parameter set

The following figure shows the controller commands which archive the current parameter set:




# 9400 HighLine | Parameter setting & configuration

Drive interface

System block "LS\_DriveInterface"

## 4.7 System block "LS\_DriveInterface"

The system block LS\_DriveInterface displays the drive interface in the function block editor.



### Inputs

Input	DIS code   Data type	Information/possible settings
DI_bSetClnh	<a href="#">C02549/1</a>   BOOL	<a href="#">Set/remove controller inhibit</a> (☐ 44) TRUE   Set controller inhibit.
DI_bResetError1	<a href="#">C02548/1</a>   BOOL	Error message reset (acknowledgement) <ul style="list-style-type: none"> <li>This function resets an active error message, if the cause of the error message has been eliminated.</li> <li>The three inputs are linked via a logic OR gate.</li> </ul>
DI_bResetError2	<a href="#">C02548/2</a>   BOOL	
DI_bResetError3	<a href="#">C02548/3</a>   BOOL	
DI_bSetExternError	<a href="#">C02548/4</a>   BOOL	Activation of error message "External error". <a href="#">▶ Monitoring of external events</a> (☐ 44) TRUE   Activate fault message with the response selected in <a href="#">C00581</a> .
DI_bSwitchOn	<a href="#">C02549/4</a>   BOOL	Deactivate switch-on inhibit <ul style="list-style-type: none"> <li>If the automatic restart is inhibited (<a href="#">C00142</a> = "0"), the state machine remains in the "Device is ready to switch on" state after mains switching.  <a href="#">▶ State "Device is ready to switch on"</a> (☐ 47)</li> </ul> FALSE↗TRUE   The switch-on inhibit is deactivated and the controller changes to the "Device is switched on" device state.

## Outputs

Output	Value/meaning																																																																
DI_dnState <small>DIS code   Data type</small> <a href="#">C02547</a>   DINT	Status (bit coded) <b>Status signals of the momentarily enabled basic function (if available):</b> <table border="1"> <tr><td>Bit 0</td><td>-</td></tr> <tr><td>Bit 1</td><td>Basic function is active (signal <i>bActive</i>).</td></tr> <tr><td>Bit 2</td><td>Basic function is completed (signal <i>bDone</i>).</td></tr> <tr><td>Bit 3</td><td>Acceleration/deceleration phase is active (signal <i>bAccDec</i>).</td></tr> <tr><td>Bit 4</td><td>-</td></tr> <tr><td>Bit 5</td><td>CCW rotation is active (signal <i>bCcw</i>).</td></tr> <tr><td>Bit 6</td><td>-</td></tr> <tr><td>Bit 7</td><td>Reference is known</td></tr> <tr><td>Bit 8</td><td>Brake is open.</td></tr> <tr><td>Bit 9</td><td>Waiting for clutch condition.</td></tr> <tr><td>Bit 10</td><td>Zero crossing detected or position = "0".</td></tr> <tr><td>Bit 11</td><td>-</td></tr> <tr><td>Bit 12</td><td>-</td></tr> <tr><td>Bit 13</td><td>-</td></tr> <tr><td>Bit 14</td><td>-</td></tr> <tr><td>Bit 15</td><td>Fault in active basic function (group signal).</td></tr> </table> <b>Status signals of the internal state machine for the basic functions:</b> <table border="1"> <tr><td>Bit 16</td><td><a href="#">Torque follower</a> active.</td></tr> <tr><td>Bit 17</td><td><a href="#">Speed follower</a> active.</td></tr> <tr><td>Bit 18</td><td><a href="#">Position follower</a> active.</td></tr> <tr><td>Bit 19</td><td>Setpoint follower is active (group signal for bit 16 ...18).</td></tr> <tr><td>Bit 20</td><td><a href="#">Positioning</a> active.</td></tr> <tr><td>Bit 21</td><td><a href="#">Homing</a> active.</td></tr> <tr><td>Bit 22</td><td><a href="#">Manual jog</a> active.</td></tr> <tr><td>Bit 23</td><td>Brake test is active.</td></tr> <tr><td>Bit 24</td><td>Drive at standstill.</td></tr> <tr><td>Bit 25</td><td>Drive is stopped.</td></tr> <tr><td>Bit 26</td><td><a href="#">Quick stop</a> active.</td></tr> <tr><td>Bit 27</td><td>-</td></tr> <tr><td>Bit 28</td><td>Controller is not ready.</td></tr> <tr><td>Bit 29</td><td>Initialisation</td></tr> <tr><td>Bit 30</td><td>State "Fault active" (signal <i>DI_bFailActive</i>).</td></tr> <tr><td>Bit 31</td><td>State machine is not ready to receive setpoints. (Group signal for bit 28 ... 30)</td></tr> </table>	Bit 0	-	Bit 1	Basic function is active (signal <i>bActive</i> ).	Bit 2	Basic function is completed (signal <i>bDone</i> ).	Bit 3	Acceleration/deceleration phase is active (signal <i>bAccDec</i> ).	Bit 4	-	Bit 5	CCW rotation is active (signal <i>bCcw</i> ).	Bit 6	-	Bit 7	Reference is known	Bit 8	Brake is open.	Bit 9	Waiting for clutch condition.	Bit 10	Zero crossing detected or position = "0".	Bit 11	-	Bit 12	-	Bit 13	-	Bit 14	-	Bit 15	Fault in active basic function (group signal).	Bit 16	<a href="#">Torque follower</a> active.	Bit 17	<a href="#">Speed follower</a> active.	Bit 18	<a href="#">Position follower</a> active.	Bit 19	Setpoint follower is active (group signal for bit 16 ...18).	Bit 20	<a href="#">Positioning</a> active.	Bit 21	<a href="#">Homing</a> active.	Bit 22	<a href="#">Manual jog</a> active.	Bit 23	Brake test is active.	Bit 24	Drive at standstill.	Bit 25	Drive is stopped.	Bit 26	<a href="#">Quick stop</a> active.	Bit 27	-	Bit 28	Controller is not ready.	Bit 29	Initialisation	Bit 30	State "Fault active" (signal <i>DI_bFailActive</i> ).	Bit 31	State machine is not ready to receive setpoints. (Group signal for bit 28 ... 30)
Bit 0	-																																																																
Bit 1	Basic function is active (signal <i>bActive</i> ).																																																																
Bit 2	Basic function is completed (signal <i>bDone</i> ).																																																																
Bit 3	Acceleration/deceleration phase is active (signal <i>bAccDec</i> ).																																																																
Bit 4	-																																																																
Bit 5	CCW rotation is active (signal <i>bCcw</i> ).																																																																
Bit 6	-																																																																
Bit 7	Reference is known																																																																
Bit 8	Brake is open.																																																																
Bit 9	Waiting for clutch condition.																																																																
Bit 10	Zero crossing detected or position = "0".																																																																
Bit 11	-																																																																
Bit 12	-																																																																
Bit 13	-																																																																
Bit 14	-																																																																
Bit 15	Fault in active basic function (group signal).																																																																
Bit 16	<a href="#">Torque follower</a> active.																																																																
Bit 17	<a href="#">Speed follower</a> active.																																																																
Bit 18	<a href="#">Position follower</a> active.																																																																
Bit 19	Setpoint follower is active (group signal for bit 16 ...18).																																																																
Bit 20	<a href="#">Positioning</a> active.																																																																
Bit 21	<a href="#">Homing</a> active.																																																																
Bit 22	<a href="#">Manual jog</a> active.																																																																
Bit 23	Brake test is active.																																																																
Bit 24	Drive at standstill.																																																																
Bit 25	Drive is stopped.																																																																
Bit 26	<a href="#">Quick stop</a> active.																																																																
Bit 27	-																																																																
Bit 28	Controller is not ready.																																																																
Bit 29	Initialisation																																																																
Bit 30	State "Fault active" (signal <i>DI_bFailActive</i> ).																																																																
Bit 31	State machine is not ready to receive setpoints. (Group signal for bit 28 ... 30)																																																																
DI_bReady <small>DIS code   Data type</small> <a href="#">C02549/6</a>   BOOL	Status signal "Controller is ready for operation" TRUE The controller is ready for operation.																																																																
DI_bFailActive <small>DIS code   Data type</small> <a href="#">C02549/7</a>   BOOL	Status signal "Error active acknowledgement is required" TRUE A monitoring function with the "Fault" response or "Quick stop by trouble" has been activated and the controller is in the device state "Fault active" or "Quick stop by trouble active". To quit the controller state the error must be acknowledged, e.g. via the input <i>DI_bErrorReset1...3</i> .																																																																

# 9400 HighLine | Parameter setting & configuration

Drive interface

System block "LS\_DriveInterface"

Output	Value/meaning
DIS code   Data type DI_bImpActive <a href="#">C02549/8</a>   BOOL	Status signal "Pulse inhibit set" TRUE   Power stages are switched with high resistance.
DI_bCInhActive <a href="#">C02549/9</a>   BOOL	Status signal "Controller inhibit active" TRUE   The controller inhibit is active.
DI_bWarningActive <a href="#">C02549/10</a>   BOOL	Status signal "Warning active" TRUE   A warning is active in the controller.
DI_bUVDetected <a href="#">C02549/11</a>   BOOL	Status signal "Undervoltage detected" • The threshold for the monitoring function depends on the setting under <a href="#">C00173</a> . TRUE   DC bus undervoltage detected.
DI_bOVDetected <a href="#">C02549/12</a>   BOOL	Status signal "Overvoltage detected" • The threshold for the monitoring function depends on the setting under <a href="#">C00173</a> . TRUE   DC bus overvoltage detected.
DI_bMainSupplyOk <a href="#">C02549/13</a>   BOOL	Status signal "mains voltage is applied" TRUE   A voltage is applied to the mains voltage inputs L1, L2 and L3.
DI_bReadyToSwitchOn <a href="#">C02549/14</a>   BOOL	Status signal "Controller ready to start" TRUE   The controller has completed the initialisation and is in the device state "Device is ready to switch on".
DI_bOperationEnabled <a href="#">C02549/15</a>   BOOL	Status signal "Operation is enabled" TRUE   The controller is in the "operation" device state and the motor follows its setpoint according to the selected basic drive function or is at standstill due to stop or quick stop.
DI_dwErrorCode DWORD	Error number of the current error message ▶ <a href="#">Error messages of the operating system</a> (□ 443)
DI_AxisData	Data structure, which contains all required machine constants.

## 4.7.1 Status signals

The following representation shows which status signals of the system block **LS\_DriveInterface** are set to TRUE in different typical cases:

**Case 1:**  
Application has been transmitted to the controller.  
No mains voltage available (LU fault).  
Controller is inhibited (via RFR terminal).

**Case 2:**  
Mains voltage has been connected.

**Case 3:**  
Controller inhibit has been deactivated.

**Case 4:**  
Fault is active.

**Case 5:**  
Quick stop by trouble is active

Status	Case 1	Case 2	Case 3	Case 4	Case 5	Status signal (output)
Ready for operation	●	●	●	●	●	DI_bReady
Fault is active	●	●	●	●	●	DI_bFailActive
Pulse inhibit is active	●	●	●	●	●	DI_bImpActive
Controller inhibit is active	●	●	●	●	●	DI_bCinhActive
Warning is active	●	●	●	●	●	DI_bWarningActive
Undervoltage detected	●	●	●	●	●	DI_bUVDetected
Overvoltage detected	●	●	●	●	●	DI_bOVDetected
Mains supply is Ok	●	●	●	●	●	DI_bMainSupplyOk
Ready to switch on	●	●	●	●	●	DI_bReadyToSwitchOn
Operation enabled	●	●	●	●	●	DI_bOperationEnabled

### 5 Motor interface

This chapter contains information on initial commissioning of the motor and parameter setting of the internal motor control of the controller.



#### Note!

To select application-specific setpoints, the motor interface can be extended by appropriate interfaces using the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)".

The application-specific conditioning of the encoder signals is executed with the basic function "[Encoder evaluation](#)".

See also:


- ▶ [Speed follower](#) (📖 190)
- ▶ [Torque follower](#) (📖 196)
- ▶ [Position follower](#) (📖 183)
- ▶ [Encoder evaluation](#) (📖 108)



## 5.1 Initial commissioning

An initial commissioning of the motor is required if the motor data in the memory module of the controller and the »Engineer« project is not suitable for the application.

- ▶ The following stepwise instructions can be used as "check list" to adjust the motor correctly to the controller.
- ▶ Detailed information on the individual steps can be found in the following subchapters:

Worksteps	
1.	Read out the motor data of the controller or select them via the »Engineer« motor catalog. <ul style="list-style-type: none"> <li>• When the motor connected to the motor has an electronic nameplate (ENP), all motor data are automatically read out of the ENP and a selection from the motor catalog is not required. ▶ <a href="#">Read the motor data out of the controller</a> (📖 66)</li> <li>• If a motor without ENP or an external motor is used, the motor data can be selected via the »Engineer« motor catalog. ▶ <a href="#">Select motor in the »Engineer« motor catalog</a> (📖 66)</li> </ul>
2.	<a href="#">Accept/adapt route data.</a> (📖 69)
3.	<a href="#">Parameterise motor encoder.</a> (📖 70)
	When an external motor is operated on the controller: <ul style="list-style-type: none"> <li>• Only in case of a synchronous motor: <a href="#">Set rotor displacement angle.</a> (📖 71)</li> <li>• Only in case of unknown motor parameters:               <ul style="list-style-type: none"> <li>– <a href="#">Optimise the switching performance of the inverter.</a> (📖 73)</li> <li>– <a href="#">Set motor parameters.</a> (📖 75)</li> </ul> </li> </ul>
4.	<a href="#">Define currents and speed limits.</a> (📖 78)
5.	<a href="#">Select switching frequency.</a> (📖 79)
6.	<a href="#">Optimise current controller.</a> (📖 81) <ul style="list-style-type: none"> <li>• Required since the controller parameters depend on the maximum switching frequency needed. The default values of the motor catalog only represent theoretically calculated approximate values.</li> </ul>
7.	<a href="#">Save parameter set.</a> (📖 57)
8.	Save »Engineer« project.

#### 5.1.1 Read the motor data out of the controller

If the Lenze motor connected to the controller has an electronic nameplate (ENP), the motor does not need to be selected in the »Engineer« motor catalog.

- ▶ When the controller is switched on initially, all motor data are automatically read out of the electronic motor nameplate and stored at first temporarily in the controller.
- ▶ For a permanent acceptance of the motor data, the parameter set must be saved ([C00002](#) = "11").
- ▶ If there is an online connection between the »Engineer« and the controller, the motor data of the controller can be taken over into the »Engineer« project.



#### How to read the motor data out of the controller:

1. Establish an online connection between »Engineer« and controller.
2. Go to the **Application parameter** tab and change to the dialog level *Overview*→*Motor*.
3. Press the **out of controller** button.
  - Then the motor data are read out of the controller and directly written into the corresponding codes of the »Engineer« project.

#### 5.1.2 Select motor in the »Engineer« motor catalog

If the Lenze motor does not have an electronic nameplate (ENP) or if a motor of a third-party manufacturer is used, select the motor in the »Engineer« via the motor catalog and transfer the motor data to the controller.

- ▶ If you, when inserting the controller into the project in the dialog step "Other components" put a checkmark in the control field **Motor**, you can select as a further dialog step the motor for the controller from the motor catalog.
- ▶ As an alternative you can also insert the motor at a later date into the project via the command **Insert component**.



#### Tip!

If you use a motor of a third-party manufacturer, you can at first select a suitable motor concerning the rated data for current, voltage and speed and then adapt the motor data exactly to the existing motor.

▶ [Display/edit motor data in the »Engineer«](#) (67)

### 5.1.3 Display/edit motor data in the »Engineer«

The "Motor data" only summarises the parameters which depend on the motor. These only characterise the electrical behaviour of the machine.

- ▶ The motor data do not depend on the application in which the controller and motor are used.
- ▶ The motor data are, if available in the »Engineer« via electronic nameplate or motor catalog, accepted by the controller without confirmation prompt.

In the »Engineer«, the motor data are indicated on the **Application parameters** tab, dialog level *Overview*→*Motor*:

The screenshot shows the 'Application parameters' dialog with the 'Motor' tab selected. The 'Motor selection' section includes a dropdown for 'From project' (MDSKA-056-22, 140) and buttons for 'From Motor Catalogue..' and 'From Drive...'. The 'Electronic nameplate' section has an 'ENP: Identified motor type' field. The 'Motor data' section lists parameters like Rated motor power (0.80 kW), Rated motor speed (3950 rpm), Rated motor current (2.40 A), Rated motor frequency (140.0 Hz), Rated motor voltage (390 V), and Motor - cosine phi (0.70). The 'Feedback system' section includes Motor feedback (Resolver X7), Control configuration (Phase control), and Position feedback (Motor feedback). The 'On encoder selection' section shows Encoder type (Incremental encoder (TTL)), Encoder - number of increments (512), and Encoder voltage (5.0 V). The 'Actual values' section displays Motor current (0.00 A), Motor voltage (0 V), Maximum torque (0.000 Nm), Motor reference torque (0.000 Nm), Motor - number of pole pairs (0), and Rotor position (0).

- ▶ If you use a motor of a third-party manufacturer, the displayed motor data can be adapted exactly to the existing motor by selecting the entry "Own motor settings" in the list field **Motor selection**.
- ▶ Click **From Motor catalog** to open the motor catalog and select a different motor.
  - ▶ [Read the motor data out of the controller](#) (66)
- ▶ Click **From controller** to accept the motor data set in the controller while being online in the »Engineer«. ▶ [Read the motor data out of the controller](#) (66)

#### Overview of motor data

Parameters	Information	Lenze setting	
		Value	Unit
<a href="#">C00006</a>	Motor control selection	Servo control with synchronous motor	
<a href="#">C00059</a>	Motor - number of pole pairs	-	
<a href="#">C00074</a>	Feedforward control of current controller	Deactivated	
<a href="#">C00075</a>	Current controller gain	28.66	V/A
<a href="#">C00076</a>	Current controller reset time	1.50	ms
<a href="#">C00077</a>	Field controller gain	165.84	A/Vs
<a href="#">C00078</a>	Field controller reset time	15.1	ms
<a href="#">C00079</a>	Motor - mutual inductance	-	mH
<a href="#">C00081</a>	Motor - rated power	1	kW
<a href="#">C00082</a>	Motor - rotor resistance	-	Ohm
<a href="#">C00083</a>	Motor - rotor time constant	-	MS
<a href="#">C00084</a>	Motor stator resistance	19.8000	Ohm
<a href="#">C00085</a>	Motor stator leakage induct.	30.500	mH
<a href="#">C00087</a>	Rated motor speed	4000	rpm
<a href="#">C00088</a>	Rated motor current	0.9	A
<a href="#">C00089</a>	Rated motor frequency	200	Hz
<a href="#">C00090</a>	Rated motor voltage	245	V
<a href="#">C00091</a>	Motor - cosine phi	1.00	
<a href="#">C00092</a>	Motor - magnetising current	-	A
<a href="#">C00128/1</a>	Therm. time constant coil	1.0	min
<a href="#">C00128/2</a>	Therm. time constant plates	5.0	min
<a href="#">C00186</a>	ENP: Identified motor type	-	
<a href="#">C00187</a>	ENP: Identified serial number	-	
<a href="#">C00188</a>	ENP: Status	-	
<a href="#">C00577</a>	Field weakening controller gain	0.000	Vs/V
<a href="#">C00578</a>	Field weakening controller reset time	2000.0	ms
<a href="#">C01190</a>	Motor thermal sensor	KTY83-110	
<a href="#">C01191/1</a>	Temperature for spec. characteristic	25	°C
<a href="#">C01191/2</a>	Temperature for spec. characteristic	150	°C
<a href="#">C01192/1</a>	Resistor for spec. characteristic	1000	Ohm
<a href="#">C01192/2</a>	Resistor for spec. characteristic	2225	Ohm

Highlighted in grey = display parameter



#### Note!

If the motor has been selected via the »Engineer« motor catalog or if the motor data have been adapted offline in the »Engineer«, all motor data must be transferred to the controller with an established online connection and stored with mains failure protection in the memory module ([C00002](#) = "11").

## 5.1.4 Accept/adapt route data

The "route data" summarises all parameters which result from the combination of motor and load. These characterise the transfer behaviour of the entire controlled system including the monitoring modes required.

- ▶ The route data depend on the application in which the controller and motor are used.
- ▶ The route data offered from the »Engineer« motor catalog or read out of the electronic nameplate (ENP) are compared with the currently set route data in a dialog box.
  - The route data in these dialog box can be selected, adapted and accepted individually.
  - They are both accepted in the controller and the »Engineer« project.

### Overview of route data

Parameters	Information	Lenze setting	
		Value	Unit
<a href="#">C00011</a>	Motor reference speed	3000	rpm
<a href="#">C00022</a>	Maximum current	0.00	A
<a href="#">C00070</a>	Speed controller gain	0.500	Nm/rpm
<a href="#">C00071</a>	Speed controller reset time	24.0	ms
<a href="#">C00072</a>	Speed controller D component	0.00	ms
<a href="#">C00254</a>	Phase controller gain	20.00	1/s
<a href="#">C00270/1</a>	Freq. current setpoint filter 1	200.0	Hz
<a href="#">C00270/2</a>	Freq. current setpoint filter 2	400.0	Hz
<a href="#">C00271/1</a>	Width current setp. filter 1	20.0	Hz
<a href="#">C00271/2</a>	Width current setp. filter 2	40.0	Hz
<a href="#">C00272/1</a>	Depth current setp. filter 1	0	db
<a href="#">C00272/2</a>	Depth current setp. filter 2	0	db
<a href="#">C00585</a>	Response to motor PTC overtemperature	Off	
<a href="#">C00596</a>	Threshold max. speed reached	6500	rpm

Highlighted in grey = display parameter



### Note!

If the route data have been adapted offline in the »Engineer«, all route data must be transferred to the controller with an established online connection and stored with mains failure protection in the memory module ([C00002](#) = "11").

## 5.1.5 Parameterise motor encoder



### Tip!

Detailed information on the encoder evaluation and on the use of a separate position encoder can be found in the following main chapter "[Encoder evaluation](#)".  
([108](#))

► The motor encoder can also be parameterised in the »Engineer« on the **Application parameter** tab in the dialog level *Overview*→*Motor*.

► The following table shows the required settings for different encoder types:

Encoder type:	Resolver Tamagawa	CDD50	ITD21	ITD22	SC570 SCM70	SRS50 SRM50	ECN1313 EQN1325	EQI1329
Motor type:	MCS MCA MDxKS MDXMA	MCA	MDFQA LMR	MDFQA LMR	MDxKS	MCS MCA	MCS MCA	MCS MCA
<a href="#">C00495</a> Motor encoder	0 Resolver	1 Encoder						
<a href="#">C00080</a> Resolver - pole pair number	1	-	-	-	-	-	-	-
<a href="#">C00422</a> Encoder - type	-	0 Incremental encoder (TTL signal)	1 Sin/cos encoder	2 Absolute value encoder (Hiperface)	3 Absolute value encoder (EnDat)			
<a href="#">C00420</a> Encoder - PPR	-	2048		512	1024	2048	32	
<a href="#">C00421</a> Encoder - voltage	-	5 V		8 V		5 V		



### Danger!

When using the encoder/resolver as motor encoder:

In case of an error as safe motor operation cannot be ensured anymore. Thus, the "Fault" response (Lenze setting) should be set permanently for the (open circuit) monitoring of the encoder/resolver!

- [C00580](#): Response to open circuit of encoder
- [C00586](#): Response to open circuit of resolver
- [C00601](#): Response to communication error of encoder

## 5.1.6 Set rotor displacement angle

**Note!**

Not required if a Lenze motor is operated on the controller!

For the control of permanent-magnet synchronous machines, the rotor angle – the angle between the motor phase U and the field axis of the rotor – must be known.

- ▶ For Lenze motors the rotor displacement angle for different feedback systems is already set correctly in [C00058/1...3](#).
- ▶ The device command "Set rotor displacement angle" serves to specify the rotor displacement angle for the current motor encoder activated in [C00495](#) for an external motor (see following instructions).

**Note!**

During the procedure of setting the rotor displacement angle, the machine must not be braked or blocked.

**How to set the rotor displacement angle for an external motor:**

1. If the controller is enabled, inhibit the controller, e.g. with the device command "Inhibit controller" ([C00002](#) = "41").
2. Execute device command "Set rotor displacement angle" with [C00002](#) = "51".

The procedure starts with controller enable, if

- a synchronous machine is selected,
- no other identification is active,
- no error (TRIP) has occurred, and
- no test mode is activated.

If one of the above conditions is not met, the procedure is cancelled and the corresponding controller command status is indicated under [C00003](#).

**Note:**

By means of controller inhibit the started procedure can be aborted any time without making a change in [C00058](#).

For detailed information about the procedure, please see the following section "Sequence".

**Tip!**

For controller enable all sources for controller inhibit must be reset. In [C00158](#) the sources for controller inhibit are displayed in a bit-coded manner.

The status of the controller command activated under [C00002](#) is indicated under [C00003](#).

#### Sequence

If all conditions are met, the motor is energised with a direct current corresponding to the lower of the following two values:

$$\sqrt{2} \cdot \text{Rated device current}$$

or

$$\sqrt{2} \cdot \frac{\text{Rated motor current}}{2}$$

- ▶ The rotor is aligned through the current flow. This is absolutely necessary for the procedure.
- ▶ To ensure that the torque-neutral axis is not accidentally energised and the rotor stops, a 45° current vector is (electrically) generated for 1 second and then (electrically) switched back to 0° (≡ phase U).
  - After this second, you could measure a direct current corresponding to the above-mentioned value in this motor phase.

The next steps of the procedure depend on the feedback system used:

- ▶ If an absolute value encoder with Hiperface or EnDat protocol is used, the encoder position is set to zero and the procedure is cancelled.
- ▶ If a resolver or an optical encoder without absolute track is used, the difference between the preselected current angle and the mechanical rotor angle is determined. After this, the current vector is (electrically) turned by another 22.5° and the difference between current angle and rotor angle is determined once again.
  - The procedure is repeated 16 times. This corresponds to one electrical revolution. The machine rotates by 360° (mech.)/pole pair number.
  - Take the average value of the 16 measurements to compensate for asymmetries.

#### After successful completion...

...the controller is inhibited automatically and the rotor displacement angle determined for the activated feedback system is set in the corresponding subcode of [C00058](#).

- ▶ For a permanent acceptance of the set rotor displacement angle, the parameter set must be saved ([C00002](#) = "11").
- ▶ The device command [C00002](#) = "42" serves to deactivate the controller inhibit automatically set by the procedure.

#### If an error occurs

If an error occurs during the procedure or the pulse inhibit gets active (e.g. due to short-time undervoltage), the procedure is terminated with controller inhibit without making a change in [C00058](#).

If the machine was braked or blocked during the procedure, this will be recognised at the end of the measurement and no change is made in [C00058](#).



## 5.1.7 Optimise the switching performance of the inverter

**Note!**

Not required if a Lenze motor is operated on the controller!

For an external motor with unknown motor parameters the optimisation of the inverter switching performance is necessary for the motor parameter setting described in the following chapter. ▶ [Set motor parameters](#) (75)

An inverter generates a pulse-width-modulated, three-phase voltage system. Due to the design of the inverter, current-dependent and chopper-frequency-dependent losses inside of the inverter falsify the output voltage. Since the output voltage is not measured, the losses must be compensated by a suitable feedforward control. This is compensated via an inverter error characteristic.

The inverter error characteristic depends, among other things, on the motor cable length and for a motor with unknown motor parameters it must be detected at least once individually with the device command "Detect inverter characteristic" so that a sinusoidal current is ensured for an automatic selection of the motor parameters.

**How to determine the inverter error characteristic:**

1. If the controller is enabled, inhibit the controller, e.g. with the device command "Inhibit controller" ([C00002](#) = "41").
2. Execute the device command "Determine inverter characteristic" with [C00002](#) = "71".

The procedure starts with controller enable, if

- no other identification is active,
- no error (TRIP) has occurred, and
- no test mode is activated.

If one of the above conditions is not met, the procedure is cancelled and the corresponding controller command status is indicated under [C00003](#).

**Note:**

By means of controller inhibit the started procedure can be aborted any time. Characteristic values already detected are not considered.

For detailed information about the procedure, please see the following section "Sequence".

**Tip!**

For controller enable all sources for controller inhibit must be reset. In [C00158](#) the sources for controller inhibit are displayed in a bit-coded manner.

The status of the controller command activated under [C00002](#) is indicated under [C00003](#).

#### Sequence

If all conditions are met, the motor is energised with a maximum direct current corresponding to the lower of the following two values:

$$\begin{aligned} & \sqrt{2} \cdot \text{Rated device current} \\ & \text{or} \\ & \sqrt{2} \cdot 1.8 \cdot \text{Rated motor current} \end{aligned}$$

- ▶ Ideally, the first value should be reached, the second value is to ensure that the load on the machine is not too high during the procedure.

During the procedure, the motor current rises up to the specified maximum value and falls back to "0" to repeat the cycle with a negative current sign.

- ▶ The maximum value is reached four times.
- ▶ The chopper frequency is set to 8 kHz, sine-wave modulation. After the procedure, it is reset to the original value.
  - If the chopper frequency should be changed later during operation, the characteristic will be adapted to the current chopper frequency.
- ▶ Presently, the characteristic is only used for the automatic selection of the motor parameters. The use for sensorless control methods is in preparation.

#### After successful completion...

...the controller is inhibited automatically and the detected characteristic is set in the controller.

- ▶ For a permanent acceptance of the characteristic, the parameter set must be saved ([C00002](#) = "11").
- ▶ The device command [C00002](#) = "42" serves to deactivate the controller inhibit automatically set by the procedure.



#### Tip!

The inverter error characteristic must only be detected again if the controller, motor, or motor cable have changed e.g. due to an exchange.

#### If an error occurs

If an error occurs during the procedure or the pulse inhibit gets active (e.g. due to short-time undervoltage), the procedure is terminated with controller inhibit and the detected characteristic is not considered.

## 5.1.8 Set motor parameters

**Note!**

Not required if a Lenze motor is operated on the controller!

To control an electrical machine, the motor parameters must be known.

- ▶ The motor parameters for Lenze motors are known and are already set accordingly by selecting them from the »Engineer« motor catalog or reading out the ENP.
- ▶ The device command "Set motor parameters" serves to set the motor parameters listed in the following table for an external motor automatically unless they are known:

Parameters	Information	ASM	SM
<a href="#">C00079</a>	Motor - magnetising inductance	<input checked="" type="checkbox"/>	
<a href="#">C00082</a>	Motor - rotor resistance	<input checked="" type="checkbox"/>	
<a href="#">C00084</a>	Motor stator resistance	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00085</a>	Motor stator leakage induct.	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00091</a>	Motor - cosine phi	<input checked="" type="checkbox"/>	
<a href="#">C00092</a>	Motor - magnetising current	<input checked="" type="checkbox"/>	

**Tip!**

The »Engineer« displays an equivalent circuit diagram with these motor parameters when you got to the **Application parameter** tab in the dialog level *Overview*→*Motor* and press the button **Other motor data...**

The representation of the equivalent circuit diagram depends on the motor control selected ([C00006](#)).

**Requirements**

- ▶ Before the automatic parameter determination is started, the switching performance of the inverter must have been optimised to ensure a sinusoidal current flow.
  - ▶ [Optimise the switching performance of the inverter](#) (📖 73)
- ▶ The motor parameters listed in the following table are excluded from the automatic determination and must be adapted to the motor used (see motor nameplate) before the determination.

Parameters	Information
<a href="#">C00081</a>	Motor - rated power
<a href="#">C00087</a>	Rated motor speed
<a href="#">C00088</a>	Rated motor current (The current amount for the procedure is derived from this specification)
<a href="#">C00089</a>	Rated motor frequency
<a href="#">C00090</a>	Rated motor voltage



## How to determine the motor parameters:

1. If the controller is enabled, inhibit the controller, e.g. with the device command "Inhibit controller" ([C00002](#) = "41").
2. Execute the controller command "Determine motor parameters" with [C00002](#) = "72".

The procedure starts with controller enable, if

- no other identification is active,
- no error has occurred, and
- no test mode is activated.

If one of the above conditions is not met, the procedure is cancelled and the corresponding controller command status is indicated under [C00003](#).

### Note:

By means of controller inhibit the started procedure can be aborted any time without changing the codes for the motor parameters.

For detailed information about the procedure, please see the following section "Sequence".



### Tip!

For controller enable all sources for controller inhibit must be reset. In [C00158](#) the sources for controller inhibit are displayed in a bit-coded manner.

The status of the controller command activated under [C00002](#) is indicated under [C00003](#).

## Sequence

If all conditions are met, the impedance of the controlled system is determined for approx. 30 different frequencies. These values are used to determine the electrical machine parameters by means of a mathematical procedure.

- ▶ Since the procedure starts with very low frequencies and always considers several complete periods, the whole process takes approx. 3 minutes.
- ▶ During the procedure, the motor is energised with a current, the r.m.s. value of which corresponds to the lower of the following two values:

$$\begin{aligned} & \text{Rated device current} \\ & \text{or} \\ & \frac{1}{2} \cdot \text{Rated motor current} \end{aligned}$$



### Note!

During the procedure, the motor should not rotate.

With synchronous machines, this cannot always be ensured. Although the current flow is produced in the torque-neutral axis, asymmetries in the machine lead to a rotation of the rotor.

- In such a case, the measurement would be useless and would have to be repeated.
- As a remedy, we recommend to use a holding brake.

With asynchronous machines, slight rotations might possibly occur. Their influence on the measurements is, however, not worth mentioning.

- In case of uncertainties, the measurement should be repeated several times to check if the results for the stator resistance, the leakage inductance of the stator and the rotor resistance differ widely. This should not be the case.
- The magnetising inductance and the  $\cos(\varphi)$  values are not that important for the diagnostics, because they are strongly non-linear.

## After successful completion...

...the controller is automatically inhibited and the selected motor data are set in the corresponding codes.

- ▶ For a permanent acceptance of the settings, the parameter set must be saved ([C00002](#) = "11").
- ▶ The device command [C00002](#) = "42" serves to deactivate the controller inhibit automatically set by the procedure.

## If an error occurs

If an error occurs during the procedure or the pulse inhibit gets active (e.g. due to short-time undervoltage), the procedure is terminated with controller inhibit without changing the codes for the motor parameters.

#### 5.1.9 Define currents and speed limits

##### Maximum current

In [C00022](#) the required maximum current must be set.

- ▶ In order that the motor does not start unintentionally without adjusting the route data, the maximum current in the Lenze setting is set to "0 A" in [C00022](#).

Moreover the motor limit current set in [C00620](#) must be checked and the error response required for the motor protection must be selected in [C00619](#).

##### Motor reference speed

In [C00011](#) the reference speed of the motor must be set.



##### Note!

When MCS motors are used check if the motor used exceeds the voltage limit in the required operating range up to maximum current/reference speed.

- If so, the reference speed must be reduced to a permissible value.
- Presently the controller does not support a field weakening control for synchronous motors so that an operation at the voltage limit causes an undefined behaviour.

On the part of the application it must be ensured that maximally 100 % of the reference speed set in [C00011](#) are required as speed setpoint.

##### Maximum system speed

Adapt the maximum system speed in [C00596](#) and select the error response required when this speed limit has been reached in [C00607](#).

## 5.1.10 Select switching frequency

The controller uses a pulse-width modulation to generate the controller output voltage. The chopper frequency is used to change the control factor of the pulse-width modulation.

- ▶ Since the control factor is determined by the current controller, the chopper frequency also limits the response of the current controller: the current controller updates the output voltage only once per switching period.
- ▶ Due to the limited response of the current controller, the current ripple and the torque ripple increase with decreasing chopper frequency.



### Note!

The maximum output frequency of the controller is limited to 1/8 of the switching frequency selected in [C00018](#)! (See the following table.)

Switching frequency ( <a href="#">C00018</a> ):	1 kHz	2 kHz	4 kHz	8 kHz	16 kHz
Maximum output frequency:	125 Hz	250 Hz	500 Hz	1 kHz	2 kHz
Motor - number of pole pairs:	Maximum synchronous motor speed [rpm]				
1	7500	15000	30000	60000	120000
2	3750	7500	15000	30000	60000
3	2500	5000	10000	20000	40000
4	1875	3750	7500	15000	30000
5	1500	3000	6000	12000	24000
6	1250	2500	5000	10000	20000

### Reduced switching losses through chopper frequency reduction

The advantage of a chopper frequency reduction are the reduced switching losses in the controller, which are monitored by means of an I x t evaluation.

- ▶ A reduced chopper frequency therefore enables a bigger current-time area at the output than it would be the case with a higher chopper frequency. However, depending on the process, you always have to make a compromise between the torque ripple and the output power.



### Tip!

The controller load (I x t) during the last 180 seconds is indicated under [C00064](#).

## Automatic chopper frequency reduction

Under [C00018](#), it is possible to select "variable" chopper frequencies for the controller. With this selection, the controller reduces the chopper frequency depending on the setpoint current.

- ▶ Depending on the current, the controller switches down to an assigned chopper frequency; the modulation mode remains unchanged.
- ▶ The switching thresholds are device-dependent (see 9400 Hardware Manual, chapter "Rated data").
- ▶ If instead of a variable switching frequency a fixed switching frequency has been selected in [C00018](#), no switching frequency changeover takes place. Due to the rotating field frequency range of 0...5 Hz only a lower continuous current and maximum currents can be applied (see 9400 Hardware Manual, chapter "Rated data").



With the same load profile, a deactivation due to an excessive controller load ( $I \times t$ ) is more likely with a fixed chopper frequency setting than with a variable setting.




## 5.1.11 Optimise current controller

In a test mode you can select current setpoint step-changes and optimise the parameter settings of the current controller (gain and reset time).



### How to optimise the current controller in the test mode:

1. If the controller is enabled, inhibit the controller, e.g. with the device command "Inhibit controller" ([C00002](#) = "41").
2. Activate the test mode for the current controller with [C00398](#) = "2".
3. Select the effective value of the current setpoint step change under [C00022](#).
  - The peak value of the measurable motor current will be 1.41 times higher.
4. Enable the controller for a short time and measure the step response of the motor current in the motor phases using the oscilloscope and clamp-on ammeters or record the field-oriented direct-axis current using the [Oscilloscope](#) function in the »Engineer«. ([416](#))
  - Motor control variable to be recorded:  
*current.dnDirectCurrentAct* (field-oriented direct-axis current)
5. Evaluate the step response:



6. Change the gain  $V_p$  under [C00075](#) and the reset time  $T_n$  under [C00076](#).
7. Repeat steps 4 ... 6 until the optimum step response of the motor brake is reached.
  - After optimisation, the current control time is typically 0.5 ... 1 ms.
  - If the adjustment results are not satisfactory, the decoupling network can be additionally activated via the setting [C00074](#) = "1". After this, repeat the steps 2 ... 6.
  - In case of MCS results may only be achieved with a current-dependent correction of the leakage inductance. For this purpose, it is required to use a motor with an electronic nameplate (ENP) or to set the saturation characteristic manually (see the following section).

8. After the optimisation has been completed with [C00398](#) = "0", deactivate the test mode for the current controller again.
9. Save parameter set ([C00002](#) = "11").

## 5.1.11.1 Correction of the leakage inductance via saturation characteristic

The current controller must be adjusted to the electrical characteristics of the motor – stator resistance and stator leakage inductance:


$$\text{Gain } V_p = \frac{\text{Leakage inductance of stator}}{240 \mu\text{s}}$$

$$\text{Reset time } T_n = \frac{\text{Stator leakage inductance}}{\text{Stator resistance}}$$

In case of modern motors, however, the stator leakage inductance changes ([C00085](#)) as a function of the magnitude of current so that each current value requires a new current controller setting.

When the motor is operated with very low and very high currents (e.g. in *Pick and place* applications), it is not always possible to achieve a satisfactory current controller setting for all operating points. For this purpose, the correction of the leakage inductance and current controller parameters is possible via a saturation characteristic that can be set in [C02853](#) (17 base points).

The following picture shows a typical saturation characteristic of an MCS motor:



[5-1] Saturation characteristic: Inductance referring to the inductance for rated current

- ▶ By optimising different current setpoints such a characteristic can be detected per "trial" and set in [C02853](#).
- ▶ The correction by means of this saturation characteristic can be switched off or on via [C02859](#).




### Note!

The saturation characteristic is not only used for the correction of the current controller but also influences the current controller feedforward control ([C00074](#)).

### Distribution of the grid points

- ▶ The saturation characteristic is displayed by 17 points which are distributed linearly on the X axis.
- ▶ The point 17 represents 100 % of the maximum motor current in the process ([C02855](#)).



[5-2] Saturation characteristic: Distribution of the grid points



### Tip!

The following chapter provides an example for determining the saturation characteristic. ▶ [Example for determining the saturation characteristic](#) (84)


## 5.1.11.2 Example for determining the saturation characteristic

### Given values:

- ▶ Rated motor current: 5 A
- ▶ Maximum motor current: 20 A
- ▶ Maximum process current: 15 A (must be set later in [C00022](#))

### Procedure:

1. Deactivate correction ([C02859](#) = "off").
2. Set the maximum current up to which the motor is to be operated in the process in [C02855](#) (in this example "15 A").
  - The value set in [C02855](#) must be higher or the same as [C00022](#).
3. Adjust the current controller with different current setpoints and note the corresponding settings for Vp and Tn.
  - The procedure for the adjustment is described in the chapter "[Optimise current controller](#)".
  - The current setpoints that are to be set for the prevailing adjustment in [C00022](#) result from the scaling of the maximum process current to the X axis of the saturation characteristic.
  - Which points are required to display the saturation characteristic with a sufficient quality, varies from motor to motor and must therefore be detected individually.
  - For this example currents have been selected which are situated on the grid points 5, 9, 13 and 15 a measurement has been carried out at rated motor current:




[5-3] Saturation characteristic: Distribution of the grid points

Specifications for adjustment			Measured values	
Grid point	Scaling	Setting C00022	Vp [V/A]	Tn [ms]
5	$0.25 * 15 \text{ A} =$	3.75 A	13	6.5
9	$0.5 * 15 \text{ A} =$	7.5 A	8	4
13	$0.75 * 15 \text{ A} =$	11.25 A	5	2.5
15	$0.875 * 15 \text{ A} =$	12.38 A	4	2
17	$1.0 * 15 \text{ A} =$	15 A	3	1.7
Rated motor current =		5 A	10	5

#### 4. Creating a characteristic based on the values calculated for Vp.

- Here, the values which have not been adjusted, must be determined by interpolation between two values.
- **Note:** In this example it is assumed that the inductance does not change considerably below 3.75 A. For this reason, the same Vp value resulting from the measurement with a motor current of 3.75 A has been used for all grid points below 3.75 A.




[5-4] Determined saturation characteristic

#### 5. Set the gain Vp in [C00075](#) and reset time Tn in [C00076](#) which were calculated during the adjustment with the rated motor current (in this example "5 A"):


- Set [C00075](#) = "10 V/A".
- Set [C00076](#) = "5 ms".

#### 6. Scale the Vp values on the Y axis of the characteristic to the 100 % Vp setting in [C00075](#):



[5-5] Scaling of the determined saturation characteristic to the "100 %" setting in C00075

7. Enter the percentage Vp values situated on the grid points in [C02853/1...17](#):



[5-6] Grid point values of the determined saturation characteristic

Grid point	Setting	Grid point	Setting
1	<a href="#">C02583/1</a> = 130 %	10	<a href="#">C02583/10</a> = 72.5 %
2	<a href="#">C02583/2</a> = 130 %	11	<a href="#">C02583/11</a> = 65 %
3	<a href="#">C02583/3</a> = 130 %	12	<a href="#">C02583/12</a> = 57.5 %
4	<a href="#">C02583/4</a> = 130 %	13	<a href="#">C02583/13</a> = 50 %
5	<a href="#">C02583/5</a> = 130 %	14	<a href="#">C02583/14</a> = 45 %
6	<a href="#">C02583/6</a> = 107 %	15	<a href="#">C02583/15</a> = 40 %
7	<a href="#">C02583/7</a> = 95 %	16	<a href="#">C02583/16</a> = 35 %
8	<a href="#">C02583/8</a> = 87.5 %	17	<a href="#">C02583/17</a> = 30 %
9	<a href="#">C02583/9</a> = 80 %		

8. Enter the maximum process current ("15 A") in [C00022](#).

9. Switch on the correction ([C02859](#) = "on").

- When the correction of the stator leakage inductance is switched on, the same current characteristic is to occur irrespective of the current magnitude.
- Since the current controller gain is corrected actively, the step responses may differ slightly compared to the previous measurements. In this case [C00075](#) and [C00076](#) must be optimised one last time.

10. Save parameter set ([C00002](#) = "11").

## 5.2 Extended commissioning

After the initial commissioning of the motor, the required technology application can be selected in the »Engineer« and loaded in the controller.

- ▶ Further information on this can be found in chapter [Technology applications \(TAs\)](#).  
([📖 233](#))
- ▶ During operation (with setpoint selection) further steps can be carried out to optimise the motor control.
- ▶ Detailed information on the individual steps can be found in the following subchapters:

Worksteps	
1.	<a href="#">Optimise speed controller.</a> ( <a href="#">📖 88</a> ) <ul style="list-style-type: none"> <li>• Via running a typical speed profile and recording the ramp response of the speed controller with the oscilloscope.</li> </ul>
2.	If the speed controller optimisation did not achieve the intended result: <a href="#">Set current setpoint filter.</a> ( <a href="#">📖 90</a> ) <ul style="list-style-type: none"> <li>• In order to suppress or damp (mechanical) resonant frequencies, two current setpoint filters are integrated in the speed control loop of the controller which are switched off in the default setting but can be parameterised accordingly, if required.</li> </ul> Then readjust the speed controller: <a href="#">Optimise speed controller.</a> ( <a href="#">📖 88</a> )
3.	<a href="#">Optimise phase controller.</a> ( <a href="#">📖 92</a> ) <ul style="list-style-type: none"> <li>• Via running a typical speed profile and recording the ramp response of the phase controller with the oscilloscope.</li> </ul>
4.	<a href="#">Optimise the response to setpoint changes by means of the torque feedforward control.</a> ( <a href="#">📖 93</a> ) <ul style="list-style-type: none"> <li>• Via running a typical speed profile and recording the inputs and outputs of the speed controller with the oscilloscope.</li> </ul>
5.	Save »Engineer« project.



### Tip!

To run a typical speed profile for optimising the motor control, you can also use the basic function "manual jog" with suitably adapted manual jog parameters.

- ▶ [Manual jog](#) ([📖 156](#))

## 5.2.1 Optimise speed controller

The speed controller has been designed as a PID controller.

### Gain, reset time & differential gain setting

The proportional gain  $V_p$  is selected under [C00070](#):

1. Select the speed setpoint.
2. Increase C00070 until the drive becomes unstable (observe motor noises).
3. Reduce C00070, until the drive becomes stable again.
4. Reduce C00070 to approx. half the value.

### Reset time setting

The reset time is selected under [C00071](#):

1. Reduce C00071 until the drive becomes unstable (observe motor noises).
2. Increase C00071 until the drive becomes stable again.
3. Increase C00071 to approx. double the value.

### Differential gain setting

The differential gain  $T_d$  is selected under [C00072](#):

- ▶ Increase C00072 during operation until an optimum control behaviour is reached.

### Adaptation of the speed controller gain

Via the input  $MI\_dnSpeedCtrlAdapt\_n$  of the system block [LS MotorInterface](#) the proportional gain  $V_p$  can be changed dynamically during operation:

$$V_p = MI\_dnSpeedCtrlAdapt\_n [\%] \cdot C00070$$

- ▶ If the input  $MI\_dnSpeedCtrlAdapt\_n$  has not been assigned:

$$V_p = 100 \% \cdot C00070 = C00070$$



## Using the ramp response for setting the speed controller

When operation of the mechanics at the stability limit is not possible, the ramp response can be used for setting the speed controller. The proceeding is similar to optimising the current controller.



### Stop!


If the controller parameters are preset unfavourably, the control can tend to heavy overshoots up to instability!

- Following and speed errors can adopt very high values.
- If the mechanics is very sensitive, the corresponding monitoring functions must be activated.



### How to optimise the speed controller setting by means of the ramp response:

1. Run a typical speed profile and record the ramp response of the speed with the [Oscilloscope](#). (416)
  - Motor control variables to be recorded:  
*Speed.dnSpeedSetpoint* (speed setpoint)  
*Speed.dnActualMotorSpeed* (actual speed value)
2. Evaluate the ramp response:




- Solid line = ramp response (actual speed value)
- Dash line = Speed setpoint

3. Change the gain  $V_p$  under [C00070](#) and the reset time  $T_n$  under [C00071](#).
4. Repeat steps 1 ... 3 until the optimum ramp response is reached.
5. Save parameter set ([C00002](#) = "11").

## 5.2.2 Set current setpoint filter

Due to the high dynamic performance or limit frequency of the closed current control loop mechanical natural frequencies can be activated which may lead to an unstable speed control loop.

In order to suppress or damp these resonant frequencies, two current setpoint filters are integrated in the speed control loop of the controller which are switched off in the default setting but can be parameterised accordingly, if required.



[5-7] Optional current setpoint filters (filter cascade) in the speed control loop

Since the frequency response of the speed controlled system is only rarely known to such an extent that the current setpoint filters can be adjusted to the controlled system in the run-up, the following example describes how to set current the current setpoint filters.



### How to set the current setpoint filters:

1. Adjust the current control loop.
2. In [C00071](#) adjust the reset time of the speed controller to the filter time constant of the speed filter ([C00497](#)) and the equivalent time constant of the current control loop:  $C00071 = 16 * (C00497 + 200 \mu s)$
3. Slowly increase the proportional gain in [C00070](#), until the speed control loop starts to become unstable (noticed acoustically or by measuring the motor current).
4. Measure the oscillation frequency using an oscilloscope (observe current or speed).
5. Set the measured oscillation frequency in [C00270/1](#) as filter frequency.
6. Set "50%" of the filter frequency in [C00271/1](#) as filter width.
  - Example: Filter frequency = 200 Hz → filter width = 100 Hz.
7. Set "40 dB" in [C00272/1](#) as filter depth.
  - If the filter depth is set to "0 dB" (default setting), the filter is not active.
8. Continue to increase the proportional gain in [C00070](#) until the speed control loop starts to become instable again.
  - If the oscillation frequency has changed now, readjust the filter frequency by trimming. The use of a second filter is ineffective here.
  - If the oscillation frequency remains the same, readjust the filter depth and/or the filter width by trimming (the first reduces the amplitude, the second lets the phase rotates faster).
  - Repeat step 8 until the desired behaviour or the limit of a sensible speed controller gain has been reached.
9. Save parameter set ([C00002](#) = "11").



### Note!

Readjust the speed controller after setting the current setpoint filter.

▶ [Optimise speed controller](#). (88)

## 5.2.3 Optimise phase controller




### How to optimise the phase controller setting by means of the ramp response:

1. Run a typical speed profile and record the ramp response of the phase controller with the [Oscilloscope](#). (416)
  - Motor control variables to be recorded:
    - Speed.dnSpeedSetpoint* (speed setpoint)
    - Speed.dnActualMotorSpeed* (actual speed value)
    - Speed.dnOutputPosCtrl* (phase controller output)
    - Position.dnEncounteringError* (following error)
2. Adjust the gain  $V_p$  of the phase controller under [C00254](#) and repeat oscilloscope recording until the intended following error behaviour is reached and the motor runs sufficiently smoothly during the constant travel phase.
3. Save parameter set ([C00002](#) = "11").

## 5.2.4 Optimise the response to setpoint changes by means of the torque feedforward control

Setting the load moment of inertia under [C00273/2](#) does not always provide the optimum torque feedforward control. Depending on the application, an adaptation of the setting under [C00273/2](#) may be necessary to optimise the response to position/speed control setpoint changes.



[5-8] Typical signal characteristics for different settings of the load moment of inertia

[C00273/2](#) can be used to compensate for effects in addition to the moment of inertia which are detected by the speed controller in the closed speed control loop (e.g. friction torque).

Below you will find a description of a procedure for optimising the feedforward control behaviour starting from the system's moment of inertia.



## How to optimise the torque feedforward control:


1. Run a typical speed profile and record the inputs and outputs of the speed controller with the [Oscilloscope](#). (416)
  - Motor control variables to be recorded:
    - Speed.dnSpeedSetpoint* (speed setpoint)
    - Speed.dnActualMotorSpeed* (actual speed value)
    - Torque.dnOutputSpeedCtrl* (speed controller output)
    - Torque.dnTotalTorqueAdd* (torque feedforward control)
  - Application variable to be recorded (if available):
    - L\_LdMonitFollowError1.dnFollowErrorIn\_p* (following error)

It is essential for optimising the response to setpoint changes to monitor the speed controller output (*Torque.dnOutputSpeedCtrl*) and the torque feedforward control (*Torque.dnTotalTorqueAdd*). The effect of the feedforward control can also be observed in the following error.

2. Select the signal source required for the torque setpoint (feedforward control path) under [C00276](#).
3. Estimate the mass inertia of the load and set it under [C00273/2](#).
4. Repeat the oscilloscope recording (see step 1).

Now the oscillogram should show that part of the required torque is generated by the feedforward control (*Torque.dnTotalTorqueAdd*) and the speed controller output signal (*Torque.dnOutputSpeedCtrl*) should be correspondingly smaller. The resulting following error decreases.
5. Change the setting under [C00273/2](#) and repeat the oscilloscope recording until the intended response to setpoint changes is reached.
  - The optimisation could aim at the speed controller being completely relieved (see signal characteristics in Fig. [\[5-8\]](#)).
6. Save parameter set ([C00002](#) = "11").

## 5.3 Signal flow




[5-9] Signal flow - motor interface

- See also:
- ▶ [Signal flow - encoder evaluation](#) (109)
  - ▶ [Signal flow - speed follower](#) (191)
  - ▶ [Signal flow - torque follower](#) (196)
  - ▶ [Signal flow - position follower](#) (184)

# 9400 HighLine | Parameter setting & configuration

## Motor interface

### Signal flow



[5-10] Signal flow of motor interface (monitoring)

### Internal variables of the motor control (oscilloscope signals)

- The red numbers specified in the signal flow represent internal variables of the motor control, which can be recorded with the [Oscilloscope](#) for diagnostic and documentation purposes. (416)

No.	Variable or the motor control	Meaning
(1)	Torque.dnInputNotchFilter1	Torque setpoint at the band-stop filter input 1
(2)	Torque.dnInputNotchFilter2	Torque setpoint at the band-stop filter input 2
(3)	Torque.dnFilteredTorqueSetpoint	Filtered torque setpoint
(4)	-	-
(5)	-	-
(6)	Current.dnQuadratureCurrentSet	Q current setpoint
(7)	Current.dnActualQuadratureCurrent	Actual Q-current
(8)	Current.dnActualDirectCurrent	Actual D current
(9)	Current.dnDirectCurrentSet	D current setpoint
(10)	Voltage.dnQuadratureVoltage	Q voltage
(11)	Voltage.dnDirectVoltage	D voltage
(12)	Common.dnActualFlux	Actual flux value
(13)	Common.dnFluxSet	Flux setpoint
(14)	Voltage.dnActualMotorVoltage	Current motor voltage
(15)	Voltage.dnActualDCBusVoltage	Actual DC-bus voltage
(16)	Current.dnActualCurrentPhaseU	Actual motor current (phase U)
(17)	Current.dnActualCurrentPhaseV	Actual motor current (phase V)
(18)	Current.dnActualCurrentPhaseW	Actual motor current (phase W)



## 5.4 Parameter setting

Short overview of the other parameters for the motor interface:

Parameters	Information
<a href="#">C00050/1</a>	Speed setpoint 1
<a href="#">C00050/2</a>	Speed setpoint 2
<a href="#">C00051</a>	Actual speed
<a href="#">C00052</a>	Motor voltage
<a href="#">C00054</a>	Motor current
<a href="#">C00055/1</a>	Phase current - phase zero system
<a href="#">C00055/2</a>	Phase current - phase U
<a href="#">C00055/3</a>	Phase current - phase V
<a href="#">C00055/4</a>	Phase current - phase W
<a href="#">C00056</a>	Torque setpoint
<a href="#">C00057/1</a>	Maximum torque
<a href="#">C00057/2</a>	Torque at maximum current
<a href="#">C00059</a>	Motor - number of pole pairs
<a href="#">C00060</a>	Rotor position
<a href="#">C00063</a>	Motor temperature
<a href="#">C00066</a>	Thermal motor load ( $I^2 \cdot t$ )
<a href="#">C00120</a>	Motor overload protection ( $I^2 \cdot t$ )
<a href="#">C00121</a>	Warning threshold - motor temperature
<a href="#">C00127</a>	Warning threshold - motor overload
<a href="#">C00583</a>	Response to motor KTY overtemperature
<a href="#">C00584</a>	Response to motor temperature > C00121
<a href="#">C00585</a>	Response to motor PTC overtemperature
<a href="#">C00606</a>	Resp. to motor overload
<a href="#">C00909/1</a>	Upper speed limit value
<a href="#">C00909/2</a>	Lower speed limit value
<a href="#">C02527</a>	Motor mounting direction
<a href="#">C02550/1</a>	Position setpoint interpolation
<a href="#">C02550/2</a>	Speed setpoint interpolation
<a href="#">C02550/3</a>	Torque setpoint interpolation
<a href="#">C02553</a>	Position controller gain
<a href="#">C02554</a>	Position controller reset time
<a href="#">C02555</a>	Position controller D component
<a href="#">C02556</a>	Pos. contr. limitation
<a href="#">C02557</a>	Motor position controller output
<a href="#">C02558</a>	Position controller output
<a href="#">C02559/1</a>	Upper int. torque limit
<a href="#">C02559/2</a>	Lower int. torque limit
<a href="#">C02560</a>	Messages motor interface
<a href="#">C02567</a>	Control mode

Highlighted in grey = display parameter

See also: [▶ Display/edit motor data in the »Engineer« \(📖 67\)](#)  
[▶ Accept/adapt route data \(📖 69\)](#)

## 5.4.1 Motor monitoring (I<sup>2</sup>xt)

The "9400 Servo Drives" are provided with an extended, sensorless thermal I<sup>2</sup>xt motor monitoring which is based on a mathematical model that calculates a thermal motor utilisation from the detected motor currents.

- ▶ The calculation considers the speed dependency of the torque (difference between standstill torque and rated torque).
- ▶ [C00066](#) indicates the calculated motor utilisation in [%].
- ▶ If the motor exceeds the advance warning threshold set in [C00127](#), the error message "I<sup>2</sup>t motor overload OC8" is output and the reaction set in [C00606](#) (default setting: "Warning") is activated.
- ▶ If the switch-off threshold set in [C00120](#) is exceeded, the error message "I<sup>2</sup>t motor overload OC6" is output and the reaction "Fault" is activated.



### Stop!

The I<sup>2</sup>xt motor monitoring is no full motor protection!


Since the motor utilisation calculated in the thermal model gets lost after mains switching, the following operating states cannot be determined correctly:

- Restarting (after mains switching) of a motor that is already very heated.
- Change of the cooling conditions (e.g. cooling air flow interrupted or too warm).

A full motor protection requires additional measures as e.g. the evaluation of temperature sensors that are situated directly in the winding of thermal contacts.

## Structure of the I<sup>2</sup>xt monitoring

The introduction of a two-component model with two time constants (one for the winding and the other for the housing/steel plates) serves to display the thermal behaviour of the motor up to 500% of the rated current:



[5-11] Structure of the motor monitoring

Parameters		Setting
$I_{act\ motor}$	Current motor current	-
$I_{perm\ motor\ (n)}$	Permissible motor current (speed-dependent)	-
$\tau_1$	Therm. time constant coil	<a href="#">C00128/1</a>
$k_1$	Percentage of the winding in the final temperature	<a href="#">C01195</a>
$\tau_2$	Therm. time constant plates	<a href="#">C00128/2</a>
$k_2$	Percentage of the steel plates in the final temperature	100 % - <a href="#">C01195</a>

## Executing the calculation with only one time constant

With the setting [C01195](#) = "0 %" the time constant for the winding is not considered and the thermal model is only calculated with the time constant set for the housing/steel plates.

- ▶ The setting [C01195](#) = "0 %" is e.g. sensible if not both time constants are known.
- ▶ The calculation simplified due to this setting corresponds to the calculation in the previous Lenze devices (e.g. servo inverter 9300 or ECS).

## Speed-dependent evaluation of the motor current

By selecting a characteristic in [C01196/1...8](#) the permissible motor current is evaluated depending on speed for calculating the thermal motor utilisation.

Parameters	Characteristic point	
<a href="#">C01196/1</a>	$n_1/n_n$	Speed = "0" (standstill)
<a href="#">C01196/2</a>	$I_1/I_n$	Permissible motor current at standstill
<a href="#">C01196/3</a>	$n_2/n_n$	Speed from which the torque must be reduced with self-ventilated motors. <ul style="list-style-type: none"><li>• Below this speed the cooling air flow of the integral fan is not sufficient anymore.</li></ul>
<a href="#">C01196/4</a>	$I_2/I_n$	Permissible motor current at speed $n_2$ (torque reduction)
<a href="#">C01196/5</a>	$n_3/n_n$	Rated speed
<a href="#">C01196/6</a>	$I_3/I_n$	Permissible motor current at rated speed
<a href="#">C01196/7</a>	$n_4/n_n$	Speed above the rated speed (in the field weakening in case of asynchronous motors)
<a href="#">C01196/8</a>	$I_4/I_n$	Permissible motor current at speed $n_4$ (field weakening)

- ▶ The speed-dependent evaluation can be more or less switched off by setting [C01196/1...8](#) to "100 %" each. The calculation simplified due to this setting corresponds to the calculation in previous devices (e.g. servo inverter 9300 or ECS).



### Note!

Self-ventilated standard motors are protected insufficiently by setting [C01196/1...8](#) to "100 %" each at low speeds.

Servo motors, however, do not have a point from which the torque must be reduced due to a too low speed.


- When setting the characteristic in [C01196/1...8](#) this point must not be ignored. Hence, point 2 is to be set ideally to point 1 or point 3.

## 5.4.1.1 Example for entry of the characteristic for asynchronous servo motor

Motor type: MDFMARS 090-32

### Data from the catalog:

- ▶ Rated speed  $n_N$ : 1410 rpm → Setting in [C00087](#)
- ▶ Rated current I: 6.1 A → Setting in [C00088](#)
- ▶ Rated torque  $M_N$ : 10.2 Nm
- ▶ Characteristic of maximum torques (50 Hz, star connection):



[5-12] Torque/speed characteristic for motor type MDFMARS 090-32 from catalog



### Note!

Currently relative current values are still expected for the specification of the grid points in subcodes 2, 4, 6, 8 of [C01196](#). This example, however, already uses relative torque values the entry of which shall be possible at a later date.


Parameters	Setting	Information
<a href="#">C00128/1</a>	1.0 min	Thermal time constant - winding • Is unknown and is therefore deactivated by setting <a href="#">C01195</a> = "0 %".
<a href="#">C00128/2</a>	5.0 min	Thermal time constant - steel plates/housing
<a href="#">C01195</a>	0 %	Percentage of the winding in the final temperature.
<a href="#">C01196/1</a>	0 %	Speed = "0" (standstill)
<a href="#">C01196/2</a>	Permissible motor torque at standstill	
Self-ventilated:	60 %	= 6.1 Nm / 10.2 Nm * 100 %
Forced ventilated:	100 %	= 10.2 Nm / 10.2 Nm * 100 %
<a href="#">C01196/3</a>	Speed $n_2$ , from which the torque must be reduced with self-ventilated motors.	
Self-ventilated:	43 %	= 600 rpm / 1410 rpm * 100 %
Forced ventilated:	0 %	No torque reduction required.
<a href="#">C01196/4</a>	100 %	Permissible motor torque at speed $n_2$ (torque reduction)
<a href="#">C01196/5</a>	100 %	Rated speed ( $\equiv$ 1410 rpm)
<a href="#">C01196/6</a>	100 %	Permissible motor torque at rated speed ( $\equiv$ 10.2 Nm)
<a href="#">C01196/7</a>	213 %	Speed above the rated speed (in the field weakening in case of asynchronous motors) = 3000 rpm / 1410 rpm * 100 %
<a href="#">C01196/8</a>	44 %	Permissible motor torque at speed $n_4$ (field weakening) = 4.5 Nm / 10.2 Nm * 100 %

## 5.4.1.2 Example for entry of the characteristic for synchronous servo motor

Motor type: MCS 06C60

### Data from the catalog:

- ▶ Rated speed  $n_N$ : 6000 rpm → Setting in [C00087](#)
- ▶ Rated current I: 2.4 A → Setting in [C00088](#)
- ▶ Rated torque  $M_N$ : 0.5 Nm (in S1 operation: 0.55 Nm)
- ▶ Characteristic - maximum torque:



[5-13] Torque/speed characteristic for motor type MCS 06C60 from the catalog



### Note!


Currently relative current values are still expected for the specification of the grid points in subcodes 2, 4, 6, 8 of [C01196](#). This example, however, already uses relative torque values the entry of which shall be possible at a later date.

Parameters	Setting	Information
<a href="#">C00128/1</a>	1.0 min	Thermal time constant - winding
<a href="#">C00128/2</a>	14.2 min	Thermal time constant - steel plates/housing
<a href="#">C01195</a>	27 %	Percentage of the winding in the final temperature. (Only the steel plate percentage is known.)
<a href="#">C01196/1</a>	0 %	Speed = "0" (standstill)
<a href="#">C01196/2</a>	160 %	Permissible motor torque at standstill = 0.8 Nm / 0.5 Nm * 100 %
<a href="#">C01196/3</a>	0 %	Speed $n_2$ , from which the torque must be reduced with self-ventilated motors.
<a href="#">C01196/4</a>	160 %	Permissible motor torque at speed $n_2$ (torque reduction)
<a href="#">C01196/5</a>	100 %	Rated speed ( $\approx$ 6000 rpm)
<a href="#">C01196/6</a>	100 %	Permissible motor torque at rated speed ( $\approx$ 0.5 Nm)
<a href="#">C01196/7</a>	100 %	Speed above rated speed
<a href="#">C01196/8</a>	100 %	Permissible motor torque at speed $n_4$ (field weakening)

### 5.4.2 Special characteristic for motor temperature sensor

If required you can select and activate a special characteristic for the motor temperature sensor.

- ▶ The special characteristic is selected with two grid points which are to be set in [C01191](#) and [C01192](#). Both grid points define a line which is extrapolated to the right and to the left.
- ▶ The special characteristic is activated by setting [C01190](#) = "1".
- ▶ In the Lenze setting the special characteristic is defined as follows:



- ▶ Grid point 1
  - [C01191/1](#) = 25°C
  - [C01192/1](#) = 1000 Ω
- ▶ Grid point 2
  - [C01191/2](#) = 150°C
  - [C01192/2](#) = 2225 Ω

[5-14] Lenze setting of the special characteristic



#### Note!

By selecting a motor from the motor catalog the parameters [C01190](#), [C01191](#) and [C01192](#) are overwritten!

### 5.4.3 Motor temperature monitoring

If the winding temperature detected by the motor temperature sensor exceeds the limit value set in [C00121](#), the reaction set in [C00584](#) is activated as advance warning.

- ▶ In the Lenze setting the reaction "Warning" occurs if the winding temperature exceeds 120 °C.
- ▶ As soon as the fixed limit value of 150 °C is exceeded, the reaction set in [C00583](#) is activated (default setting: "Fault").
- ▶ If an open circuit is detected in the motor temperature sensor, the reaction set in [C00594](#) (default setting: "Fault") is activated.



#### Note!


By setting [C00583](#) = "0" the monitoring response and the temperature correction is switched off within the motor control (identification and parameter correction)

This setting is e.g. sensible if no realisable winding temperature signal is available.

#### 5.5 System block "LS\_MotorInterface"

The system block **LS\_MotorInterface** displays the interface to the driving machine in the function block editor, which consists of phase controller, speed controller and motor control.

- ▶ The interface contains all control functions which are not made available via other basic drive functions.
- ▶ All input and output signals directly refer to the motor.



#### Inputs

Input <small>DIS code   Data type</small>	Information/possible settings
MI_dnPosCtrlAdaptLoad_n <small>C02568/1   DINT</small>	Dynamic change of the proportional gain $V_p$ of the position controller ▶ <a href="#">Signal flow - position follower (184)</a>
MI_bReserved <small>BOOL</small>	Reserved input for future extensions
MI_dnPosCtrlAdaptMotor_n <small>C02568/2   DINT</small>	Dynamic change of the proportional gain $V_p$ of the phase controller ▶ <a href="#">Signal flow - position follower (184)</a>
MI_dnSpeedCtrlAdapt_n <small>C02568/3   DINT</small>	Dynamic change of the proportional gain $V_p$ of the speed controller ▶ <a href="#">Signal flow - speed follower (191)</a> ▶ <a href="#">Signal flow - torque follower (196)</a>



Input <small>DIS code   Data type</small>	Information/possible settings		
MI_- bResetSpeedCtrlIntegrator <small>C02569/2   BOOL</small>	Reset integral action component in the speed controller <a href="#">▶ Signal flow - speed follower (□ 191)</a> <table border="1"> <tr> <td>TRUE</td> <td>Integral action component is reset to "0".</td> </tr> </table>	TRUE	Integral action component is reset to "0".
TRUE	Integral action component is reset to "0".		
MI_dnTorqueHighLimit_n <small>C02568/4   DINT</small> MI_dnTorqueLowLimit_n <small>C02568/5   DINT</small>	Upper/lower bipolar limit value for correcting variable of the speed controller and total torque setpoint <ul style="list-style-type: none"> <li>Via these both inputs you can select an external torque limitation. <ul style="list-style-type: none"> <li>–If the motor torque reaches the selected limits, the drive can no longer follow the speed setpoint!</li> <li>–If the torque limitation is active, the output <i>MI_bTorqueSetpointLimited</i> is set to TRUE.</li> </ul> </li> <li>100 % ≙ <a href="#">C00057/2</a></li> <li>When both values overlap, the upper limit value has priority.</li> <li>The motor mounting position (<a href="#">C02527</a>) defines the assignment to the limitation inputs of the motor control.</li> <li>The internally effective torque limit values are displayed in <a href="#">C02559/1...2</a>.  <a href="#">▶ Signal flow - motor interface (□ 95)</a></li> </ul>		
MI_dnReserved <small>DINT</small>	Reserved input for future extensions		
MI_dnFluxSetpoint_n <small>C02568/7   DINT</small>	Setpoint for the field controller		

## Outputs

Output <small>DIS code   Data type</small>	Value/meaning										
MI_dwControlMode <small>DWORD</small>	Active control structure of the motor control <ul style="list-style-type: none"> <li>Displayed value is bit-coded:</li> </ul> <table border="1"> <tr> <td>Bit 1</td> <td>Position control without feedback, external following error calculation</td> </tr> <tr> <td>Bit 2</td> <td>Position control with encoder on the motor side</td> </tr> <tr> <td>Bit 3</td> <td>Position control with encoder on the load side</td> </tr> <tr> <td>Bit 4</td> <td>Speed control</td> </tr> <tr> <td>Bit 5</td> <td>Torque control</td> </tr> </table>	Bit 1	Position control without feedback, external following error calculation	Bit 2	Position control with encoder on the motor side	Bit 3	Position control with encoder on the load side	Bit 4	Speed control	Bit 5	Torque control
Bit 1	Position control without feedback, external following error calculation										
Bit 2	Position control with encoder on the motor side										
Bit 3	Position control with encoder on the load side										
Bit 4	Speed control										
Bit 5	Torque control										
MI_- bMotorOrientationInverse <small>BOOL</small>	Parameterised motor mounting position <table border="1"> <tr> <td>FALSE</td> <td>Motor mounting position in the same direction, setpoints are not defined.</td> </tr> <tr> <td>TRUE</td> <td>Motor mounting position in the opposite direction, setpoints are reversed.</td> </tr> </table>	FALSE	Motor mounting position in the same direction, setpoints are not defined.	TRUE	Motor mounting position in the opposite direction, setpoints are reversed.						
FALSE	Motor mounting position in the same direction, setpoints are not defined.										
TRUE	Motor mounting position in the opposite direction, setpoints are reversed.										
MI_dwReferenceSpeed <small>DWORD</small>	Parameterised motor reference speed ( <a href="#">C00011</a> ) in [rpm]										
MI_dwReferenceTorque <small>DWORD</small>	Reachable motor torque with $I_{\max\_device}$ ( <a href="#">C00022</a> ) in [mNm] <ul style="list-style-type: none"> <li>1000 mNm ≙ 1 Nm</li> <li>Display in <a href="#">C00782</a> in [Nm]</li> </ul>										
MI_bLimitationActive <small>C02569/3   BOOL</small>	Status signal "Internal limitation active" <ul style="list-style-type: none"> <li>Group signal for all limitation messages.</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>One of the internal limitations is active.</td> </tr> </table>	TRUE	One of the internal limitations is active.								
TRUE	One of the internal limitations is active.										
MI_bPosCtrlLimited <small>C02569/4   BOOL</small>	Status signal "Phase/position controller in the limitation" <a href="#">▶ Signal flow - position follower (□ 184)</a> <table border="1"> <tr> <td>TRUE</td> <td>The limitation of the phase and/or position controller is active.</td> </tr> </table>	TRUE	The limitation of the phase and/or position controller is active.								
TRUE	The limitation of the phase and/or position controller is active.										

# 9400 HighLine | Parameter setting & configuration

Motor interface

System block "LS\_MotorInterface"

Output <small>DIS code   Data type</small>	Value/meaning
MI_bSpeedSetPointLimited <small>C02569/5   BOOL</small>	Status signal "Resulting speed setpoint in the limitation" <ul style="list-style-type: none"> <li>▶ <a href="#">Signal flow - position follower</a> (□ 184)</li> <li>▶ <a href="#">Signal flow - speed follower</a> (□ 191)</li> </ul>
	TRUE The resulting speed setpoint is limited to the limit values parameterised in <a href="#">C00909/1</a> and <a href="#">C00909/2</a> .
MI_dnSpeedSetpoint_n <small>DINT</small>	Current speed setpoint from position control and speed feedforward control or direct setpoint selection in [%] <ul style="list-style-type: none"> <li>• After limitation by the upper speed limit value (<a href="#">C00909/1</a>) and lower speed limit value (<a href="#">C00909/2</a>).</li> <li>• 100 % ≙ Motor reference speed (<a href="#">C00011</a>)</li> </ul> <ul style="list-style-type: none"> <li>▶ <a href="#">Signal flow - position follower</a> (□ 184)</li> <li>▶ <a href="#">Signal flow - speed follower</a> (□ 191)</li> </ul>
MI_dnSpeedSetpoint_s <small>DINT</small>	Current speed setpoint from position control and speed feedforward control or direct setpoint selection in [rpm] <ul style="list-style-type: none"> <li>• After limitation by the upper speed limit value (<a href="#">C00909/1</a>) and lower speed limit value (<a href="#">C00909/2</a>).</li> </ul>
MI_bSpeedFollowingError <small>C02569/10   BOOL</small>	Status signal "Impermissible speed control deviation" <ul style="list-style-type: none"> <li>▶ <a href="#">Signal flow - speed follower</a> (□ 191)</li> </ul>
	TRUE Speed control deviation is higher than the window set in <a href="#">C00576</a> .
MI_bSpeedCtrlLimited <small>C02569/6   BOOL</small>	Status signal "Speed controller in the limitation" <ul style="list-style-type: none"> <li>▶ <a href="#">Signal flow - speed follower</a> (□ 191)</li> <li>▶ <a href="#">Signal flow - position follower</a> (□ 184)</li> </ul>
	TRUE The speed controller limitation is active.
MI_bTorqueSetpointLimited <small>C02569/7   BOOL</small>	Status signal "Total torque setpoint in the limitation" <ul style="list-style-type: none"> <li>▶ <a href="#">Signal flow - motor interface</a> (□ 95)</li> </ul>
	TRUE The total torque setpoint is limited.
MI_dnTorqueSetpoint_n <small>DINT</small>	Current torque setpoint from speed control and torque feedforward control or direct setpoint selection <ul style="list-style-type: none"> <li>• After limitation by <a href="#">MI_dnTorqueLimit_n</a>.</li> <li>• 100 % ≙ <a href="#">C00057/2</a></li> </ul> <ul style="list-style-type: none"> <li>▶ <a href="#">Signal flow - motor interface</a> (□ 95)</li> </ul>
MI_-dnFilteredTorqueSetpoint_n <small>DINT</small>	Filtered torque setpoint (after jerk limitation and band-stop filter) <ul style="list-style-type: none"> <li>• 100 % ≙ <a href="#">C00057/2</a></li> </ul> <ul style="list-style-type: none"> <li>▶ <a href="#">Signal flow - motor interface</a> (□ 95)</li> </ul>
MI_bCurrentSetpointLimited <small>C02569/8   BOOL</small>	Status signal "Setpoint for current controller in the limitation" <ul style="list-style-type: none"> <li>▶ <a href="#">Signal flow - motor interface</a> (□ 95)</li> </ul>
	TRUE The setpoint for the current controller is limited to $I_{\max\_device}$ ( <a href="#">C00022</a> ).
MI_-bMotorOverloadWarning <small>C02569/11   BOOL</small>	Status signal "Motor overload" <ul style="list-style-type: none"> <li>• Group signal for warning signals from temperature monitoring (KTY, PTC, thermal switch) or <math>I^2xt</math> monitoring.</li> </ul>
	TRUE One of the monitoring modes for motor overload protection is active.
MI_-bSpeedBelowThresholdC19 <small>C02569/9   BOOL</small>	Status signal "Standstill reached" <ul style="list-style-type: none"> <li>▶ <a href="#">Signal flow - motor interface</a> (□ 95)</li> </ul>
	TRUE The current speed is below the threshold set in <a href="#">C00019</a> .
MI_-dnActualMotorCurrent_n <small>DINT</small>	Current motor current <ul style="list-style-type: none"> <li>• 100 % ≙ <math>I_{\max\_device}</math> (<a href="#">C00789</a>)</li> <li>• Display in <a href="#">C00780</a> in [A]</li> </ul> <ul style="list-style-type: none"> <li>▶ <a href="#">Signal flow - motor interface</a> (□ 95)</li> </ul>
MI_-dnActualMotorVoltage_n <small>DINT</small>	Current motor voltage <ul style="list-style-type: none"> <li>• 100 % ≙ 1000 V</li> <li>• Display in <a href="#">C00783</a> in [V]</li> </ul> <ul style="list-style-type: none"> <li>▶ <a href="#">Signal flow - motor interface</a> (□ 95)</li> </ul>

Output <small>DIS code   Data type</small>	Value/meaning
MI_dnActualMotorTorque_n <small>DINT</small>	Current motor torque <ul style="list-style-type: none"> <li>• 100 % ≙ <a href="#">C00057/2</a></li> <li>• Display in <a href="#">C00774</a> in [Nm]</li> </ul> <p style="text-align: right;"><a href="#">▶ Signal flow - motor interface (📖 95)</a></p>
MI_dnActualMotorSpeed_n <small>DINT</small>	Current speed of the motor shaft in [%] <ul style="list-style-type: none"> <li>• 100 % ≙ Motor reference speed (<a href="#">C00011</a>)</li> </ul> <p style="text-align: right;"><a href="#">▶ Signal flow - encoder evaluation (📖 109)</a></p>
MI_dnActualMotorSpeed_s <small>DINT</small>	Current speed of the motor shaft in [rpm] <ul style="list-style-type: none"> <li>• Display under <a href="#">C00772</a></li> </ul> <p style="text-align: right;"><a href="#">▶ Signal flow - encoder evaluation (📖 109)</a></p>
MI_dnActualMotorPos_p <small>DINT</small>	Current position of the motor shaft in [increments] <ul style="list-style-type: none"> <li>• Display under <a href="#">C00770</a></li> </ul> <p style="text-align: right;"><a href="#">▶ Signal flow - encoder evaluation (📖 109)</a></p>
MI_- dnActualDCBusVoltage_n <small>DINT</small>	Actual DC-bus voltage <ul style="list-style-type: none"> <li>• 100 % ≙ 1000 V</li> </ul> <p style="text-align: right;"><a href="#">▶ Signal flow - motor interface (📖 95)</a></p>
MI_dnThermalLoadDevice_n <small>DINT</small>	Thermal device utilisation in [%] <ul style="list-style-type: none"> <li>• Current result of the Ixt calculation.</li> </ul>
MI_dnThermalLoadMotor_n <small>DINT</small>	Thermal motor utilisation in [%] <ul style="list-style-type: none"> <li>• Current result of the I<sup>2</sup>xt calculation.</li> </ul>

### 6 Encoder evaluation

This chapter informs how to use feedback systems for the motor control.



#### Note!

The encoder position is stored safe against mains failure in the memory module and is therefore known to the drive control even after the mains has been switched.

The position resolution of higher-level applications follow the resolution of the encoder which will be activated for the position control.

#### Behaviour of the home position after mains switching

If the home position/information is to be available after mains switching as well, the setting [C02652](#) = "1: Keep" is required.

- One further condition for keeping the home position/information after mains switching is the compliance with the maximally permissible angle of rotation of the encoder which can be set in [C02653](#).
- When resolvers or single-turn absolute value encoders are used and the mains is switched off (24-V supply off), the drive may only be moved by  $\frac{1}{2}$  motor revolution since otherwise the home position will get lost due to the ambiguity of the encoder information.



#### Danger!


When using the encoder/resolver as motor encoder:

In case of an error as safe motor operation cannot be ensured anymore. Thus, the "Fault" response (Lenze setting) should be set permanently for the (open circuit) monitoring of the encoder/resolver!

- [C00580](#): Response to open circuit of encoder
- [C00586](#): Response to open circuit of resolver
- [C00601](#): Response to communication error of encoder

See also: [Parameterise motor encoder \(70\)](#)

## 6.1 Signal flow



[6-1] Signal flow - encoder evaluation

### Internal variables of the motor control (oscilloscope signals)

- ▶ The red numbers specified in the signal flow represent internal variables of the motor control, which can be recorded with the [Oscilloscope](#) for diagnostic and documentation purposes. (416)

No.	Variable or the motor control	Meaning
(1)	Position.dnActualLoadPos	Actual position
(2)	Position.dnActualMotorPos	Current motor position
(3)	Speed.dnActualMotorSpeed	Current motor speed

See also:

- ▶ [Signal flow - motor interface](#) (95)
- ▶ [Signal flow - speed follower](#) (191)
- ▶ [Signal flow - torque follower](#) (196)
- ▶ [Signal flow - position follower](#) (184)

## 6.2 Parameter setting

Short overview of parameters for the encoder evaluation:

Parameter	Information	Lenze setting	
		Value	Unit
<a href="#">C00058/1</a>	Rotor displ. angle of resolver	-90.0	°
<a href="#">C00058/2</a>	Rotor displ. angle of encoder	0.0	°
<a href="#">C00058/3</a>	Rotor displ. angle of module	0.0	°
<a href="#">C00080</a>	Resolver pole pair number	1	
<a href="#">C00420</a>	Encoder PPR	512	
<a href="#">C00421</a>	Encoder voltage	5.0	V
<a href="#">C00422</a>	Encoder type	Incremental encoder (TTL signal)	
<a href="#">C00490</a>	Position encoder	Motor encoder	
<a href="#">C00495</a>	Motor encoder	Resolver X7	
<a href="#">C00497</a>	Speed act. val. time const.	0.4	ms
<a href="#">C00579</a>	Resp. to speed monitoring	Off	
<a href="#">C00580</a>	Resp. to encoder open circuit	Fault	
<a href="#">C00586</a>	Resp. to resolver open circuit	Fault	
<a href="#">C00601</a>	Resp. to encoder error	Fault	
<a href="#">C02527</a>	Motor mounting direction	Motor rotating clockwise	
<a href="#">C02529</a>	Mounting direction of position encoder	Motor rotating counter-clockwise	
<a href="#">C02570</a>	Controller configuration	Phase control	
<a href="#">C02572</a>	Speed setpoint	-	Unit/s
<a href="#">C02573</a>	Position setpoint	-	Unit
<a href="#">C02574</a>	Actual speed	-	Unit/s
<a href="#">C02575</a>	Actual position	-	Unit
<a href="#">C02576</a>	Following error	-	Unit
<a href="#">C02577</a>	External actual position	-	Unit
<a href="#">C02578</a>	Offset - actual position value/position setpoint	-	Unit

Highlighted in grey = display parameter

See also: [▶ Parameterise motor encoder \(📖 70\)](#)

### 6.2.1 Controller configuration

The device interfaces for the encoder on the motor side and, if available, on the load side are directly assigned to the corresponding control according to the controller configurations selected ([C02570](#)):

	Phase control (Lenze setting)	Position control
Cycle time:	250 $\mu$ s	Application-dependent
Dead time:	Smaller dead time in the actual value channel	Same dead time for position setpoint and actual position

- ▶ If only an encoder on the motor side is available, this "motor encoder" provides the actual value signals for the phase/position control and the speed control.
  - The motor encoder on the motor side supports the secondary servo control irrespective of the use for position and speed control (commutation).
- ▶ If an additional encoder is available on the motor side, this "position encoder" exclusively supports the position control, and the controller configuration ([C02570](#)) must be set to position control so that the load encoder will be evaluated.
  - The starting position of the position encoder can be set via the basic function "Homing".



#### Note!


When the basic function "Quick stop" is activated, the controller configuration is internally changed over to phase control independent of the setting in [C02570](#).

- If the basic function "Quick stop" is to be used, the gain of the phase controller ([C00254](#)) must also be set correctly for the "Position control" controller configuration.

In case of the technology application for the network via the "Electrical shaft" the controller configuration is preset to position control.

## 6.2.2 System with motor encoder

No encoder is installed on the load side. The motor position (angle of rotation) and motor speed are detected via the motor encoder selected in [C00495](#) and converted with regard to the load side.



[6-2] Schematic diagram - feedback with position encoder = motor encoder

The actual position and speed values on the machine side result from the conversion via the gearbox factor on the motor side ([C02520/C02521](#)) and the feed constant ([C02524](#)).


See also:

- ▶ [Gearbox ratio](#) (📖 37)
- ▶ [Feed constant](#) (📖 42)



### 6.2.3 System with motor encoder and position encoder

The optional position encoder is used as feedback for the position control and transmits the position of slide or drive roll to the controller.



[6-3] Schematic diagram - feedback with separate position encoder

In this case, the actual position and speed values on the machine side result from converting the position encoder position via the resulting gearbox factor (ratio of motor speed to position encoder speed; display in [C02531/3](#)) and the feed constant ([C02524](#)).



#### How to activate the use of a separate position encoder:

On the **Application** parameter

tab in the dialog level *Overview* → *Drive interface* → *Machine parameter*:

1. Select the "position control" in the **Controller configuration** list field ([C02570](#)) in order that the position encoder will be evaluated.
2. Select the position encoder available in the **Position encoder** list field ([C00490](#)).
3. Select the gearbox ratio of the position encoder (ratio of load speed to encoder speed) as a quotient (numerator/denominator) which results from the resulting teeth number:
  - Enter numerator in the input field **Gearbox fact. numer. load** ([C02522](#)).
  - Enter denominator in the input field **Gearbox fact. denom. load** ([C02523](#)).
4. If required, adapt the position encoder mounting direction via the list field **Position encoder mounting direction** ([C02529](#)). The position encoder mounting direction is preset to "Encoder rotating CW".



#### Tip!

The resulting gearbox factor for the position encoder is displayed in [C02531/2](#).

See also:

▶ [Feed constant](#) (42)

## 6.2.4 Use external position encoder.

The *FDB\_dnActPosIn\_p* input of the system block [LS Feedback](#) serves to evaluate an external encoder (CAN, SSI, Profibus).

- ▶ Via this input an actual position of an external encoder in [increments] can be directly given to the encoder evaluation.



### How to activate the use of the external actual position:

On the **Application parameter**

tab in the dialog level *Overview* → *Drive interface* → *Machine parameter*:

1. Select the "position control" in the **Controller configuration** list field ([C02570](#)) in order that the position encoder will be evaluated.
2. Set "From application" in the list field **Position encoder** ([C00490](#)).




### Note!

- Encoder inversion and offset selection *FDB\_dnPositionOffset\_p* also affect the external actual position.
- If the use of the external actual position preset via *FDB\_dnActPosIn\_p* is activated, a, the "Home position known" status (*HM\_bHomePosAvailable* = TRUE) is automatically set and homing with the basic function "Homing" cannot be activated anymore.
- When the traversing range ([C02528](#)) is set to "Modulo", the external actual position value must also be set to modulo (0 ... cycle-1).

## 6.3 System block "LS\_Feedback"

The system block **LS\_Feedback** displays the encoder evaluation in the function block editor d.



### Inputs

Input	Data type	Information/possible settings
FDB_dnPosOffset_p	DINT	Offset for position setpoint and actual position value in [increments]
FDB_dnActPosIn_p	DINT	External actual position value in [increments] <ul style="list-style-type: none"> <li>For defining an external actual position value with corresponding position control.</li> </ul> ▶ <a href="#">Use external position encoder.</a> (114)

### Outputs

Output	DIS code   Data type	Value/meaning		
FDB_dnActualPos_p	DINT	Current position of the load encoder in [increments]		
FDB_dnActualSpeed_s	DINT	Current speed of the position encoder in [rpm]		
FDB_dnPosFollowingError_p	DINT	Current following error in [increments]		
FDB_dnSetPos_p	DINT	Set position calculated by active basic drive function in [increments] <ul style="list-style-type: none"> <li>Considering the motor mounting position.</li> </ul>		
FDB_dnSetSpeed_s	DINT	Setpoint speed calculated by active basic drive function in [rpm] <ul style="list-style-type: none"> <li>Considering the motor mounting position.</li> </ul>		
FDB_bResolverError	<a href="#">C02579/1</a>   BOOL	Status signal "Resolver error" <table border="1"> <tr> <td>TRUE</td> <td>A resolver error (e.g. open circuit) has occurred.</td> </tr> </table>	TRUE	A resolver error (e.g. open circuit) has occurred.
TRUE	A resolver error (e.g. open circuit) has occurred.			
FDB_bSinCosSignalError	<a href="#">C02579/2</a>   BOOL	Status signal "sin/cos encoder error" <table border="1"> <tr> <td>TRUE</td> <td>A sin/cos encoder error has occurred.</td> </tr> </table>	TRUE	A sin/cos encoder error has occurred.
TRUE	A sin/cos encoder error has occurred.			
FDB_bEncoderComError	<a href="#">C02579/3</a>   BOOL	Status signal "Encoder communication error" <table border="1"> <tr> <td>TRUE</td> <td>An encoder communication error has occurred.</td> </tr> </table>	TRUE	An encoder communication error has occurred.
TRUE	An encoder communication error has occurred.			

## 7 I/O terminals

This chapter informs about possible parameter settings and configurations of the controller input and output terminals.



**Tip!**

Information on wiring the terminals can be found in the Mounting Instructions of the controller!

### 7.1 Overview


Front view	Terminal assignment	Information
	<b>X2</b> 	<ul style="list-style-type: none"> <li>▶ <a href="#">Monitoring function "State bus"</a> (📖 127)</li> </ul>
	<b>X3</b> 	<ul style="list-style-type: none"> <li>▶ <a href="#">Analog inputs</a> (📖 117)</li> <li>▶ <a href="#">Analog outputs</a> (📖 120)</li> </ul>
	<b>X4</b> 	<ul style="list-style-type: none"> <li>▶ <a href="#">Digital outputs</a> (📖 125)</li> </ul>
	<b>X5</b> 	<ul style="list-style-type: none"> <li>▶ <a href="#">Digital inputs</a> (📖 123)</li> <li>▶ <a href="#">Touch probe detection</a> (📖 129)</li> </ul>

## 7.2 Analog inputs

The controller has 2 analog inputs that can be used to detect differential voltage signals in the range of  $\pm 10$  V, e.g. analog speed setpoint selections or the voltage signals of an external sensor (temperature, pressure, etc.).

- Optionally, analog input 1 can also be used to detect current setpoints.

### 7.2.1 Terminal assignment/electrical data



Terminal	Use	Electrical data
X3/A1- X3/A1+	Differential voltage input 1 (no bridge between A1R and A1)	Level: -10 V ... +10 V
		Resolution: 11 bits + sign
		Normalisation: When <a href="#">C00034</a> = "0": $\pm 10 \text{ V} \equiv \pm 2^{30}$
		Conversion rate: 1 kHz
	Current input (bridge between A1R and A1)	Level: -20 mA ... +20 mA
	Resolution: 10 bits + sign	
	Normalisation: When <a href="#">C00034</a> = "1": -20 mA ... -4 mA = $-2^{30}$ ... 0 +4 mA ... +20 mA = 0 ... $2^{30}$ When <a href="#">C00034</a> = "2": $\pm 20 \text{ mA} \equiv \pm 2^{30}$	
	Conversion rate: 1 kHz	
X3/A2- X3/A2+	Differential voltage input 2	Level: -10 V ... +10 V
		Resolution: 11 bits + sign
		Normalisation: $\pm 10 \text{ V} \equiv \pm 2^{30}$
		Conversion rate: 1 kHz

## 7.2.2 Parameter setting

Short overview of parameters for the analog inputs:

Parameter	Information
<a href="#">C00034</a>	Config. analog input 1
<a href="#">C00598</a>	Resp. to open circuit AIN1
<a href="#">C02730/1</a>	AIN1: Gain
<a href="#">C02730/2</a>	AIN2: Gain
<a href="#">C02731/1</a>	AIN1: Offset
<a href="#">C02731/2</a>	AIN2: Offset
<a href="#">C02732/1</a>	AIN1: Dead band
<a href="#">C02732/2</a>	AIN2: Dead band
<a href="#">C02800/1</a>	AIN1: Input signal (-16384 ≙ -100 %, 16383 ≙ 100 %)
<a href="#">C02800/2</a>	AIN2: Input signal (-16384 ≙ -100 %, 16383 ≙ 100 %)

Highlighted in grey = display parameter

## 7.2.3 Reconfiguring analog input 1 as a current input

Proceed as follows to reconfigure analog input 1 as a current input:

1. Bridge terminals A1R and A1 on terminal strip X3 by means of wiring.
2. Select the corresponding current loop under [C00034](#).



**Tip!**

In this way, you can implement a 4 ...20 mA current loop, e.g. for speed setpoint selection.


### Open-circuit monitoring

Under

[C00598](#), you can select an error response to an open circuit for the 4 ...20 mA current loop.

## 7.2.4 System block "LS\_AnalogInput"

The system block LS\_AnalogInput displays the analog inputs in the function block editor.



Output	Data type	Value/meaning
AIN1_dnIn_n	DINT	Analog input 1 • Scaling: $\pm 2^{30} \equiv \pm 10 \text{ V}$ for use as voltage input $\pm 2^{30} \equiv \pm 20 \text{ mA}$ for use as current input
AIN2_dnIn_n	DINT	Analog input 2 • Scaling: $\pm 2^{30} \equiv \pm 10 \text{ V}$
AIN1_bCurrentError	BOOL	Status signal "Current input error" • Only when analog input 1 is used as current input. • Application: Cable-breakage monitoring of the 4 ...20 mA circuit.
		TRUE   $ I_{AIN1}  < 2 \text{ mA}$

## 7.3 Analog outputs

The controller has 2 analog outputs that can be used to output internal analog signals as voltage signals, e.g. for analog indicator control or as setpoint for slave drives.



### Note!


Initialisation behaviour:

- After mains switching up to the start of the application the analog outputs remain set to 0 V.

Exception handling:

- In case of a critical exception in the application (e.g. reset) the analog outputs are set to 0 V.

### 7.3.1 Terminal assignment/electrical data



Terminal	Use	Electrical data
X3/AO1	Voltage output 1	Level: -10 V ... +10 V (max. 2 mA)
		Resolution: 11 bits + sign
		Normalisation: $\pm 2^{30} \equiv \pm 10 \text{ V}$
		Conversion rate: 1 kHz
X3/AO2	Voltage output 2	Level: -10 V ... +10 V (max. 2 mA)
		Resolution: 11 bits + sign
		Normalisation: $\pm 2^{30} \equiv \pm 10 \text{ V}$
		Conversion rate: 1 kHz
X3/GA	Reference potential (analog ground)	



### 7.3.2 Parameter setting


Short overview of parameters for the analog outputs:

Parameter	Information
<a href="#">C02733/1</a>	AOUT1: Gain
<a href="#">C02733/2</a>	AOUT2: Gain
<a href="#">C02734/1</a>	AOUT1: Offset
<a href="#">C02734/2</a>	AOUT2: Offset
<a href="#">C02801/1</a>	AOUT1: output signal
<a href="#">C02801/2</a>	AOUT2: output signal

Highlighted in grey = display parameter

## 7.3.3 System block "LS\_AnalogOutput"

The system block **LS\_AnalogOutput** displays the interface to the analog outputs in the function block editor.




Input	Data type	Information/possible settings
AOUT1_dnOut_n	DINT	Analog output 1 • Scaling: $\pm 2^{30} \equiv \pm 10 \text{ V}$
AOUT2_dnOut_n	DINT	Analog output 2 • Scaling: $\pm 2^{30} \equiv \pm 10 \text{ V}$

## 7.4 Digital inputs

The controller has 8 freely configurable digital inputs.

- ▶ All digital inputs can be used for touch probe. ▶ [Touch probe detection](#) (129)
- ▶ Control input RFR of terminal strip X5 for controller enable is connected to the device control.

### 7.4.1 Terminal assignment/electrical data



Terminal	Use	Electrical data
X5/D11	Digital inputs 1 ... 8	LOW level: 0 ... +5 V
X5/D18		HIGH level: +15 ... +30 V
		Input current: 8 mA per input (at 24 V)
		Electric strength of external voltage: max. ±30 V
		Conversion rate: 1 kHz
X5/RFR	Controller enable	See digital inputs
X5/GI	Reference potential (digital ground)	

### 7.4.2 Parameter setting


Short overview of parameters for the digital inputs:

Parameter	Information
<a href="#">C00114</a>	Dlx terminal polarity
<a href="#">C00443</a>	Dlx status
<a href="#">C02803</a>	Status word dig. inputs
<a href="#">C02830</a>	Dlx delay time

Highlighted in grey = display parameter

## 7.4.3 System block "LS\_DigitalInput"

The system block **LS\_DigitalInput** displays the digital inputs and the status of the state bus in the function block editor.



Output	Value/meaning
DIGIN_bCInh <small>DIS code   data type</small> <a href="#">C00443/9</a>   BOOL	Status signal "Controller inhibit" <ul style="list-style-type: none"> <li>An inverter is used to connect control input RFR (X5/pin 9) for the setting/reset of controller inhibit to the device control (DCTRL).</li> </ul> TRUE   Controller inhibit active
DIGIN_bIn1 <small>DIS code   data type</small> <a href="#">C00443/1</a>   BOOL ... DIGIN_bIn8 <small>DIS code   data type</small> <a href="#">C00443/8</a>   BOOL	Digital inputs 1 ... 8
DIGIN_bStateBusIn <small>DIS code   data type</small> <a href="#">C00443/12</a>   BOOL	State bus status ▶ <a href="#">Monitoring function "State bus"</a> (📖 127)  TRUE   A device connected to the state bus has set the state bus to LOW level and the status "Error" has been set. <ul style="list-style-type: none"> <li>Status "Error" is also set if a device connected to the state bus is not supplied with voltage.</li> </ul>

## 7.5 Digital outputs

The controller has 4 freely configurable digital outputs.



### Note!


Initialisation behaviour:

- After mains switching up to the start of the application the digital outputs remain set to FALSE.

Exception handling:

- In case of a critical exception in the application (e.g. reset) the digital outputs are set to FALSE considering the terminal polarity parameterised in [C00118](#).

### 7.5.1 Terminal assignment/electrical data



Terminal	Use	Electrical data	
X4/DO1 ... X4/DO4	Digital outputs 1 ... 4	LOW level:	0 ... +5 V
		HIGH level:	+15 ... +30 V
		Output current:	max. 50 mA per output (external resistance > 480 Ω at 24 V)
		Conversion rate:	1 kHz
X4/240	External 24 V voltage supply for the digital outputs		
X4/GO	Reference potential (digital ground)		

### 7.5.2 Parameter setting


Short overview of parameters for the digital outputs:

Parameter	Information
<a href="#">C00118</a>	DOx terminal polarity
<a href="#">C00444</a>	DOx status
<a href="#">C02802</a>	Status word dig. outputs

Highlighted in grey = display parameter

## 7.5.3 System block "LS\_DigitalOutput"


The system block **LS\_DigitalOutput** displays the interface to the digital outputs, the state bus and the yellow user LED on the front of the controller in the function block editor.



Input	Information/possible settings
DIGOUT_bOut1 <small>DIS code   Data type</small> <a href="#">C00444/1</a>   BOOL ... DIGOUT_bOut4 <small>DIS code   Data type</small> <a href="#">C00444/4</a>   BOOL	Digital outputs 1 ... 4
DIGOUT_bStateBusOut <small>DIS code   Data type</small> <a href="#">C00444/18</a>   BOOL	Setting the state bus to the status "Error" ▶ <a href="#">Monitoring function "State bus"</a> (127)
	TRUE The state bus is set to LOW level, all devices connected to the state bus start their pre-programmed response.
DIGOUT_bUserLED <small>DIS code   Data type</small> <a href="#">C00444/9</a>   BOOL	Control of yellow user LED on the front of the controller TRUE LED on

## 7.6 Monitoring function "State bus"

The state bus has been exclusively designed for Lenze controllers. The bus system can interconnect up to 20 controllers and can be used to simulate the function of a "rip cord":



[7-1] Schematic diagram: Networking via state bus

- ▶ The state bus only knows the states "OK" and "Error".
- ▶ The state bus is a bus with multi-master capability, i.e. each device connected to the state bus can set the state bus to the status "Error" by setting it to LOW level.
- ▶ With "Error", all devices start their adjustable response, e.g. synchronised braking of the drive system.
- ▶ Status "Error" is also set if a device connected to the state bus is not supplied with voltage.




### Note!

Exception handling:

- In case of a critical exception in the application (e.g. reset) the "release cord" is not released, the state bus remains in the "OK" state.


## 7.6.1 Detecting the current status

Use the output *DIGIN\_bStateBusIn* of the system block [LS\\_DigitalInput](#) to display the current state bus status. If an error occurs, the output *DIGIN\_bStateBusIn* is set to TRUE.



## 7.6.2 Setting the state bus to the status "Error"

If the input *DIGOUT\_bStateBusOut* of the system block [LS\\_DigitalOutput](#) is set to TRUE, the state bus is set to "Error" and all connected devices start their pre-programmed response.





## 7.7 Touch probe detection

A "touch probe" is a signal-controlled event that can, for instance, be activated via a digital input to detect an actual value (that rapidly changes) at the latch time and process it in the program.

### Overview of the touch probe channels


12 touch probe signals which can be configured independently of each other are available for touch probe detection:

Touch probe channel	Activating event	System block
1	Signal change at digital input 1	<a href="#">LS_TouchProbe1...8</a> (📖 132)
2	Signal change at digital input 2	
3	Signal change at digital input 3	
4	Signal change at digital input 4	
5	Signal change at digital input 5	
6	Signal change at digital input 6	
7	Signal change at digital input 7	
8	Signal change at digital input 8	
9	Motor encoder zero pulse	<a href="#">LS_TouchProbeMotor</a> (📖 133)
10	Load encoder zero pulse	<a href="#">LS_TouchProbeLoad</a> (📖 133)
11	DFIN zero pulse	LS_TouchProbeDFIN
12	DFOUT zero pulse	LS_TouchProbeDFOUT

- ▶ Each touch probe channel is assigned to a system block which provides the application with a scaled time stamp.
- ▶ The time stamp refers to the sampling time of the encoder signals and outputs the difference compared to the touch probe event.

### Touch-probe processing

In order to process the touch probe event the time stamp must be transferred to an entity of the FB **L\_SdTouchProbe**:




[7-2] Transfer of the FB **L\_SdTouchProbe**

- ▶ The FB **L\_SdTouchProbe** takes over the interpolation of the input signal based on the time stamp and outputs the interpolated value and the difference compared with the last input signal.

## 7.7.1 Actual value interpolation (principle)


If a touch probe is detected, the (residual) time to the following task cycle is determined and a time stamp is created from it. Based on this time stamp the FB `L_SdTouchProbe` can execute a linear interpolation between both actual position points. The result is the exact actual position at the time of the physical touch probe event.



[7-3] Actual value determination through linear interpolation (principle)

## 7.7.2 Dead time compensation

For dead time compensation during the detection of the touch probe event, it is possible to select a delay time (*touch probe delay*) in [C02810](#) for each touch probe channel, which will be considered in the touch probe calculation.




[7-4] Dead time compensation (principle)

- ▶ Filtering of the digital inputs influences the electrical detection of the touch probe, i.e. the DIx delay time set in [C02830](#) for the digital inputs must be considered in the delay time [C02810](#).
- ▶ For the optional digital frequency input/output the delay times must be set via special parameters:
  - C13021 or C14021: TP delay time - digital frequency input.
  - C13061 or C14061: TP delay time - digital frequency output.

## 7.7.3 System block "LS\_TouchProbe1...8"

The system blocks **LS\_TouchProbe1** ... **LS\_TouchProbe8** display the touch probe channels 1 ... 8 which are assigned to the digital inputs **DI1** ... **DI8** in the function block editor.




Input	Data type	Value/meaning
TPx_bEnablePosEdge	BOOL	Enable response to rising edge <b>Note:</b> <ul style="list-style-type: none"> <li>If several positive edges occur within the basic cycle time (HighLine: 1 ms), only the first positive edge initiates the touch probe event and no status signal "touch probe(s) lost" are generated.</li> </ul>
		TRUE   A touch probe event is activated by a positive edge at the digital input DIx.
TPx_bEnableNegEdge	BOOL	Enable response to negative edge <b>Note:</b> <ul style="list-style-type: none"> <li>If several negative edges occur within the basic cycle time (HighLine: 1 ms), only the first negative edge initiates the touch probe event.</li> <li>If a positive and negative edge occur within the basic cycle time (1 ms) and if the response to both edges is enabled, only the positive edge initiates the touch probe event.</li> <li>In both cases no status signal "touch probe(s) lost" is generated.</li> </ul>
		TRUE   A touch probe event is activated by a negative edge at the digital input DIx.

Output	Data type	Value/meaning
TPx_dnTouchProbeTimeLag	DINT	Scaled time stamp for processing the touch probe event with the FB <b>L_SdTouchProbe</b> . <ul style="list-style-type: none"> <li>1 ms = 20 bits</li> </ul>
TPx_bTouchProbeReceived	BOOL	Status signal "Touch probe detected" <ul style="list-style-type: none"> <li>Status is only set for one task cycle.</li> </ul>
		TRUE   Touch probe event has been activated.
TPx_bTouchProbeLost	BOOL	Status signal "Touch probe(s) lost" <ul style="list-style-type: none"> <li>Status is only set for one task cycle.</li> </ul>
		TRUE   More than one touch probe event has been released during the task runtime. The output time stamp only refers to the first touch probe event.
TPx_bNegativeEdge	BOOL	Status signal "Negative edge detected" <ul style="list-style-type: none"> <li>Status is only set for one task cycle.</li> </ul>
		TRUE   A negative edge has been detected at the digital input DIx.

## 7.7.4 System block "LS\_TouchProbeMotor"


The system block **LS\_TouchProbeMotor** displays the touch probe channel, which is assigned to the motor encoder zero pulse, in the function block editor.



Output	Data type	Value/meaning
TPM_dnTouchProbeTimeLag	DINT	Scaled time stamp for processing the touch probe event with the FB <b>L_SdTouchProbe</b> .
TPM_bTouchProbeReceived	BOOL	Status signal "Touch probe detected" <ul style="list-style-type: none"> <li>Status is only set for one task cycle.</li> </ul>
		TRUE Touch probe event has been activated.
TPM_bTouchProbeLost	BOOL	Status signal "Touch probe(s) lost" <ul style="list-style-type: none"> <li>Status is only set for one task cycle.</li> </ul>
		TRUE More than one touch probe event has been activated in the task run time and could therefore not be detected.

## 7.7.5 System block "LS\_TouchProbeLoad"

The system block **LS\_TouchProbeLoad** displays the touch probe channel, which is assigned to the load encoder zero pulse, in the function block editor.



Output	Data type	Value/meaning
TPL_dnTouchProbeTimeLag	DINT	Scaled time stamp for processing the touch probe event with the FB <b>L_SdTouchProbe</b> .
TPL_bTouchProbeReceived	BOOL	Status signal "Touch probe detected" <ul style="list-style-type: none"> <li>Status is only set for one task cycle.</li> </ul>
		TRUE Touch probe event has been activated.
TPL_bTouchProbeLost	BOOL	Status signal "Touch probe(s) lost" <ul style="list-style-type: none"> <li>Status is only set for one task cycle.</li> </ul>
		TRUE More than one touch probe event has been activated in the task run time and could therefore not be detected.

## 7.8 System bus "CAN on board"


The controller has an integrated CANopen system bus interface for process and parameter data exchange between different devices and the connection of additional modules such as distributed terminals, keypads and input devices ("HMI's") and external controls.

- ▶ In the »Engineer« parameter list or in the keypad, category **CAN**, you can find the parameters relevant for the CANopen system bus interface classified in different subcategories.



### Note!

For detailed information about the CANopen system bus interface, please see the "System bus (CANopen) - CAN on-board 9400" Communication Manual.



## 8 Safety engineering

The 9400 HighLine controllers can be equipped with a safety module. The individual safety module types have a different range of functions to optimally meet different requirements.

"Integrated safety technology" stands for user-related safety functions that are applicable to the protection of persons working with machines and the machine protection.

The motion functions are executed by the controller. The safety modules monitor the reliable observation of limit values and provide safe inputs and outputs. When the limit values are exceeded, the safety modules start control functions for the fault scenario according to EN 60204-1 standard directly in the controller.

The safety functions are suitable for applications according to IEC 61508, SIL 3 and, depending on the module, meet the requirements of EN 954, part 1, up to control category 4.



### Note!

For detailed information about the integrated safety technology, please see the Controller Manual for the "9400 Servo Drives" and the Manual for the safety module.

## 8.1 Integration into the application

If a safety function is required, the safety engineering activates a corresponding safe monitoring function. The standstill function, however, is only executed directly in case of the function "Safe torque off" (STO). In case of the other safety functions an action of the controller is required, which is safely monitored. The implementation of the corresponding action (e.g. braking, braking to standstill, holding of the standstill position) must be carried out by the application.

### "LS\_SafetyModule" system block

For the transmission of the control and status information from the safety module to the application the **LS\_SafetyModule** system block is provided in the function block editor of the »Engineers«.

### Basic function "Limiter"

Furthermore the **LS\_Limiter** system block which contains the basic function [Limiter](#)" is provided in the function block editor for the connection of safety engineering to the application. ([□ 200](#))

The basic function "Limiter" provides a parameter setting surface in the »Engineer« for a comfortable setting of limit positions, limited speeds and limit values and enables the drive to braked selectively **after request** through the safety module.

### General procedure

1. Activation of the safety function on the safety module (e. g. SS1 - safe stop 1).  
→ Monitoring starts.
2. The safety module informs the controller via a control word that the safety function has been activated.
3. The application evaluates the control word and starts the required motion sequence (e.g. braking).

## 8.2 Selecting the required safety module

The safety module expected by the application and the controller is selected in [C00214](#).

- ▶ In the »Engineer« this setting is carried out automatically by assigning the device module to the controller, i.e., the »Engineer« sets [C00214](#) automatically according to the safety module selected.
- ▶ If the safety module selected in [C00214](#) does not correspond to the safety module type connected, an error will be activated.



## 8.3 Control word of the safety module SM3xx

A safety function is requested via the control word transferred from the SM3xx safety module to the basic device *SM\_dwControl*.

- ▶ The corresponding actions (e.g. braking, braking to standstill, holding of the standstill position) must be executed by the application, e.g. via the basic function "[Limiter](#)".  
([□ 200](#))
- ▶ The following table shows the bit coding of the control word *SM\_dwControl*.
  - The bits that are supported depend on the safety module used.

Bit	Abbreviation	Meaning
0	STO	Safe torque off ("Safe Torque Off")
1	SS1	Safe stop 1 ("Safe Stop")
2	SS2	Safe stop 2
3	SLS1	Safely limited speed 1 ("Safely Limited Speed")
4	SLS2	Safely limited speed 2
5	SLS3	Safely limited speed 3
6	SLS4	Safely limited speed 4
7	SDIpos	Safe direction positive ("Safe Direction positive")
8	SDIneg	Safe direction negative ("Safe Direction negative")
9	ES	Enable switch ("Enable Switch")
10	SLI	Safely limited increment ("Safely Limited Increment")
11	OMS	Operating mode selector switch ("Operation Mode Selector")
12	SLP1	Safely limited position 1 ("Safely Limited Position")
13	SLP2	Safely-limited position 2
14	SLP3	Safely-limited position 3
15	SLP4	Safely-limited position 4
16	SOS	Safe operating stop ("Safe Operating Stop")
17	SLS1 observed	Safely limited speed 1 activated and complied with
18	SLS2 observed	Safely limited speed 2 activated and complied with
19	SLS3 observed	Safely limited speed 3 activated and complied with
20	SLS4 observed	Safely limited speed 4 activated and complied with
21	SDIpos observed	"Safe direction positive" activated and complied with
22	SDIneg observed	"Safe direction negative" activated and complied with
23	SSE	Safe stop emergency ("Safe Stop Emergency")
24	-	<i>Reserved</i>
...		
30		
31	Error	SM301 safety module reports and error

[8-1] Bit coding of the control word sent by the safety module

## 8.4 Status information of the SM3xx safety module

In addition to the control word *SM\_dwControl* the SM3xx safety module transfers the two status words *SM\_wState* and *SM\_wIoState* to the basic device.

### Status word *SM\_wState*

- ▶ The following table shows the bit coding of the status word *SM\_dwState*.
  - The bits that are supported depend on the safety module used.

Bit	Abbreviation	Meaning
0	STO	"safe torque off (STO)" function is active. • The drive is safely switched to torqueless operation.
1	-	<i>Reserved</i>
2	-	<i>Reserved</i>
3	EC_S0	Error stop category 0: "Safe torque off (STO)" function is active.
4	EC_S1	Error stop category 1: "Safe stop 1 (SS1)" function is active.
5	EC_S2	Error stop category 2: "Safe stop 2 (SS2)" function is active.
6	-	<i>Internal use</i>
7	-	<i>Internal use</i>
8	-	<i>Reserved</i>
...		
15		

[8-2] Bit coding of the status word sent by the safety module

### Status word *SM\_wIoState*


- ▶ The following table shows the bit coding of the status word *SM\_wIoState*.
  - The bits that are supported depend on the safety module used.

Bit	Abbreviation	Meaning
0	SD-In1	Sensor input 1 in ON state.
1	SD-In2	Sensor input 2 in ON state.
2	SD-In3	Sensor input 3 in ON state.
3	SD-In4	Sensor input 4 in ON state.
4	-	<i>Reserved</i>
5	AIS	Restart acknowledgement via terminal effected (negative edge: 1↘0).
6	AIE	Error acknowledgement via terminal effected (negative edge: 1↘0).
7	-	<i>Reserved</i>
8	PS_AIS	Restart acknowledgement via safety bus effected (positive edge: 0↗1)
9	PS_AIE	Error acknowledgement via safety bus effected (positive edge: 0↗1)
10	-	<i>Reserved</i>
11	-	<i>Reserved</i>
12	SD-Out1	Safe output 1 (feedback output) in the ON state.
13	-	<i>Reserved</i>
14	-	<i>Reserved</i>
15	-	<i>Reserved</i>

[8-3] Bit coding of the I/O status word sent by the safety module

### 8.5 System block "LS\_SafetyModule"

The **LS\_SafetyModule** system block is used as interface to the (optional) safety module in the function block editor.



#### Outputs

Output	Data type	Value/meaning
SM_dwControl	DWORD	Control word of the safety module ▶ <a href="#">Control word of the safety module SM3xx (137)</a>
SM_wState	Word	Status word of the safety module ▶ <a href="#">Status information of the SM3xx safety module (138)</a>
SM_wIoState	Word	I/O status word of the safety module ▶ <a href="#">Status information of the SM3xx safety module (138)</a>
SM_bPowerStageEnable	BOOL	Status signal "Inverter enable" TRUE   Inverter is enabled by the safety module.
SM_byModuleId	BYTE	ID of the safety module available in the controller

## 9 Basic drive functions

This chapter describes the basic functions of the "Servo Drives 9400".

### 9.1 General information

Before the basic functions are described in detail, the following subchapter provides general information on how to use the basic functions and the internal state machine which controls the execution of the basic functions.

#### 9.1.1 Conditions for the use of the basic functions

##### Parameter setting, configuring or programming?

The basic functions described in the following chapters can be executed depending on the controller type and the available MotionControl license as follows:

- ▶ Parameter setting by means of »Engineer« or keypad
- ▶ Configuration in the function block editor of the »Engineers«
- ▶ Programming according to IEC 61131-3 in the »PLC Designer«<sup>1</sup>

##### Parameter setting

Each basic function can be parameterised and executed in the »Engineer« via a corresponding dialog or alternatively via the keypad.

##### Configuration

The function block editor of the »Engineers« provides an own system block (SB) for each basic function which is inserted into the application interconnection and linked with the corresponding signals to implement the desired functions.



##### Note!

Ensure that the corresponding system block is called in a cyclic application task.  
Basically projects which only contain an unsolicited task and no cyclic task, are not permissible!

##### Programming

In the »PLC Designer« the basic functions are also available as separate system blocks which can be inserted in the control configuration, if required, and be accessed from the IEC 61131-3 program via the corresponding system variables.

<sup>1</sup> In preparation

## 9.1.2 Internal state machine

The execution of the different basic functions is internally controlled by a state machine which can adopt the following "function states":



[9-1] Function states of the state machine "Basic functions"

The state machine ensures that:

- ▶ one basic function at a time adopts the control of the drive.
- ▶ only the basic function with the highest priority (= smallest number) is executed if several basic functions are activated at the same time. ▶ [Priorities](#) (p. 145)
- ▶ the drive always has a defined state both in case of error and in normal operation.



## Note!

The basic functions "[Limiter](#)" and "[Brake control](#)" run autonomously, but are able to control the state machine to a certain function state, if required.

The function states are not to be confused with the device states ("Operation", "Fault active", "Device is switched on", etc.) of the controller. ▶ [Device states](#)

( 45)



## Tip!

In [C02530](#) the currently active function state is displayed.

### 9.1.2.1 "Initialisation" status

If the controller has completed the device initialisation, the function state "Initialisation" is passed through.

- ▶ In the function state "Initialisation", the process data required for processing the basic functions are initialised.
- ▶ The monitoring mode is not yet active.
- ▶ The basic functions are not yet processed (e.g. brake control) and cannot yet be parameterised or activated either.
- ▶ When the basic functions are initialised and no error had occurred, it is automatically changed to the basic state "Drive in standstill".

### 9.1.2.2 Status "Controller not ready"

In this function state the pulse inhibit is set in the controller, which means that the power output stages are tristated and the drive cannot be controlled.

### 9.1.2.3 Status "drive in standstill"

This "basic state" is assumed if no other state is active.

- ▶ The setpoints for speed and acceleration are set to "0".
- ▶ The drive stands position-controlled.
- ▶ No error has occurred and quick stop is not active.
- ▶ Every basic function can be activated out of this state.

## 9.1.2.4 Status "Drive is stopped"

This function state is automatically passed through when a basic function is deactivated.

- ▶ If the drive does is not yet in the standstill state, it is decelerated to standstill via a parameterisable deceleration ramp.
- ▶ If a basic function is activated during the "stopping", this basic function takes over the control of the drive from the current speed on and the function state "Drive is stopped" is abandoned.
- ▶ If the drive is at standstill, it is automatically changed to the basic function "Drive in standstill".

## 9.1.2.5 Status "Manual jog active"

In this function state the drive can be manually directed in CW or CCW rotation ("inching mode"). ▶ [Manual jog](#) (☞ 156)

- ▶ If the controller knows the home position, the set software limit positions are monitored and, if available, connected travel range limit switches.
- ▶ "Retracting" from an activated travel range limit switch is also possible.

## 9.1.2.6 Status "Homing active"

In this function state the home position and the machine measuring system for the drive can be determined. ▶ [Homing](#) (☞ 164)

- ▶ The home position can be determined by an active homing or reference setting.
- ▶ A renewed determination of the home position is only required in case of recommissioning or in case of service (e.g. when drive components are exchanged) or after travel command have been executed which reset the reference.

## 9.1.2.7 Status "Positioning active"

In this function state all positioning types (absolute, relative, modulo, continuous, touch probe etc.) can be executed. ▶ [Positioning](#) (☞ 176)

- ▶ In the position-controlled mode, the drive executes a time-controlled point-to-point setpoint generation based on the defined motion profile.

## 9.1.2.8 Status "Setpoint follower active"

In this function state the drive directly follows the defined setpoint.

- ▶ The setpoint can optionally be specified as speed, torque or position via three separate basic functions:
  - [Speed follower](#) (☞ 190)
  - [Torque follower](#) (☞ 196)
  - [Position follower](#) (☞ 183)

## 9.1.2.9 Status "Quick stop active"

This function state is active if quick stop has been activated by the user. ▶ [Quick stop](#) (☞ 152)

- ▶ The drive is decelerated to standstill irrespective of the defined setpoint within the parameterised deceleration time.
- ▶ If quick stop is deactivated again by the user, it is changed to a setpoint-generating basic function (e.g. "speed follower"), if requested.



### Tip!

Quick stop can also be set as error response for many monitoring functions ("quick stop by trouble"). Detailed information can be found in the chapter "Diagnostics & fault analysis".

The source which activated the quick stop function is shown bit-coded in [C00159](#).

## 9.1.2.10 Status "Error"

This function state is active if an error has occurred and the controller is in the status "Error active" or "Quick stop by trouble active".

- ▶ The function state can only be abandoned by acknowledging the error if the error is removed.



## 9.1.2.11 Interrupting/replacing states

An active function state cannot be interrupted or replaced by the activation of another function state. However, the following exceptions apply:

- ▶ The "Initialisation" state replaces all other states.
- ▶ The "Error" state can replace all other states except "Initialisation".
- ▶ The status "Controller not ready" can replace all other states except "Error" and "Initialisation".
- ▶ The status "Quick stop active" can replace all other states except "Initialisation", "Error" and "Controller not ready".

## 9.1.2.12 Priorities

The function states are assigned to priorities so that, if several basic functions are activated at the same time, it is always changed to the function state with the highest priority:

Priority	Function state	Executable basic function
1	Initialisation	-
2	Error	-
3	Controller not ready	-
4	Quick stop active	▶ <a href="#">Quick stop</a> (☞ 152)
5	Manual jog active	▶ <a href="#">Manual jog</a> (☞ 156)
6	Homing active	▶ <a href="#">Homing</a> (☞ 164)
7	Positioning active	▶ <a href="#">Positioning</a> (☞ 176)
8	Setpoint follower (position) active	▶ <a href="#">Position follower</a> (☞ 183)
9	Setpoint follower (speed) active	▶ <a href="#">Speed follower</a> (☞ 190)
10	Setpoint follower (torque) active	▶ <a href="#">Torque follower</a> (☞ 196)
10	Brake check	▶ <a href="#">Brake control</a> (☞ 211)
12	Drive is stopped	▶ <a href="#">Standard stop</a> (☞ 148)

1 ≙ highest priority; 12 ≙ lowest priority



### Note!

The basic state "Drive in standstill" is accepted automatically if no other state is active.

## 9.1.3 Requesting control via a basic function

### Enable input "bEnable"

The basic functions "[Manual jog](#)", "[Homing](#)" and "[Positioning](#)" and the three setpoint followers each possess an enable input *bEnable*, via which the control of the corresponding basic function can be requested.

- ▶ If no other basic function and no error state is active, it is changed to the corresponding function state and the basic function can be controlled now.
- ▶ If several enable inputs are set to TRUE at the same time, the change to the function state is executed with the highest priority.

### Status outputs "bEnabled", "bActive" and "bDone"

If the basic function is enabled, the status output *bEnabled* of the basic function is set to TRUE and the corresponding drive motion can be started via the control inputs of the basic function.

- ▶ If the basic function executes a current drive motion, this is indicated through a TRUE signal at the status output *bActive*.
- ▶ The basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)" only have the status output *bEnabled*, since after the enable the drive follows the setpoint selection.
- ▶ The basic functions "[Homing](#)" and "[Positioning](#)" additionally are provided with a status output *bDone*, which display that the drive movement that was started (homing or positioning) has been completed.

Priority	Basic function	Status outputs		
		<i>bEnabled</i>	<i>bActive</i>	<i>bDone</i>
1	<a href="#">Manual jog</a>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
2	<a href="#">Homing</a>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
3	<a href="#">Positioning</a>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
4	<a href="#">Speed follower</a>	<input checked="" type="checkbox"/>		
5	<a href="#">Torque follower</a>	<input checked="" type="checkbox"/>		
6	<a href="#">Position follower</a>	<input checked="" type="checkbox"/>		

## Re-deactivation the enable of a basic function

When the enable input *bEnable* of the active basic function is reset to FALSE, the control inputs of the basic function are inhibited and the status outputs *bEnabled*, *bActive* and *bDone* are reset to FALSE.

- ▶ When the drive is not at standstill, it is decelerated to standstill within the deceleration time for [Standard stop](#) unless another basic function takes over the control of the drive. Here, the active function state is changed to the basic state "Drive in standstill" via the function state "Drive is stopped".
- ▶ When the enable input of another basic function is set to TRUE, this basic function adopts the control of the drive immediately.

## 9.2 Standard stop

The standard stop of the drive will be automatically activated by the internal state machine if a basic function is deactivated and the drive is not yet in standstill.

- ▶ The drive is braked to standstill via a parameterisable deceleration ramp.
  - While the drive is braked to standstill, the state machine is in the function state "Drive is stopped".
  - If meanwhile another basic function is activated, this basic function takes over the control of the drive from the current speed on and the function state "Drive is stopped" is abandoned.
  - If the drive is at standstill, it is automatically changed to the basic function "Drive in standstill".
- ▶ An acceleration phase active at the time of activating the stopping process is considered by the standard stop, i.e. the current acceleration is at first led to "0" with the parameterised S-ramp time before the real deceleration process starts.
- ▶ If the controller is enabled while the shaft is coasting (controller inhibit and pulse inhibit are deactivated), the drive is braked from the current speed to standstill.



### Stop!


The basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)" take over the control of the drive not from the current speed on but with the defined setpoint which may lead to a jerk!

## 9.2.1 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameter** → Dialog level *Overview* → *All basic functions* → *Stop*
- ▶ Short overview of parameters for standard stop :


Parameters	Information
<a href="#">C02610</a>	Deceleration time for stop
<a href="#">C02611</a>	S-ramp time for stop
<a href="#">C02612</a>	Ref. for decel. time of stop

### Parameter setting of stop




[9-2] Deceleration time referred to the motor reference speed

- ▶ The deceleration time set in [C02610](#) for stop refers to a speed variation from the motor reference speed ([C00011](#)) to standstill, i. e. the deceleration is constant.



[9-3] Deceleration time referred to the current speed

- ▶ When [C02612](#) is set = "1", the deceleration time refers to the current speed, i. e. the braking time is constant.



[9-4] S-shaped deceleration ramp through selection of a relative S-ramp time


- ▶ Through the entry of a S-ramp time in [C02611](#) an S-shaped deceleration ramp for jerk reduction can be set. This prolongs the total time to standstill by the selected S-ramp time.

- ▶ Braking time at motor reference speed or [C02612](#) = "1":

$$C02610 [s] + C02611 [s]$$

#### 9.2.2 Behaviour of the function (example)


In the following example the enable of manual jog is deactivated during an active manual jog. Then the drive is braked to standstill within the deceleration time ❶ set for stop:



[9-5]

Example: Stop with reaching standstill

If the basic function "Manual Jog" is reactivated within the deceleration time ❶, this basic function takes over the control of the drive from the current speed and the function state "Drive is stopped" is abandoned immediately:




[9-6]

Example: Stop without reaching standstill

## 9.2.3 System block "LS\_Stop"

The LS\_Stop system block in the function block editor maps the basic function "Stop".



### Outputs

Identifier DIS code   Data type	Value/meaning								
STP_dnState <a href="#">C02616</a>   DINT	<p>Status (bit-coded)</p> <ul style="list-style-type: none"> <li>When the basic function is not active, all bits are set to "0".</li> <li>Bits which are not listed are not assigned with a status (always "0").</li> </ul> <table border="1"> <tr> <td>Bit 1</td> <td>Drive is braked to standstill.                             <ul style="list-style-type: none"> <li>The internal state machine is in the function state "Drive is stopped".</li> </ul> </td> </tr> <tr> <td>Bit 2</td> <td>Drive is at standstill.                             <ul style="list-style-type: none"> <li>The internal state machine is in the function state "Drive in standstill".</li> </ul> </td> </tr> <tr> <td>Bit 3</td> <td>Deceleration phase is active.</td> </tr> <tr> <td>Bit 5</td> <td>CCW rotation is active.</td> </tr> </table>	Bit 1	Drive is braked to standstill. <ul style="list-style-type: none"> <li>The internal state machine is in the function state "Drive is stopped".</li> </ul>	Bit 2	Drive is at standstill. <ul style="list-style-type: none"> <li>The internal state machine is in the function state "Drive in standstill".</li> </ul>	Bit 3	Deceleration phase is active.	Bit 5	CCW rotation is active.
Bit 1	Drive is braked to standstill. <ul style="list-style-type: none"> <li>The internal state machine is in the function state "Drive is stopped".</li> </ul>								
Bit 2	Drive is at standstill. <ul style="list-style-type: none"> <li>The internal state machine is in the function state "Drive in standstill".</li> </ul>								
Bit 3	Deceleration phase is active.								
Bit 5	CCW rotation is active.								
STP_bStopActive <a href="#">C02617</a>   BOOL	<p>Status output "stop is active"</p> <table border="1"> <tr> <td>TRUE</td> <td>The drive is braked to standstill or is at standstill.                             <ul style="list-style-type: none"> <li>The internal state machine is in the function state "Drive is stopped" or in the function state "Drive in standstill".</li> </ul> </td> </tr> </table>	TRUE	The drive is braked to standstill or is at standstill. <ul style="list-style-type: none"> <li>The internal state machine is in the function state "Drive is stopped" or in the function state "Drive in standstill".</li> </ul>						
TRUE	The drive is braked to standstill or is at standstill. <ul style="list-style-type: none"> <li>The internal state machine is in the function state "Drive is stopped" or in the function state "Drive in standstill".</li> </ul>								

#### 9.3 Quick stop

Compared to the [Standard stop](#) quick stop (QSP) is determined for a stop in the case of an error. If quick stop is activated, the drive is braked to standstill irrespective of the defined setpoint within the deceleration time set.



#### Note!

Through this, superimposed controls (e.g. synchronous or position control) may produce following errors. If several drives execute a coordinated motion, the quick stop function should only be used for the motion master (master drive) in order to maintain the coordination.



#### Tip!

Quick stop can also be set as error response for many monitoring functions ("quick stop by trouble"). Detailed information can be found in the chapter "Diagnostics & fault analysis".

The source which activated the quick stop function is shown bit-coded in [C00159](#).


#### 9.3.1 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameter** → dialog level *Overview* → *All basic functions* → *Quick stop*
- ▶ Short overview of the parameters for quick stop:

Parameters	Information
<a href="#">C00105</a>	Quick stop deceleration time
<a href="#">C00106</a>	Quick stop S-ramp time
<a href="#">C00107</a>	Reference for "Quick stop" deceleration time




## Parameter setting of quick stop




[9-7] Deceleration time referred to the motor reference speed

- ▶ The deceleration time set in [C00105](#) for the quick stop function refers to a speed variation from the motor reference speed ([C00011](#)) to standstill.



[9-8] Deceleration time referred to the current speed

- ▶ When [C00107](#) is set = "1", the deceleration time refers to the current speed.



[9-9] S-shaped deceleration ramp through selection of a relative S-ramp time

- ▶ Through the entry of a relative S-ramp time in [C00106](#) an S-shaped deceleration ramp for jerk reduction can be set. This prolongs the total time to standstill by the selected S-ramp time.

- ▶ Braking time at motor reference speed or [C00107](#) = "1":

$$C00105 + \frac{C00105 \cdot C00106 [\%]}{100 \%}$$



### Tip!

After the drive has come to standstill, you can use the torque to hold the standstill position.

- For this purpose, select the phase controller gain in [C00254](#) > "0".
- With [C00254](#) > "0" the phase control is automatically activated after the standstill is reached.

#### 9.3.2 Activating/Deactivating quick stop

Quick stop through the application is activated/deactivated via the three inputs *QSP\_bActivate1...3* of the system block [LS Quickstop](#). (155)


- ▶ The three control inputs are linked via a logic OR gate, i.e. in order to activate quick stop, only one of the three inputs must be set to TRUE. To deactivate quick stop, though, all three inputs must be reset to FALSE.
- ▶ The control inputs can be linked with terminals (digital inputs) and/or process data in the function block editor.



#### Note!


In the standard technology applications the control input *QSP\_bActivate1* is linked with the digital input **DI1** in the Lenze setting.

#### Further options for activating quick stop

- ▶ Via controller command "Activate quick stop" ([C00002](#) = "45"), e.g. via a corresponding SDO of a higher-level control, an HMI or the »Engineer«.
- ▶ Via the  key at the keypad, unless the Lenze setting of [C00469](#) (assignment of the key) has been changed.
- ▶ Through the response "quick stop by trouble" parameterised for monitoring.

## 9.3.3 System block "LS\_quick stop"

The **LS\_quick stop** system block in the function block editor maps the basic function "Quick stop".



### Inputs

Identifier DIS code   data type	Information/possible settings
QSP_bActivate1 <a href="#">C02619/1</a>   BOOL	Activate quick stop <ul style="list-style-type: none"> <li>The three inputs are linked via a logic OR gate.</li> </ul>
QSP_bActivate2 <a href="#">C02619/2</a>   BOOL	
QSP_bActivate3 <a href="#">C02619/3</a>   BOOL	
	TRUE If one of the three inputs is set to TRUE, it is changed to the function state "Quick stop active" and the drive is braked to standstill within the deceleration time set for quick stop.
	TRUE↔FALSE When all three inputs are reset to FALSE, it is changed to a setpoint-generating basic function (e.g. "speed follower") via the function state "Drive is stopped".

### Outputs

Identifier DIS code   data type	Value/meaning
QSP_bActive <a href="#">C02619/4</a>   BOOL	Status output "quick stop is active"
	TRUE Quick stop is active.

#### 9.4 Manual jog

The basic function "Manual jog" serves to traverse the drive manually, e.g. to clean or exchange the tool.

- ▶ Optionally, you can change over to a second manual speed during the process.
- ▶ A "retracting" from operated travel range limit switches is also supported. Then, you can only traverse in the corresponding retracting direction.



#### Note!

In the manual mode the travel mode is monitored via limit switches and software limit positions by the basic function "[Limiter](#)". ([📖 200](#))



#### Stop!


When the reference is **not** known and **no** software limit positions are set, the drive can run into a mechanical limit during the manual jog and machine parts can be destroyed or damaged!

#### 9.4.1 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameter** → dialog level *Overview* → *All basic functions* → *Manual jog*
- ▶ Short overview of the parameters for manual jog:

Parameters	Information
<a href="#">C02620</a>	Manual jog speed 1
<a href="#">C02621</a>	Manual jog speed 2
<a href="#">C02622</a>	Manual acceleration
<a href="#">C02623</a>	Manual deceleration
<a href="#">C02624</a>	Inaccuracy time of manual traversing

## 9.4.1.1 Smooth start and quick stop of the drive



[9-10] Example: Smooth start and quick stop


- Different values for acceleration and deceleration can be set in [C02622/C02623](#) in order to implement a smooth start and a quick stop of the drive.
- By entering a relative S-ramp time in [C02624](#) both ramps can be set in S-shape for jerk reduction.



### Tip!

A quick deceleration ([C02623](#)) reduces the time from the release of the "Jog key" to the stop of the drive in order to ensure a better positioning of the drive according to one's sense of proportion and to prevent that the desired stop position is not overtravelled.

## 9.4.1.2 Second manual speed



[9-11] Example: Changeover to a second manual speed

- By setting the input *MAN\_bActivateJogSpeed2* to TRUE you can change over to a second manual speed ([C02621](#)) during the process.

#### 9.4.2 Executing manual jog

##### Requirements

- ▶ The controller is in the device state "Operation".
- ▶ The basic function "manual jog" is part of the active application.
- ▶ No other basic function is active.

##### Activation

To request the control via the basic function, the enable input *MAN\_bEnable* in the application must be set to TRUE.

- ▶ If no other basic function is active, it is changed to the function state "Manual jog active" and manual jog can be executed via the control inputs.
- ▶ A successful change to the function state "Manual jog active" is displayed by a TRUE signal at the status output *MAN\_bEnabled*.

##### Deactivation

If the enable input *MAN\_bEnable* is reset to FALSE, an active manual jog is reset, i.e. the control inputs for manual jog are inhibited and the drive is braked to standstill within the deceleration time for [Standard stop](#). (📖 148)

- ▶ The status output *MAN\_bEnabled* is reset to FALSE and a changeover from the active function state "Manual jog active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.

## 9.4.2.1 Manual jog in positive/negative direction

In the function state "Manual jog active" the drive can be traversed manually via the control inputs according to the following truth table:

MAN_bJogNegative	MAN_bJogPositive	MAN_bActivateJogSpeed2	Function
FALSE	FALSE	-	Stop <ul style="list-style-type: none"> <li>The drive is braked to standstill with the deceleration set.</li> </ul>
FALSE	TRUE	FALSE	Manual jog <ul style="list-style-type: none"> <li>In positive direction</li> <li>With manual speed 1</li> </ul>
		TRUE	Manual jog <ul style="list-style-type: none"> <li>In positive direction</li> <li>With manual speed 2</li> </ul>
TRUE	FALSE	FALSE	Manual jog <ul style="list-style-type: none"> <li>In negative direction</li> <li>With manual speed 1</li> </ul>
		TRUE	Manual jog <ul style="list-style-type: none"> <li>In negative direction</li> <li>With manual speed 2</li> </ul>
TRUE	TRUE	-	When both inputs are set to TRUE at the same time: <ul style="list-style-type: none"> <li>The drive is braked to standstill with the deceleration set.</li> </ul> When both inputs are not set to TRUE at the same time: <ul style="list-style-type: none"> <li>The drive continues to travel to the direction selected first.</li> </ul>



### Note!

In the standard technology applications "actuator – speed" and "actuator – torque" the control inputs are linked in the Lenze setting with the following digital inputs:

- **DI6:** Activate manual mode
- **DI7:** Manual jog in positive direction
- **DI8:** Manual jog in negative direction

## 9.4.2.2 Manual jog to limit position




### Note!

Detailed information on travel range monitoring via limit switches and software limit positions can be found in the description of the basic function "[Limiter](#)".

([📖 200](#))


### Manual jog to software limit position



[9-12] Example: Manual jog to positive software limit position

- ▶ When the reference is known and the software limit positions are set, a positioning to the corresponding software limit positions unless the manual jog has been manually stopped by resetting *MAN\_bJogNegative* or *MAN\_bJogPositive*.
- ▶ The drive brakes with the deceleration set ([C02623](#)) to the position of the corresponding software limit position.

### Manual jog to hardware limit position (limit switch)



[9-13] Example: Manual jog to positive limit switch

- ▶ When a limit switch is approached during manual jog, the drive is braked to standstill within the deceleration time set for the quick stop function.

See also:

- ▶ [Software limit positions](#) ([📖 202](#))
- ▶ [Hardware limit positions \(limit switch\)](#) ([📖 204](#))



### 9.4.2.3 Retracting of an activated limit switch

By setting *MAN\_bReleaseLimitSwitch* to TRUE a retraction from an activated limit switch is possible. Travel in the retracting direction until the limit switch is not active anymore.

- ▶ If, while retracting, a direction is selected additionally via the control inputs *MAN\_bJogPositive* or *MAN\_bJogNegative* towards the retracting direction, the travel is continued even the limit switch has been abandoned until *MAN\_bJogPositive* or *MAN\_bJogNegative* are reset to FALSE.
- ▶ If the direction is selected against the retracting direction, the drive stops and a corresponding status is output via the status output *MAN\_dnState* of the system block [LS ManualJog](#).



#### Note!

It can only be retracted from a limit switch if this is still activated, i.e. the corresponding limit switch input of the limiter is still active. Therefore ensure that while travelling towards a limit switch that the trigger mechanics will not be overtravelled by a too high mass or swing so that the limit switch will not be activated by this.



#### Tip!

An activated limit switch can also be abandoned by manual jog in retracting direction via the control inputs *MAN\_bJogPositive* or *MAN\_bJogNegative*.

See also: ▶ [Hardware limit positions \(limit switch\)](#) (📖 204)


# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Manual jog | System block "LS\_ManualJog"

## 9.4.3 System block "LS\_ManualJog"

The **LS\_ManualJog** system block in the function block editor maps the basic function "Manual jog".



### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings
MAN_bEnable <a href="#">C02639/1</a>   BOOL	Requesting control via the basic function TRUE If no other basic function is active, it is changed to the function state "Manual jog active" and manual jog can be executed via the control inputs. TRUE↘FALSE An active manual jog is stopped, i. e. a changeover from the active function state "Manual jog active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.
MAN_bJogPositive <a href="#">C02639/2</a>   BOOL	▶ <a href="#">Manual jog in positive/negative direction</a> (□ 159)
MAN_bJogNegative <a href="#">C02639/3</a>   BOOL	
MAN_bActivateJogSpeed2 <a href="#">C02639/4</a>   BOOL	Changeover to a second manual speed FALSE Manual speed 1 ( <a href="#">C02620</a> ) active. TRUE Manual speed 2 ( <a href="#">C02621</a> ) active.
MAN_bReleaseLimitSwitch <a href="#">C02639/5</a>   BOOL	Retracting of an activated limit switch TRUE Retracting from each activated limit switch towards the corresponding retracting direction until the limit switch is enabled again (not activated anymore) and the drive is located inside the software limit positions set. Afterwards the drive is braked to standstill with the deceleration set unless the control input <i>MAN_bJogPositive</i> or <i>MAN_bJogNegative</i> is activated for the corresponding retracting direction.

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning
MAN_dnState <a href="#">C02638</a>   DINT	Status (bit-coded) <ul style="list-style-type: none"> <li>When the basic function is not enabled, all bits are set to "0".</li> <li>Bits which are not listed are not assigned with a status (always "0").</li> </ul>
	Bit 1 Manual jog active
	Bit 2 Manual jog is completed.
	Bit 3 Acceleration/deceleration phase is active.
	Bit 5 CCW rotation is active.
	Bit 15 Error in basic function active (group signal).
	Bit 16 Stop by simultaneous selection of negative direction and retraction from limit switch.
	Bit 17 Stop by simultaneous selection of positive and negative direction.
	Bit 18 Stop by simultaneous selection of positive direction and retraction from limit switch.
	Bit 20 Manual speed 2 ( <a href="#">C02621</a> ) active.
	Bit 21 Manual speed 1 ( <a href="#">C02620</a> ) active.
	Bit 22 Stop by selecting positive direction and simultaneous activation of the positive software limit position or the positive limit switch.
	Bit 23 Stop by selecting negative direction and simultaneous activation of the negative software limit position or the negative limit switch.
	Bit 24 General abort process (ramp-down of the speed setpoint) <ul style="list-style-type: none"> <li>Takes place e.g. when a manual direction initiator is let go or due to an impermissible status (see bit 16, 17, 18, 22, 23).</li> </ul>
	Bit 25 Stopping is active.
Bit 30 Profile generation error.	
MAN_bEnabled <a href="#">C02639/6</a>   BOOL	Status output "Basic function is enabled"
	TRUE Manual jog via the control inputs is possible. <ul style="list-style-type: none"> <li>The enable input <i>MAN_bEnable</i> is set to TRUE and the controller is in the function state "Manual jog active".</li> </ul>
MAN_bActive <a href="#">C02639/7</a>   BOOL	Status output "Basic function is active"
	TRUE Manual jog is active (the drive axis is moving).

#### 9.5 Homing

The basic function "Homing" serves to transfer the measuring system to the physically possible travel range of the controller.

- ▶ The reference (e.g. zero position of the drive axis in the machine measuring system) can be defined by reference search or reference setting.
- ▶ In case of reference search, the drive travels according to the defined homing mode to detect the reference in the measuring system independently.
- ▶ In case of reference setting in the homing mode "100: Set reference directly" or via control input *HM\_bLoadHomePos* the drive can also be referenced manually when the motor is at standstill. The measuring system is set according to the home position parameterised in [C02642](#) or applied to the input *HM\_dnHomePos\_p*.



#### Note!

The encoder position is stored safe against mains failure in the memory module and is therefore known to the drive control even after the mains has been switched.

#### Behaviour of the home position after mains switching

If the home position/information is to be available after mains switching as well, the setting [C02652](#) = "1: Keep" is required.

- One further condition for keeping the home position/information after mains switching is the compliance with the maximally permissible angle of rotation of the encoder which can be set in [C02653](#).
- When resolvers or single-turn absolute value encoders are used and the mains is switched off (24-V supply off), the drive may only be moved by ½ motor revolution since otherwise the home position will get lost due to the ambiguity of the encoder information.

A renewed reference setting is only required in case of a renewed commissioning or in case of service (e.g. when drive components are exchanged).

## 9.5.1 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameter** → dialog level *Overview* → *All basic functions* → *Homing*
- ▶ Short overview of the parameters for homing:

Parameters	Information
<a href="#">C02528</a>	Traversing range
<a href="#">C02640</a>	Ref. mode
<a href="#">C02642</a>	HM position
<a href="#">C02643</a>	HM target position
<a href="#">C02644</a>	Ref. speed 1
<a href="#">C02645</a>	Home acceleration 1
<a href="#">C02646</a>	Ref. speed 2
<a href="#">C02647</a>	Ref. acceleration 2
<a href="#">C02648</a>	Home S-ramp time
<a href="#">C02649</a>	HM torque limit
<a href="#">C02650</a>	Homing inhibit time
<a href="#">C02651</a>	HM touch probe configuration
<a href="#">C02652</a>	Home position after mains switching
<a href="#">C02653</a>	Max. rot. angle after mains sw.
<a href="#">C02656</a>	Current position

### 9.5.1.1 Homing mode

The zero position, also called reference, can be defined by a reference search or reference setting:

- ▶ In case of a reference search the drive travels according to a defined mode to detect the reference independently.
- ▶ In case of reference setting the reference is manually set when the drive has stopped.



#### Tip!

A reference search is mainly used for continuous systems or if the traversing range or machine cycle of the drive cannot be displayed in the display space of the encoder, e.g. when incremental encoders are used on a motor or single-turn absolute value encoders or resolvers on geared motors.

Reference setting is usually executed only once during commissioning or in case of service (e.g. when drive components are exchanged) and are normally used in systems the machine cycle of which can be displayed in the display space of the encoder, e.g. when multi-turn absolute value encoder or single-turn absolute value encoders/resolvers are used in a machine cycle on one motor revolution.

- ▶ For reference setting, select the homing mode "100" in [C02640](#).
- ▶ The homing modes "0"..."15", which are described in detail in the following sections, are available for a reference search in [C02640](#).
  - Depending on the mode selected the following switches/sensors are evaluated:


Switch	Input for digital input signal
Reference switch	<i>HM_bHomingMark</i> on SB <a href="#">LS Homing</a>
Touch probe sensor	<i>DIGIN_bIn1</i> ... <i>DIGIN_bIn8</i> (or optional use of the motor encoder or load encoder zero pulse). Configuration: <a href="#">C02651</a> .
Positive travel range limit switch	<i>LIM_bLimitSwitchPositive</i> on SB <a href="#">LS Limiter</a>
Negative travel range limit switch	<i>LIM_bLimitSwitchNegative</i> on SB <a href="#">LS Limiter</a>



### Note!


In the homing modes 0...5 as well as 10 and 11, the search for the limit switch/reference switch is achieved by changing over to a higher speed than for approaching the encoder zero pulse/touch probe sensor. This serves to reduce the homing time and increase the accuracy.

After setting the home position the drive travels to the target position set in [C02643](#).




#### Operation of mode 0:

1. Movement in positive direction.
2. Negative edge at *HM\_bHomingMark* enables home position detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor set the reference.




#### Operation of mode 1:

1. Movement in negative direction.
2. Negative edge at *HM\_bHomingMark* enables home position detection.
3. The following positive edge of the encoder zero pulse/touch probe sensor set the reference.




### Operation of mode 2:

1. Movement in positive direction.
2. Reversing to positive travel range limit switch.
3. Negative edge at *HM\_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor set the reference.




### Operation of mode 3:

1. Movement in negative direction.
2. Reversing to negative travel range limit switch.
3. Negative edge at *HM\_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor set the reference.




### Operation of mode 4:

1. Movement in positive direction.
2. Reversing with positive edge at *HM\_bHomingMark*.
3. Negative edge at *HM\_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor set the reference.




### Operation of mode 5:

1. Movement in negative direction.
2. Reversing with positive edge at *HM\_bHomingMark*.
3. Negative edge at *HM\_bHomingMark* enables home position detection.
4. The following positive edge of the encoder zero pulse/touch probe sensor set the reference.




#### Operation of mode 8:

1. Movement in positive direction.
2. The following positive edge of the touch probe sensor set the reference.




#### Operation of mode 9:

1. Movement in negative direction.
2. The following positive edge of the touch probe sensor set the reference.




#### Operation of mode 10:

1. Movement in positive direction.
2. Reversing with positive edge of the positive travel range limit switch.
3. The following positive edge of the touch probe sensor set the reference.




#### Operation of mode 11:

1. Movement in negative direction.
2. Reversing with positive edge of the negative travel range limit switch.
3. The following positive edge of the touch probe sensor set the reference.



#### Operation of mode 12:

1. Movement in positive direction.
2. Positive edge of the travel range limit switch sets the reference.



#### Operation of mode 13:

1. Movement in negative direction
2. Positive edge of the travel range limit switch sets the reference.




#### Note!

In the homing modes 12 and 13 the load mechanics is able to leave the travel range limit switch. It is then travelled back to the home position which has been set with the positive edge of the travel range limit switch. The mechanics may possibly stop on an activated limit switch.


We recommend to set a reference offset to enable the travel range limit switch.





## Operation of mode 14:

1. Movement in positive direction with reduced torque.
2. The reference is set if the torque limit has been exceeded via a defined period of time ("homing to end stop").
  - If a reference offset is set, it is traversed by this offset with the correct sign and the reference is set at the end of this travel way.



## Operation of mode 15:

1. Movement in negative direction with reduced torque.
2. The reference is set if the torque limit has been exceeded via a defined period of time ("homing to end stop").
  - If a reference offset is set, it is traversed by this offset with the correct sign and the reference is set at the end of this travel way.

### 9.5.1.2 Home position & target position


When the home position is set during the reference search, the position detected in the machine measuring system corresponds to the value set in [C02642](#).

Afterwards the drive travels to the target position set in [C02643](#).

## 9.5.1.3 Second homing speed

For the homing modes 0...5 as well as 10 and 11 two different speeds can be parameterised to reduce the homing time and increase the accuracy:

- ▶ The higher speed set in [C02644](#) causes a quick approach of the limit switch/reference switch.
- ▶ After reversing to the limit switch/reference switch the encoder zero pulse/touch probe sensor is approached slower but more precisely with the lower speed set in [C02646](#).



### Example: Operation of mode 2:

- A. Movement in positive direction.
- B. Reversing to positive travel range limit switch.
- C. Negative edge at *HM\_bHomingMark* enables home position detection.
- D. The following positive edge of the encoder zero pulse (MP) sets the reference.
- E. Drive has reached defined target position.

## 9.5.1.4 Homing to end stop

By selecting the homing modes 14 & 15, homing to end stop can be executed as follows:

1. The drive travels with reduced torque in positive direction (mode 14) or negative direction (mode 15).
2. When the drives hits an end stop so that the torque limit set in [C02649](#) is exceeded for the period of time defined in [C02650](#), the reference is set.
  - When a reference offset is set, it is traversed by this offset with correct sign.

## 9.5.1.5 Connection of reference switch

For the homing modes with reference switch, the control input *HM\_bHomingMark* of the system block [LS Homing](#) must be connected to the digital input which is connected to the reference switch.

## 9.5.1.6 Touch probe interface configuration

The touch probe channel to be used for homing with touch probe detection is selected in the »Engineer« on the **Application parameter** tab in the *overview* → *dialog level*. *All basic functions* → *Homing* → *TP interface*.

- ▶ The setting carried out in this parameterisation dialog directly affects the setting of [C02651](#) ("Ref. touch probe configuration") and vice versa.
- ▶ For a direct setting of [C02651](#) (e.g. with keypad) the following table lists the decimal values for all possible configurations.

Selection Touch probe channel	Touch probe response		
	Positive edge	Negative edge	Both edges
DigIn 1	1	2	3
DigIn 2	4	8	12
DigIn 3	16	32	48
DigIn 4	64	128	192
DigIn 5	256	512	768
DigIn 6	1024	2048	3072
DigIn 7	4096	8192	12288
DigIn 8	16384	32768	49152
Motor encoder zero pulse	65536		
Load encoder zero pulse	262144		

- ▶ Example: For selecting the touch probe channel "DIGIN 8" and response to only one positive edge, it is required to set the decimal value "16384" in [C02651](#).

#### 9.5.2 Executing homing

##### Requirements

- ▶ The controller is in the device state "Operation".
- ▶ The basic function "Homing" is part of the active application.
- ▶ No other basic function is active.

##### Activation

To request the control via the basic function, the enable input *HM\_bEnable* in the application must be set to TRUE.

- ▶ If no other basic function is active, a changeover to the function state "Homing active" is effected and homing can be executed via the control inputs.
- ▶ A successful change to the function state "Homing active" is displayed by a TRUE signal at the status output *HM\_bEnabled*.

##### Deactivation

When the enable input *HM\_bEnable* is reset to FALSE, an active homing is stopped, i.e. the control inputs for homing are inhibited and the drive is braked to standstill within the deceleration time for stop.

- ▶ The status output *HM\_bEnabled* is reset to FALSE and a changeover from the active function state "Homing active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.

### 9.5.2.1 Setting reference search/setting reference directly

By setting the control input *HM\_bActivateHoming* to TRUE, the reference search in the selected homing mode is started.

- ▶ During reference search, the status output *HM\_bActive* is set to TRUE.
- ▶ When the reference search is completed, the status output *HM\_bActive* is reset to FALSE and the status output *HM\_bDone* is set to TRUE.
- ▶ When the home position could be detected, the status output *HM\_bHomePosAvailable* is set to TRUE.



#### Note!

In the homing mode "100: Set reference directly" no reference search will be started but the home position set in [C02642](#) will be directly accepted.

### 9.5.2.2 Loading home position via input

By setting the control input *HM\_bLoadHomePos* to TRUE the "tool position" applied to input *HM\_dnHomePos\_p* is accepted manually as home position with drive at standstill.

### 9.5.2.3 Resetting home position

By setting the control input *HM\_bResetHomePos* to TRUE the status "Reference known" is reset.

- ▶ The status outputs *HM\_bDone* and *HM\_bHomePosAvailable* are reset to FALSE.


# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Homing | System block "LS\_Homing"

## 9.5.3 System block "LS\_Homing"

The **LS\_Homing** system block in the function block editor maps the basic function "Homing".



### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings				
HM_bEnable <small>C02659/1   BOOL</small>	<p>Requesting control via the basic function.</p> <table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, a changeover to the function state "Homing active" is effected and homing can be executed via the control inputs.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>An active reference search is stopped, i. e. a changeover from the active function state "Homing active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.</td> </tr> </table>	TRUE	If no other basic function is active, a changeover to the function state "Homing active" is effected and homing can be executed via the control inputs.	TRUE↔FALSE	An active reference search is stopped, i. e. a changeover from the active function state "Homing active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.
TRUE	If no other basic function is active, a changeover to the function state "Homing active" is effected and homing can be executed via the control inputs.				
TRUE↔FALSE	An active reference search is stopped, i. e. a changeover from the active function state "Homing active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.				
HM_bActivateHoming <small>C02659/2   BOOL</small>	<p>Starting homing/directly setting reference</p> <table border="1"> <tr> <td>TRUE</td> <td>Reference search is started in the homing mode selected (<a href="#">C02640</a>). In the homing mode "100: Set reference directly" no reference search will be started but the home position set in <a href="#">C02642</a> will be directly accepted.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>Active reference search is completed.</td> </tr> </table>	TRUE	Reference search is started in the homing mode selected ( <a href="#">C02640</a> ). In the homing mode "100: Set reference directly" no reference search will be started but the home position set in <a href="#">C02642</a> will be directly accepted.	TRUE↔FALSE	Active reference search is completed.
TRUE	Reference search is started in the homing mode selected ( <a href="#">C02640</a> ). In the homing mode "100: Set reference directly" no reference search will be started but the home position set in <a href="#">C02642</a> will be directly accepted.				
TRUE↔FALSE	Active reference search is completed.				
HM_bHomingMark <small>C02659/3   BOOL</small>	<p>Input for reference switch</p> <table border="1"> <tr> <td>TRUE</td> <td>Reference switch is activated.</td> </tr> </table>	TRUE	Reference switch is activated.		
TRUE	Reference switch is activated.				
HM_bLoadHomePos <small>C02659/4   BOOL</small>	<p>Loading home position</p> <table border="1"> <tr> <td>FALSE↔TRUE</td> <td>The position applied to input <i>HM_dnHomePos_p</i> is accepted as home position.</td> </tr> </table>	FALSE↔TRUE	The position applied to input <i>HM_dnHomePos_p</i> is accepted as home position.		
FALSE↔TRUE	The position applied to input <i>HM_dnHomePos_p</i> is accepted as home position.				
HM_dnHomePos_p <small>C02658   DINT</small>	<p>Home position in [increments] for acceptance with <i>HM_bLoadHomePos</i></p>				
HM_bResetHomePos <small>C02659/5   BOOL</small>	<p>Resetting the status "Reference known"</p> <table border="1"> <tr> <td>FALSE↔TRUE</td> <td>                     The internal status "Reference known" is reset.                     <ul style="list-style-type: none"> <li>The status outputs <i>HM_bDone</i> and <i>HM_bHomePosAvailable</i> are reset to FALSE.</li> </ul> </td> </tr> </table>	FALSE↔TRUE	The internal status "Reference known" is reset. <ul style="list-style-type: none"> <li>The status outputs <i>HM_bDone</i> and <i>HM_bHomePosAvailable</i> are reset to FALSE.</li> </ul>		
FALSE↔TRUE	The internal status "Reference known" is reset. <ul style="list-style-type: none"> <li>The status outputs <i>HM_bDone</i> and <i>HM_bHomePosAvailable</i> are reset to FALSE.</li> </ul>				

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning																										
HM_dnState <a href="#">C02657</a>   DINT	<p>Status (bit-coded)</p> <ul style="list-style-type: none"> <li>When the basic function is not enabled, all bits are set to "0".</li> <li>Bits which are not listed are not assigned with a status (always "0").</li> </ul> <table border="1"> <tr><td>Bit 1</td><td>Reference search is active.</td></tr> <tr><td>Bit 2</td><td>Reference search is completed.</td></tr> <tr><td>Bit 3</td><td>Acceleration/deceleration phase is active.</td></tr> <tr><td>Bit 5</td><td>CCW rotation is active.</td></tr> <tr><td>Bit 7</td><td>Reference is known</td></tr> <tr><td>Bit 15</td><td>Error in basic function active (group signal).</td></tr> <tr><td>Bit 16</td><td>Pre-stop (home switch) has been detected.</td></tr> <tr><td>Bit 17</td><td>Touch probe/zero pulse has been detected.</td></tr> <tr><td>Bit 21</td><td>Profile data are limited by basic function "<a href="#">Limiter</a>".</td></tr> <tr><td>Bit 22</td><td>Traversing direction is inhibited by basic function "<a href="#">Limiter</a>".</td></tr> <tr><td>Bit 23</td><td>Abort by basic function "<a href="#">Limiter</a>".</td></tr> <tr><td>Bit 25</td><td>Stopping is active. (Homing is enable but not active or speed ≠ 0)</td></tr> <tr><td>Bit 30</td><td>Profile generation error.</td></tr> </table>	Bit 1	Reference search is active.	Bit 2	Reference search is completed.	Bit 3	Acceleration/deceleration phase is active.	Bit 5	CCW rotation is active.	Bit 7	Reference is known	Bit 15	Error in basic function active (group signal).	Bit 16	Pre-stop (home switch) has been detected.	Bit 17	Touch probe/zero pulse has been detected.	Bit 21	Profile data are limited by basic function " <a href="#">Limiter</a> ".	Bit 22	Traversing direction is inhibited by basic function " <a href="#">Limiter</a> ".	Bit 23	Abort by basic function " <a href="#">Limiter</a> ".	Bit 25	Stopping is active. (Homing is enable but not active or speed ≠ 0)	Bit 30	Profile generation error.
Bit 1	Reference search is active.																										
Bit 2	Reference search is completed.																										
Bit 3	Acceleration/deceleration phase is active.																										
Bit 5	CCW rotation is active.																										
Bit 7	Reference is known																										
Bit 15	Error in basic function active (group signal).																										
Bit 16	Pre-stop (home switch) has been detected.																										
Bit 17	Touch probe/zero pulse has been detected.																										
Bit 21	Profile data are limited by basic function " <a href="#">Limiter</a> ".																										
Bit 22	Traversing direction is inhibited by basic function " <a href="#">Limiter</a> ".																										
Bit 23	Abort by basic function " <a href="#">Limiter</a> ".																										
Bit 25	Stopping is active. (Homing is enable but not active or speed ≠ 0)																										
Bit 30	Profile generation error.																										
HM_bEnabled <a href="#">C02659/6</a>   BOOL	<p>Status output "Basic function is enabled"</p> <table border="1"> <tr> <td>TRUE</td> <td>Homing via the control inputs is possible. <ul style="list-style-type: none"> <li>The enable input <i>HM_bEnable</i> is set to TRUE and the controller is in the function state "Homing active".</li> </ul> </td> </tr> </table>	TRUE	Homing via the control inputs is possible. <ul style="list-style-type: none"> <li>The enable input <i>HM_bEnable</i> is set to TRUE and the controller is in the function state "Homing active".</li> </ul>																								
TRUE	Homing via the control inputs is possible. <ul style="list-style-type: none"> <li>The enable input <i>HM_bEnable</i> is set to TRUE and the controller is in the function state "Homing active".</li> </ul>																										
HM_bActive <a href="#">C02659/7</a>   BOOL	<p>Status output "Basic function is active"</p> <table border="1"> <tr> <td>TRUE</td> <td>Reference search is active (the drive axis is moving).</td> </tr> </table>	TRUE	Reference search is active (the drive axis is moving).																								
TRUE	Reference search is active (the drive axis is moving).																										
HM_bDone <a href="#">C02659/8</a>   BOOL	<p>Status output "Basic function is completed"</p> <table border="1"> <tr> <td>TRUE</td> <td>Reference search is completed. <ul style="list-style-type: none"> <li>Output is reset to FALSE when input <i>HM_bActivateHoming</i> is reset to FALSE.</li> </ul> </td> </tr> </table>	TRUE	Reference search is completed. <ul style="list-style-type: none"> <li>Output is reset to FALSE when input <i>HM_bActivateHoming</i> is reset to FALSE.</li> </ul>																								
TRUE	Reference search is completed. <ul style="list-style-type: none"> <li>Output is reset to FALSE when input <i>HM_bActivateHoming</i> is reset to FALSE.</li> </ul>																										
HM_bHomePosAvailable <a href="#">C02659/9</a>   BOOL	<p>Status output "Reference is known"</p> <table border="1"> <tr> <td>TRUE</td> <td>The drive knows the home position.</td> </tr> </table>	TRUE	The drive knows the home position.																								
TRUE	The drive knows the home position.																										

## 9.6 Positioning

The basic function "Positioning" provides the functions for executing the (travel) profiles and supports an "override" of speed and acceleration.

- ▶ A profile describes a motion request which can be implemented by the SB [LS Positioner](#) into a rotary motion.
- ▶ A profile is described via the following profile parameters: Mode (type of positioning), position, speed, acceleration, deceleration, S-ramp time, final speed, standard sequence profile, TP sequence profile, TP window starting and end position and touch probe signal source(s).

### 9.6.1 Parameter setting

A parameter setting is not required for the basic function "Positioning".

- ▶ After activating the function, the profile is executed which has been transferred to the basic function via the input *POS\_ProfileData*.
- ▶ For profiles with touch probe positioning mode (residual path positioning) touch probe is detected implicitly.

#### Options for selecting the profiles

For specifying as well as storing and managing (travel) profiles, the following function blocks are available:

Function block	Function
<b>L_PosPositionerTable</b>	...serves to file and manage up to 100 (travel) profiles and allows the "teaching" of positions, speed, acceleration/deceleration and S-ramp times. <ul style="list-style-type: none"><li>• Another important task of this FB is the conversion of the table values according to the scaling selected in the SB <a href="#">LS_DriveInterface</a>.</li></ul>
<b>L_PosProfileTable</b>	...serves to file and manage up to four (travel) profiles and allows the "teaching" of target positions. <ul style="list-style-type: none"><li>• In contrast to the FB <b>L_PosPositionerTable</b> this FB does not use any variable tables but the data of the profile parameters are entered directly into the assigned codes.</li><li>• Another special feature: When selecting the profile no. 1 as target position, the position applied to input <i>dnExtPos_p</i>.</li></ul>
<b>L_PosProfileInterface</b>	...provides a profile data record for the SB <a href="#">LS_Positioner</a> .



## 9.6.2 Carrying out positioning

### Requirements

- ▶ The controller is in the device state "Operation".
- ▶ The basic function "Positioning" is part of the active application.
- ▶ No other basic function is active.

### Activation

To request the control via the basic function, the enable input *POS\_bEnable* in the application must be set to TRUE.

- ▶ If no other basic function is active, a changeover to the function state "Positioning active" is effected and positioning can be executed via the control inputs.
- ▶ A successful change to the function state "Positioning active" is displayed by a TRUE signal at the status output *POS\_bEnabled*.

### Deactivation

When the enable input *POS\_bEnable* is reset to FALSE, an active homing is stopped, i.e. the control inputs for positioning are inhibited and the drive is braked to standstill within the deceleration time for stop.

- ▶ The status output *POS\_bEnabled* is reset to FALSE and a changeover from the active function state "Positioning active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.

#### 9.6.2.1 Starting positioning

By setting the control input *POS\_bStart* to TRUE positioning starts.

- ▶ The (travel) profile is executed which has been transferred to the basic function via the input *POS\_ProfileData*.

#### 9.6.2.2 Aborting/interrupting positioning

By setting the control input *POS\_bAbort* to TRUE, the active positioning can be aborted or interrupted.

- ▶ The current profile is not completed but braked to standstill with the deceleration defined in the profile data.
- ▶ When the control input *POS\_bAbort* is remained on TRUE, a restart or the continuation of an interrupted positioning process is inhibited.
- ▶ After resetting the control input *POS\_bAbort* to FALSE, a restart or the continuation of an interrupted positioning process is possible again.

#### 9.6.2.3 Continuing an interrupted positioning process

By setting the control input *POS\_bRestart* to TRUE an interrupted positioning process can be continued if the control input *POS\_bAbort* has been reset again to FALSE.

- ▶ Distance already covered in a relative positioning process will be considered.

#### 9.6.2.4 Activating override

"Override" is the change of profile parameters and their acceptance during the positioning process.

- ▶ When the input *POS\_bEnableOverride* is set to TRUE, a speed and acceleration override occurs according to the override values applied to the inputs *POS\_dnSpeedOverride\_n* and *POS\_dnAccOverride\_n*.
  - The override values represent percentage multipliers with regard to the current profile parameters for speed and acceleration.
  - For override values  $\leq 1\%$  a status bit is set.
  - Override values  $\leq 0\%$  are set internally to 0%.
  - Changes of the override values are accepted in each cycle.



#### Note!

The online change of speed and acceleration is effective from the profile start to the beginning of the deceleration phase. Thus, the deceleration phase cannot be changed via an override!

- In case of an override value of 0% for speed, the drive is braked to standstill.
- In case of an override value of 0% for acceleration, no acceleration takes place anymore.

- ▶ When the input *POS\_bEnableOverride* is reset to FALSE again, the speeds and accelerations defined via the profile parameters are executed again. The drive is immediately accelerated from the override speed to the speed set in the profile.


# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Positioning | System block "LS\_Positioner"

## 9.6.3 System block "LS\_Positioner"

The **LS\_Positioner** system block in the function block editor maps the basic function "Positioning".



### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings						
POS_bEnable <small>C02679/1   BOOL</small>	<p>Requesting control via the basic function</p> <table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, a changeover to the function state "Positioning active" is effected and positioning can be executed via the control inputs.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>An active positioning is stopped, i. e. a changeover from the active function state "Positioning active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.</td> </tr> </table>	TRUE	If no other basic function is active, a changeover to the function state "Positioning active" is effected and positioning can be executed via the control inputs.	TRUE↔FALSE	An active positioning is stopped, i. e. a changeover from the active function state "Positioning active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.		
TRUE	If no other basic function is active, a changeover to the function state "Positioning active" is effected and positioning can be executed via the control inputs.						
TRUE↔FALSE	An active positioning is stopped, i. e. a changeover from the active function state "Positioning active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.						
POS_bStart <small>C02679/2   BOOL</small>	<p>Starting positioning</p> <table border="1"> <tr> <td>FALSE↔TRUE</td> <td>The profile <i>POS_ProfileData</i> is executed.</td> </tr> <tr> <td>FALSE↔TRUE (once again)</td> <td>"Restart" <ul style="list-style-type: none"> <li>During an active positioning, another profile can be specified via the input <i>POS_ProfileData</i> which is executed after restart.</li> </ul> </td> </tr> </table>	FALSE↔TRUE	The profile <i>POS_ProfileData</i> is executed.	FALSE↔TRUE (once again)	"Restart" <ul style="list-style-type: none"> <li>During an active positioning, another profile can be specified via the input <i>POS_ProfileData</i> which is executed after restart.</li> </ul>		
FALSE↔TRUE	The profile <i>POS_ProfileData</i> is executed.						
FALSE↔TRUE (once again)	"Restart" <ul style="list-style-type: none"> <li>During an active positioning, another profile can be specified via the input <i>POS_ProfileData</i> which is executed after restart.</li> </ul>						
POS_bAbort <small>C02679/3   BOOL</small>	<p>Aborting or interrupting positioning</p> <table border="1"> <tr> <td>FALSE↔TRUE</td> <td>The current profile is not completed but braked to standstill with the deceleration defined in the profile data.</td> </tr> <tr> <td>TRUE</td> <td>A restart via <i>POS_bStart</i> or the continuation of an interrupted positioning via <i>POS_bRestart</i> is inhibited.</td> </tr> <tr> <td>FALSE</td> <td>A restart via <i>POS_bStart</i> or the continuation of an interrupted positioning via <i>POS_bRestart</i> is possible again. <ul style="list-style-type: none"> <li>If the restart signal <i>POS_bRestart</i> occurs during the acceleration phase, the positioning is continued immediately.</li> </ul> </td> </tr> </table>	FALSE↔TRUE	The current profile is not completed but braked to standstill with the deceleration defined in the profile data.	TRUE	A restart via <i>POS_bStart</i> or the continuation of an interrupted positioning via <i>POS_bRestart</i> is inhibited.	FALSE	A restart via <i>POS_bStart</i> or the continuation of an interrupted positioning via <i>POS_bRestart</i> is possible again. <ul style="list-style-type: none"> <li>If the restart signal <i>POS_bRestart</i> occurs during the acceleration phase, the positioning is continued immediately.</li> </ul>
FALSE↔TRUE	The current profile is not completed but braked to standstill with the deceleration defined in the profile data.						
TRUE	A restart via <i>POS_bStart</i> or the continuation of an interrupted positioning via <i>POS_bRestart</i> is inhibited.						
FALSE	A restart via <i>POS_bStart</i> or the continuation of an interrupted positioning via <i>POS_bRestart</i> is possible again. <ul style="list-style-type: none"> <li>If the restart signal <i>POS_bRestart</i> occurs during the acceleration phase, the positioning is continued immediately.</li> </ul>						
POS_bRestart <small>C02679/4   BOOL</small>	<p>Continuing an interrupted positioning process</p> <ul style="list-style-type: none"> <li>Only possible when <i>POS_bAbort</i> has been reset from TRUE to FALSE again.</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>The positioning interrupted before via <i>POS_bAbort</i> is completed. <ul style="list-style-type: none"> <li>Distance already covered in a relative positioning process will be considered.</li> </ul> </td> </tr> </table>	TRUE	The positioning interrupted before via <i>POS_bAbort</i> is completed. <ul style="list-style-type: none"> <li>Distance already covered in a relative positioning process will be considered.</li> </ul>				
TRUE	The positioning interrupted before via <i>POS_bAbort</i> is completed. <ul style="list-style-type: none"> <li>Distance already covered in a relative positioning process will be considered.</li> </ul>						
POS_ProfileData	<p>Pointer to the profile to be executed in internal units (increments)</p> <ul style="list-style-type: none"> <li>A profile chaining is caused by the pointer in the profile which points to the sequence profile.</li> </ul>						
POS_bEnableOverride <small>C02679/5   BOOL</small>	<p>Activating override</p> <table border="1"> <tr> <td>TRUE</td> <td>Override of speed and acceleration is active.</td> </tr> </table>	TRUE	Override of speed and acceleration is active.				
TRUE	Override of speed and acceleration is active.						

Identifier <small>DIS code   data type</small>	Information/possible settings		
POS_dnSpeedOverride_n <a href="#">C02677/1</a>   DINT	<p>Value of speed override</p> <ul style="list-style-type: none"> <li>• Percentage multiplier for the current profile parameter "Speed".</li> <li>• Changes are accepted in each cycle.</li> <li>• <math>2^{30} \equiv 100\%</math> of the speed defined in the profile.</li> <li>• In case of values <math>\leq 1\%</math> the status bit 18 is set.</li> <li>• Values <math>\leq 0\%</math> are set internally to 0% and let the drive be braked to standstill.</li> </ul>		
POS_dnAccOverride_n <a href="#">C02677/2</a>   DINT	<p>Value for acceleration override</p> <ul style="list-style-type: none"> <li>• Percentage multiplier for the current profile parameter "Acceleration".</li> <li>• Changes are accepted in each cycle.</li> <li>• <math>2^{30} \equiv 100\%</math> of the acceleration defined in the profile.</li> <li>• In case of values <math>\leq 1\%</math> the status bit 19 is set.</li> <li>• Values <math>\leq 0\%</math> are set internally to 0% ("no acceleration").</li> </ul>		
POS_bDisableTP <a href="#">C02679/6</a>   BOOL	<p>Deactivating touch probe positioning</p> <table border="1"> <tr> <td>TRUE</td> <td>Identified touch probes are ignored. It is not automatically changed to the TP sequence profile defined in the profile data.</td> </tr> </table>	TRUE	Identified touch probes are ignored. It is not automatically changed to the TP sequence profile defined in the profile data.
TRUE	Identified touch probes are ignored. It is not automatically changed to the TP sequence profile defined in the profile data.		

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning																																												
POS_dnState <a href="#">C02675</a>   DINT	<p>Status (bit-coded)</p> <ul style="list-style-type: none"> <li>• When the basic function is not enabled, all bits are set to "0".</li> <li>• Bits which are not listed are not assigned with a status (always "0").</li> </ul> <table border="1"> <tr><td>Bit 1</td><td>Positioning is active.</td></tr> <tr><td>Bit 2</td><td>Positioning is completed (all profiles are executed).</td></tr> <tr><td>Bit 3</td><td>Acceleration/deceleration phase is active.</td></tr> <tr><td>Bit 5</td><td>CCW rotation is active.</td></tr> <tr><td>Bit 6</td><td>Set position reached (in case of sequence profiles the drive continues to travel).</td></tr> <tr><td>Bit 10</td><td>Zero crossing in the positioning mode "modulo".</td></tr> <tr><td>Bit 15</td><td>Error in basic function active (group signal).</td></tr> <tr><td>Bit 16</td><td>Positioning is aborted.</td></tr> <tr><td>Bit 17</td><td>Reversing phase is active.</td></tr> <tr><td>Bit 18</td><td>Speed override <math>\leq 1\%</math></td></tr> <tr><td>Bit 19</td><td>Acceleration override <math>\leq 1\%</math></td></tr> <tr><td>Bit 20</td><td>Position is limited by basic function "<a href="#">Limiter</a>".</td></tr> <tr><td>Bit 21</td><td>Profile data are limited by basic function "<a href="#">Limiter</a>".</td></tr> <tr><td>Bit 22</td><td>Direction is inhibited by basic function "<a href="#">Limiter</a>".</td></tr> <tr><td>Bit 23</td><td>Abort by basic function "<a href="#">Limiter</a>".</td></tr> <tr><td>Bit 24</td><td>Home position is not known.</td></tr> <tr><td>Bit 25</td><td>Stopping is active.</td></tr> <tr><td>Bit 26</td><td>Cycle is not known.</td></tr> <tr><td>Bit 27</td><td>Invalid positioning mode.</td></tr> <tr><td>Bit 28</td><td>Invalid change of the positioning mode.</td></tr> <tr><td>Bit 29</td><td>Profile data is not plausible or faulty.</td></tr> <tr><td>Bit 30</td><td>Profile generation error.</td></tr> </table>	Bit 1	Positioning is active.	Bit 2	Positioning is completed (all profiles are executed).	Bit 3	Acceleration/deceleration phase is active.	Bit 5	CCW rotation is active.	Bit 6	Set position reached (in case of sequence profiles the drive continues to travel).	Bit 10	Zero crossing in the positioning mode "modulo".	Bit 15	Error in basic function active (group signal).	Bit 16	Positioning is aborted.	Bit 17	Reversing phase is active.	Bit 18	Speed override $\leq 1\%$	Bit 19	Acceleration override $\leq 1\%$	Bit 20	Position is limited by basic function " <a href="#">Limiter</a> ".	Bit 21	Profile data are limited by basic function " <a href="#">Limiter</a> ".	Bit 22	Direction is inhibited by basic function " <a href="#">Limiter</a> ".	Bit 23	Abort by basic function " <a href="#">Limiter</a> ".	Bit 24	Home position is not known.	Bit 25	Stopping is active.	Bit 26	Cycle is not known.	Bit 27	Invalid positioning mode.	Bit 28	Invalid change of the positioning mode.	Bit 29	Profile data is not plausible or faulty.	Bit 30	Profile generation error.
Bit 1	Positioning is active.																																												
Bit 2	Positioning is completed (all profiles are executed).																																												
Bit 3	Acceleration/deceleration phase is active.																																												
Bit 5	CCW rotation is active.																																												
Bit 6	Set position reached (in case of sequence profiles the drive continues to travel).																																												
Bit 10	Zero crossing in the positioning mode "modulo".																																												
Bit 15	Error in basic function active (group signal).																																												
Bit 16	Positioning is aborted.																																												
Bit 17	Reversing phase is active.																																												
Bit 18	Speed override $\leq 1\%$																																												
Bit 19	Acceleration override $\leq 1\%$																																												
Bit 20	Position is limited by basic function " <a href="#">Limiter</a> ".																																												
Bit 21	Profile data are limited by basic function " <a href="#">Limiter</a> ".																																												
Bit 22	Direction is inhibited by basic function " <a href="#">Limiter</a> ".																																												
Bit 23	Abort by basic function " <a href="#">Limiter</a> ".																																												
Bit 24	Home position is not known.																																												
Bit 25	Stopping is active.																																												
Bit 26	Cycle is not known.																																												
Bit 27	Invalid positioning mode.																																												
Bit 28	Invalid change of the positioning mode.																																												
Bit 29	Profile data is not plausible or faulty.																																												
Bit 30	Profile generation error.																																												

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Positioning | System block "LS\_Positioner"

Identifier DIS code   data type	Value/meaning
POS_bEnabled <a href="#">C02679/7</a>   BOOL	Status output "Basic function is enabled"  TRUE Positioning via the control inputs is possible. <ul style="list-style-type: none"> <li>The enable input <i>POS_bEnable</i> is set to TRUE and the controller is in the function state "Positioning active".</li> </ul>
POS_bActive <a href="#">C02679/8</a>   BOOL	Status output "Basic function is active"  TRUE Positioning is active (the drive axis is moving).
POS_bDone <a href="#">C02679/9</a>   BOOL	Status output "Basic function is completed"  TRUE Positioning is completed. <ul style="list-style-type: none"> <li>The profile is executed and no sequence profile is defined.</li> </ul>
POS_bInTarget <a href="#">C02679/10</a>   BOOL	Status output "Target position reached"  FALSE Positioning is still active or has been aborted.  TRUE The current position setpoint has reached the target position.
POS_dnSetPos_p <a href="#">C02678/1</a>   DINT	Current position setpoint in [increments] <ul style="list-style-type: none"> <li>Absolute positioning: point of reference is the home position.</li> <li>Relative positioning: point of reference is the starting position of the current profile.</li> </ul>
POS_dnProfileTarget_p <a href="#">C02678/2</a>   DINT	Target position of the current profile in [increments] <ul style="list-style-type: none"> <li>Absolute positioning: point of reference is the home position.</li> <li>Relative positioning: point of reference is the starting position of the current profile.</li> </ul>
POS_dnProfileSpeed_s <a href="#">C02676</a>   DINT	Current setpoint speed of the current profile as speed in [rpm] <ul style="list-style-type: none"> <li>In consideration of a speed override.</li> </ul>
POS_-dwActualProfileNumber <a href="#">C02674</a>   DWORD	Profile number (1 .... 100) of the current profile

## 9.7 Position follower

This basic function is used as setpoint interface for position-controlled drives.

- ▶ The specified position setpoint can either refer to the encoder on the motor side or to the (load) encoder used additionally to detect the machine position. The selection of the encoder configuration serves to adapt the internal control structure accordingly.
- ▶ Instead of a position setpoint a speed setpoint can be specified as well by a corresponding selection in [C02680](#). Then, the set position is calculated by integrating the speed setpoint based on the current actual position (relative positioning).
- ▶ As an option, an internal interpolation of the setpoints can be carried out in order to specify setpoints with reduced cycle rates without the drive behaviour being unsteady. The detection of the cycle rate and the synchronisation of the setpoint transfer is carried out automatically.
- ▶ If the direction of rotation of the motor must be inverted due to the mounting position of the motor or the existing gearbox ratio the use of the control signals can be changed over accordingly via parameter setting.
- ▶ The speed can also be precontrolled with the position setpoint by a corresponding selection in [C02681](#). Then, the speed is calculated by differentiation of the position setpoint.





**Internal variables of the motor control (oscilloscope signals)**

- The red numbers specified in the signal flow represent internal variables of the motor control, which can be recorded with the [Oscilloscope](#) for diagnostic and documentation purposes. ([□ 416](#))

No.	Variable or the motor control	Meaning
(1)	Torque.dnTotalTorqueAdd	Additive torque precontrol value
(2)	Torque.dnTorqueSetpoint	Torque setpoint
(3)	Position.dnActualLoadPos	Actual position
(4)	Position.dnPositionSetpoint	Position setpoint
(5)	Position.dnActualMotorPos	Current motor position
(6)	Position.dnContouringError	Following error
(7)	Speed.dnOutputPosCtrl	Output signal - phase controller
(8)	Speed.dnSpeedSetpoint	Speed setpoint
(9)	Speed.dnActualMotorSpeed	Current motor speed

## 9.7.2 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameter** → dialog level *Overview* → *All basic functions* → *Position follower*
- ▶ Short overview of the parameters for the position follower:

Parameters	Information
<a href="#">C00050/1</a>	Speed setpoint 1
<a href="#">C00070</a>	Speed controller gain
<a href="#">C00071</a>	Speed controller reset time
<a href="#">C00072</a>	D component - speed controller
<a href="#">C00273/1</a>	Motor moment of inertia
<a href="#">C00273/2</a>	Load moment of inertia
<a href="#">C00275</a>	Signal source speed setpoint
<a href="#">C00276</a>	Signal source torque setpoint
<a href="#">C00909/1</a>	Upper speed limit value
<a href="#">C00909/2</a>	Lower speed limit value
<a href="#">C02520</a>	Gearbox fact. numer. motor
<a href="#">C02521</a>	Gearbox fact. denom. motor
<a href="#">C02522</a>	Gearbox fact. numer. load
<a href="#">C02523</a>	Gearbox fact. denom. load
<a href="#">C02527</a>	Motor mounting direction
<a href="#">C02550/1</a>	Position setpoint interpolation
<a href="#">C02550/2</a>	Speed setpoint interpolation
<a href="#">C02550/3</a>	Torque setpoint interpolation
<a href="#">C02553</a>	Position controller gain
<a href="#">C02554</a>	Integral-action time of position controller
<a href="#">C02555</a>	D component of position controller
<a href="#">C02559</a>	Internal torque limit
<a href="#">C02680</a>	Source position setpoint
<a href="#">C02681</a>	Source add. speed

Highlighted in grey = display parameter

## 9.7.2.1 Setpoint interpolation

When the setpoint interpolation is activated, the motor control creates intermediate values to "smoothly" follow the setpoints which may be transferred from a slower task.

- ▶ [C02550/1](#) = "1": The motor control follows the position setpoint in interpolated steps.
- ▶ [C02550/2](#) = "1": The motor control follows the speed setpoint in interpolated steps.
- ▶ [C02550/3](#) = "1": The motor control follows the torque setpoint in interpolated steps.

## 9.7.2.2 Inversion of the direction of rotation

Depending on the motor mounting position the direction of rotation can be reversed, if required:

- ▶ [C02527](#) = "0": Clockwise motor ≡ positive machine direction.
- ▶ [C02527](#) = "1": Counter-clockwise motor ≡ positive machine direction.

## 9.7.3 Activating setpoint interface

### Requirements

- ▶ The controller is in the device state "Operation".
- ▶ The basic function "Position follower" is part of the active application.
- ▶ No other basic function is active.

### Activation

To request the control via the basic function, the enable input *PF\_bEnable* in the application must be set to TRUE.

- ▶ If no other basic function is active, it is changed to the function state "Position follower active". Setpoints can now be specified via the corresponding inputs. ▶ [Signal flow](#)
- ▶ A successful change to the function state "Position follower" is displayed by a TRUE signal at the status output *PF\_bEnabled*.



### Stop!

The basic function takes over the control of the drive not from the current speed on but directly with the defined setpoint which may lead to a jerk!


### Deactivation

When the enable input *PF\_bEnable* is reset to FALSE, the setpoint inputs are inhibited. If the drive is not at standstill, it is braked to standstill within the deceleration time set for stop unless another basic function takes over the control of the drive.

- ▶ The status output *PF\_bEnabled* is reset to FALSE and a changeover from the active function state "Position follower active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.

## 9.7.4 System block "LS\_PositionFollower"

The LS\_PositionFollower system block in the function block editor maps the basic function "Position follower".



### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings				
PF_bEnable <small>C02689/1   BOOL</small>	Requesting control via the basic function <table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, it is changed to the function state "Position follower active" and the defined setpoints are accepted.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a changeover from the active function state "Position follower active" via the function state "Drive is stopped" back to the basic state "drive in standstill" is effected.</td> </tr> </table>	TRUE	If no other basic function is active, it is changed to the function state "Position follower active" and the defined setpoints are accepted.	TRUE↔FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a changeover from the active function state "Position follower active" via the function state "Drive is stopped" back to the basic state "drive in standstill" is effected.
TRUE	If no other basic function is active, it is changed to the function state "Position follower active" and the defined setpoints are accepted.				
TRUE↔FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a changeover from the active function state "Position follower active" via the function state "Drive is stopped" back to the basic state "drive in standstill" is effected.				
PF_dnPositionSet_p <small>C02688/1   DINT</small>	Position setpoint in [increments]				
PF_dnSpeedAdd1_s <small>C02686   DINT</small>	Speed precontrol value in [rpm]				
PF_dnSpeedAdd2_n <small>C02687/1   DINT</small>	Additional speed setpoint in [%] • 100 % ≙ Motor reference speed (C00011)				
PF_dnAccAdd_x <small>C02685   DINT</small>	Motor acceleration • For calculating the acceleration torque (in case of setting C00276 = "0"). • Specified as speed variation/time in [rpm/s]				
PF_dnTorqueAdd_n <small>C02687/2   DINT</small>	Additive torque precontrol value in [%] • 100 % ≙ torque at maximum current (C00057/2).				

### Outputs


Identifier <small>DIS code   data type</small>	Value/meaning		
PF_bEnabled <small>C02689/2   BOOL</small>	Status output "Basic function is enabled" <table border="1"> <tr> <td>TRUE</td> <td>The defined setpoints are accepted.</td> </tr> </table>	TRUE	The defined setpoints are accepted.
TRUE	The defined setpoints are accepted.		

#### 9.8 Speed follower

This basic function is used as setpoint interface for speed-controlled drives.

- ▶ The motor control is automatically changed over to speed control with torque limitation.
- ▶ As an option, an internal interpolation of the setpoints can be carried out in order to specify setpoints with reduced cycle rates without the drive behaviour being unsteady. The detection of the cycle rate and the synchronisation of the setpoint transfer is carried out automatically.
- ▶ If the direction of rotation of the motor must be inverted due to the mounting position of the motor or the existing gearbox ratio the use of the control signals can be changed over accordingly via parameter setting.

## 9.8.1 Signal flow



[9-2] Signal flow - speed follower

### Internal variables of the motor control (oscilloscope signals)

- ▶ The red numbers specified in the signal flow represent internal variables of the motor control, which can be recorded with the [Oscilloscope](#) for diagnostic and documentation purposes. (416)

No.	Variable or the motor control	Meaning
(1)	Torque.dnTotalTorqueAdd	Additive torque precontrol value
(2)	Torque.dnTorqueSetpoint	Torque setpoint
(3)	Speed.dnTotalSpeedAdd	Additive speed setpoint
(4)	Speed.dnSpeedSetpoint	Speed setpoint
(5)	Speed.dnActualMotorSpeed	Current motor speed

See also:

- ▶ [Signal flow - motor interface](#) (95)
- ▶ [System block "LS\\_MotorInterface"](#) (104)

#### 9.8.2 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameter** → dialog level *Overview* → *All basic functions* → *Speed follower*
- ▶ Short overview of the parameters for the speed follower:

Parameters	Information
<a href="#">C00050/1</a>	Speed setpoint 1
<a href="#">C00070</a>	Speed controller gain
<a href="#">C00071</a>	Speed controller reset time
<a href="#">C00072</a>	D component - speed controller
<a href="#">C00273/1</a>	Motor moment of inertia
<a href="#">C00273/2</a>	Load moment of inertia
<a href="#">C00276</a>	Signal source torque setpoint
<a href="#">C00576</a>	Window - speed monitoring
<a href="#">C00579</a>	React. speed monitoring
<a href="#">C00909/1</a>	Upper speed limit value
<a href="#">C00909/2</a>	Lower speed limit value
<a href="#">C02520</a>	Gearbox fact. numer. motor
<a href="#">C02521</a>	Gearbox fact. denom. motor
<a href="#">C02522</a>	Gearbox fact. numer. load
<a href="#">C02523</a>	Gearbox fact. denom. load
<a href="#">C02527</a>	Motor mounting direction
<a href="#">C02531/3</a>	Resulting gearbox factor - motor/load
<a href="#">C02550/2</a>	Speed setpoint interpolation
<a href="#">C02550/3</a>	Torque setpoint interpolation
<a href="#">C02570</a>	Controller configuration
<a href="#">C02559</a>	Internal torque limit

Highlighted in grey = display parameter



## 9.8.2.1 Setpoint interpolation

When the setpoint interpolation is activated, the motor control creates intermediate values to "smoothly" follow the speed and/or torque setpoints which may be transferred from a slower task.

- ▶ [C02550/2](#) = "1": The motor control follows the speed setpoint in interpolated steps.
- ▶ [C02550/3](#) = "1": The motor control follows the torque setpoint in interpolated steps.

## 9.8.2.2 Inversion of the direction of rotation

Depending on the motor mounting position the direction of rotation can be reversed, if required:

- ▶ [C02527](#) = "0": Clockwise motor ≡ positive machine direction.
- ▶ [C02527](#) = "1": Counter-clockwise motor ≡ positive machine direction.

#### 9.8.3 Activating setpoint interface

##### Requirements

- ▶ The controller is in the device state "Operation".
- ▶ The basic function "Speed follower" is part of the active application.
- ▶ No other basic function is active.

##### Activation

To request the control via the basic function, the enable input *SF\_bEnable* in the application must be set to TRUE.

- ▶ If no other basic function is active, it is changed to the function state "Speed follower active" and the motor control is automatically switched to speed control with torque limitation. Setpoints can now be defined via the corresponding inputs. ▶ [Signal flow](#)
- ▶ A successful change to the function state "Speed follower active" is displayed by a TRUE signal at the status output *SF\_bEnabled*.



##### Stop!

The basic function takes over the control of the drive not from the current speed on but directly with the defined setpoint which may lead to a jerk!


##### Deactivation

When the enable input *SF\_bEnable* is reset to FALSE, the setpoint inputs are inhibited. If the drive is not at standstill, it is braked to standstill within the deceleration time set for stop unless another basic function takes over the control of the drive.

- ▶ The status output *SF\_bEnabled* is reset to FALSE and a changeover from the active function state "Speed follower active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.

## 9.8.4 System block "LS\_SpeedFollower"

The **LS\_SpeedFollower** system block in the function block editor maps the basic function "Speed follower".



### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings				
SF_bEnable <a href="#">C02695/1</a>   BOOL	Requesting control via the basic function <table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, it is changed to the function state "Speed follower active" and the defined setpoints are accepted.</td> </tr> <tr> <td>TRUE⇒FALSE</td> <td>If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a changeover from the active function state "Speed follower active" via the function state "Drive is stopped" back to the basic state "drive in standstill" is effected.</td> </tr> </table>	TRUE	If no other basic function is active, it is changed to the function state "Speed follower active" and the defined setpoints are accepted.	TRUE⇒FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a changeover from the active function state "Speed follower active" via the function state "Drive is stopped" back to the basic state "drive in standstill" is effected.
TRUE	If no other basic function is active, it is changed to the function state "Speed follower active" and the defined setpoints are accepted.				
TRUE⇒FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a changeover from the active function state "Speed follower active" via the function state "Drive is stopped" back to the basic state "drive in standstill" is effected.				
SF_dnSpeedSet_n <a href="#">C02694/1</a>   DINT	Speed setpoint in [%] • 100 % ≙ Motor reference speed ( <a href="#">C00011</a> )				
SF_dnSpeedAdd_s <a href="#">C02693</a>   DINT	Additive speed setpoint in [rpm] • Without position control function.				
SF_dnAccAdd_x <a href="#">C02692</a>   DINT	Motor acceleration • For calculating the acceleration torque (in case of setting <a href="#">C00276</a> = "0"). • Specified as speed variation/time in [rpm/s]				
SF_dnTorqueAdd_n <a href="#">C02694/2</a>   DINT	Additive torque precontrol value in [%] • 100 % ≙ torque at maximum current ( <a href="#">C00057/2</a> ).				

### Outputs


Identifier <small>DIS code   data type</small>	Value/meaning		
SF_bEnabled <a href="#">C02695/2</a>   BOOL	Status output "Basic function is enabled" <table border="1"> <tr> <td>TRUE</td> <td>The defined setpoints are accepted.</td> </tr> </table>	TRUE	The defined setpoints are accepted.
TRUE	The defined setpoints are accepted.		

## 9.9 Torque follower

This basic function is used as setpoint interface for torque-controlled drives.

- ▶ The motor control is automatically changed over to torque control with speed limitation.
- ▶ As an option, an internal interpolation of the torque setpoint can be carried out in order to specify the setpoint with reduced cycle rates without the drive behaviour being unsteady. The detection of the cycle rate and the synchronisation of the setpoint transfer is carried out automatically.
- ▶ If the direction of rotation of the motor must be inverted due to the mounting position of the motor or the existing gearbox ratio the use of the control signals can be changed over accordingly via parameter setting.

### 9.9.1 Signal flow



[9-3] Signal flow - torque follower

### Internal variables of the motor control (oscilloscope signals)

- ▶ The red numbers specified in the signal flow represent internal variables of the motor control, which can be recorded with the [Oscilloscope](#) for diagnostic and documentation purposes. (416)

No.	Variable or the motor control	Meaning
(1)	Speed.dnSpeedSetpoint	Speed setpoint
(2)	Speed.dnActualMotorSpeed	Current motor speed

See also:

- ▶ [Signal flow - motor interface](#) (95)
- ▶ [System block "LS MotorInterface"](#) (104)

## 9.9.2 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameter** → dialog level *Overview* → *All basic functions* → *Torque follower*
- ▶ Short overview of the parameters for the torque follower:

Parameters	Information
<a href="#">C00050/1</a>	Speed setpoint 1
<a href="#">C00050/2</a>	Speed setpoint 2
<a href="#">C00070</a>	Speed controller gain
<a href="#">C00071</a>	Speed controller reset time
<a href="#">C00909/1</a>	Upper speed limit value
<a href="#">C00909/2</a>	Lower speed limit value
<a href="#">C02527</a>	Motor mounting direction
<a href="#">C02550/2</a>	Speed setpoint interpolation
<a href="#">C02550/3</a>	Torque setpoint interpolation
<a href="#">C02559</a>	Internal torque limit

Highlighted in grey = display parameter

### 9.9.2.1 Setpoint interpolation

When the setpoint interpolation is activated, the motor control creates intermediate values to "smoothly" follow the speed and/or torque setpoints which may be transferred from a slower task.

- ▶ [C02550/2](#) = "1": The motor control follows the speed setpoint in interpolated steps.
- ▶ [C02550/3](#) = "1": The motor control follows the torque setpoint in interpolated steps.

### 9.9.2.2 Inversion of the direction of rotation

Depending on the motor mounting position the direction of rotation can be reversed, if required:

- ▶ [C02527](#) = "0": Clockwise motor ≡ positive machine direction.
- ▶ [C02527](#) = "1": Counter-clockwise motor ≡ positive machine direction.

#### 9.9.3 Activating setpoint interface

##### Requirements

- ▶ The controller is in the device state "Operation".
- ▶ The basic function "Torque follower" is part of the active application.
- ▶ No other basic function is active.

##### Activation

To request the control via the basic function, the enable input *TF\_bEnable* in the application must be set to TRUE.

- ▶ If no other basic function is active, it is changed to the function state "Torque follower active" and the motor control is automatically switched to torque control with speed limitation. Setpoints can now be defined via the corresponding inputs. ▶ [Signal flow](#)
- ▶ A successful change to the function state "Torque follower active" is displayed by a TRUE signal at the status output *TF\_bEnabled*.



##### Stop!

The basic function takes over the control of the drive not from the current speed on but directly with the defined setpoint which may lead to a jerk!


##### Deactivation

When the enable input *TF\_bEnable* is reset to FALSE, the setpoint inputs are inhibited. If the drive is not at standstill, it is braked to standstill within the deceleration time set for stop unless another basic function takes over the control of the drive.

- ▶ The status output *TF\_bEnabled* is reset to FALSE and a changeover from the active function state "Torque follower active" via the function state "Drive is stopped" back to the basic state "Drive in standstill" is effected.

## 9.9.4 System block "LS\_TorqueFollower"

The **LS\_TorqueFollower** system block in the function block editor maps the basic function "Torque follower".



### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings				
TF_bEnable <a href="#">C02699/1</a>   BOOL	Requesting control via the basic function <table border="1"> <tr> <td>TRUE</td> <td>If no other basic function is active, it is changed to the function state "Torque follower active" and the defined setpoints are accepted.</td> </tr> <tr> <td>TRUE⇒FALSE</td> <td>If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a changeover from the active function state "Torque follower active" via the function state "Drive is stopped" back to the basic state "drive in standstill" is effected.</td> </tr> </table>	TRUE	If no other basic function is active, it is changed to the function state "Torque follower active" and the defined setpoints are accepted.	TRUE⇒FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a changeover from the active function state "Torque follower active" via the function state "Drive is stopped" back to the basic state "drive in standstill" is effected.
TRUE	If no other basic function is active, it is changed to the function state "Torque follower active" and the defined setpoints are accepted.				
TRUE⇒FALSE	If no other basic function takes over the control of the drive, the drive is brought to standstill, i. e. a changeover from the active function state "Torque follower active" via the function state "Drive is stopped" back to the basic state "drive in standstill" is effected.				
TF_dnTorqueSet_n <a href="#">C02698/1</a>   DINT	Torque setpoint in [%] • 100 % ≙ torque at maximum current ( <a href="#">C00057/2</a> ).				
TF_dnSpeedHighLimit_n <a href="#">C02698/2</a>   DINT	Upper speed limit value in [%] for speed limitation • For positive direction of motion. • 100 % ≙ Motor reference speed ( <a href="#">C00011</a> ). • Negative values are limited internally to the value "0".				
TF_dnSpeedLowLimit_n <a href="#">C02698/3</a>   DINT	Lower speed limit value in [%] for speed limitation • For negative direction of motion. • 100 % ≙ Motor reference speed ( <a href="#">C00011</a> ). • Positive values are limited internally to the value "0".				

### Outputs

Identifier <small>DIS code   data type</small>	Value/meaning		
TF_bEnabled <a href="#">C02699/2</a>   BOOL	Status output "Basic function is enabled" <table border="1"> <tr> <td>TRUE</td> <td>The defined setpoints are accepted.</td> </tr> </table>	TRUE	The defined setpoints are accepted.
TRUE	The defined setpoints are accepted.		

#### 9.10 Limiter

The basic function "Limiter" monitors the travel range limits via limit switches and parameterised software limit positions and can lead the drive to defined limit ranges when being asked accordingly by the safety module.



#### Note!

In order that the basic function "Limiter", **after being asked accordingly by the safety module**, can lead the drive to the defined limit ranges before the limits set for the safety module are reached which stops the drive, the limit values for the basic function "Limiter" must be set lower than the limit values for the safety module!



#### Danger!

The safety is exclusively ensured by the safety module!

When the request for the safety function is cancelled, the drive restarts automatically.

Ensure by external measures that the drive only starts after a confirmation (EN 60204).

See also:

▶ [Safety engineering](#) (📖 135)



## 9.10.1 Parameter setting

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameter** → dialog level *Overview* → *All basic functions* → *Limiter*
- ▶ Short overview of the parameters for the limiter:

Parameters	Information
<a href="#">C02700</a>	Software limit positions are active
<a href="#">C02701/1</a>	Positive software limit position
<a href="#">C02701/2</a>	Negative software limit position
<a href="#">C02702</a>	Limitations effective
<a href="#">C02703</a>	Max. speed
<a href="#">C02704</a>	Max. speed (display in [rpm])
<a href="#">C02705</a>	Max. acceleration
<a href="#">C02706</a>	Min. S-ramp time
<a href="#">C02707</a>	Permissible direction of rotation
<a href="#">C02708/1...4</a>	Limited speed 1 .... 4
<a href="#">C02709/1...4</a>	Limited speed 1 .... 4 (display in [rpm])
<a href="#">C02710/1...4</a>	Delay lim. speed. 1 .... 4
<a href="#">C02711/1...4</a>	S-ramp time lim. speed. 1 .... 4
<a href="#">C02712/1...4</a>	Dec. time lim. speed. 1 .... 4
<a href="#">C02713</a>	Max. path - manual jog
<a href="#">C02714</a>	Max. path - manual jog (display in [increments])
<a href="#">C02715</a>	Active limitation (status display)
<a href="#">C02716/1</a>	Resp. to rotation limitation
<a href="#">C02716/2</a>	Resp. to SW limit pos. excess
<a href="#">C02716/3</a>	Resp. to max. value excess

Highlighted in grey = display parameter



### Note!

The safety module has its own parameters.

Relevant to the basic function "Limiter" are the parameters of the safety modules for setting "Limited direction of rotation", "speed with time limit" and "Limited increment (position)".

Several other parameters of the safety module, however, do not have another meaning for the basic function "Limiter", e.g. the parameters for configuring the inputs of the safety module.

## 9.10.1.1 Software limit positions

The software limit positions serve to limit the travel range by means of software and prevent that travel commands are executed which would cause an exit of the permissible travel range.



### Note!


The software limit positions are only evaluated and monitored if the drive knows the home position and the software limit positions are active ([C02700](#) = "1").

- When the traversing range is limited ([C02528](#) = "1") the software limit positions are basically monitored with regard to the internal value range that can be maximally displayed ( $\pm 2^{31}$  increments) even if the monitoring mode is deactivated.
- In case of the "Modulo" traversing range ([C02528](#) = "2") the software limit positions are not effective.

The software limit positions are not effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)".

- When the software limit positions are exceeded, it is only displayed via the status output *LIM\_dnState*.
- If a response is to take place (e.g. "fault" or "quick stop by trouble"), this must be set accordingly in [C02716/2](#).

- ▶ The positive software limit positions are set in [C02701/1](#) and the negative software limit positions are set in [C02701/2](#).




[9-4] Example: Traversing range limitation by software limit position



## Note!

When the drive is outside the permissible travel range and the software limit positions are switched effectively, only those travel commands can be executed which cause the drive to traverse back into the permissible travel range.




[9-5] Example: Permissible traversing direction with effective software limit positions

See also: ▶ [Manual jog to limit position](#) (160)

## 9.10.1.2 Hardware limit positions (limit switch)

The travel range limits are monitored via limit switch inputs *LIM\_bLimitSwitchPositive* and *LIM\_bLimitSwitchNegative* of the SB *LS\_Limiter*.

Both inputs react to the TRUE status and must be connected to the corresponding digital inputs which are connected with the limit switches.



[9-6] Example: Connection of the travel range limit switches to the digital inputs 3 & 4

- ▶ If the limit switch is activated, the drive axis is stopped automatically and a changeover via the function state "Drive is stopped" to the function state "Error" is effected.
- ▶ An error is caused via an internal system interface and entered in to the logbook of the controller. The drive can only be traversed again when the error is acknowledged.
- ▶ An activated limit switch can be retracted using the function "Retracting the limit switch". ▶ [Retracting of an activated limit switch](#) (📖 161)
- ▶ When the limit switches are connected to the distributed terminals, both inputs *LIM\_bLimitSwitchPositive* and *LIM\_bLimitSwitchNegative* of the SB *LS\_Limiter* can be connected via a bus system (e.g. system bus) with the distributed terminal.



### Note!

If digital inputs for connecting the limit switch are to be fail-safe (activation at LOW level), simply change the terminal polarity of the corresponding digital inputs in [C00114](#).

See also: ▶ [Manual jog to limit position](#) (📖 160)

### 9.10.1.3 Limitations

Limit values for the basic functions "[Manual jog](#)", "[Homing](#)" and "[Positioning](#)" can be set via the following parameters:

Parameters	Information
<a href="#">C02703</a>	Max. speed <ul style="list-style-type: none"> <li>• Max. permissible speed that can be driven by the system.</li> <li>• This parameter depends, among other things, by the max. motor speed.</li> </ul>
<a href="#">C02705</a>	Max. acceleration <ul style="list-style-type: none"> <li>• Max. permissible acceleration or deceleration for positioning procedures.</li> <li>• This parameter depends, among other things, on the motor torque and moment of inertia of the entire mechanics which is driven during the positioning process.</li> </ul>
<a href="#">C02706</a>	Min. S-ramp time
<a href="#">C02707</a>	Permissible direction of rotation
<a href="#">C02713</a>	Max. path - manual jog

- ▶ The parameters depend on the mechanics (e.g. the tool used).
- ▶ Usually the parameters must be changed when a tool is exchanged, e.g. by means of a recipe management of a superimposed control or via an HMI ("*Human Machine Interface*").



#### Note!

In order that the limit values set are effective, "1" must be selected in [C02702](#).

- Irrespective of this setting the speed setpoint is basically limited to the motor reference speed ([C00011](#))!

The limitations are not effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" und "[Position follower](#)"!

- In case of these basic functions only speed and acceleration are monitored.
- When the limit values for speed and acceleration are exceeded, the response parameterised in [C02716/3](#) takes place (Lenze setting: No response).
- **Background:** The setpoint followers in technology applications which are synchronised via an electrical shaft may not be limited since this may cause the synchronism to get lost. A possible consequence would be a collision of tools.

### Response if limit values are exceeded

When the limit values are switched effectively and a set limit value is exceeded, the following reactions occur:

- ▶ The setpoints of the active basic function ("[Manual jog](#)", "[Homing](#)" or "[Positioning](#)") are changed (limited).
- ▶ Via the output *LIM\_dnState* of the SB [LS Limiter](#) a corresponding status is output.
- ▶ The display parameter [C02714](#) is set to "1" ("limitation is active").
- ▶ The response parameterised in [C02716/3](#) is activated (Lenze setting: "No response").

#### 9.10.1.4 Limited speed

"Limited speeds" for the basic functions "[Manual jog](#)", "[Homing](#)" and "[Positioning](#)" can be set via the following parameters:

Parameters	Information
<a href="#">C02708/1...4</a>	Limited speed 1 .... 4
<a href="#">C02710/1...4</a>	Delay lim. speed. 1 .... 4
<a href="#">C02711/1...4</a>	S-ramp time lim. speed. 1 .... 4
<a href="#">C02712/1...4</a>	Dec. time lim. speed. 1 .... 4



#### Note!

The limited speeds are not effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)"!

#### Request "Limited speed"

"Limited speed 1 ... 4" is requested via the input *LIM\_dwControl* of the SB [LS Limiter](#) and normally through the control word of the safety module.


- ▶ If no safety module is available, the control word for the input *LIM\_dwControl* can also be generated by means of a converter.
- ▶ Via the input *LIM\_bActivateLimitedSpeed1* of the SB [LS Limiter](#) the "Limited speed 1" can be requested additionally, e.g. via a digital input connected to this input.

#### Process example: "Manual jog"

1. Manual jog in positive direction is active and the manual speed is higher than the "Limited speed 1" set.
2. Via the control word of the safety module the "Limited speed 1" is requested.
3. The drive is decelerated to the "Limited speed 1" with the deceleration and S-ramp time set for the "Limited speed 1".
4. At the same time a corresponding status is output via the output *LIM\_dnState* des SB [LS Limiter](#).

## 9.10.2 Control word of the safety module

To provide an easy connection of the safety module to the application the currently valid safety requirement is transferred to the following interface using a bit-coded control word:




[9-7] Interface to connect the safety module to the basic function "Limiter"

- ▶ It is also possible to make several requirements at the same time via the control word, e.g. manual jog with limited increment and limited speed 2.
- ▶ If no safety module is connected, the control word can be generated by means of a converter module.
- ▶ The bit coding of the control word is described in the "safety engineering" chapter.
  - ▶ [Control word of the safety module SM3xx](#) (📖 137)



## 9.10.3 System block "LS\_Limiter"

The LS\_Limiter system block in the function block editor maps the basic function "Limiter".



### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings
LIM_dwControl <a href="#">C02717</a>   DWORD	Interface to the safety module <ul style="list-style-type: none"> <li>Connect this input with the output <i>SM_dwControl</i> of the LS_SafetyModule system block.</li> <li>▶ <a href="#">System block "LS_SafetyModule"</a> (📖 139)</li> </ul>
LIM_bLimitSwitchPositive <a href="#">C02719/1</a>   BOOL	Input for positive travel range limit switch TRUE   Limit switch is activated.
LIM_bLimitSwitchNegative <a href="#">C02719/2</a>   BOOL	Input for negative travel range limit switch TRUE   Limit switch is activated.
LIM_bActivateLimitedSpeed1 <a href="#">C02719/3</a>   BOOL	Request limited speed 1 <ul style="list-style-type: none"> <li>If a setpoint follower is active, no limitation takes place, but an exceeding of the limit values is displayed via the output <i>LIM_dnState</i>.</li> </ul> TRUE   Request limited speed 1.

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Limiter | System block "LS\_Limiter"

## Outputs

Identifier DIS code   data type	Value/meaning																																						
LIM_dnState <a href="#">C02718</a>   DINT	Status word (bit coded) <ul style="list-style-type: none"> <li>• Bits which are not listed are not assigned with a status (always "0").</li> </ul> <table border="1"> <tr> <td>Bit 0</td> <td>Controller inhibit is initiated. (Safe torque off is requested.)</td> </tr> <tr> <td>Bit 1</td> <td>Quick stop is initiated. (Safe stop 1 is requested.)</td> </tr> <tr> <td>Bit 2</td> <td>Quick stop is initiated. (Safe stop 2 is requested.)</td> </tr> <tr> <td>Bit 3</td> <td>Profile change due to speed limitation. (Limited speed 1 is requested.)</td> </tr> <tr> <td>Bit 4</td> <td>Profile change due to speed limitation. (Limited speed 2 is requested.)</td> </tr> <tr> <td>Bit 5</td> <td>Profile change due to speed limitation. (Limited speed 3 is requested.)</td> </tr> <tr> <td>Bit 6</td> <td>Profile change due to speed limitation. (Limited speed 4 is requested.)</td> </tr> <tr> <td>Bit 7</td> <td>Only positive direction of rotation is permissible.                             <ul style="list-style-type: none"> <li>• When the direction of rotation is negative while requesting "Only positive direction of rotation", the drive is braked to standstill.</li> </ul> </td> </tr> <tr> <td>Bit 8</td> <td>Only negative direction of rotation is permissible.                             <ul style="list-style-type: none"> <li>• When the direction of rotation is negative while requesting "Only negative direction of rotation", the drive is braked to standstill.</li> </ul> </td> </tr> <tr> <td>Bit 10</td> <td>Increment in manual jog mode is limited.</td> </tr> <tr> <td>Bit 12</td> <td>Limitation of the set position is active.</td> </tr> <tr> <td>Bit 16</td> <td>Positive limit switch inhibits travel in positive direction.</td> </tr> <tr> <td>Bit 17</td> <td>Negative limit switch inhibits travel in positive direction.</td> </tr> <tr> <td>Bit 18</td> <td>Positive software limit position inhibits travel in positive direction.</td> </tr> <tr> <td>Bit 19</td> <td>Negative software limit position inhibits travel in negative direction.</td> </tr> <tr> <td>Bit 20</td> <td>Limitation of speed is active.</td> </tr> <tr> <td>Bit 21</td> <td>Limitation of acceleration is active.</td> </tr> <tr> <td>Bit 22</td> <td>Limitation of deceleration is active.</td> </tr> <tr> <td>Bit 23</td> <td>Limitation of jerk is active (S-ramp time is increased).</td> </tr> </table>	Bit 0	Controller inhibit is initiated. (Safe torque off is requested.)	Bit 1	Quick stop is initiated. (Safe stop 1 is requested.)	Bit 2	Quick stop is initiated. (Safe stop 2 is requested.)	Bit 3	Profile change due to speed limitation. (Limited speed 1 is requested.)	Bit 4	Profile change due to speed limitation. (Limited speed 2 is requested.)	Bit 5	Profile change due to speed limitation. (Limited speed 3 is requested.)	Bit 6	Profile change due to speed limitation. (Limited speed 4 is requested.)	Bit 7	Only positive direction of rotation is permissible. <ul style="list-style-type: none"> <li>• When the direction of rotation is negative while requesting "Only positive direction of rotation", the drive is braked to standstill.</li> </ul>	Bit 8	Only negative direction of rotation is permissible. <ul style="list-style-type: none"> <li>• When the direction of rotation is negative while requesting "Only negative direction of rotation", the drive is braked to standstill.</li> </ul>	Bit 10	Increment in manual jog mode is limited.	Bit 12	Limitation of the set position is active.	Bit 16	Positive limit switch inhibits travel in positive direction.	Bit 17	Negative limit switch inhibits travel in positive direction.	Bit 18	Positive software limit position inhibits travel in positive direction.	Bit 19	Negative software limit position inhibits travel in negative direction.	Bit 20	Limitation of speed is active.	Bit 21	Limitation of acceleration is active.	Bit 22	Limitation of deceleration is active.	Bit 23	Limitation of jerk is active (S-ramp time is increased).
Bit 0	Controller inhibit is initiated. (Safe torque off is requested.)																																						
Bit 1	Quick stop is initiated. (Safe stop 1 is requested.)																																						
Bit 2	Quick stop is initiated. (Safe stop 2 is requested.)																																						
Bit 3	Profile change due to speed limitation. (Limited speed 1 is requested.)																																						
Bit 4	Profile change due to speed limitation. (Limited speed 2 is requested.)																																						
Bit 5	Profile change due to speed limitation. (Limited speed 3 is requested.)																																						
Bit 6	Profile change due to speed limitation. (Limited speed 4 is requested.)																																						
Bit 7	Only positive direction of rotation is permissible. <ul style="list-style-type: none"> <li>• When the direction of rotation is negative while requesting "Only positive direction of rotation", the drive is braked to standstill.</li> </ul>																																						
Bit 8	Only negative direction of rotation is permissible. <ul style="list-style-type: none"> <li>• When the direction of rotation is negative while requesting "Only negative direction of rotation", the drive is braked to standstill.</li> </ul>																																						
Bit 10	Increment in manual jog mode is limited.																																						
Bit 12	Limitation of the set position is active.																																						
Bit 16	Positive limit switch inhibits travel in positive direction.																																						
Bit 17	Negative limit switch inhibits travel in positive direction.																																						
Bit 18	Positive software limit position inhibits travel in positive direction.																																						
Bit 19	Negative software limit position inhibits travel in negative direction.																																						
Bit 20	Limitation of speed is active.																																						
Bit 21	Limitation of acceleration is active.																																						
Bit 22	Limitation of deceleration is active.																																						
Bit 23	Limitation of jerk is active (S-ramp time is increased).																																						
LIM_bLimitationActive <a href="#">C02715</a>   BOOL	Status signal "Limitation is active" (group signal) <table border="1"> <tr> <td>TRUE</td> <td>A limitation is active.</td> </tr> </table>	TRUE	A limitation is active.																																				
TRUE	A limitation is active.																																						

## 9.11 Brake control

This basic function is used for wear free control and monitoring of a holding brake which is connected to the optionally available brake module. As an alternative, the holding brake can also be controlled and monitored via the digital inputs/outputs.

### Intended use

Motor holding brakes are used to stop axes when controller inhibit or pulse inhibit is set. This is particularly important for unbalanced vertical axes.



### Stop!

Basically, holding brakes at Lenze motors are not designed for braking during operation. The increased wear resulting from braking during operation may lead to an early destruction of the motor holding brake!



### Danger!

Please note that the holding brake is an important element of the safety concept of the entire machine.

Therefore act with caution when commissioning this part of the system!

## 9.11.1 Parameter setting



### Danger!

For a faultless function of the automatic brake system the different delay times must be set correctly in the following parameters!

If the delay times are set incorrectly, a faulty brake control may be caused!

- ▶ Parameterisation dialog in the »Engineer«: Tab **Application parameter** → dialog level *Overview* → *All basic functions* → *Brake control*
- ▶ Short overview of parameters for brake control:

Parameters	Information
<a href="#">C02580</a>	Operating mode - brake
<a href="#">C02581</a>	Brake activation threshold
<a href="#">C02582</a>	Brake resp. to pulse inhibit
<a href="#">C02583</a>	Status input monitoring
<a href="#">C02585</a>	Brake control polarity
<a href="#">C02586</a>	Starting torque 1
<a href="#">C02587</a>	Starting torque 2
<a href="#">C02588</a>	Source of starting torque
<a href="#">C02589</a>	Brake closing time
<a href="#">C02590</a>	Brake opening time
<a href="#">C02591</a>	Waiting time - status monit.
<a href="#">C02593</a>	Waiting time - brake active.
<a href="#">C02594</a>	Test torque
<a href="#">C02595</a>	Permissible angle of rotation
<a href="#">C02596</a>	Grinding speed
<a href="#">C02597</a>	Accel./decel. time - grinding
<a href="#">C02598</a>	Grinding ON time
<a href="#">C02599</a>	Grinding OFF time


## 9.11.1.1 Operating mode

Various operating modes are available in [C02580](#) for different applications and tasks:

- ▶ [Mode 0: Brake control is switched off](#) ([□ 222](#))
- ▶ [Mode 1/11: Direct control of the brake](#) ([□ 222](#))
  - Without using a special logic or automatic, can be used, for instance, to check in a simple manner if the brake operates correctly.
- ▶ [Mode 2/12: Automatic control of the brake](#) ([□ 223](#))
  - The common mode for controlling mechanical holding brakes with or without holding torque precontrol.

## 9.11.1.2 Signal configuration

The signal configuration of the control and status signals for the brake logic and monitoring function is executed via the parameters shown in the following signal flow:



[9-8] Signal configuration of the control and status signals




### Note!

- If an electrically holding (self-releasing) brake is to be controlled instead of an electrically releasing (self-holding) brake, the corresponding control and status signals must be inverted!
- For detailed information about the assembly and electrical installation of the motor holding brake, please see the documentation for the brake module and the brake.

## 9.11.1.3 Standstill monitoring

After the brake closing time and the waiting time for status monitoring have elapsed, the standstill monitoring becomes active, i.e. the stop position is memorised and compared with the permissible angle of rotation set in [C02595](#) (Lenze setting: 5°) when the brake is applied.



[9-9] Automatic monitoring of the holding position


- ▶ When the stop position of the motor axis has changed by more than the permissible angle of rotation set in [C02595](#) despite the applied brake:
  - The controller is enabled again and the drive is held at standstill with speed control to prevent a further rotation/acceleration of the drive.
  - The error output *BRK\_bError* is set to TRUE for one task cycle.
  - The status "position drift when brake is applied" is displayed at the status output *BRK\_dnState* via bit 21 for one task cycle.



### Note!

The standstill monitoring function can be switched off via the setting [C02595](#) = "0°".

## 9.11.1.4 Brake activation in automatic operation

Brake activation through  $N < N_{\min}$ [9-10] Process of brake activation through  $N < N_{\min}$ 

- ▶ If the motor speed falls below the threshold for brake activation set in [C02581](#), the brake is automatically triggered to close in the automatic operation (mode 2/12).
- ▶ Here, only the absolute value of the motor speed is considered, the direction of rotation is disregarded.

**Tip!**

The value at [C02581](#) is to be set to approx. 5 ... 20 % of the maximum speed to minimise the wear of the brake and provide for an optimum brake response by a low grinding of the brake.


## Brake activation through time-out

If the waiting time for the brake activation is set  $> 0$  s in [C02593](#), time monitoring is active, i.e. the brake will be triggered to close not later than after the waiting time has elapsed even if the actual speed value is above the threshold for brake activation set in [C02581](#).



### Note!

In the Lenze setting the time monitoring function is not active ([C02593](#) = "0 s").



[9-11] Process of brake activation through time-out

- ▶ The lapse of waiting time starts when the speed setpoint has reached the threshold for brake activation.
- ▶ If the speed setpoint is still above the threshold after the waiting time has elapsed:
  - The brake is automatically triggered to close in automatic operation (mode 2/12).
  - The "brake activation via waiting time" status is displayed at the status output *BRK\_dnState* via bit 23.



## 9.11.1.5 Brake time response


### Closing and opening time



#### Danger!

A wrong setting of the closing and opening time can cause a wrong activation of the brake!


- When the closing time is set too low, the controller is inhibited and the drive gets torqueless before the brake is closed completely.



[9-12] Definition of the closing and opening time of the brake

- ▶ Every mechanical brake has a construction-conditioned closing and opening time which must be considered by the brake control and must be set in [C02589](#) and [C02590](#).
- ▶ The closing and opening time of a Lenze holding brake can be found in the corresponding Operating Instructions in chapter "Technical data".
- ▶ If the closing and opening time is set too high, it is not critical with regard to safety but results in needlessly long delays in cyclic braking processes.

### Motor magnetising time (only for asynchronous motor)




[9-13] Consideration of the motor magnetising time

- ▶ In an asynchronous motor the required magnetic field is created (is already available in synchronous motors) after the controller inhibit is deactivated.
- ▶ The brake will only be released if the actual torque has reached 90 % of the precontrol torque.

## Waiting time for status monitoring

Every time the brake status changes, the waiting time set in [C02591](#) is awaited after the brake opening or brake closing time has elapsed, before the monitoring of the brake module/status input *BRK\_bBrakeApplied* (if activated via C02583) and the standstill monitoring function are switched active again.

- ▶ During the "Closing the brake" process, a mechanical contact must signal the status "brake closed" after the waiting time has elapsed.
- ▶ During the "Releasing the brake" process, a mechanical contact must signal the status "brake released" after the waiting time has elapsed.



- ▶ The waiting time in [C02591](#) must be set so that bouncing of a feedback contact and the transient response of the brake current monitoring will be suppressed completely.
- ▶ If there is no appropriate feedback after the waiting time has expired, the error output *BRK\_bError* is set to TRUE until the next control attempt.

[9-14] Definition of the waiting time for status monitoring


## 9.11.1.6 Torque feedforward control

The motor control serves to precontrol the required torque of the drive when the brake is released. Here it must be ensured that the position controller is switched off and the speed setpoint is loaded with the actual value (no additional torque via the P component of the speed controller).

**Note!**

The torque is precontrolled for one second. During this time, the actual torque must have reached 90 % of the set torque, otherwise a fault is tripped!

Via [C02588](#) it is selected whether a parameterised starting torque or the torque memorised during the last closing operation shall be used for the feedforward control.

**Feedforward control with parameterised starting torque**

- ▶ When [C02588](#) = 0, a change-over between two starting torques is possible via input *BRK\_bStartingTorque2*:
  - *BRK\_bStartingTorque2* = FALSE: Starting torque 1 ([C02586](#)) is used.
  - *BRK\_bStartingTorque2* = TRUE: Starting torque 2 ([C02587](#)) is used.

[9-15] Feedforward control with parameterised starting torque

**Application example:**

A hoist drive is to be operated with different loads. Unfortunately we do not know when the load is available, but the starting direction (lifting or lowering) is known.

- ▶ In a no-load condition, the hoist drive needs a torque of 10 Nm. For holding the maximum load it needs a torque of 50 Nm.
- ▶ The change-over between lifting and lowering at start-up is done via the input *BRK\_bStartingTorque2*.

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Brake control | Parameter setting


- ▶ To ensure the correct direction at start-up, the speed controller is loaded with the following starting torques:

	Lifting	Lowering
Starting torque:	<a href="#">C02586</a> = 50 Nm	<a href="#">C02587</a> = 10 Nm

- ▶ This results in the following behaviour depending on load and direction:

	Lifting	Lowering
Behaviour at max. load:	Optimum behaviour	Start-up a bit fast, but correct direction (non-critical).
Behaviour without load:	Start-up a bit fast, but correct direction (non-critical).	Optimum behaviour

## Feedforward control with memorised torque



- ▶ When [C02588](#) = 1, the starting torque is the setpoint which has been automatically memorised during the last closing process (falling below the speed threshold set in [C02581](#)).

[9-16] Feedforward control with parameterised starting torque




### Note!

The higher the threshold for brake activation set in [C02581](#), the higher is the dynamic part in the marked torque (e.g. the speed-dependent friction torque).

In the special case that the load changes when the brake is closed, a correction value, which is added to the marked torque, can be defined for the torque precontrol via the input *BRK\_dnTorqueAdd\_n*.

### Further torque feedforward control options



- ▶ An additional precontrol value can be set via the input  $BRK\_dnTorqueAdd\_n$ .

[9-17] Feedforward control with parameterised starting torque

#### Application example:

The load for a hoist drive is always known. For an optimum behaviour a torque proportional to the load and 10 Nm in addition as constant precontrol value are to be loaded in the speed controller.

- ▶ The starting torque 1 is used as constant precontrol value ( $C02586 = "10 \text{ Nm}"$ ,  $C02588 = "0"$  and  $BRK\_bStartingTorque2 = \text{FALSE}$ ).
- ▶ Via the input  $BRK\_dnTorqueAdd\_n$  the torque is specified proportional to the load.

#### 9.11.2 Mode 0: Brake control is switched off

If the mode 0 is selected in [C02580](#), the brake activation is switched off.

- ▶ If a brake module is available, it will not be triggered.
- ▶ The brake monitoring function is not active.
- ▶ If a fault is reported by the brake control, it will be reset.
- ▶ The output signals of the system block LS\_Brake are reset:
  - *BRK\_dnState* = 0
  - *BRK\_bReleaseBrakeOut* = FALSE
  - *BRK\_bBrakeReleased* = FALSE
  - *BRK\_bError* = FALSE



#### Note!

The mode 0 is preset in the Lenze setting to reach a safe status after mains connection.

#### 9.11.3 Mode 1/11: Direct control of the brake

If the mode 1 or 11 has been selected in [C02580](#), the brake is directly controlled via the input *BRK\_bReleaseBrake*.



#### Tip!

Mode 1/11 can be used to easily check if the brake switches correctly.

- ▶ At the same time, the selection of the mode defines the type of brake control:
  - Mode 1: Direct brake control via brake module.
  - Mode 11: Direct brake control via a digital output.
- ▶ Setting the pulse inhibit or controller inhibit does not influence the output signal.
- ▶ After the brake has been activated and the brake closing time has elapsed, the controller inhibit is set automatically by the basic function "brake control".
- ▶ For the operation with the brake module (mode 1) the required polarity for brake control can be set in [C02585](#).

#### 9.11.4 Mode 2/12: Automatic control of the brake

If the mode 2 or 12 is selected in [C02580](#), the brake is controlled automatically, i.e. if another basic function is activated which causes the drive to traverse, the brake is opened automatically and the operation is enabled. If the corresponding basic function is deactivated again, the drive is stopped via the basic function "[Standard stop](#)" and the brake is automatically closed again, if speed setpoint and actual speed value fall below the speed threshold set in [C02581](#).



#### Tip!

The mode 2/12 is the common mode for brake control.

In this mode, the input *BRK\_bReleaseBrake* is to be set permanently to FALSE. If *BRK\_bReleaseBrake* = TRUE, the brake is permanently released and the automatic control cannot close the brake.

- ▶ At the same time, the selection of the mode defines the type of brake control:
  - Mode 2: Automatic brake control via brake module.
  - Mode 12: Automatic brake control via a digital output.
- ▶ The brake is also activated automatically if a quick stop is activated in the drive, e.g. via the basic function "[Quick stop](#)" or as a response to a fault.
- ▶ After the brake has been activated automatically and the brake closing time has elapsed, the controller inhibit is set automatically by the basic function "brake control".
- ▶ For the operation with the brake module (mode 1) the required polarity for brake control can be set in [C02585](#).

## 9.11.4.1 Behaviour at pulse inhibit

In case of pulse inhibit the brake is applied. This occurs according to the parameter setting in [C02582](#) either immediately (default setting) or delayed when the threshold set for brake activation is fallen below, which can be selected to protect the brake if high centrifugal masses occur.



### Note!

Pulse inhibit can be set in the enabled controller e.g. due to a DC overvoltage during brake operation by a wrong dimensioning of the brake resistor.

### Activate the brake in any case

When setting [C02582](#) = "0", the brake is triggered to close to prevent the mechanics from being damaged.

### Only activate the brake below the threshold set for brake activation

When [C02582](#) = "1", the brake remains released until the threshold set in [C02581](#) for brake activation has been reached to protect the brake from excessive wear.

- ▶ Braking is exclusively executed by the friction of the load mechanics.
- ▶ Only when the motor speed has reached the threshold for brake activation, the brake will be closed.



### Stop!

Do not set the threshold for brake activation in [C02581](#) too high to protect the brake from wear.



## 9.11.4.2 Process when brake is released

The following process occurs when a basic function is requested which causes the drive to traverse:

1. The controller inhibit is deactivated.
2. A magnetic field is created in the motor required for the holding torque (is already available in synchronous machines).
3. The precontrol torque is loaded in the speed controller.
4. When the actual torque has reached 90 % of the precontrol torque:
  - The output *BRK\_bReleaseBrakeOut* is set to TRUE for releasing the brake.
  - Monitoring of the brake module is deactivated temporarily.
  - Monitoring of the status input is deactivated temporarily (if switched active via [C02583](#)).
  - The lapse of brake opening time starts.
5. After the brake opening time has elapsed:
  - The output *BRK\_bBrakeReleased* is set to TRUE.
  - The requested basic function is enabled.
6. After the additional waiting time set for the status monitoring in [C02591](#) has elapsed:
  - Monitoring of the brake module is active again.
  - Monitoring of the status input is active again (if switched active via [C02583](#)).

## 9.11.4.3 Process when brake is closed

The following process occurs if the enable of the requested basic function for traversing the drive is deactivated again:

1. The drive is braked to standstill via the basic function "[Standard stop](#)", or also via the basic function "[Quick stop](#)".
2. When speed setpoint and actual speed value have fallen below the speed threshold set in [C02581](#):
  - The output *BRK\_bReleaseBrakeOut* is set to FALSE for opening the brake.
  - The current torque is saved to be used for the feedforward control for the next start, if required.
  - Monitoring of the brake module is deactivated temporarily.
  - Monitoring of the status input is deactivated temporarily (if switched active via [C02583](#)).
  - The lapse of brake closing time starts.
3. After the brake closing time has elapsed and the corresponding status change of the status signal:
  - The output *BRK\_bBrakeReleased* is reset to FALSE.
  - The controller inhibit is activated.
4. After the additional waiting time set for the status monitoring in [C02591](#) has elapsed:
  - Monitoring of the brake module is active again.
  - Monitoring of the status input is active again (if switched active via [C02583](#)).
  - Standstill monitoring is activated. ▶ [Standstill monitoring](#) (□ 214)

## 9.11.5 Grinding the brake

**Function only implemented from bundle 1.1!**

This function is required if the brake is exchanged. The holding torque listed in the data sheet is only reached if the friction partners are ground after installation.

**Stop!**

If this function is activated, the drive is automatically accelerated to the grinding speed parameterised in [C02596](#).

- The axis must move freely without driving against the travel range limitations.
- The maximally permissible friction energy of the brake must not be exceeded (observe the specifications of the manufacturer)!

$$W_{\text{total}}[\text{J}] \sim M_K[\text{Nm}] \cdot \frac{2\pi}{60} \cdot N[\text{min}^{-1}] \cdot t_{\text{total}}[\text{s}]$$

[9-18] Formula for estimating the friction energy during grinding process

**Requirements**

To activate the grinding of the brake, the following conditions must be fulfilled:

- ▶ The grinding speed in [C02596](#) is set higher than 0 rpm.
- ▶ The brake is activated, i.e. the "brake closing time" ([C02589](#)) and the "waiting time for status monitoring" ([C02591](#)) are elapsed.
- ▶ No other source for controller inhibit is active so that the controller inhibit can be deactivated by the brake control.


**Note!**

When grinding the brake it must be ensured that the motor shaft can be kept at speed against the closed brake.

- For this purpose, make sure that the maximum torque of the motor control ([C00057/2](#)) is higher than the holding torque of the brake.

## Sequence

When all conditions mentioned are fulfilled, the grinding process can be started by setting the input *BRK\_bBrakeGrindIn* to TRUE.



- ▶ After the grinding speed has been reached, the friction partners in the brake are ground by a pulse-type control.
- ▶ After the brake has been closed and opened ten times, the direction of rotation changes and grinding in the opposite direction is carried out.
- ▶ By resetting the input *BRK\_bBrakeGrindIn* to FALSE the grinding process can be aborted.

[9-19] Sequence of the grinding operation

### 9.11.6 Carry out brake test

**Function only implemented from bundle 1.1!**

This function can be used to check the holding torque of the brake.



#### Tip!

You can carry out this test regularly to early detect defects or wear of the brake in good time.



#### Note!

Due to possible deviations in the torque generation, the test of the holding torque cannot determine the holding torque exactly!

- The generated motor torque can deviate up to  $\pm 15\%$  from the default value depending on temperature.


#### Requirements

To activate the brake test, the following conditions must be fulfilled:

- ▶ The test torque in [C02594](#) is set higher than 0 Nm.
- ▶ The permissible angle of rotation in [C02595](#) is set higher than 0° and thus standstill monitoring is active. ▶ [Standstill monitoring](#) (☰ 214)
- ▶ The brake is activated, i.e. the "brake closing time" ([C02589](#)) and the "waiting time for status monitoring" ([C02591](#)) are elapsed.
- ▶ No other source for controller inhibit is active so that the controller inhibit can be deactivated by the brake control.

#### Sequence

When all conditions mentioned are fulfilled, the brake test can be started by setting the input *BRK\_bBrakeTest* to TRUE.



[9-20] Sequence of the brake test


- ▶ The specified test torque is created via a ramp generator with an acceleration time of 1 s and held max. 4 s.
  - By this it is tried to rotate the motor shaft while the brake is applied.
- ▶ By resetting the input *BRK\_bBrakeTest* to FALSE the brake test can be aborted.

#### Error behaviour

- ▶ When the stop position of the motor axis has changed during the brake test by more than the permissible angle of rotation set in [C02595](#) despite the applied brake:
  - The brake test is aborted immediately and the controller is inhibited.
  - The status "position drift when brake is applied" is displayed at the status output *BRK\_dnState* via bit 21 and the status "brake error" is displayed via bit 15.
  - The output *BRK\_bError* is set to TRUE.
- ▶ By resetting the input *BRK\_bBrakeTest* to FALSE an error can be reset automatically.

## 9.11.7 System block "LS\_Brake"

The LS\_Brake system block in the function block editor maps the basic function "brake control".



### Inputs

Identifier <small>DIS code   data type</small>	Information/possible settings				
BRK_bReleaseBrake <small>C02609/1   BOOL</small>	<p>Opening/closing the brake in connection with the selected operating mode</p> <table border="1"> <tr> <td>FALSE</td> <td>Close the brake.                             <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic takes over the brake control.</li> </ul> </td> </tr> <tr> <td>TRUE</td> <td>Release brake.                             <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic is deactivated and the brake is opened. If the controller is inhibited by the brake control, it will be deactivated again.</li> </ul> </td> </tr> </table>	FALSE	Close the brake. <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic takes over the brake control.</li> </ul>	TRUE	Release brake. <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic is deactivated and the brake is opened. If the controller is inhibited by the brake control, it will be deactivated again.</li> </ul>
FALSE	Close the brake. <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic takes over the brake control.</li> </ul>				
TRUE	Release brake. <ul style="list-style-type: none"> <li>In automatic operation the internal brake logic is deactivated and the brake is opened. If the controller is inhibited by the brake control, it will be deactivated again.</li> </ul>				
BRK_bStartingTorque2 <small>C02609/2   BOOL</small>	<p>Selection of the torque feedforward control value</p> <ul style="list-style-type: none"> <li>For the general use of the parameterisable starting torque as precontrol value, set <a href="#">C02588</a> = 0.</li> <li>▶ <a href="#">Torque feedforward control</a> (□ 219)</li> </ul> <table border="1"> <tr> <td>FALSE</td> <td>Starting torque 1 (<a href="#">C02586</a>) is active.</td> </tr> <tr> <td>TRUE</td> <td>Starting torque 2 (<a href="#">C02587</a>) is active.</td> </tr> </table>	FALSE	Starting torque 1 ( <a href="#">C02586</a> ) is active.	TRUE	Starting torque 2 ( <a href="#">C02587</a> ) is active.
FALSE	Starting torque 1 ( <a href="#">C02586</a> ) is active.				
TRUE	Starting torque 2 ( <a href="#">C02587</a> ) is active.				
BRK_dnTorqueAdd_n <small>C02608   DINT</small>	<p>Additive torque value in [%] for torque feedforward control during start</p> <ul style="list-style-type: none"> <li>100 % ≙ <a href="#">C00057/2</a></li> <li>▶ <a href="#">Torque feedforward control</a> (□ 219)</li> </ul>				
BRK_bBrakeApplied <small>C02609/3   BOOL</small>	<p>Input for status detection via switching contact at the brake</p> <ul style="list-style-type: none"> <li>Activation of the input by setting <a href="#">C02583</a> = 1.</li> <li>▶ <a href="#">Signal configuration</a> (□ 213)</li> </ul> <table border="1"> <tr> <td>FALSE</td> <td>Status "Brake is released".</td> </tr> <tr> <td>TRUE</td> <td>Status "Brake is applied".</td> </tr> </table>	FALSE	Status "Brake is released".	TRUE	Status "Brake is applied".
FALSE	Status "Brake is released".				
TRUE	Status "Brake is applied".				
BRK_bBrakeTest <small>C02609/4   BOOL</small>	<p>Start/abort of the brake test</p> <ul style="list-style-type: none"> <li>▶ <a href="#">Carry out brake test</a> (□ 229)</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>Carry out brake check.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>Abort brake test (deactivate mode).</td> </tr> </table>	TRUE	Carry out brake check.	TRUE↔FALSE	Abort brake test (deactivate mode).
TRUE	Carry out brake check.				
TRUE↔FALSE	Abort brake test (deactivate mode).				
BRK_bBrakeGrindIn <small>C02609/5   BOOL</small>	<p>Start/abort of the brake grinding process</p> <ul style="list-style-type: none"> <li>▶ <a href="#">Grinding the brake</a> (□ 227)</li> </ul> <table border="1"> <tr> <td>TRUE</td> <td>Brake grinding.</td> </tr> <tr> <td>TRUE↔FALSE</td> <td>Abort grinding process (deactivate mode).</td> </tr> </table>	TRUE	Brake grinding.	TRUE↔FALSE	Abort grinding process (deactivate mode).
TRUE	Brake grinding.				
TRUE↔FALSE	Abort grinding process (deactivate mode).				

# 9400 HighLine | Parameter setting & configuration

Basic drive functions

Brake control | System block "LS\_Brake"

## Outputs

Identifier <small>DIS code   data type</small>	Value/meaning
BRK_dnState <a href="#">C02607</a>   BOOL	Status (bit-coded) • Bits which are not listed are not assigned with a status (always "0").
	Bit 1 Brake control is active.
	Bit 4 Brake module is used.
	Bit 8 Brake status (internal status signal).
	Bit 9 Torque feedforward control is active.
	Bit 10 Controller inhibit is active or set by brake.
	Bit 15 Error is active (collective message).
	Bit 16 Status "Brake grinding-in".
	Bit 17 Status "Brake test".
	Bit 18 Status "Direct control".
	Bit 19 Status "Automatic control".
	Bit 20 Error: External feedback.
	Bit 21 Error: Position drift when brake is applied/checked.
	Bit 22 Error: Brake module monitoring.
	Bit 23 Information: Brake activation via waiting time.
Bit 24 Information: Brake grinding-in is completed.	
Bit 25 Information: Brake test completed.	
Bit 26 Error: precontrol torque could not be created within one second.	
BRK_bReleaseBrakeOut <a href="#">C02609/6</a>   BOOL	Control signal for triggering an external brake/status signal for control state
	FALSE Close the brake.
	TRUE Release brake.
BRK_bBrakeReleased <a href="#">C02609/7</a>   BOOL	Status signal of the brake control considering the closing and opening time of the brake
	FALSE Brake is applied (after the brake closing time has elapsed). TRUE Brake is released (after the brake opening time has elapsed).
BRK_bError <a href="#">C02609/8</a>   BOOL	Status signal "Brake error"
	TRUE An error has been detected.
BRK_bClnhActive <a href="#">C02609/9</a>   BOOL	Status signal "Controller inhibit"
	TRUE Controller inhibit has been set by brake control.



## 10 Technology applications (TAs)

Technology applications are block applications with parameter setting interface prepared by Lenze which form the basis of solving typical applications.

### Delivery

The technology applications available for the 9400 Servo Drives can be selected in the »Engineer« from the application catalog.

### Commissioning

Commissioning is carried out D with the »Engineer« by selection from the catalogue, transmission to the controller, and parameter setting via corresponding dialogs.

▶ [Commissioning using the »Engineer«](#) (📖 235)


### Licensing

Technology applications require a runtime software license which is determined by the plugged memory module and is higher or equal to the required license.

MM		License	Controller
MM	↑		
1	→	Motion Control StateLevel	9400 StateLine
2	→	Motion Control HighLevel	9400 HighLine
3	→	Motion Control TopLevel	9400 HighLine
4	→	PLC	9400 HighLine

[10-1] Indication of the runtime software license in the designation of the memory module






### 10.1 Overview

Technology application/application ranges	Required license/delivery
<p><a href="#">TA "Actuator – speed"</a> (📖 244)</p>  <ul style="list-style-type: none"> <li>• General servo drive for speed control of:                             <ul style="list-style-type: none"> <li>– Conveyor drives (connected in one system)</li> <li>– Extruder</li> <li>– Test benches</li> <li>– Vibrators</li> <li>– Travelling drives</li> <li>– Presses</li> <li>– Machine tools</li> <li>– Dosing machines</li> </ul> </li> <li>• Actuating drives for master control                             <ul style="list-style-type: none"> <li>– Positioning drives with external position control</li> <li>– Multi-axis systems with external path control</li> </ul> </li> </ul>	<p>Available in every license stage. The technology application can be selected in the »Engineer« application catalog.</p>

# 9400 HighLine | Parameter setting & configuration







## Technology applications (TAs)

### Overview

Technology application/application ranges	Required license/delivery
<p><a href="#">TA "Actuator – torque" (📄 265)</a></p>  <ul style="list-style-type: none"> <li>• Slave drives for material transport                             <ul style="list-style-type: none"> <li>– Chain conveyors</li> <li>– S-shaped frame structure</li> <li>– Bilateral tandem drives</li> </ul> </li> <li>• Test facilities                             <ul style="list-style-type: none"> <li>– Test benches for tensile stress</li> <li>– Motor test benches</li> <li>– Brake assemblies</li> </ul> </li> <li>• Support of higher-level technology solutions for e.g. traction-controlled winders</li> </ul>	<p>Available in every license stage. The technology application can be selected in the »Engineer« application catalog.</p>
<p><a href="#">TA "Electronic gearbox" (📄 297)</a></p>  <ul style="list-style-type: none"> <li>• Slitters</li> <li>• Calender drives</li> <li>• Line drives</li> <li>• Conveying belts</li> <li>• Vibrators</li> <li>• Roller mills</li> <li>• Stretching machines</li> <li>• Wire drawing machines</li> </ul>	<p>License stage Motion Control HighLevel or higher required. The technology application can be selected in the »Engineer« application catalog.</p>
<p><a href="#">TA "Synchronism with mark synchronisation" (📄 332)</a></p>  <ul style="list-style-type: none"> <li>• Printing units</li> <li>• Asynchronous cross cutters</li> <li>• Perforating machines</li> <li>• Insetters</li> <li>• Vibrating drives</li> <li>• Line drives</li> <li>• Labelling machines</li> </ul>	<p>License stage Motion Control HighLevel or higher required. The technology application can be selected in the »Engineer« application catalog.</p>
<p><a href="#">TA "Multi-purpose positioning" (📄 371)</a></p>  <p><b>Note:</b> In this TA the sequence control is carried out through the controller.</p> <ul style="list-style-type: none"> <li>• Transport units</li> <li>• Rotary tables</li> <li>• Storage and retrieval units</li> <li>• Feed drives</li> <li>• Dosing machines</li> <li>• Hoists</li> </ul>	<p>License stage Motion Control TopLevel or higher required. The technology application can be selected in the »Engineer« application catalog.</p>
<p><a href="#">TA "Table positioning" (📄 411)</a></p>  <p><b>Note:</b> This TA requires an external sequence control.</p> <ul style="list-style-type: none"> <li>• Transport units</li> <li>• Rotary tables</li> <li>• Storage and retrieval units</li> <li>• Feed drives</li> <li>• Dosing machines</li> <li>• Hoists</li> </ul>	<p>Available in every license stage. The technology application can be selected in the »Engineer« application catalog.</p>

## 10.2 Commissioning using the »Engineer«



### Basic procedure

1. Start »Engineer«.
2. Open available project or create a new project.
3. Assign each controller to a technology application  from the catalogue.
4. For a project with several interconnected devices:
  - Insert network  and machine application .
  - Make suitable network settings.
  - Specialise the predefined ports to concrete interfaces for the devices involved in the network on the **Ports** tab.
  - Interconnect the ports conveniently inside the machine application.
5. Parameterise the application(s).
6.  Update devices.
7.  Go online.
8.  Download application(s) into the controller(s).



### Note!

The downloaded application is basically stored in the first application memory location of the controller.

9. Confirm  Dialog box *Start application* with **Yes, all devices**.
10. Confirm  Dialog box *Enable controller* with **Yes, all devices**.
11. Control application(s) via terminals or network.

#### 10.2.1 Parameterise application

In the »Engineer« all required settings for the technology application can be made via the **Application parameter** tab which contains several levels of parameter dialogs.

- ▶ The top level *Overview* includes all parameters required to carry out a short setup.
  - The left half of all technology applications is nearly identical and serves to set mains, motor and gearboxes and the basic functions supported by the technology application.
  - The right half, however, depends on the technology application selected.

1 Mains voltage

2 Basic functions

3 Motor/feedback system

4 Gearbox

5 Technology application

[10-2] Example: Parameter setting dialog in the »Engineer« for a technology application

- ▶ If you click on one of the pictographs marked with the symbol →, you get one level deeper in the corresponding parameter dialog.
- ▶ This parameter dialog can also have further subordinate parameter dialogs, depending on the complexity.



#### Tip!

The online documentation for the »Engineer« contains detailed information on how to work in the **Application parameter** tab.

## 10.2.2 Parameterise signal combinations

In order to easily change existing signal combinations between the device interfaces and the application inputs and outputs, parameterisable "multiplexers" are implemented in all technology applications.

- ▶ From a number of signal sources, each multiplexer combines exactly one with a signal target of the same data type ("combinatorial circuit").
- ▶ The signal source is selected by setting the "multiplexer parameter" that is firmly assigned to the signal target. Each multiplexer parameter always offers a selection of sensible signal sources only.
- ▶ Thus, signal combinations can also be changed (e.g. the assignment of the digital inputs and outputs) with the keypad only.



### Note!

When you enable the function block editor in the »Engineer« on the **FB editor** tab, all multiplexers are removed from the interconnection and the currently set signal combinations are replaced by fixed signal combinations!

This process is irreversible!




### Tip!

The multiplexer parameters are marked by a prefixed "X" in the name and listed in the chapter of the corresponding technology application.

Several options are available for changing the signal combinations which are described in the following sections.

## Changing signal combinations via the parameters setting interface

On the **Application** parameter tab all parameterisable signal combinations are marked by white buttons.




- ▶ If you press one of such buttons, the *I/O configuration for...* dialog level is displayed via which another signal source can be selected.

## Changing signal combinations in the function block editor


In the function block editor parameterisable signal combinations are marked by the background colour Cyan.

- ▶ If the command **Set multiplexer** is selected from the context menu (right mouse button) for the signal source, all multiplexer parameters available are displayed in a parameter list and can also be changed here:



## Changing signal combinations via the parameter list

If you go to the **All parameters** tab and select the subcategory **Multiplexer** as technology application, all multiplexer parameters available are displayed in the parameter list and can also be changed here:



## 10.2.3 Configure application

The interconnection of the technology application defined by Lenze is indicated on the **FB-Editor** tab.


- ▶ The current values at the inputs and outputs are indicated in the online mode.
- ▶ If you click the **Activate editor** button, the defined interconnection can be changed.



### Note!

The activation of the function block editor causes the parameter dialogs for the technology application to be replaced by general dialogs. The dialogs for parameter setting of the system and function blocks available in the interconnection can continue to be used.

Moreover all multiplexers are removed from the interconnection and the currently set signal combinations are replaced by configurable signal combinations.



[10-3] Example: Representation of the interconnection of the technology application in the function block editor



### Tip!

The online documentation for the »Engineer« contains detailed information on how to use the function block editor.

## 10.2.4 Networking via standardised ports

For the implementation of different control concepts each technology application has predefined ports:

Input ports	Output ports	Use
LPortAxisIn1	LPortAxisOut1	For the connection of several axes ("horizontal communication")
LPortControl1	LPortStatus1	For the connection with a master control ("vertical communication")
LPortControl2	LPortStatus2	
LPort32In1	LPort32Out1	For additional 32 bit process signals
LPort32In2	LPort32Out2	
LPort32In3	LPort32Out3	
LPort16In1	LPort16Out1	For additional 16 bit process signals
LPort16In2	LPort16Out2	
LPort16In3	LPort16Out3	



### Note!

The TA variants for the 9400 HighLine have the ports predefined with the "automatic" interface.

After the addition of a network and interconnection of the ports inside the machine applications the "automatic" interface is specified according to the bus system used during the device update.

For commissioning of the communication the »Engineer« is required.





### Tip!

The exact assignment of the ports can be found in the description of the technology application.



## 11 Standard TAs

The technology applications described in this chapter are available for general drive tasks.


Technology application/application ranges	Required license/delivery
<p><a href="#">TA "Actuator – speed" (📄 244)</a></p>  <ul style="list-style-type: none"> <li>• General servo drive for speed control of:                             <ul style="list-style-type: none"> <li>– Conveyor drives (connected in one system)</li> <li>– Extruders</li> <li>– Test benches</li> <li>– Vibrators</li> <li>– Travelling drives</li> <li>– Presses</li> <li>– Machine tools</li> <li>– Dosing machines</li> </ul> </li> <li>• Actuators for master control                             <ul style="list-style-type: none"> <li>– Positioning drives with external position control</li> <li>– Multi-axis systems with external path control</li> </ul> </li> </ul>	<p>Available in every license stage. The technology application can be selected in the »Engineer« application catalog.</p>
<p><a href="#">TA "Actuator – torque" (📄 265)</a></p>  <ul style="list-style-type: none"> <li>• Slave drives for material transport                             <ul style="list-style-type: none"> <li>– Chain conveyors</li> <li>– S-shaped frame structure</li> <li>– Bilateral tandem drives</li> </ul> </li> <li>• Test facilities                             <ul style="list-style-type: none"> <li>– Test benches for tensile stress</li> <li>– Motor test benches</li> <li>– Brake assemblies</li> </ul> </li> <li>• Support of higher-level technology solutions for e.g. traction-controlled winders</li> </ul>	<p>Available in every license stage. The technology application can be selected in the »Engineer« application catalog.</p>

## 11.1 Introduction

### 11.1.1 Application examples

#### Dosing drives

- ▶ Both dosing drives are operated in speed-controlled mode and determine the mix ratio with their speed:



- ❶ Mains
- ❷ System bus (CAN)
- ❸ Drive 1 with TA "actuator – speed"
- ❹ Drive 2 with TA "actuator – speed"

$i$  = gearbox factor  
 $n$  = Load reference speed in [rpm]  
 $v$  = Reference speed in [m/s]  
 $d$  = roll diameter in [m]

[11-1] Example: Dosing drives with adjustable mix ratio  $v_1/v_2$

- ▶ Technical connections/machine parameters:

$$\text{Load reference speed [min-1]} = \frac{\text{Motor reference speed [min-1]}}{\text{Gearbox factor}}$$

Parameters	Information
<a href="#">C00011</a>	Motor reference speed
<a href="#">C02520</a>	Gearbox fact. numer. motor
<a href="#">C02521</a>	Gearbox fact. denom. motor
<a href="#">C02542</a>	Load reference speed


Highlighted in grey = display parameter

$$\text{Reference speed [m/s]} = \frac{\text{Roll diameter [m]} \cdot \pi \cdot \text{Load reference speed [min-1]}}{60}$$

Parameters	Information
<a href="#">C02524</a>	Feed constant → roll diameter in [m] * $\pi$
<a href="#">C02525</a>	Selection of the unit → [m]

Highlighted in grey = display parameter

## Conveyor drive with adjustable tension



[11-2] Example: Conveyor drive with adjustable tension

- ▶ The master drive is operated speed-controlled and determines the speed of the material path.
- ▶ The slave drive with the standard technology application "actuator – torque" ensures that a certain minimum tensile stress is complied with between master and slave drive. When torque-controlled, the slave drive is permanently able to follow the speed specified by the master drive.

## 11.2 TA "Actuator – speed"

The technology application "actuator – speed" enables the drive to create a speed to be defined. The speed setpoint can be complied with using a speed controller which adopts the motor torque to the prevailing load situation.


- ▶ The speed setpoint of the drive can be specified for both directions. The driven machine parts accordingly moves forwards or backwards. As an alternative to the inversion of the setpoint, the change of the direction of movement can be done via the digital input DI3.
- ▶ After the speed-controlled operation is enabled via the digital input DI2 the acceleration/deceleration of the drive to the setpoint is controlled via a ramp generator based on the current setpoint/actual speed.
- ▶ The maximum torque of the drive can also be controlled, if required.

### Basic drive functions

- ▶ A quick stop can be activated via the digital input DI1.
  - ▶ [Quick stop](#) (☞ 257)
- ▶ A manual control is provided for the setting-up operation. It is enabled via the digital input DI6. The inputs DI7 and DI8 activate parameterisable setpoints for both directions of rotation. ▶ [Manual jog](#) (☞ 256)
- ▶ The basic function "limiter" enables the travel range to be monitored via limit switches.
  - ▶ [Limiter](#) (☞ 258)
- ▶ When a brake is available the brake control opens and closes the brake. ▶ [Brake control](#) (☞ 259)

See also: ▶ [Basic drive functions](#) (☞ 140)

## 11.2.1 Basic signal flow



[11-3] Signal flow of the TA "Actuator – speed" (schematic diagram)

### Speed setpoint conditioning

- A** Setpoint gain
- B** Selection of analog input/fixed setpoints
- C** Setpoint inversion
- D** Ramp generator

### Basic drive functions


- E** Speed follower
- F** Manual jog
- G** Quick stop
- H** Stop
- I** Brake control (optional)
- J** Limiter (optional)

## 11.2.2 Assignment of the I/O terminals


### 11.2.2.1 Setpoint and control signals

The following tables contain the Lenze assignment of the analog and digital inputs for the technology application "actuator – speed".

#### Analog inputs

Terminal X3	Signal (Lenze setting)
	<b>A1-</b> <b>A1+</b> Speed setpoint <a href="#">▶ Speed setpoint conditioning (📖 250)</a>
	<b>A2-</b> <b>A2+</b> -
<a href="#">▶ I/O terminals ▶ Analog inputs (📖 117)</a>	

#### Digital inputs


Terminal X5	Signal (Lenze setting)														
	<b>DI1</b> Quick stop <ul style="list-style-type: none"> <li>If DI1 is set to LOW level, the drive is decelerated to standstill within the deceleration time set for the quick stop function independent of the setpoint selection.</li> <li>If the quick stop function is deactivated, the drive is led to the selected setpoint again via the set acceleration time.</li> </ul> <a href="#">▶ Quick stop (📖 257)</a>														
	<b>DI2</b> Enable speed follower <a href="#">▶ Speed follower (📖 255)</a>														
	<b>DI3</b> Invert speed setpoint <a href="#">▶ Setpoint inversion (📖 252)</a>														
	<b>DI4</b> Activate fixed setpoint 1 <ul style="list-style-type: none"> <li>Instead of the selection via the analog input 1 the fixed setpoint 1 is used as speed setpoint.</li> </ul> <a href="#">▶ Change-over to fixed setpoint (📖 251)</a>														
	<b>DI5</b> Reset error <ul style="list-style-type: none"> <li>By means of a LOW-HIGH edge an existing error status can be reset if the cause of the fault is removed.</li> </ul>														
	<b>DI6</b> Manual jog <a href="#">▶ Manual jog (📖 256)</a> <table border="1" data-bbox="533 1671 1442 1861"> <thead> <tr> <th>DI7</th> <th>DI8</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>LOW</td> <td>LOW</td> <td>Stop</td> </tr> <tr> <td>HIGH</td> <td>LOW</td> <td>Manual control in positive direction</td> </tr> <tr> <td>LOW</td> <td>HIGH</td> <td>Manual control in negative direction</td> </tr> <tr> <td>HIGH</td> <td>HIGH</td> <td>- (previous state remains active)</td> </tr> </tbody> </table>	DI7	DI8	Function	LOW	LOW	Stop	HIGH	LOW	Manual control in positive direction	LOW	HIGH	Manual control in negative direction	HIGH	HIGH
DI7	DI8	Function													
LOW	LOW	Stop													
HIGH	LOW	Manual control in positive direction													
LOW	HIGH	Manual control in negative direction													
HIGH	HIGH	- (previous state remains active)													
<a href="#">▶ I/O terminals ▶ Digital inputs (📖 123)</a>															

## 11.2.2.2 Actual value and status signals

The following tables contain the Lenze assignment of the analog and digital outputs for the technology application "actuator – speed".


- The default signal configuration if required can be easily changed by parameterising the multiplexer parameters assigned.

### Analog outputs

Terminal X3	Signal (Lenze setting)	Signal configuration
	<b>AO1</b> Motor speed • Scaling: $\pm 10\text{ V} \equiv$ motor reference speed ( <a href="#">C00011</a> )	C03110/1
	<b>AO2</b> Motor torque (setpoint) • Scaling: $\pm 10\text{ V} \equiv$ Motor reference torque ( <a href="#">C00057/2</a> )	C03110/2


► [I/O terminals](#) ► [Analog outputs](#) ([120](#))

### Digital outputs

Terminal X4	Signal (Lenze setting)	Signal configuration
	<b>DO1</b> Status "Drive ready" • This operating state is active if the controller is enabled by setting the digital input RFR to HIGH level and no error has occurred.	C03100/1
	<b>DO2</b> Status "Speed follower enabled" • The speed follower has been enabled via the digital input DI2.	C03100/2
	<b>DO3</b> Status "Speed follower in limitation" • The enabled speed follower is in the limitation for more than 100 ms. • The setpoint is limited to the upper or lower speed limit value ( <a href="#">C00909/1</a> or <a href="#">C00909/2</a> ).	C03100/3
	<b>DO4</b> Status "Error active acknowledgement is required" • Monitoring with the error response "Error" or "Quick stop by trouble" has been activated, and the controller is in the device state "Error active" or "Quick stop by trouble active".	C03100/4


► [I/O terminals](#) ► [Digital outputs](#) ([125](#))

### State bus

Terminal X2	Signal (Lenze setting)	Signal configuration
	<b>SB</b> Status "Speed follower in limitation" • The enabled speed follower is in the limitation for more than 100 ms. • The setpoint is limited to the upper or lower speed limit value ( <a href="#">C00909/1</a> or <a href="#">C00909/2</a> ). • The state bus is put in the "error" status.	C03100/5

► [I/O terminals](#) ► [Monitoring function "State bus"](#) ([127](#))


## Display elements

User LED	Signal (Lenze setting)	Signal configuration
	Status "Speed follower enabled" <ul style="list-style-type: none"><li>• The speed follower has been enabled via the digital input DI2.</li></ul>	C03100/6

▶ [Drive interface](#) ▶ [LED status displays](#) (📖 34)



## 11.2.3 Machine parameters



The machine parameters describe e.g. the motor end of the mechanics used.

The setting of the machine parameters in the »Engineer« is carried out on the **Application parameters** tab in the dialog level *Overview* → *Drive interface*.



### Tip!


In the »Engineer« the most important machine parameters can be adapted to the machine on the **Application parameter** tab directly in the topmost *Overview* dialog level:

Detailed information for selecting and entering the machine parameters can be found in the chapter "[Drive interface](#)". ▶ [Machine parameters](#) (35)

### Short overview of machine parameters

Parameters		Lenze setting	
		Value	Unit
<a href="#">C00173</a>	Mains - voltage	400/415	V
<a href="#">C00174</a>	Threshold undervoltage (LU)	285	V
<a href="#">C00600</a>	Resp. to DC bus overvoltage	Trouble	
<a href="#">C02520</a>	Gearbox fact. numer. motor	1	
<a href="#">C02521</a>	Gearbox fact. denom. motor	1	
<a href="#">C02527</a>	Motor mounting direction	Motor rotating CW	
<a href="#">C02570</a>	Controller configuration	Phase control	
<a href="#">C02522</a>	Gearbox fact. numer. load	1	
<a href="#">C02523</a>	Gearbox fact. denom. load	1	
<b>Description of the mechanics (load, tool)</b>			
<a href="#">C02528</a>	Traversing range	Unlimited	
<a href="#">C02524</a>	Feed constant	360.0000	Unit
<a href="#">C02525</a>	Unit	°	
<a href="#">C02526</a>	User-defined unit	°	
<a href="#">C02533</a>	Time unit	s	
<a href="#">C00273/1</a>	Motor moment of inertia	Motor-dependent	kg cm <sup>2</sup>
<a href="#">C00273/2</a>	Load moment of inertia	0.00	kg cm <sup>2</sup>

## 11.2.4 Speed setpoint conditioning



[11-4] Speed setpoint conditioning (schematic diagram)

The speed setpoint is defined in the Lenze setting via the analog input 1 and take place in both directions (bipolar) and accordingly the driven machine part moves forward or backward.


► Parameter setting: Tab **Application parameter** → Dialog level *Overview*

Parameters		Lenze setting	
		Value	Unit
C03002	Setpoint gain	100.00	%

Setpoint inputs of the function		Signal configuration
Lenze setting	Setpoint input	(Multiplexer parameters)
AIn 1	→ Speed setpoint	C03000

### 11.2.4.1 Change-over to fixed setpoint



[11-5] Additional offset for the speed limit value (schematic diagram)

Via the digital input DI4 a change-over to a parameterisable fixed setpoint can take place.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview*

Parameters		Lenze setting	
		Value	Unit
C03500/1	Fixed setpoint 1	10.00	%

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
DigIn 4	→ Activate fixed setpoint 1	C03009/4

#### Use of further fixed setpoints


A total of 15 different fixed setpoints can be parameterised. For the selection of the fixed setpoints 2 ... 15 the selection inputs are to be assigned with the corresponding signals. The selection of the fixed setpoints is carried out in a binary coded manner.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Ramp generator* → *All fixed setpoints*

Parameters		Lenze setting	
		Value	Unit
C03500/1	Fixed setpoint 1	10.00	%
C03500/2	Fixed setpoint 2	0.00	%
C03500/...	Fixed setpoint ...	...	...
C03500/15	Fixed setpoint 15	0.00	%

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
DigIn 4	→ Activate fixed setpoint 1	C03009/4
FALSE	→ Activate fixed setpoint 2	C03009/5
FALSE	→ Activate fixed setpoint 4 a	C03009/6
FALSE	→ Activate fixed setpoint 8 a	C03009/7

## 11.2.4.2 Setpoint inversion




[11-6] Setpoint inversion (schematic diagram)

Via the digital input DI3 the effective direction of the (bipolar) setpoint can be inverted, if required.

- ▶ Parameter setting: **Application parameter tab** → dialog level *Overview* → *Ramp generator*

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
DigIn 3	→ Invert direction of rotation	C03009/1

## 11.2.4.3 Speed ramp generator



[11-7] Ramp generator (schematic diagram)

In order to avoid setpoint step-changes the speed setpoint passes a ramp generator with a parameterisable acceleration/deceleration and S-ramp time before it is transmitted to the basic drive function "Speed follower".

► Parameter setting: Tab **Application parameter** → Dialog level *Overview*

Parameters		Lenze setting	
		Value	Unit
C03502	Basic acceleration time	1.000	s
C03503	Basic deceleration time	1.000	s
C03504	Basic S-ramp time	0.100	s
C03510	Profile mode	Linear ramps	

## Use of further ramp parameter sets


If required, 15 further ramp parameter sets can be parameterised. For the selection of the ramp parameter sets 1 ... 15 the selection inputs are to be assigned with the corresponding signals. The selection of the ramp parameter sets is carried out in a binary coded manner.

- ▶ Parameter setting: Tab **Application parameter W** Dialog level *Overview W Ramp generator W All ramp parameters*

Parameters		Lenze setting	
		Value	Unit
C03512/1	Acceleration time 1	0.000	s
C03512/...	Acceleration time ...	...	...
C03512/15	Acceleration time 15	0.000	s
C03513/1	Deceleration time 1	0.000	s
C03513/...	Deceleration time ...	...	...
C03513/15	Deceleration time 15	0.000	s
C03514/1	S-ramp time 1	0.000	s
C03514/...	S-ramp time	...	...
C03514/15	S-ramp time 15	0.000	s

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
FALSE	→ Activate ramp parameter set 1	C03009/8
FALSE	→ Activate ramp parameter set 2	C03009/9
FALSE	→ Activate ramp parameter set 4	C03009/10
FALSE	→ Activate ramp parameter set 8 a	C03009/11

## 11.2.5 Speed follower



[11-8] Basic function "Speed follower" (schematic diagram)


The speed-controlled operation is requested via the digital input DI2. If no other basic function and error state are active, the speed-controlled operation is enabled.

- ▶ The acceleration/deceleration of the drive to the setpoint is controlled via a ramp generator based on the current setpoint/actual speed.
- ▶ If the enable of the speed-controlled operation is reset via the digital input DI2, the drive is decelerated to standstill via an independent profile generator of the basic function "Stop". ▶ [Standard stop](#) (148)

 **Tip!**

Detailed information on the speed follower can be found in the chapter "basic drive functions" → subchapter "[Speed follower](#)". (190)

## 11.2.6 Manual jog



[11-9] Basic function "Manual jog" (schematic diagram)

For the setting-up operation the basic function "Manual jog" is available. It is requested via the digital input DI6. If no other basic function and error status are active, enable is carried out and the manual jog via the inputs DI7 and DI8 is possible.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Manual jog*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02620</a>	Manual jog speed 1	360.0000	Unit/s
<a href="#">C02621</a>	Manual jog speed 2	720.0000	Unit/s
<a href="#">C02622</a>	Manual acceleration	360.0000	Unit/s <sup>2</sup>
<a href="#">C02623</a>	Manual deceleration	1440.0000	Unit/s <sup>2</sup>
<a href="#">C02624</a>	Inaccuracy time of manual traversing	0.100	s

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
DigIn 6	→ Request manual jog	C03155/1
DigIn 7	→ Activate positive manual jog	C03155/2
DigIn 8	→ Activate negative manual jog	C03155/3
FALSE	→ Activate 2. speed	C03155/4




**Tip!**

Detailed information on the manual jog function can be found in chapter "Basic drive functions" → subchapter "[Manual jog](#)". (156)



## 11.2.7 Quick stop



The basic function "Quick stop" brakes the drive to standstill within the deceleration time set for the quick stop function after a corresponding request independent of the setpoint selection.

If the quick stop function is deactivated, the drive is led to the selected setpoint again via the acceleration time set in the speed ramp generator.

[11-10] Basic function "Quick stop" (schematic diagram)

- ▶ The quick stop function can be activated as follows in the Lenze setting:
  - By setting the digital input DI1 to LOW level.
  - By a master control via the port *LPortControl1*:  
By setting bit 2 of the bit-coded control word 1.
- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Quick stop*


Parameters		Lenze setting	
		Value	Unit
<a href="#">C00105</a>	Quick stop deceleration time	0.000	s
<a href="#">C00106</a>	Quick stop S-ramp time	0.00	%
<a href="#">C00107</a>	Reference for deceleration time "Quick stop"	Motor reference speed ( <a href="#">C00011</a> )	

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
DigIn 1	→ Activate quick stop 1	C03135/1
Control word 1 bit 02	→ Activate quick stop 2	C03135/2
FALSE	→ Activate quick stop 3	C03135/3

 **Tip!**

Detailed information on quick stop can be found in chapter "Basic drive functions" → subchapter "[Quick stop](#)". (📖 152)

## 11.2.8 Limiter



[11-11] Basic function "Limiter" (schematic diagram)

The basic function "Limiter", where applicable, by means of limit switches monitors travel range limits.

In the case of homing, positioning and manual jog the basic function "Limiter" if required provides for the compliance with kinematic limit values.



### Note!

The parameterised limit values are not effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)"!

For the exceeding of the limit values an error response can be set.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Limiter*

Parameters		Lenze setting	
		Value	Unit
<b>Only for homing, positioning and manual jog</b>			
<a href="#">C02702</a>	Limitations effective	Deactivated	
<a href="#">C02703</a>	Max. speed	3600.0000	Unit/s
<a href="#">C02705</a>	Max. acceleration	3600.0000	Unit/s <sup>2</sup>
<a href="#">C02706</a>	Min. S-ramp time	100	ms
<a href="#">C02707</a>	Permissible direction of rotation	Positive and negative	


Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
FALSE	→ Positive limit switch	C03150/1
FALSE	→ Negative limit switch	C03150/2



### Tip!

Detailed information on the limiter function can be found in chapter "Basic drive functions" → subchapter "[Limiter](#)". (📖 200)

## 11.2.9 Brake control



[11-12] Basic function "Brake control" (schematic diagram)

The basic function "Brake control" serves to the wear free control and monitoring of a holding brake.

In the simplest case, an optionally available brake module is used.

Alternatively the holding brake can also be controlled and monitored via the digital inputs/outputs.



### Note!

In the Lenze setting the brake control is switched off to reach a safe status after mains connection.



### Tip!

Detailed information on brake control can be found in chapter "Basic drive functions" → subchapter "[Brake control](#)". (📖 211)

# 9400 HighLine | Parameter setting & configuration

Standard TAs

TA "Actuator – speed" | Brake control

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Brake control*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02580</a>	Operating mode - brake	Brake control off	
<a href="#">C02581</a>	Brake activation threshold	50	rpm
<a href="#">C02582</a>	Brake resp. to pulse inhibit	Activate the brake immediately	
<a href="#">C02583</a>	Status input monitoring	Not active	
<a href="#">C02585</a>	Brake control polarity	Not inverted	
<a href="#">C02586</a>	Starting torque 1	0.00	Nm
<a href="#">C02587</a>	Starting torque 2	0.00	Nm
<a href="#">C02588</a>	Source of starting torque	Starting torque 1/2	
<a href="#">C02589</a>	Brake closing time	100	ms
<a href="#">C02590</a>	Brake opening time	100	ms
<a href="#">C02591</a>	Waiting time - status monit.	100	ms
<a href="#">C02593</a>	Waiting time - brake active.	0.000	s
<a href="#">C02594</a>	Test torque	0.00	Nm
<a href="#">C02595</a>	Permissible angle of rotation	5	°
<a href="#">C02596</a>	Grinding speed	100	rpm
<a href="#">C02597</a>	Accel./decel. time - grinding	1.000	s
<a href="#">C02598</a>	Grinding ON time	0.5	s
<a href="#">C02599</a>	Grinding OFF time	0.5	s

Control/setpoint inputs of the function		Signal configuration
Lenze setting	Control/setpoint input	(Multiplexer parameters)
FALSE	→ Open brake (release)	C03165/1
FALSE	→ Activate starting torque 2	C03165/2
FALSE	→ Brake status signal	C03165/3
FALSE	→ Activate brake test	C03165/4
FALSE	→ Grind brake	C03165/5
0 %	→ Additional torque	C03166

## 11.2.10 Signal configuration of drive and motor interface

If required, the preset signal configuration of the control and setpoint inputs of the drive and motor interface can be easily reconfigured per parameter setting of the assigned multiplexer parameters.

### Drive interface

Signal (Lenze setting)	Control input	Signal configuration
FALSE	→ Set controller inhibit	C03130/1
DigIn 5	→ Reset error 1	C03130/2
Control word 1 bit 07	→ Reset error 2	C03130/3
FALSE	→ Reset error 3	C03130/4
FALSE	→ Set error	C03130/5
Control word 1 bit 00	→ Switch on drive	C03130/6

### Motor interface

Signal (Lenze setting)	Setpoint input	Signal configuration
100 %	→ Upper torque limit value	C03141/1
-100 %	→ Lower torque limit value	C03141/2

## 11.2.11 Signal configuration of the output ports

If required, the preset signal configuration of the output ports can be easily reconfigured per parameter setting of the assigned multiplexer parameters.

### "LPortAxisOut1" output port

The output port **LPortAxisOut1** is intended for the connection with a following axis.

Signal (Lenze setting)	Output port	Signal configuration
<b>Axis status word</b>		
• Application-specific signals can be supplemented.		
Drive ready	→ Axis status word bit 00	C03120/1
FALSE	→ Axis status word bit 01	C03120/2
Operation enabled	→ Axis status word bit 02	C03120/3
Error is active.	→ Axis status word bit 03	C03120/4
FALSE	→ Axis status word bit 04	C03120/5
Quick stop active	→ Axis status word bit 05	C03120/6
Drive is ready to start	→ Axis status word bit 06	C03120/7
Warning active	→ Axis status word bit 07	C03120/8
FALSE	→ Axis status word bit 08	C03120/9
FALSE	→ Axis status word bit 09	C03120/10
FALSE	→ Axis status word bit 10	C03120/11
Motor control limited	→ Axis status word bit 11	C03120/12
FALSE	→ Axis status word bit 12	C03120/13
FALSE	→ Axis status word bit 13	C03120/14
FALSE	→ Axis status word bit 14	C03120/15
FALSE	→ Axis status word bit 15	C03120/16
<b>Setpoints for horizontal communication</b>		
Filtered torque setpoint	→ Axis-Port Out 1	C03124/1
Speed setpoint	→ Axis-Port Out 2	C03124/2

**Output port "LPortStatus1"**

The output port **LPortStatus1** is intended for the connection with a higher-level control.

Signal (Lenze setting)	Output port	Signal configuration
<b>Status word 1</b>		
Drive ready	→ Status word 1 bit 00	C03121/1
FALSE	→ Status word 1 bit 01	C03121/2
Operation enabled	→ Status word 1 bit 02	C03121/3
Error is active.	→ Status word 1 bit 03	C03121/4
FALSE	→ Status word 1 bit 04	C03121/5
Quick stop active	→ Status word 1 bit 05	C03121/6
Drive is ready to start	→ Status word 1 bit 06	C03121/7
Warning active	→ Status word 1 bit 07	C03121/8
FALSE	→ Status word 1 bit 08	C03121/9
FALSE	→ Status word 1 bit 09	C03121/10
FALSE	→ Status word 1 bit 10	C03121/11
Motor control limited	→ Status word 1 bit 11	C03121/12
FALSE	→ Status word 1 bit 12	C03121/13
FALSE	→ Status word 1 bit 13	C03121/14
FALSE	→ Status word 1 bit 14	C03121/15
FALSE	→ Status word 1 bit 15	C03121/16

**Output port "LPortStatus2"**

Signal (Lenze setting)	Output port	Signal configuration
<b>Status word 2</b>		
FALSE	→ Status word 2 bit 00	C03122/1
FALSE	→ Status word 2 bit 01	C03122/2
FALSE	→ Status word 2 bit 02	C03122/3
FALSE	→ Status word 2 bit 03	C03122/4
FALSE	→ Status word 2 bit 04	C03122/5
FALSE	→ Status word 2 bit 05	C03122/6
FALSE	→ Status word 2 bit 06	C03122/7
FALSE	→ Status word 2 bit 07	C03122/8
FALSE	→ Status word 2 bit 08	C03122/9
FALSE	→ Status word 2 bit 09	C03122/10
FALSE	→ Status word 2 bit 10	C03122/11
FALSE	→ Status word 2 bit 11	C03122/12
FALSE	→ Status word 2 bit 12	C03122/13
FALSE	→ Status word 2 bit 13	C03122/14
FALSE	→ Status word 2 bit 14	C03122/15
FALSE	→ Status word 2 bit 15	C03122/16

## 11.2.12 Application error messages

For the output of application-specific error messages an FB instance *ApplicationError* of the function block **L\_DevApplErr** is available in the network.

- ▶ Via the 8 boolean inputs up to 8 different application error messages with parameterisable module ID, error ID and error response can be released by the application.

Error message		Error-ID	Error response
1	Speed follower in limitation	8001	Warning locked
2	-	8000	Error
3	-	8000	Error
4	-	8000	Error
5	-	8000	Error
6	-	8000	Error
7	-	8000	Error
8	-	8000	Error

- ▶ Parameter setting: Tab **All parameters**

Parameters		Lenze setting
C05900	Module-ID	980
C05901/1...8	Error ID 1 ... 8	See table above
C05902/1...8	Error response 1 ... 8	See table above

### Reset of error message

In the Lenze setting the digital input DI5 for resetting (acknowledging) an error message is connected to the input *DI\_bResetError1* of the drive interface.



### 11.3 TA "Actuator – torque"

When the technology application "actuator – torque" is used the drive creates a torque to be specified independent of the motor speed. A superimposed speed limitation prevents the drive from accelerating in an uncontrolled mode. The torque setpoint and torque limit value are the main setpoint values of the application.


- ▶ The setpoint of the motor torque can be specified for both directions. The drive accordingly acts in a driving or braking way. With a unipolar setpoint the effective direction can be changed via the digital input DI3.
- ▶ After the enable of the torque-controlled operation via the digital input DI2 the creation of the torque is controlled via a ramp generator starting from the current torque.
- ▶ The torque limit value to be specified refers to the freely setting direction of rotation with positive torque. Based on the current motor speed the internal speed limit value is also led to the setpoint via a ramp generator after enable.
- ▶ If the specified speed limit value directly corresponds to the line speed, the internal limit value can be increased by entering an offset in C03008.
- ▶ The speed limit value in negative direction of rotation equals, according to amount, the limit value for the positive direction of rotation.
- ▶ If the speed of the drive is inside the limitations, the motor generates the specified torque.
- ▶ If the positive or negative speed limit value (for CW or CCW rotation) is reached, the drive changes to the speed-controlled operation. The set speed limit values are not exceeded.

#### Basic drive functions

- ▶ A quick stop can be activated via the digital input DI1.
  - ▶ [Quick stop](#) (☞ 279)
- ▶ A manual control is provided for the setting-up operation. It is enabled via the digital input DI6. The inputs DI7 and DI8 activate parameterisable setpoints for both directions of rotation. ▶ [Manual jog](#) (☞ 278)
- ▶ The basic function "limiter" enables the travel range to be monitored via limit switches.
  - ▶ [Limiter](#) (☞ 258)
- ▶ When a brake is available the brake control opens and closes the brake. ▶ [Brake control](#) (☞ 281)

See also: ▶ [Basic drive functions](#) (☞ 140)

## 11.3.1 Basic signal flow



[11-13] Signal flow of the TA "Actuator – torque" (schematic diagram)

### Torque setpoint conditioning

- A** Setpoint gain
- B** Setpoint inversion
- C** Ramp generator

### Speed limit value conditioning

- D** Offset
- E** Selection of analog input/fixed setpoints
- F** Speed profile generator

### Basic drive functions


- G** Torque follower
- H** Manual jog
- I** Quick stop
- J** Stop
- K** Brake control (optional)
- L** Limiter (optional)

## 11.3.2 Assignment of the I/O terminals


### 11.3.2.1 Setpoint and control signals

The following tables contain the Lenze assignment of the analog and digital inputs for the technology application "actuator – torque".

#### Analog inputs

Terminal X3	Signal (Lenze setting)	
	<b>AI1-</b> <b>AI1+</b> Torque setpoint <a href="#">▶ Torque setpoint conditioning (271)</a>	
	<b>AI2-</b> <b>AI2+</b> Speed limit value <a href="#">▶ Speed limit value conditioning (273)</a>	
	<a href="#">▶ I/O terminals</a> ▶ <a href="#">Analog inputs (117)</a>	

#### Digital inputs


Terminal X5	Signal (Lenze setting)														
	<b>DI1</b> Quick stop <ul style="list-style-type: none"> <li>If DI1 is set to LOW level, the drive is decelerated to standstill within the deceleration time set for the quick stop function independent of the setpoint selection.</li> <li>If the quick stop function is deactivated, the defined torque is available again, as the case may be, an acceleration via the set acceleration time of the speed limit value is effected.</li> </ul> <a href="#">▶ Quick stop (279)</a>														
	<b>DI2</b> Enable torque follower <a href="#">▶ Torque follower (277)</a>														
	<b>DI3</b> Invert torque setpoint														
	<b>DI4</b> Activate fixed setpoint 1 Instead of the selection via the analog input 2 the fixed setpoint 1 is used as speed limit value. <a href="#">▶ Change-over to fixed setpoint (274)</a>														
	<b>DI5</b> Reset error <ul style="list-style-type: none"> <li>By means of a LOW-HIGH edge an existing error status can be reset if the cause of the fault is removed.</li> </ul>														
	<b>DI6</b> Manual jog <a href="#">▶ Manual jog (278)</a>														
	<table border="1"> <thead> <tr> <th>DI7</th> <th>DI8</th> <th>Function</th> </tr> </thead> <tbody> <tr> <td>LOW</td> <td>LOW</td> <td>Stop</td> </tr> <tr> <td>HIGH</td> <td>LOW</td> <td>Manual control in positive direction</td> </tr> <tr> <td>LOW</td> <td>HIGH</td> <td>Manual control in negative direction</td> </tr> <tr> <td>HIGH</td> <td>HIGH</td> <td>- (previous state remains active)</td> </tr> </tbody> </table>	DI7	DI8	Function	LOW	LOW	Stop	HIGH	LOW	Manual control in positive direction	LOW	HIGH	Manual control in negative direction	HIGH	HIGH
DI7	DI8	Function													
LOW	LOW	Stop													
HIGH	LOW	Manual control in positive direction													
LOW	HIGH	Manual control in negative direction													
HIGH	HIGH	- (previous state remains active)													
<a href="#">▶ I/O terminals</a> ▶ <a href="#">Digital inputs (123)</a>															

#### 11.3.2.2 Actual value and status signals

The following tables contain the Lenze assignment of the analog and digital outputs for the technology application "actuator – torque".


- The default signal configuration if required can be easily changed by parameterising the multiplexer parameters assigned.

#### Analog outputs

Terminal X3	Signal (Lenze setting)	Signal configuration
	<b>AO1</b> Motor speed • Scaling: $\pm 10\text{ V} \equiv$ motor reference speed ( <a href="#">C00011</a> )	C03110/1
	<b>AO2</b> Motor torque (setpoint) • Scaling: $\pm 10\text{ V} \equiv$ Motor reference torque ( <a href="#">C00057/2</a> )	C03110/2


► [I/O terminals](#) ► [Analog outputs](#) ([120](#))

#### Digital outputs

Terminal X4	Signal (Lenze setting)	Signal configuration
	<b>DO1</b> Status "Drive ready" • This operating state is active if the controller is enabled by setting the digital input RFR to HIGH level and no error has occurred.	C03100/1
	<b>DO2</b> Status "Torque follower enabled" • The torque follower has been enabled via the digital input DI2.	C03100/2
	<b>DO3</b> Status "Torque follower in limitation" • If the torque follower is enabled, the torque setpoint or the current setpoint are within the limitation.	C03100/3
	<b>DO4</b> Status "Error active acknowledgement is required" • Monitoring with the error response "Error" or "Quick stop by trouble" has been activated, and the controller is in the device state "Error active" or "Quick stop by trouble active".	C03100/4


► [I/O terminals](#) ► [Digital outputs](#) ([125](#))

#### State bus

Terminal X2	Signal (Lenze setting)	Signal configuration
	<b>SB</b> Status "Torque follower in limitation" • If the torque follower is enabled, the torque setpoint or the current setpoint are within the limitation. • The state bus is put in the "error" status.	C03100/5


► [I/O terminals](#) ► [Monitoring function "State bus"](#) ([127](#))

## Display elements

User LED	Signal (Lenze setting)	Signal configuration
	Status "Torque follower enabled" <ul style="list-style-type: none"><li>• The torque follower has been enabled via the digital input DI2.</li></ul>	C03100/6

▶ [Drive interface](#) ▶ [LED status displays](#) (📖 34)

## 11.3.3 Machine parameters



The machine parameters describe e.g. the motor end of the mechanics used.

The setting of the machine parameters in the »Engineer« is carried out on the **Application parameters** tab in the dialog level *Overview* → *Drive interface*.



**Tip!**


In the »Engineer« the most important machine parameters can be adapted to the machine on the **Application parameter** tab directly in the topmost *Overview* dialog level:

Detailed information for selecting and entering the machine parameters can be found in the chapter "[Drive interface](#)". ▶ [Machine parameters](#) (📖 35)

### Short overview of machine parameters

Parameters		Lenze setting	
		Value	Unit
<a href="#">C00173</a>	Mains - voltage	400/415	V
<a href="#">C00174</a>	Threshold undervoltage (LU)	285	V
<a href="#">C00600</a>	Resp. to DC bus overvoltage	Trouble	
<a href="#">C02520</a>	Gearbox fact. numer. motor	1	
<a href="#">C02521</a>	Gearbox fact. denom. motor	1	
<a href="#">C02527</a>	Motor mounting direction	Motor rotating CW	
<a href="#">C02570</a>	Controller configuration	Phase control	
<a href="#">C02522</a>	Gearbox fact. numer. load	1	
<a href="#">C02523</a>	Gearbox fact. denom. load	1	
<b>Description of the mechanics (load, tool)</b>			
<a href="#">C02528</a>	Traversing range	Unlimited	
<a href="#">C02524</a>	Feed constant	360.0000	Unit
<a href="#">C02525</a>	Unit	°	
<a href="#">C02526</a>	User-defined unit	°	
<a href="#">C02533</a>	Time unit	s	
<a href="#">C00273/1</a>	Motor moment of inertia	Motor-dependent	kg cm <sup>2</sup>
<a href="#">C00273/2</a>	Load moment of inertia	0.00	kg cm <sup>2</sup>

## 11.3.4 Torque setpoint conditioning



[11-14] Torque setpoint conditioning (schematic diagram)


The torque setpoint is defined in the Lenze setting via the analog input 1 and take place in both directions (bipolar) and accordingly the drive acts in a driving or braking manner.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview*

Parameters		Lenze setting	
		Value	Unit
C03002	Setpoint gain	100.00	%

Setpoint inputs of the function		Signal configuration
Lenze setting	Setpoint input	(Multiplexer parameters)
AIn 1	→ Torque setpoint	C03000

## 11.3.4.1 Setpoint inversion




[11-15] Setpoint inversion (schematic diagram)

Via the digital input DI3 the effective direction of the (bipolar) setpoint can be inverted, if required.

► Parameter setting: **All parameters** tab → Category *Actuator - torque* → *Multiplexer*

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
DigIn 3	→ Invert setpoint	C03003

## 11.3.4.2 Ramp generator



[11-16] Ramp generator (schematic diagram)


In order to avoid setpoint step-changes the torque setpoint passes a ramp generator with a parameterisable acceleration/deceleration and S-ramp time before it is transmitted to the basic drive function "Torque follower".

► Parameter setting: Tab **Application parameter** → Dialog level *Overview*

Parameters		Lenze setting	
		Value	Unit
C03550	Acceleration / deceleration time	0.010	s
C03551	S-ramp time	0.001	s



## 11.3.5 Speed limit value conditioning



[11-17] Speed limit value conditioning (schematic diagram)


The speed limit value is defined in the Lenze setting via the analog input 2.

- ▶ The defined speed limit value refers to the direction of rotation which can be set freely with positive torque.
- ▶ The speed limit value in negative direction of rotation equals, according to amount, the limit value for the positive direction of rotation.
- ▶ If the speed of the drive is inside the limitations, the motor generates the specified torque.
- ▶ If the positive or negative speed limit value (for CW or CCW rotation) is reached, the drive changes to the speed-controlled operation. The set speed limit values are not exceeded.
- ▶ If the specified speed limit value directly corresponds to the line speed, the internal limit value can be increased by entering an offset in C03008.
- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview*

Parameters		Lenze setting	
		Value	Unit
C03008	Offset for limit speed	0.00	%

Setpoint inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Setpoint input	
AIN 2	→ Upper limit speed	C03006
Inverted upper limit speed	→ Lower speed limit value	C03171

## 11.3.5.1 Change-over to fixed setpoint



[11-18] Additional offset for the speed limit value (schematic diagram)

Via the digital input DI4 a change-over to a parameterisable fixed setpoint can take place.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview*

Parameters		Lenze setting	
		Value	Unit
C03500/1	Fixed setpoint 1	10.00	%

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
DigIn 4	→ Activate fixed setpoint 1	C03009/4

### Use of further fixed setpoints


A total of 15 different fixed setpoints can be parameterised. For the selection of the fixed setpoints 2 ... 15 the selection inputs are to be assigned with the corresponding signals. The selection of the fixed setpoints is carried out in a binary coded manner.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Ramp generator* → *All fixed setpoints*

Parameters		Lenze setting	
		Value	Unit
C03500/1	Fixed setpoint 1	10.00	%
C03500/2	Fixed setpoint 2	0.00	%
C03500/...	Fixed setpoint ...	...	...
C03500/15	Fixed setpoint 15	0.00	%

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
DigIn 4	→ Activate fixed setpoint 1	C03009/4
FALSE	→ Activate fixed setpoint 2	C03009/5
FALSE	→ Activate fixed setpoint 4 a	C03009/6
FALSE	→ Activate fixed setpoint 8 a	C03009/7

11.3.5.2 Speed ramp generator



[11-19] Ramp generator (schematic diagram)

In order to avoid setpoint step-changes the speed limit value passes a ramp generator with a parameterisable acceleration and deceleration time before it is transmitted to the basic drive function "Torque follower".

► Parameter setting: Tab **Application parameter** → Dialog level *Overview*

Parameters		Lenze setting	
		Value	Unit
C03502	Basic acceleration time	1.000	s
C03503	Basic deceleration time	1.000	s
C03510	Profile mode	Linear ramps	

## Use of further ramp parameter sets


If required, 15 further ramp parameter sets can be parameterised. For the selection of the ramp parameter sets 1 ... 15 the selection inputs are to be assigned with the corresponding signals. The selection of the ramp parameter sets is carried out in a binary coded manner.

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Ramp generator* → *All ramp parameters*

Parameters		Lenze setting	
		Value	Unit
C03512/1	Acceleration time 1	0.000	s
C03512/...	Acceleration time ...	...	...
C03512/15	Acceleration time 15	0.000	s
C03513/1	Deceleration time 1	0.000	s
C03513/...	Deceleration time ...	...	...
C03513/15	Deceleration time 15	0.000	s
C03514/1	S-ramp time 1	0.000	s
C03514/...	S-ramp time	...	...
C03514/15	S-ramp time 15	0.000	s

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
FALSE	→ Activate ramp parameter set 1	C03009/8
FALSE	→ Activate ramp parameter set 2	C03009/9
FALSE	→ Activate ramp parameter set 4	C03009/10
FALSE	→ Activate ramp parameter set 8 a	C03009/11

## 11.3.6 Torque follower



[11-20] Basic function "Torque follower" (schematic diagram)


The torque-controlled operation is requested via the digital input DI2. If no other basic function and error state are active, the torque-controlled operation is enabled.

- ▶ The build-up of the defined torque is controlled via a ramp generator based on the current torque.
- ▶ Based on the current motor speed the internal speed limit value is also led to the setpoint via a ramp generator after the operation is enabled.
- ▶ If the enable of the torque-controlled operation is reset via the digital input DI2, the drive is decelerated to standstill via an independent profile generator of the basic function "Stop". ▶ [Standard stop](#) (148)

 **Tip!**

Detailed information on the torque follower can be found in the chapter "basic drive functions" → subchapter "[Torque follower](#)". (196)

## 11.3.7 Manual jog



[11-21] Basic function "Manual jog" (schematic diagram)

For the setting-up operation the basic function "Manual jog" is available. It is requested via the digital input DI6. If no other basic function and error status are active, enable is carried out and the manual jog via the inputs DI7 and DI8 is possible.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Manual jog*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02620</a>	Manual jog speed 1	360.0000	Unit/s
<a href="#">C02621</a>	Manual jog speed 2	720.0000	Unit/s
<a href="#">C02622</a>	Manual acceleration	360.0000	Unit/s <sup>2</sup>
<a href="#">C02623</a>	Manual deceleration	1440.0000	Unit/s <sup>2</sup>
<a href="#">C02624</a>	Inaccuracy time of manual traversing	0.100	s


Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
DigIn 6	→ Request manual jog	C03155/1
DigIn 7	→ Activate positive manual jog	C03155/2
DigIn 8	→ Activate negative manual jog	C03155/3
FALSE	→ Activate 2. speed	C03155/4



**Tip!**

Detailed information on the manual jog function can be found in chapter "Basic drive functions" → subchapter "[Manual jog](#)". (156)

## 11.3.8 Quick stop



[11-22] Basic function "Quick stop" (schematic diagram)

The basic function "Quick stop" brakes the drive to standstill within the deceleration time set for the quick stop function after a corresponding request independent of the setpoint selection.

If the quick stop is deactivated, the defined torque is available again, as the case may be, an acceleration via the set acceleration time of the speed limit value is effected.

- ▶ The quick stop function can be activated as follows in the Lenze setting:
  - By setting the digital input DI1 to LOW level.
  - By a master control via the port *LPortAxisIn1*:  
By setting bit 3 of the bit-coded axis control word.
- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Quick stop*


Parameters		Lenze setting	
		Value	Unit
<a href="#">C00105</a>	Quick stop deceleration time	0.000	s
<a href="#">C00106</a>	Quick stop S-ramp time	0.00	%
<a href="#">C00107</a>	Reference for deceleration time "Quick stop"	Motor reference speed ( <a href="#">C00011</a> )	

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
DigIn 1	→ Activate quick stop 1	C03135/1
Axis control word bit 03	→ Activate quick stop 2	C03135/2
FALSE	→ Activate quick stop 3	C03135/3

**Tip!**

Detailed information on quick stop can be found in chapter "Basic drive functions" → subchapter "[Quick stop](#)". (📖 152)

## 11.3.9 Limiter



[11-23] Basic function "Limiter" (schematic diagram)

The basic function "Limiter", where applicable, by means of limit switches monitors travel range limits.

In the case of homing, positioning and manual jog the basic function "Limiter" if required provides for the compliance with kinematic limit values.



### Note!

The parameterised limit values are not effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)"!

For the exceeding of the limit values an error response can be set.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Limiter*

Parameters		Lenze setting	
		Value	Unit
<b>Only for homing, positioning and manual jog</b>			
<a href="#">C02702</a>	Limitations effective	Deactivated	
<a href="#">C02703</a>	Max. speed	3600.0000	Unit/s
<a href="#">C02705</a>	Max. acceleration	3600.0000	Unit/s <sup>2</sup>
<a href="#">C02706</a>	Min. S-ramp time	100	ms
<a href="#">C02707</a>	Permissible direction of rotation	Positive and negative	

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
FALSE	→ Positive limit switch	C03150/1
FALSE	→ Negative limit switch	C03150/2




### Tip!

Detailed information on the limiter function can be found in chapter "Basic drive functions" → subchapter "[Limiter](#)". (📖 200)



## 11.3.10 Brake control



[11-24] Basic function "Brake control" (schematic diagram)

The basic function "Brake control" serves to the wear free control and monitoring of a holding brake.

In the simplest case, an optionally available brake module is used.

Alternatively the holding brake can also be controlled and monitored via the digital inputs/outputs.

**Note!**

In the Lenze setting the brake control is switched off to reach a safe status after mains connection.

**Tip!**

Detailed information on brake control can be found in chapter "Basic drive functions" → subchapter "[Brake control](#)". (211)

# 9400 HighLine | Parameter setting & configuration

Standard TAs

TA "Actuator – torque" | Brake control

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Brake control*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02580</a>	Operating mode - brake	Brake control off	
<a href="#">C02581</a>	Brake activation threshold	50	rpm
<a href="#">C02582</a>	Brake reaction in case of pulse inhibit	Activate the brake immediately	
<a href="#">C02583</a>	Status input monitoring	Not active	
<a href="#">C02585</a>	Brake control polarity	Not inverted	
<a href="#">C02586</a>	Starting torque 1	0.00	Nm
<a href="#">C02587</a>	Starting torque 2	0.00	Nm
<a href="#">C02588</a>	Source of starting torque	Starting torque 1/2	
<a href="#">C02589</a>	Brake closing time	100	ms
<a href="#">C02590</a>	Brake opening time	100	ms
<a href="#">C02591</a>	Waiting time - status monit.	100	ms
<a href="#">C02593</a>	Waiting time - brake active.	0.000	s
<a href="#">C02594</a>	Test torque	0.00	Nm
<a href="#">C02595</a>	Permissible angle of rotation	5	°
<a href="#">C02596</a>	Grinding speed	100	rpm
<a href="#">C02597</a>	Accel./decel. time - grinding	1.000	s
<a href="#">C02598</a>	Grinding ON time	0.5	s
<a href="#">C02599</a>	Grinding OFF time	0.5	s

Control/setpoint inputs of the function		Signal configuration
Lenze setting	Control/setpoint input	(Multiplexer parameters)
FALSE	→ Open brake (release)	C03165/1
FALSE	→ Activate starting torque 2	C03165/2
FALSE	→ Brake status signal	C03165/3
FALSE	→ Activate brake test	C03165/4
FALSE	→ Grind brake	C03165/5
0 %	→ Additional torque	C03166

## 11.3.11 Signal configuration of drive and motor interface

If required, the preset signal configuration of the control and setpoint inputs of the drive and motor interface can be easily reconfigured per parameter setting of the assigned multiplexer parameters.

### Drive interface

Signal (Lenze setting)	Control input	Signal configuration
FALSE	→ Set controller inhibit	C03130/1
FALSE	→ Set error	C03130/2
Axis control word bit 00	→ Switch on drive	C03130/3
DigIn 5	→ Reset error 1	C03130/4
Axis control word bit 07	→ Reset error 2	C03130/5
FALSE	→ Reset error 3	C03130/6

### Motor interface

Signal (Lenze setting)	Setpoint input	Signal configuration
100 %	→ Upper torque limit value	C03141/1
-100 %	→ Lower torque limit value	C03141/2

#### 11.3.12 Signal configuration of the output ports

If required, the preset signal configuration of the output ports can be easily reconfigured per parameter setting of the assigned multiplexer parameters.

##### "LPortAxisOut1" output port

The output port **LPortAxisOut1** is intended for the connection with a following axis.

Signal (Lenze setting)	Output port	Signal configuration
<b>Axis status word</b>		
• Application-specific signals can be supplemented.		
Drive ready	→ Axis status word bit 00	C03120/1
FALSE	→ Axis status word bit 01	C03120/2
Operation enabled	→ Axis status word bit 02	C03120/3
Error is active.	→ Axis status word bit 03	C03120/4
FALSE	→ Axis status word bit 04	C03120/5
Quick stop active	→ Axis status word bit 05	C03120/6
Drive is ready to start	→ Axis status word bit 06	C03120/7
Warning active	→ Axis status word bit 07	C03120/8
FALSE	→ Axis status word bit 08	C03120/9
FALSE	→ Axis status word bit 09	C03120/10
FALSE	→ Axis status word bit 10	C03120/11
Motor control limited	→ Axis status word bit 11	C03120/12
FALSE	→ Axis status word bit 12	C03120/13
FALSE	→ Axis status word bit 13	C03120/14
FALSE	→ Axis status word bit 14	C03120/15
FALSE	→ Axis status word bit 15	C03120/16
<b>Setpoints for horizontal communication</b>		
Filtered torque limit value	→ Axis-Port Out 1	C03124/1
Filtered torque setpoint	→ Axis-Port Out 2	C03124/2

## Output port "LPortStatus1"

The output port **LPortStatus1** is intended for the connection with a higher-level control.

Signal (Lenze setting)	Output port	Signal configuration
<b>Status word 1</b>		
Drive ready	→ Status word 1 bit 00	C03121/1
FALSE	→ Status word 1 bit 01	C03121/2
Operation enabled	→ Status word 1 bit 02	C03121/3
Error is active.	→ Status word 1 bit 03	C03121/4
FALSE	→ Status word 1 bit 04	C03121/5
Quick stop active	→ Status word 1 bit 05	C03121/6
Drive is ready to start	→ Status word 1 bit 06	C03121/7
Warning active	→ Status word 1 bit 07	C03121/8
FALSE	→ Status word 1 bit 08	C03121/9
FALSE	→ Status word 1 bit 09	C03121/10
FALSE	→ Status word 1 bit 10	C03121/11
Motor control limited	→ Status word 1 bit 11	C03121/12
FALSE	→ Status word 1 bit 12	C03121/13
FALSE	→ Status word 1 bit 13	C03121/14
FALSE	→ Status word 1 bit 14	C03121/15
FALSE	→ Status word 1 bit 15	C03121/16

## Output port "LPortStatus2"

Signal (Lenze setting)	Output port	Signal configuration
<b>Status word 2</b>		
FALSE	→ Status word 2 bit 00	C03122/1
FALSE	→ Status word 2 bit 01	C03122/2
FALSE	→ Status word 2 bit 02	C03122/3
FALSE	→ Status word 2 bit 03	C03122/4
FALSE	→ Status word 2 bit 04	C03122/5
FALSE	→ Status word 2 bit 05	C03122/6
FALSE	→ Status word 2 bit 06	C03122/7
FALSE	→ Status word 2 bit 07	C03122/8
FALSE	→ Status word 2 bit 08	C03122/9
FALSE	→ Status word 2 bit 09	C03122/10
FALSE	→ Status word 2 bit 10	C03122/11
FALSE	→ Status word 2 bit 11	C03122/12
FALSE	→ Status word 2 bit 12	C03122/13
FALSE	→ Status word 2 bit 13	C03122/14
FALSE	→ Status word 2 bit 14	C03122/15
FALSE	→ Status word 2 bit 15	C03122/16

### 11.3.13 Application error messages

For the output of application-specific error messages an FB instance *ApplicationError* of the function block **L\_DevApplErr** is available in the network.

- ▶ Via the 8 boolean inputs up to 8 different application error messages with parameterisable module ID, error ID and error response can be released by the application.

Error message		Error-ID	Error response
1	Torque follower in limitation	8001	Warning locked
2	-	8000	Error
3	-	8000	Error
4	-	8000	Error
5	-	8000	Error
6	-	8000	Error
7	-	8000	Error
8	-	8000	Error

- ▶ Parameter setting: Tab **All parameters**



Parameters		Lenze setting
C05900	Module-ID	980
C05901/1...8	Error ID 1 ... 8	See table above
C05902/1...8	Error response 1 ... 8	See table above

#### Reset of error message

In the Lenze setting the digital input DI5 for resetting (acknowledging) an error message is connected to the input *DI\_bResetError1* of the drive interface.

### 12 TAs for interconnection via electrical shaft

The technology applications described in this chapter are available for a DC-bus operation of several drives via the electrical shaft.


Technology application/application ranges	Required license/delivery
<p><a href="#">TA "Electronic gearbox" (📖 297)</a></p>  <ul style="list-style-type: none"> <li>• Slitters</li> <li>• Calender drives</li> <li>• Line drives</li> <li>• Conveying belts</li> <li>• Vibrators</li> <li>• Roller mills</li> <li>• Stretching machines</li> <li>• Wire drawing machines</li> </ul>	<p>License stage Motion Control HighLevel or higher required. The technology application can be selected in the »Engineer« application catalog.</p>
<p><a href="#">TA "Synchronism with mark synchronisation" (📖 332)</a></p>  <ul style="list-style-type: none"> <li>• Printing units</li> <li>• Asynchronous cross cutters</li> <li>• Perforating machines</li> <li>• Insetters</li> <li>• Vibrating drives</li> <li>• Line drives</li> <li>• Labelling machines</li> </ul>	<p>License stage Motion Control HighLevel or higher required. The technology application can be selected in the »Engineer« application catalog.</p>

#### 12.1 Introduction

The following subchapters provide information on the electrical shaft.

##### 12.1.1 Synchronisation of the drives via a master angle

By coupling the drives via a master angle the positions are firmly allocated to each other like a mechanical shaft.



- ▶ A drive with a virtual master or a real master (encoder) is able to create the master angle and transmit this to the other drives which follow this master angle.


#### Advantages of this type of synchronisation

- ▶ The communication between the drives is very simple. A time-consuming evaluation of the status signals of each drive and the control signals to be generated from it for each single drive is not required.
- ▶ Due to the flexible electronics trimming functions can be carried out very easily. Thus, motion sequences in machines can be easily synchronised and optimised.
- ▶ A variation of the master angle speed changes the number of cycles of the machine. The drives keep the position allocation.



## 12.1.2 Virtual master/real master


### Virtual master



[12-1] Example "Virtual master" (with master value transmission via digital frequency extension module)

- ▶ In an interconnection, a drive takes over the task of the (virtual) master and is the first slave drive at the same time.
- ▶ The master value created in the TA by the "Virtual master" function is transmitted via a bus system or the digital frequency output to the other slave drives.

### Real master



[12-2] Example "Real master" (with master value transmission via digital frequency extension module)

- ▶ The master value for a slave drive can be also specified by a real master (e.g. external encoder).
- ▶ The master value can be specified e.g. via the digital frequency input of the master frequency extension module or a bus system.
- ▶ The master value (possibly conditioned in the TA) by the "Virtual master" function is transmitted via a bus system or the digital frequency output to the other slave drives.

## 12.1.3 Transmission of the master angle

The master value/angle can be transmitted via the following transmission media:

- ▶ Digital frequency
- ▶ System bus (CAN)
- ▶ ETHERNET Powerlink (in preparation)

The suitable bus medium is selected according to the criteria listed in the following sections:

### Digital frequency (simulation of an incremental encoder)

- ▶ Rail or cascade structure is possible.
- ▶ Only relative master value/master angle possible.
- ▶ Max resolution 16 bits/revolution
- ▶ Cable length is virtually unlimited but must not exceed 50 m from drive to drive.
- ▶ Digital frequency extension module is required.

### System bus (CAN)

- ▶ No cascade structure possible.
- ▶ Optionally absolute or relative master angle transfer possible.
- ▶ Resolution up to 28 bits/revolution (in preparation; currently 16 bits/revolution).
- ▶ Cable length is limited (dependent on baud rate, number of nodes and cable cross-section).
  - With a baud rate of 500 Kbit/s the total cable length is limited to e.g. 117 metres.
- ▶ Interface of 9400 HighLine is already integrated.
  - ▶ [System bus "CAN on board"](#) (☞ 134)



### Note!

For detailed information about the CANopen system bus interface, please see the "CAN on-board 9400" Communication Manual.

### ETHERNET Powerlink (in preparation)

- ▶ Rail or cascade structure is possible.
- ▶ Optionally absolute or relative master angle transfer possible.
- ▶ Resolution up to 28 bits/revolution.
- ▶ Cable length is virtually unlimited but must not exceed 100 m from drive to drive.
- ▶ Additional hardware (communication module ETHERNET Powerlink) is required.



## Note!

For detailed information about the ETHERNET Powerlink, please see the "Ethernet" Communication Manual.

### 12.1.4 Speed or angular synchronism?

The decision whether to use a speed or angular synchronism mainly refers to the [TA "Electronic gearbox"](#) (☞ 297)

#### Angular synchronism

Use the angular synchronism if the material is not able to absorb any force and no remaining positional variation may be available. Please note that a position controller always causes additional trouble in a track since disturbances and reference value variations must be compensated exactly.

#### Speed synchronism

Use the speed synchronism if the material is able to absorb force which ensures a better concentricity.

### 12.1.5 Rail or cascade structure?

#### Rail structure

All drives obtain the same master value/master angle.

#### Cascade structure

Each drive obtains its own master value/master angle which is created or merely prepared through the upstream drive.

### 12.1.6 Master or actual value transfer?

#### Master value transmission

The master value transfer results in a much quieter machine running. The mark corrections, superimposed control functions and disturbances of the drive, however, do not affect the system.

#### Actual value transfer

The actual value transfer results in an uneven machine running. Mark corrections, superimposed control functions and disturbances of the leading drive affect the system.

## 12.1.7 Absolute or relative master angle processing?

### Absolute master angle processing


All drives have a common fix reference to each other via the position of the master angle.

### Relative master value/master angle processing

Stands for a high-precision transmission of the master value. However, there is no firm reference to the other drives (e.g. in case of a material path each printing roll is synchronised one by one to the print image).

## 12.1.8 Functions with synchronisation via the electrical shaft

The functions of the electrical shaft are built on each other and thus are scalable:



### Electronic gearbox

The electronic gearbox represents the simplest function in the DC-bus operation via the electrical shaft. The function is suited for e.g. material transport or material processing. A direct synchronism of tools to a material path can be created without direct position reference or for stretching plants with adjustable stretching ratio.

▶ [TA "Electronic gearbox"](#) (📖 297)

### Absolute synchronism

This function is suited for applications with continuously rotating tools (e.g. groove cylinder), which are fed with material in a fixed machine cycle and for which several tools have to be synchronised to each other.

### Relative synchronism (with mark synchronisation)

This function is suited for processing continuous material in the form of a material web. Here the tools (e.g. pressure cylinders) are aligned via marks to e.g. print images which are located on the web. There must be no risk of collision. We distinguish between "Relative synchronism with register formation and mark synchronisation" and "Relative synchronism with register control".

▶ [TA "Synchronism with mark synchronisation"](#) (📖 332)

### Absolute table synchronism (cam)


Like "Absolute synchronism", although the tools can also perform a non-linear movement.

## Relative table synchronism (with mark synchronisation)

Like "Relative synchronism", although the tools can also perform a non-linear movement.


### 12.1.9 Application examples

#### Electronic gearbox with virtual master



[12-3] Electronic gearbox with virtual master (rail)

#### Electronic gearbox with real master




[12-4] Electronic gearbox with real master (rail)

## Electronic gearbox as cascade

The technology application "Electronic gearbox" is often operated as cascade since changes of speed/gearbox ratio of an upstream drive also have an effect on the subsequent drive.

- ▶ Typical applications are, for instance, stretching machines, wire drawing machines and roller mills.
- ▶ There is no position reference between tool and material. However, it may be required to position the tools for maintenance work.
- ▶ The master speed is transmitted via the digital frequency or ETHERNET Powerlink (in preparation).



[12-5] Electronic gearbox with real master (cascade)


- ▶ The following applies to the speed of the web in case of a cascade:

$$v_3 > v_2$$

$$v_3 = v_2 \cdot K$$


## Tighten the web via trimming function with cascade

In case a clearance has developed, the web must be "tightened" again. Only then the machine can be accelerated again via the master. The subsequent slave (cascade structure) must run along in the set ratio. Thus, the trimming function acts directly before or after the stretching factor.



[12-6] Trimming function in case of the electronic gearbox as cascade

## Relative synchronism with mark synchronisation and virtual master



[12-7] Relative synchronism with virtual master (rail)

# 9400 HighLine | Parameter setting & configuration


TAs for interconnection via electrical shaft

Introduction | Application examples

In case of the relative synchronism with mark synchronisation, there is a position reference between tool and web, which occurs in each register. For this, a slight correction is superimposed to the synchronous motion with regard to the web. Such applications are, for instance, printing machines.

For the mark synchronisation in particular the register ④ (the cycle of the guiding angle) and the distance of the sensor ⑤ from the home position of the tool (distances  $a_2$  and  $a_3$ ) are relevant.

## Relative synchronism with mark synchronisation and real master



[12-8] Relative synchronism with real master (track)



## 12.2 TA "Electronic gearbox"

The technology application "Electronic gearbox" serves to implement a synchronism with adjustable stretching ratio between the drives in the system.

- ▶ The ratio can be freely adjusted, the values are input in the form of a fraction (numerator/denominator) with 32 bit resolution.
- ▶ The master value can be specified either by a "Virtual master", or via a bus system or the digital frequency extension module. It is selected from the **Application parameter** tab via the **Master value source** list field (C03052).
- ▶ The master value transmission (high speed stability) is preset. The actual values can be transmitted by the corresponding selection in the list fields **Master value output** (C3054/1, C3054/2, C3197).



### Note!

The electrical shaft can be implemented with a bus system as e.g. system bus (CAN) or Ethernet Powerlink or via digital frequency transmission.

With regard to the configuration of the digital frequency extension module in the controller, two variants of technology applications are available in the »Engineer« application catalog.

- In the TA variant "Electronic gearbox" the configuration of a digital frequency extension module is expected. Therefore, the TA can provide the function of the electrical shaft either via digital frequency transmission and via a bus system.
- In the TA variant "Electronic gearbox *MotionBus*" the configuration of a digital frequency extension module is not included and corresponding interfaces are not available in the TA. Thus the function of the electrical shaft with this TA can only be provided via a bus system.

### Functions


- ▶ Virtual master with inching, handwheel and reduced speed.
- ▶ Master value conditioning (master shaft) with master value scaling, stretch factor and reversal of rotation direction.
- ▶ Virtual clutch with emergency stop and basic speed
- ▶ Trimming function via profile generator.
- ▶ Master value conditioning (machine axis/tool) with setpoint scaling.
- ▶ Additional operating modes for activating the basic drive functions "Homing", "Manual jog (inching)" and "Position override function".
- ▶ Support of the basic drive functions "Quick stop" and "Limiter".
- ▶ Following error monitoring.
- ▶ Optional control of a holding brake.

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Electronic gearbox" | Basic signal flow

## 12.2.1 Basic signal flow



[12-9] Signal flow of the TA "Electronic gearbox" (schematic diagram)

### Functions in the operating mode "Electronic gearbox"

- ▣ A Master value processing with stretch factor
- ▣ B Virtual clutch
- ▣ C Master value trimming
- ▣ D Setpoint conditioning

### Basic drive functions


- ▣ E Homing
- ▣ F Manual jog (inching)
- ▣ G Position override function
- ▣ H Quick stop
- ▣ I Limiter (optional)
- ▣ J Brake control (optional)

## 12.2.2 Assignment of the I/O terminals


### 12.2.2.1 Setpoint and control signals

The following tables contain the Lenze assignment of the analog and digital inputs for the technology application "Electronic gearbox".

#### Analog inputs

Terminal X3	Signal (Lenze setting)	
	A1- A1+	-
	A2- A2+	-
	<a href="#">I/O terminals</a> ▶ <a href="#">Analog inputs</a> (📖 117)	

#### Digital inputs

Terminal X5	Signal (Lenze setting)	
	DI1	Quick stop <ul style="list-style-type: none"> <li>If DI1 is set to LOW level, the drive is decelerated to standstill within the deceleration time set for the quick stop function independent of the setpoint selection.</li> <li>If the quick stop function is deactivated, the drive is led to the selected setpoint again via the set acceleration time.</li> </ul> <a href="#">Basic drive functions</a> ▶ <a href="#">Quick stop</a> (📖 152)
	DI2	Connection of reference switch
	DI3	-
	DI4	Close clutch
	DI5	Reset error <ul style="list-style-type: none"> <li>By means of a LOW-HIGH edge an existing error status can be reset if the cause of the fault is removed.</li> </ul>
	DI6	-
	DI7	-
	DI8	-
	<a href="#">I/O terminals</a> ▶ <a href="#">Digital inputs</a> (📖 123)	

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft


TA "Electronic gearbox" | Assignment of the I/O terminals

## 12.2.2.2 Actual value and status signals

The following tables contain the Lenze assignment of the analog and digital outputs for the technology application "Electronic gearbox".


- The default signal configuration if required can be easily changed by parameterising the multiplexer parameters assigned.

### Analog outputs

Terminal X3	Signal (Lenze setting)	Signal configuration
	<b>AO1</b> Motor speed • Scaling: $\pm 10\text{ V} \equiv$ motor reference speed ( <a href="#">C00011</a> )	C03110/1
	<b>AO2</b> Motor torque (setpoint) • Scaling: $\pm 10\text{ V} \equiv$ Motor reference torque ( <a href="#">C00057/2</a> )	C03110/2


► [I/O terminals](#) ► [Analog outputs](#) (📖 120)

### Digital outputs

Terminal X4	Signal (Lenze setting)	Signal configuration
	<b>DO1</b> Status "Drive ready" • This operating state is active if the controller is enabled by setting the digital input RFR to HIGH level and no error has occurred.	C03100/1
	<b>DO2</b> Status "Electrical shaft enabled"	C03100/2
	<b>DO3</b> Status "Limitation active" • A setpoint is limited at the moment.	C03100/3
	<b>DO4</b> "Error" status • If the controller is in the error state, the digital output DO4 is set to HIGH level.	C03100/4


► [I/O terminals](#) ► [Digital outputs](#) (📖 125)

### State bus

Terminal X2	Signal (Lenze setting)	Signal configuration
	<b>SB</b> "Application error" status • The state bus is put in the "error" status.	C03100/5

► [I/O terminals](#) ► [Monitoring function "State bus"](#) (📖 127)


### Display elements

User LED	Signal (Lenze setting)	Signal configuration
	Status "Electrical shaft enabled"	C03100/6

► [Drive interface](#) ► [LED status displays](#) (📖 34)

## 12.2.3 Machine parameters

The following schematic diagram shows the relevant global data (machine parameters) for the interconnection via the electrical shaft:



[12-10] Schematic diagram of the most important machine parameters

Symbol	Description
$i_1$	Gearbox ratio of master value encoder
$d_1$	Diameter of the master roll
$l_1$	Master value cycle (if available)
$v_{max}$	Maximum speed
$i_2, i_3$	Gearbox ratio of the slave axes
$d_2, d_3$	Diameter of the slave rolls

Detailed information for setting the machine parameters can be obtained from the following subchapters.

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft  
TA "Electronic gearbox" | Machine parameters

## 12.2.3.1 Master axis (master shaft)

For scaling and imaging the master value in the application, the machine parameters of the higher-level drive (master shaft) must be set.




### Note!

When setting (scaling) the electrical shaft, ensure that the ratio and encoder constants are identical for all drives in the system. The reference to the scaling of the master drive is sensible.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Electronic gearbox* → *Master value scaling*

Parameters		Lenze setting	
		Value	Unit
C03930	Gearbox ratio - numerator	1	
C03931	Gearbox ratio - denominator	1	
C03932	Feed constant	360.0000	Unit/incr.
C03933	Path units	User-defined	
C03934	User-defined path unit	°	
C03938	Cycle	360.0000	Unit
C03941	Reference speed	500.0000	Unit/t

### Example of determining the machine parameters for the master axis



1. Set gearbox ratio for the master value in the form of a quotient (numerator and denominator):  
 $i_1 = 3.333 = 10/3$ 
  - Numerator (C03930) = 10
  - Denominator (C03931) = 3
2. Set feed constant (C03932).
  - For the master value:  $V_k = d_1 * \pi = 471,2389 \text{ mm}$
3. Set the selection "mm" as path unit (C03933).
4. As reference speed (C03941) set the max. machine speed  $v_{\max} = "1000 \text{ mm/s}"$ .



## Tip!

Setting the cycle (C03938) only is required if the selection "Modulo" is set as traversing range (C02528).

For operation with a virtual master the following setting of the gearbox ratio is recommended to achieve a good resolution of the guiding angle/master value:

- Numerator (C03930) = 100
- Denominator (C03931) = 1

### 12.2.3.2 Slave axis (machine axis)

Among other things, the following machine parameters describe the motor end of the mechanics used.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Electronic gearbox* → *Machine parameters*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C00173</a>	Mains - voltage	400/415	V
<a href="#">C00174</a>	Threshold undervoltage (LU)	285	V
<a href="#">C00600</a>	Resp. to DC bus overvoltage	Trouble	
<a href="#">C02520</a>	Gearbox fact. numer. motor	1	
<a href="#">C02521</a>	Gearbox fact. denom. motor	1	
<a href="#">C02527</a>	Motor mounting direction	Motor rotating CW	
<a href="#">C02570</a>	Controller configuration	Position control	
<a href="#">C02522</a>	Gearbox fact. numer. load	1	
<a href="#">C02523</a>	Gearbox fact. denom. load	1	
<a href="#">C02529</a>	Mounting direction of position encoder	Encoder rotating CW	
<b>Description of the mechanics (load, tool)</b>			
<a href="#">C02528</a>	Traversing range	Modulo	
<a href="#">C02524</a>	Feed constant	360.0000	Unit
<a href="#">C02525</a>	Unit	°	
<a href="#">C02526</a>	User-defined unit	°	
<a href="#">C02533</a>	Time unit	s	
<a href="#">C00273/1</a>	Motor moment of inertia	Motor-dependent	kg cm <sup>2</sup>
<a href="#">C00273/2</a>	Load moment of inertia	0.00	kg cm <sup>2</sup>




## Tip!

Detailed information for selecting and entering the machine parameters for the machine axis can be found in the chapter "[Drive interface](#)

► [Machine parameters](#) (📖 35)

## Example of determining the machine parameters for the slave axis



1. Set gearbox ratio for the motor in the form of a quotient (numerator and denominator):  $i_2 = 12.612 = 12612/1000$ 
  - Numerator (C02520) = 12612
  - Denominator (C02521) = 1000
2. Set the same gearbox ratio for the encoder on the load side:
  - Numerator (C02522) = 12612
  - Denominator (C02523) = 1000
3. Set feed constant (C02524).
  - For the conveyor drive:  $Vk = d_2 * \pi = 628,3185 \text{ mm}$
4. Set the selection "mm" as unit (C02525).




### Tip!

The feed constant corresponds to the movement on the machine side when the gearbox output shaft carries out one revolution (for selection as angle =  $360^\circ$ ).

When the unit is set, the real unit of the machine for the selection of physical values (e. g. speeds, accelerations and decelerations) is defined.



## 12.2.4 Selection of master value source and output



[12-11] Signal flow for selecting the master value source and the master values to be output

### Master value source

The master values can be either selected by a "Virtual master", via a bus system or the digital frequency extension module. ▶ [Transmission of the master angle](#) (□ 290)

- ▶ They can be selected on the **Application parameter** tab via the **Master value source** list field or via C03052.

### Master value output

The master value to be output ([A] ... [E]) is selected individually for the three possible communication channels:

- ▶ List field **Master value output DF module** (C03197):  
Selection of the master value output for the digital frequency module.
- ▶ List field **Master value output MotionBus** (C03054/1):  
Selection of the master value output for horizontal communication.
- ▶ List field **Master value output LPort32Out1** (C03054/2):  
Selection of the master value output for vertical communication.

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Electronic gearbox" | Selection of master value source and output

## 12.2.4.1 Master value source: Virtual master

If the "Virtual master" is selected as master value source, the master value is created in the TA and transmitted via a bus system or the digital frequency output to the other slave drives.

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Virtual master*

Parameters		Lenze setting	
		Value	Unit
C03565	Operating mode	Continuous operation	
C03568/1	Master speed 1	500.0000	Unit/t
C03568/2	Master speed 2	0.1000	Unit/t
C03569/1	Speed inching right	50.0000	Unit/t
C03569/2	Speed inching left	25.0000	Unit/t
C03570/1	Inching ramp	0.010	s
C03570/2	Continuous operation ramp	1.000	s
C03570/3	Stop ramp	1.000	s

Control/setpoint inputs of the function		Signal configuration
Lenze setting	Control/setpoint input	(Multiplexer parameters)
FALSE	→ VMas master shaft STOP1	C03058/1
C03016	→ Activate master function	C03058/3
C03017	→ VMas inching positive	C03058/4
C03018	→ VMas inching negative	C03058/5
FALSE	→ VMas start continuous operation	C03058/7
FALSE	→ VMas 2. master speed	C03058/8
0	→ VMaster handwheel	C03056

- ▶ Configuration: Tab **FB editor** → FB *VirtualMaster*

## 12.2.4.2 Master value source: Digital frequency input

To use the digital frequency input as master value source, the controller must be provided with digital frequency extension module (E94AYFLF).

To ensure the integration of the extension module in the application, the TA "Electronic gearbox" must be used as technology application.



### Note!

The technology application "Electronic gearbox" *MotionBus* which can also be selected in the application catalog does not contain any interfaces to the digital frequency extension module.



### Tip!

Detailed information on the digital frequency extension module can be found in the User Manual "Digital frequency extension module (E94AYFLF) – parameter setting & configuration".

## 12.2.4.3 Master value source: Bus system

When the master value is selected via a bus system as e.g. system bus (CAN) it is possible to first extrapolate the received position information to compensate higher bus transmission cycles.

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Electronic gearbox* → *Master value extrapolation*

Parameters		Lenze setting	
		Value	Unit
C03550	Number of extrapolation cycles	1	


  

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
TRUE	→ Activate extrapolation	C03058/9

- ▶ Configuration: Tab **FB editor** → FB *MotionBusIn*

## 12.2.5 Operating mode "Electronic gearbox"

In the "Electronic gearbox" (C03006 = "0") operating mode the drive follows the master value of the electrical shaft if the clutch is engaged.



[12-12] "Electronic gearbox" operating mode (schematic diagram)

### Functions in the "Electronic gearbox" operating mode


- A** Master value processing
- B** Virtual clutch
- C** Master value trimming
- D** Setpoint conditioning



#### Tip!

A description of the different functions for conditioning the master value can be found in the following subchapters.

## 12.2.5.1 Master value processing



[12-13] "Master value processing" function in the signal flow (schematic diagram)

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Electronic gearbox*

Parameters		Lenze setting	
		Value	Unit
C03957	Master value	-	Unit/t
C03000	Stretch factor - numerator	1000000000	
C03001	Stretch factor - denominator	1000000000	
C03673	Master value with stretch factor	-	Unit/t

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Electronic gearbox* → *Master value processing*

Parameters		Lenze setting	
		Value	Unit
C03025	Master value - direction of rotation	Not inverted	

Setpoint inputs of the function		Signal configuration (Multiplexer parameters)	
Lenze setting	Setpoint input		
C03000	→ Stretch factor - numerator	C03050/1	
C03001	→ Stretch factor - denominator	C03050/2	


► Configuration: Tab **FB editor** → FB *GearElectricalShaft*

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Electronic gearbox" | Operating mode "Electronic gearbox"

## 12.2.5.2 Virtual clutch



[12-14] Function "Virtual clutch" in the signal flow (schematic diagram)


► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Electronic gearbox* → *Virtual clutch*

Parameters		Lenze setting	
		Value	Unit
C03673	Master value with stretch factor	-	Unit/t
C03021	Activate clutch	Deactivated	
C03665/1	Clutch in ramp	1.000	s
C03665/2	Decoupling ramp	1.000	s
C03665/3	Stop ramp	1.000	s
C03668	Jerk limitation	1.000	s
C03674	Master value with clutch	-	Unit/t

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
DigIn 4	→ Close clutch	C03058/12
FALSE	→ Clutch - positive opening operation	C03058/13

► Configuration: Tab **FB editor** → FB *ClutchElectricalShaft*

## 12.2.5.3 Master value trimming



[12-15] "Master value trimming" function in the signal flow (schematic diagram)

This function serves to adjust the master value.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Electronic gearbox* → *Master value trimming*

Parameters		Lenze setting	
		Value	Unit
C03674	Master value with clutch	-	Unit/t
C03026	Activate trimming	Deactivated	
C03027	Positive trimming	Inactive	
C03028	Negative trimming	Inactive	
C03685	Positive speed	400.0000	Unit/t
C03686	Negative speed	-200.0000	Unit/t
C03687	Acceleration ramp	1.000	s
C03688	Deceleration ramp	1.000	s
C03689	Disable ramp	1.000	s
C03690	Master value with trimming	-	Unit/t

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
C03026	→ Activate trimming	C03058/15
C03027	→ Positive trimming	C03058/17
C03028	→ Negative trimming	C03058/18


► Configuration: Tab **FB editor** → *FB Trimming*

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Electronic gearbox" | Operating mode "Electronic gearbox"

## 12.2.5.4 Setpoint conditioning



[12-16] "Setpoint conditioning" function in the signal flow (schematic diagram)

This function is used for speed ratio between the master shaft and the machine axis.

- Parameter setting: Tab **All parameters** → Category *Electronic gearbox* → *ConvertEIShaftMotor*


Parameters		Lenze setting	
		Value	Unit
C03715	Operating mode	Unit coupling	
C03717/1	Reference variable X	1.0000	
C03717/2	Reference variable Y	1.0000	

- Configuration: Tab **FB editor** → FB *ConvertEIShaftMotor*



## 12.2.6 "Homing" mode

In the "Homing" mode (C03006 = "2") the drive is decoupled from the electrical shaft and the basic function "Homing" is enabled:



[12-17] "Homing" mode (schematic diagram)

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Homing*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02528</a>	Traversing range	Modulo	
<a href="#">C02640</a>	Ref. mode	Set home pos. directly	
<a href="#">C02642</a>	HM position	0.0000	Unit
<a href="#">C02643</a>	HM target position	0.0000	Unit
<a href="#">C02644</a>	Ref. speed 1	360.0000	Unit/s
<a href="#">C02645</a>	Home acceleration 1	720.0000	Unit/s <sup>2</sup>
<a href="#">C02646</a>	Ref. speed 2	180.0000	Unit/s
<a href="#">C02647</a>	Ref. acceleration 2	360.0000	Unit/s <sup>2</sup>
<a href="#">C02648</a>	Home S-ramp time	100	ms
<a href="#">C02649</a>	HM torque limit	10.00	%
<a href="#">C02650</a>	Homing inhibit time	1.000	s
<a href="#">C02652</a>	Home position after mains switching	Delete	
<a href="#">C02653</a>	Max. rot. angle after mains sw.	180	°
C3011	Set home position	Inactive	
C3012	Home position	100.0000	Unit

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Electronic gearbox" | "Homing" mode

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
FALSE	→ Start homing	C03160/2
DigIn 2	→ Home mark	C03160/3
C03011	→ Set home position	C03160/4
C03012	→ Home position	C03163
FALSE	→ Reset home position	C03160/5




## Tip!

Detailed information on homing can be found in chapter "Basic drive functions" → subchapter "[Homing](#)". (📖 164)

## 12.2.7 "Manual jog" mode

In the "Manual jog" mode (C03006 = "4") the drive is decoupled from the electrical shaft and the basic function "Manual jog" is enabled:



[12-18] "Manual jog" mode (schematic diagram)

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Manual jog*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02620</a>	Manual jog speed 1	360.0000	Unit/s
<a href="#">C02621</a>	Manual jog speed 2	720.0000	Unit/s
<a href="#">C02622</a>	Manual acceleration	360.0000	Unit/s <sup>2</sup>
<a href="#">C02623</a>	Manual deceleration	1440.0000	Unit/s <sup>2</sup>
<a href="#">C02624</a>	Inaccuracy time of manual traversing	0.100	s
C03007	Positive manual jog	Inactive	
C03008	Negative manual jog	Inactive	

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
C03007	→ Activate positive manual jog	C03155/2
C03008	→ Activate negative manual jog	C03155/3
FALSE	→ Activate 2. speed	C03155/4
FALSE	→ Retract limit switch	C03155/5



**Tip!**


Detailed information on the manual jog function can be found in chapter "Basic drive functions" → subchapter "[Manual jog](#)". (156)

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft  
 TA "Electronic gearbox" | "Positioning" mode"

## 12.2.8 "Positioning" mode"

In the "Positioning" mode (C03006 = "8") the drive is decoupled from the electrical shaft and the basic function "Positioning" is enabled:



[12-19] "Positioning" mode (schematic diagram)

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *All basic functions* → *Positioning*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C00070</a>	Speed controller gain	0.00700	Nm/rpm
<a href="#">C00071</a>	Speed controller reset time	10.0	ms
<a href="#">C00072</a>	D component - speed controller	0.00	ms
<a href="#">C02570</a>	Controller configuration	Phase control	
<a href="#">C02554</a>	Integral-action time of position controller	60.000	s
<a href="#">C02553</a>	Position controller gain	20.00	1/s
C03040	Positioning - profile no.	0	
C03041	Positioning - teach profile no.	0	

Control/setpoint inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control/setpoint input	
FALSE	→ Start positioning step	C03185/2
FALSE	→ Abort positioning step	C03185/3
FALSE	→ Restart positioning step	C03185/4
FALSE	→ Activate override	C03185/5
100 %	→ Speed override	C03186/1
100 %	→ Acceleration override	C03186/2
FALSE	→ Inhibit touch probe evaluation	C03185/6
FALSE	→ Teach position	C03185/7

## Profile data record management

For the profile data record management the FB **L\_PosProfileTable** is used. This FB serves to file and manage up to four (travel) profiles and to "teach" target positions.

- ▶ A profile describes a motion request which can be implemented by the **SB LS\_Positioner** into a rotary motion.
- ▶ A profile is described via the following profile parameters: Mode (type of positioning), position, speed, acceleration, deceleration, S-ramp time, standard sequence profile, TP sequence profile and TP selection.
- ▶ The data of the profile parameters is directly input in the assigned codes:

Profile parameters	Unit	Profile no. 1	Profile no. 2	Profile no. 3	Profile no. 4
Positioning mode	-	C03970/1	C03970/2	C03970/3	C03970/4
Position	Unit	Set position	C03971/2	C03971/3	C03971/4
Speed	Unit/t	C03972/1	C03972/2	C03972/3	C03972/4
Acceleration	Unit/t <sup>2</sup>	C03973/1	C03973/2	C03973/3	C03973/4
Delay	Unit/t <sup>2</sup>	C03974/1	C03974/2	C03974/3	C03974/4
S-ramp time	s	C03975/1	C03975/2	C03975/3	C03975/4
TP sequence profile	-	C03976/1	C03976/2	C03976/3	C03976/4
TP selection	-	C03977/1	C03977/2	C03977/3	C03977/4



### Note!

For profile no. 1 the set position of the tool which belongs to the master position is always used as target position.

- Application: Returning the tool e.g. from a maintenance position to the network.

## "Teach" position

When the control input "Teach position" is set to TRUE, the current tool position is saved in the profile the number of which is set in C03041. After the control input is reset to FALSE the position saved last is maintained in the profile.

# 9400 HighLine | Parameter setting & configuration


TAs for interconnection via electrical shaft

TA "Electronic gearbox" | Following error monitoring

## 12.2.9 Following error monitoring

In the Lenze setting the following error monitoring is active.

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Electronic gearbox* → *Following error monitoring*




Parameters		Lenze setting	
		Value	Unit
C03911	Switching threshold	1.0000	Unit
C03916	Hysteresis	0.5000	Unit

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
TRUE	→ Activate following error monitoring	C03058/21

- ▶ Configuration: Tab **FB editor** → *FB MonitFollowError*

## 12.2.10 Quick stop



[12-20] Basic function "Quick stop" (schematic diagram)

The basic function "Quick stop" brakes the drive to standstill within the deceleration time set for the quick stop function after a corresponding request independent of the setpoint selection.

If the quick stop function is deactivated, the drive is led to the selected setpoint again via the set acceleration time.

- ▶ The quick stop function can be activated as follows in the Lenze setting:
  - By setting the digital input DI1 to LOW level.
  - By a master control via the port *LPortControl1*:  
By setting bit 2 of the bit-coded control word 1.
- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *All basic functions* → *Quick stop*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C00105</a>	Quick stop deceleration time	0.000	s
<a href="#">C00106</a>	Quick stop S-ramp time	0.00	%
<a href="#">C00107</a>	Reference for deceleration time "Quick stop"	Motor reference speed ( <a href="#">C00011</a> )	

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
DigIn 1	→ Activate quick stop 1	C03135/1
Control word 1 bit 02	→ Activate quick stop 2	C03135/2
FALSE	→ Activate quick stop 3	C03135/3



**Tip!**


Detailed information on quick stop can be found in chapter "Basic drive functions" → subchapter "[Quick stop](#)". (152)

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Electronic gearbox" | Limiter

## 12.2.11 Limiter



The basic function "Limiter" monitors the travel range limits via limit switches and parameterised software limit positions and can lead the drive to defined limit ranges when being asked accordingly by the safety module.

[12-21] Basic function "Limiter" (schematic diagram)

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Limiter*

Parameters		Lenze setting	
		Value	Unit
<b>Limit values</b>			
<a href="#">C02707</a>	Permissible direction of rotation	Positive and negative	
<a href="#">C02700</a>	Software limit positions are active	Deactivated	
<a href="#">C02701/1</a>	Positive software limit position	0.0000	Unit
<a href="#">C02701/2</a>	Negative software limit position	0.0000	Unit
<b>Only for homing, positioning and manual jog</b>			
<a href="#">C02702</a>	Limitations effective	Deactivated	
<a href="#">C02703</a>	Max. speed	3600.0000	Unit/s
<a href="#">C02705</a>	Max. acceleration	3600.0000	Unit/s <sup>2</sup>
<a href="#">C02706</a>	Min. S-ramp time	100	ms
<b>Limited speed 1 ... 4 (only for homing, positioning, and manual jog)</b>			
<a href="#">C02708/1</a>	Limited speed 1	3600.0000	Unit/s
<a href="#">C02710/1</a>	Delay lim. speed 1	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/1</a>	S-ramp time lim. speed 1	100	ms
<a href="#">C02708/2</a>	Limited speed 2	7200.0000	Unit/s
<a href="#">C02710/2</a>	Delay lim. speed 2	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/2</a>	S-ramp time lim. speed 2	100	ms
<a href="#">C02708/3</a>	Limited speed 3	14400.0000	Unit/s
<a href="#">C02710/3</a>	Delay lim. speed 3	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/3</a>	S-ramp time lim. speed 3	100	ms
<a href="#">C02708/4</a>	Limited speed 4	28800.0000	Unit/s
<a href="#">C02710/4</a>	Delay lim. speed 4	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/4</a>	S-ramp time lim. speed 4	100	ms
<b>For manual jog only</b>			
<a href="#">C02713</a>	Max. path - manual jog	360.0000	Unit




Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
FALSE	→ Positive limit switch	C03150/1
FALSE	→ Negative limit switch	C03150/2



### Tip!

Detailed information on the limiter function can be found in chapter "Basic drive functions" → subchapter "[Limiter](#)". (📖 200)

## 12.2.12 Brake control



[12-22] Basic function "Brake control" (schematic diagram)

The basic function "Brake control" serves to the wear free control and monitoring of a holding brake.

In the simplest case, an optionally available brake module is used.

Alternatively the holding brake can also be controlled and monitored via the digital inputs/outputs.



### Note!

In the Lenze setting the brake control is switched off to reach a safe status after mains connection.



### Tip!

Detailed information on brake control can be found in chapter "Basic drive functions" → subchapter "[Brake control](#)". (📖 211)

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Brake control*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02580</a>	Operating mode - brake	Brake control off	
<a href="#">C02581</a>	Brake activation threshold	50	rpm
<a href="#">C02582</a>	Brake resp. to pulse inhibit	Activate the brake immediately	
<a href="#">C02583</a>	Status input monitoring	Not active	
<a href="#">C02585</a>	Brake control polarity	Not inverted	
<a href="#">C02586</a>	Starting torque 1	0.00	Nm
<a href="#">C02587</a>	Starting torque 2	0.00	Nm
<a href="#">C02588</a>	Source of starting torque	Starting torque 1/2	
<a href="#">C02589</a>	Brake closing time	100	ms
<a href="#">C02590</a>	Brake opening time	100	ms
<a href="#">C02591</a>	Waiting time - status monit.	100	ms
<a href="#">C02593</a>	Waiting time - brake active.	0.000	s
<a href="#">C02594</a>	Test torque	0.00	Nm
<a href="#">C02595</a>	Permissible angle of rotation	5	°
<a href="#">C02596</a>	Grinding speed	100	rpm
<a href="#">C02597</a>	Accel./decel. time - grinding	1.000	s
<a href="#">C02598</a>	Grinding ON time	0.5	s
<a href="#">C02599</a>	Grinding OFF time	0.5	s

Control/setpoint inputs of the function		Signal configuration
Lenze setting	Control/setpoint input	(Multiplexer parameters)
FALSE	→ Release brake	C03165/1
FALSE	→ Activate starting torque 2	C03165/2
FALSE	→ Brake status signal	C03165/3
FALSE	→ Activate brake test	C03165/4
FALSE	→ Grind brake	C03165/5
0 %	→ Additional torque	C03166

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Electronic gearbox" | Signal configuration of drive and motor interface

## 12.2.13 Signal configuration of drive and motor interface

If required, the preset signal configuration of the control and setpoint inputs of the drive and motor interface can be easily reconfigured per parameter setting of the assigned multiplexer parameters.

### Drive interface

Signal (Lenze setting)	Control input	Signal configuration
FALSE	→ Set controller inhibit	C03130/1
DigIn 5	→ Reset error 1	C03130/2
Control word 1 bit 07	→ Reset error 2	C03130/3
FALSE	→ Reset error 3	C03130/4
FALSE	→ Set error	C03130/5
Control word 1 bit 00	→ Switch on drive	C03130/6

### Motor interface

Signal (Lenze setting)	Setpoint input	Signal configuration
100 %	→ Position controller adaption	C03141/1
100 %	→ Phase controller adaption	C03141/2
100 %	→ Adaptation of speed controller	C03141/3
100 %	→ Upper torque limit value	C03141/4
-100 %	→ Lower torque limit value	C03141/5
100 %	→ Flux setpoint	C03141/6

## 12.2.14 Signal configuration of the output ports

If required, the preset signal configuration of the output ports can be easily reconfigured per parameter setting of the assigned multiplexer parameters.

### "LPortAxisOut1" output port

The output port **LPortAxisOut1** is intended for the connection with a following axis.

Signal (Lenze setting)	Output port	Signal configuration
<b>Axis status word</b>		
• Application-specific signals can be supplemented.		
FALSE	→ Axis status word bit 00	C03120/1
FALSE	→ Axis status word bit 01	C03120/2
FALSE	→ Axis status word bit 02	C03120/3
FALSE	→ Axis status word bit 03	C03120/4
FALSE	→ Axis status word bit 04	C03120/5
FALSE	→ Axis status word bit 05	C03120/6
FALSE	→ Axis status word bit 06	C03120/7
FALSE	→ Axis status word bit 07	C03120/8
FALSE	→ Axis status word bit 08	C03120/9
FALSE	→ Axis status word bit 09	C03120/10
FALSE	→ Axis status word bit 10	C03120/11
FALSE	→ Axis status word bit 11	C03120/12
FALSE	→ Axis status word bit 12	C03120/13
FALSE	→ Axis status word bit 13	C03120/14
FALSE	→ Axis status word bit 14	C03120/15
FALSE	→ Axis status word bit 15	C03120/16
<b>Setpoints for horizontal communication</b>		
0 %	→ Axis-Port Out 1	C03124/1
Master value	→ Axis-Port Out 2	C03054/1

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Electronic gearbox" | Signal configuration of the output ports

## Output port "LPortStatus1"

The output port **LPortStatus1** is intended for the connection with a higher-level control.

Signal (Lenze setting)	Output port	Signal configuration
<b>Status word 1</b>		
Drive ready	→ Status word 1 bit 00	C03121/1
FALSE	→ Status word 1 bit 01	C03121/2
Drive is ready to start	→ Status word 1 bit 02	C03121/3
Error is active.	→ Status word 1 bit 03	C03121/4
FALSE	→ Status word 1 bit 04	C03121/5
Quick stop active	→ Status word 1 bit 05	C03121/6
Switch-on inhibit is active	→ Status word 1 bit 06	C03121/7
Warning active	→ Status word 1 bit 07	C03121/8
FALSE	→ Status word 1 bit 08	C03121/9
FALSE	→ Status word 1 bit 09	C03121/10
FALSE	→ Status word 1 bit 10	C03121/11
Drive in the limitation	→ Status word 1 bit 11	C03121/12
Homing complete	→ Status word 1 bit 12	C03121/13
Home position available	→ Status word 1 bit 13	C03121/14
FALSE	→ Status word 1 bit 14	C03121/15
FALSE	→ Status word 1 bit 15	C03121/16

## Output port "LPortStatus2"

The output port **LPortStatus2** is intended for the connection with a higher-level control.

Signal (Lenze setting)	Output port	Signal configuration
<b>Status word 2</b>		
Virtual master is active	→ Status word 2 bit 00	C03122/1
Clutch is disengaged	→ Status word 2 bit 01	C03122/2
Trimming is active	→ Status word 2 bit 02	C03122/3
FALSE	→ Status word 2 bit 03	C03122/4
FALSE	→ Status word 2 bit 04	C03122/5
FALSE	→ Status word 2 bit 05	C03122/6
FALSE	→ Status word 2 bit 06	C03122/7
FALSE	→ Status word 2 bit 07	C03122/8
FALSE	→ Status word 2 bit 08	C03122/9
FALSE	→ Status word 2 bit 09	C03122/10
FALSE	→ Status word 2 bit 10	C03122/11
FALSE	→ Status word 2 bit 11	C03122/12
FALSE	→ Status word 2 bit 12	C03122/13
FALSE	→ Status word 2 bit 13	C03122/14
FALSE	→ Status word 2 bit 14	C03122/15
FALSE	→ Status word 2 bit 15	C03122/16

## 12.2.15 Application error messages

For the output of application-specific error messages an FB instance *ApplicationError* of the function block **L\_DevApplErr** is available in the network.

- ▶ Via the 8 boolean inputs up to 8 different application error messages with parameterisable module ID, error ID and error response can be released by the application.
- ▶ The first four inputs can be connected to the multiplexer parameters with the desired tripping signals. The next four inputs are firmly connected to the tripping signals of the application.

Error message		Error-ID	Error response
1	Free (configurable via C03060/1)	8001	No reaction
2	Free (configurable via C03060/2)	8002	Error
3	Free (configurable via C03060/3)	8003	Error
4	Free (configurable via C03060/4)	8004	Error
5	Following error	8005	Warning
6	Drive cannot follow	8006	Warning
7	Drive system interrupted	8007	Quick stop by trouble
8	External fault in drive system	8008	Quick stop by trouble

### ▶ Parameter setting: Tab **All parameters**

Parameters		Lenze setting
C03990	Module-ID	999
C03991/1...8	Error ID 1 ... 8	See table above
C03992/1...8	Error response 1 ... 8	See table above

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
FALSE	→ Application fault 1	C03060/1
FALSE	→ Application fault 2	C03060/2
FALSE	→ Application fault 3	C03060/3
FALSE	→ Application fault 4	C03060/4

# 9400 HighLine | Parameter setting & configuration



TAs for interconnection via electrical shaft


TA "Electronic gearbox" | Step by step: Electrical shaft via system bus (CAN)

## 12.2.16 Step by step: Electrical shaft via system bus (CAN)


The following instructions describe step by step the proceeding for commissioning the electrical shaft via the system bus (CAN).

### Create project view

1. Start »Engineer«.
2. Go to *Start-up wizard* and select the option "New project (empty)" and enter a name for the project in a next step.
3.  Insert system module.
4.  Enter axes for master and slave(s).
  - Add the corresponding components (controller, motor, extension module) to the axes.
  - Select for each controller the application "Electronic gearbox".
  - Example *project view* in the »Engineer«:




### Parameterise the virtual master



1. Go to the *Project view* and select the controller  which is to take over the part of the "Virtual master" in the network.
2. Go to the **Application parameter** tab and select the entry "Virtual master" in the list field **Master value source** (C03052).
3. Click **Technology application** to change to the dialog level *Overview* → *Electronic gearbox*.
4. Click **Master value scaling** to change to the dialog level *Overview* → *Electronic gearbox* → *Master value scaling*.
  - Parameterise gearbox ratio, feed constant, cycle, path unit, and reference speed for the master value.
5. Click **Back** to change to the previous dialog level.
6. Click **virtual master** to change to the dialog level *Overview* → *Electronic gearbox* → *Virtual master*.
  - Parameterise desired operating mode, speed and ramps.



## Parameterising slave(s)

1. Go to *Project view* and select the first slave controller .
2. Go to the **Application parameter** tab and select the entry "Virtual master in the list field **Virtual master** (C03052).
3. Make the same settings for all other slave controllers.

## Establish network


1. Go to *Project view* and select the system module .
2.  Insert network.
  - Go to the dialog box *Insert network* to select the entry "System bus (CAN) from the list field.
  - The checkmark in the control field **Insert and configure node** must be set so that a machine application is inserted in the *Project view* together with the network.
3. On the **Node** tab for the inserted network:
  - Set node addresses for the controllers according to the DIP switch setting of the CAN address of the memory module.
  - Go to *Context menu* for the master controller (right mouse button) and select the command **Set as master**.
4. On the **Synchronisation** tab for the inserted network:
  - Select the master controller as sync source in the list field **Node**.
  - Select all slave controllers as sync receivers by setting the checkmark in the first column **Appl.**


# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft



TA "Electronic gearbox" | Step by step: Electrical shaft via system bus (CAN)

## Connect ports in the machine application

1. Go to *Project view* and select the machine application  which has been inserted automatically with the insertion of the network.
2. Go to the **Connections** tab and connect the output port *LPortAxisOut1* of the master controller with the input port *LPortAxisIn1* of all slave controllers.



## Compile the project

1. Go to *Project view* and select the system module .
2.  Update devices.
  - Set the checkmark in the control field **Recreate all**.
  - Click **Create** to start the compiling process.

## Optimise bus load


In order that the bus load will not be too high, the transmission time for the master controller can be set to a value  $> 1$  ms. Then the same time must be set in the slave controllers for the master value extrapolation.




### Note!

This setting is only possible after the compiling process is completed since only then the process data objects are defined for the data exchange among the devices.

1. Go to *Project view* below the network and select the master controller.



2. Go to the **Process data objects** tab and set a transmission time  $> 1$  ms (e.g. 5 ms) for the process data object.

3. Go to *Project view* and select the first slave controller .
4. Go to the **Application parameter** and change to the dialog level *Electronic gearbox* → *Electronic gearbox* → *Master value extrapolation*.
5. Set the number of extrapolation cycles to the same value than the transmission time set before.
  - This means: In case of a transmission time of 5 ms set for the master set the number of extrapolation cycles for the slave to the value "5".
6. Make the same settings for all other slave controllers.

### Transmit applications to the controller




1.  Go online.
2.  Download applications in the controller.



#### Note!

The downloaded application is basically stored in the first application memory location of the controller.

The preinstalled technology applications on the following memory locations are still available.

3. Confirm  Dialog box *Save parameter set* with **Yes, all devices**.
4. Confirm  Dialog box *Start application* with **Yes, all devices**.
5. Confirm  Dialog box *Enable controller* with **Yes, all devices**.
6. Control applications via terminals or network.

### 12.3 TA "Synchronism with mark synchronisation"

The technology application "Synchronism with register formation and mark synchronisation" serves to implement a high-precision angular synchronism between the drives in the system.

- ▶ Thanks to a free adjustable position resolution of up to 24 bits per motor revolution a very good synchronism result is achieved so that applications with direct drive can be resolved with high precision.
- ▶ The ratio can be freely adjusted, the values are input in the form of a fraction (numerator/denominator) with 32 bit resolution.
- ▶ The master value can be specified either by a "Virtual master", or via a bus system or the digital frequency extension module. It is selected from the **Application parameter** tab via the **Master value source** list field (C03052).
- ▶ The master value transmission (high speed stability) is preset. The actual values can be transmitted by the corresponding selection in the list fields **Master value output** (C3054/1, C3054/2, C3197).



#### Note!

The electrical shaft can be implemented with a bus system as e.g. system bus (CAN) or Ethernet Powerlink or via digital frequency transmission.


With regard to the configuration of the digital frequency extension module in the controller, two variants of technology applications are available in the »Engineer« application catalog.

- In the TA variant "Synchronism with mark synchronisation" the configuration of a digital frequency extension module is expected. Therefore, the TA can provide the function of the electrical shaft either via digital frequency transmission and via a bus system.
- In the TA variant "Synchronism with mark synchronisation *MotionBus*" the configuration of a digital frequency extension module is not included and corresponding interfaces are not available in the TA. Thus the function of the electrical shaft with this TA can only be provided via a bus system.

### Functions

- ▶ Virtual master with inching, handwheel and reduced speed.
- ▶ Conditioning of the master value (master shaft) with master value scaling, register generation, stretch factor, reversal of rotation direction, and mark synchronisation via profile generator.
- ▶ Virtual clutch with emergency stop and basic speed
- ▶ Trimming function via profile generator.
- ▶ Conditioning of the setpoint (machine axis/tool) with setpoint scaling, register generation, and mark synchronisation via profile generator.
- ▶ Additional operating modes for activating the basic drive functions "Homing", "Manual jog (inching)" and "Position override function".
- ▶ Support of the basic drive functions "Quick stop" and "Limiter".
- ▶ Following error monitoring.
- ▶ Optional control of a holding brake.

## 12.3.1 Basic signal flow



[12-23] Signal flow of the TA "Synchronism" (schematic diagram)

### Functions in the "Synchronism" operating mode

- ▣ A Master value processing
- ▣ B Mark synchronisation (master value)
- ▣ C Virtual clutch
- ▣ D Master value adjustment
- ▣ E Setpoint conditioning
- ▣ F Mark synchronisation (setpoint)

### Basic drive functions


- ▣ G Homing
- ▣ H Manual jog (inching)
- ▣ I Position override function
- ▣ J Quick stop
- ▣ K Limiter (optional)
- ▣ L Brake control (optional)

## 12.3.2 Assignment of the I/O terminals

### 12.3.2.1 Setpoint and control signals


The following tables contain the Lenze assignment of the analog and digital inputs for the technology application "Synchronism".

#### Analog inputs

Terminal X3	Signal (Lenze setting)	
	A1-	-
	A1+	-
	A2-	-
	A2+	-

[I/O terminals](#) ▶ [Analog inputs](#) (📖 117)

#### Digital inputs

Terminal X5	Signal (Lenze setting)	
	DI1	Quick stop <ul style="list-style-type: none"> <li>If DI1 is set to LOW level, the drive is decelerated to standstill within the deceleration time set for the quick stop function independent of the setpoint selection.</li> <li>If the quick stop function is deactivated, the drive is led to the selected setpoint again via the set acceleration time.</li> </ul> <a href="#">Basic drive functions</a> ▶ <a href="#">Quick stop</a> (📖 152)
	DI2	Connection of reference switch/touch probe sensor for tool synchronisation
	DI3	Connection of touch probe sensor for master value synchronisation
	DI4	Close clutch
	DI5	Reset error <ul style="list-style-type: none"> <li>By means of a LOW-HIGH edge an existing error status can be reset if the cause of the fault is removed.</li> </ul>
	DI6	Start trimming
	DI7	-
	DI8	-

[I/O terminals](#) ▶ [Digital inputs](#) (📖 123)

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft


TA "Synchronism with mark synchronisation" | Assignment of the I/O terminals

## 12.3.2.2 Actual value and status signals

The following tables contain the Lenze assignment of the analog and digital outputs for the technology application "Synchronism".


- The default signal configuration if required can be easily changed by parameterising the multiplexer parameters assigned.

### Analog outputs

Terminal X3	Signal (Lenze setting)	Signal configuration
	<b>AO1</b> Motor speed • Scaling: $\pm 10\text{ V} \equiv$ motor reference speed ( <a href="#">C00011</a> )	C03110/1
	<b>AO2</b> Motor torque (setpoint) • Scaling: $\pm 10\text{ V} \equiv$ Motor reference torque ( <a href="#">C00057/2</a> )	C03110/2


► [I/O terminals](#) ► [Analog outputs](#) ([120](#))

### Digital outputs

Terminal X4	Signal (Lenze setting)	Signal configuration
	<b>DO1</b> Status "Drive ready" • This operating state is active if the controller is enabled by setting the digital input RFR to HIGH level and no error has occurred.	C03100/1
	<b>DO2</b> Status "Electrical shaft enabled"	C03100/2
	<b>DO3</b> Status "Limitation active" • A setpoint is limited at the moment.	C03100/3
	<b>DO4</b> "Error" status • If the controller is in the error state, the digital output DO4 is set to HIGH level.	C03100/4


► [I/O terminals](#) ► [Digital outputs](#) ([125](#))

### State bus

Terminal X2	Signal (Lenze setting)	Signal configuration
	<b>SB</b> "Application error" status • The state bus is put in the "error" status.	C03100/5

► [I/O terminals](#) ► [Monitoring function "State bus"](#) ([127](#))

### Display elements


User LED	Signal (Lenze setting)	Signal configuration
	Status "Electrical shaft enabled"	C03100/6

► [Drive interface](#) ► [LED status displays](#) ([34](#))



## 12.3.3 Machine parameters

The following schematic diagram shows the relevant global data (machine parameters) for the interconnection via the electrical shaft:



[12-24] Schematic diagram of the most important machine parameters

Symbol	Description
$i_1$	Gearbox ratio of master value encoder
$d_1$	Diameter of the master roll
$l_1$	Master value cycle (if available)
$v_{max}$	Maximum speed
$i_2, i_3$	Gearbox ratio of the slave axes
$d_2, d_3$	Diameter of the slave rolls

Detailed information for setting the machine parameters can be obtained from the following subchapters.

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | Machine parameters

## 12.3.3.1 Master axis (master shaft)

For scaling and imaging the master value in the application, the machine parameters of the higher-level drive (master shaft) must be set.




### Note!

When setting (scaling) the electrical shaft, ensure that the ratio and encoder constants are identical for all drives in the system. The reference to the scaling of the master drive is sensible.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Synchronism* → *Master value scaling*

Parameters		Lenze setting	
		Value	Unit
C03930	Gearbox ratio - numerator	1	
C03931	Gearbox ratio - denominator	1	
C03932	Feed constant	360.0000	Unit/incr.
C03933	Path units	User-defined	
C03934	User-defined path unit	°	
C03938	Cycle	360.0000	Unit
C03941	Reference speed	500.0000	Unit/t

### Example of determining the machine parameters for the master axis



1. Set gearbox ratio for the master value in the form of a quotient (numerator and denominator):  
 $i_1 = 3.333 = 10/3$ 
  - Numerator (C03930) = 10
  - Denominator (C03931) = 3
2. Set feed constant (C03932).
  - For the master value:  $V_k = d_1 * \pi = 471,2389 \text{ mm}$
3. Set the selection "mm" as path unit (C03933).
4. As reference speed (C03941) set the max. machine speed  $v_{\max} = "1000 \text{ mm/s}"$ .



## Tip!

Setting the cycle (C03938) only is required if the selection "Modulo" is set as traversing range (C02528).

For operation with a virtual master the following setting of the gearbox ratio is recommended to achieve a good resolution of the guiding angle/master value:

- Numerator (C03930) = 100
- Denominator (C03931) = 1

### 12.3.3.2 Slave axis (machine axis)

Among other things, the following machine parameters describe the motor end of the mechanics used.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Synchronism* → *Machine parameters*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C00173</a>	Mains - voltage	400/415	V
<a href="#">C00174</a>	Threshold undervoltage (LU)	285	V
<a href="#">C00600</a>	Resp. to DC bus overvoltage	Trouble	
<a href="#">C02520</a>	Gearbox fact. numer. motor	1	
<a href="#">C02521</a>	Gearbox fact. denom. motor	1	
<a href="#">C02527</a>	Motor mounting direction	Motor rotating CW	
<a href="#">C02570</a>	Controller configuration	Position control	
<a href="#">C02522</a>	Gearbox fact. numer. load	1	
<a href="#">C02523</a>	Gearbox fact. denom. load	1	
<a href="#">C02529</a>	Mounting direction of position encoder	Encoder rotating CW	
<b>Description of the mechanics (load, tool)</b>			
<a href="#">C02528</a>	Traversing range	Modulo	
<a href="#">C02524</a>	Feed constant	360.0000	Unit
<a href="#">C02525</a>	Unit	°	
<a href="#">C02526</a>	User-defined unit	°	
<a href="#">C02533</a>	Time unit	s	
<a href="#">C00273/1</a>	Motor moment of inertia	Motor-dependent	kg cm <sup>2</sup>
<a href="#">C00273/2</a>	Load moment of inertia	0.00	kg cm <sup>2</sup>



## Tip!

Detailed information for selecting and entering the machine parameters for the machine axis can be found in the chapter "[Drive interface](#)


► [Machine parameters](#) (📖 35)

## 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | Machine parameters

### Example of determining the machine parameters for the slave axis



1. Set gearbox ratio for the motor in the form of a quotient (numerator and denominator):  $i_2 = 12.612 = 12612/1000$ 
  - Numerator (C02520) = 12612
  - Denominator (C02521) = 1000
2. Set the same gearbox ratio for the encoder on the load side:
  - Numerator (C02522) = 12612
  - Denominator (C02523) = 1000
3. Set feed constant (C02524).
  - For the conveyor drive:  $Vk = d_2 * \pi = 628,3185 \text{ mm}$
4. Set the selection "mm" as unit (C02525).




#### Tip!

The feed constant corresponds to the movement on the machine side when the gearbox output shaft carries out one revolution (for selection as angle =  $360^\circ$ ).

When the unit is set, the real unit of the machine for the selection of physical values (e. g. speeds, accelerations and decelerations) is defined.

## 12.3.4 Selection of master value source and output



[12-25] Signal flow for selecting the master value source and the master values to be output

### Master value source

The master values can be either selected by a "Virtual master", via a bus system or the digital frequency extension module.

- They can be selected on the **Application parameter** tab via the **Master value source** list field or via C03052.

### Master value output

The master value to be output ([A] ... [E]) is selected individually for the three possible communication channels:

- List field **Master value output DF module** (C03197):  
Selection of the master value output for the digital frequency module.
- List field **Master value output MotionBus** (C03054/1):  
Selection of the master value output for horizontal communication.
- List field **Master value output LPort32Out1** (C03054/2):  
Selection of the master value output for vertical communication.

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | Selection of master value source and output

## 12.3.4.1 Master value source: Virtual master

If the "Virtual master" is selected as master value source, the master value is created in the TA and transmitted via a bus system or the digital frequency output to the other slave drives.

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Virtual master*

Parameters		Lenze setting	
		Value	Unit
C03565	Operating mode	Continuous operation	
C03566	STOP position	0.0000	Unit
C03567	START position	0.0000	Unit
C03568/1	1. master speed	360.0000	Unit/t
C03568/2	2. master speed	180.0000	Unit/t
C03569/1	Speed - inching - CW rotation	900.0000	Unit/t
C03569/2	Speed - inching - CCW rotation	900.0000	Unit/t
C03570/1	Inching ramp	5.000	s
C03570/2	Ramp - single cycle/continuous operation	5.000	s
C03570/3	STOP ramp	0.5000	s

Control/setpoint inputs of the function		Signal configuration
Lenze setting	Control/setpoint input	(Multiplexer parameters)
FALSE	→ VMas master shaft STOP1	C03058/1
C03016	→ Activate master function	C03058/3
C03017	→ VMas inching positive	C03058/4
C03018	→ VMas inching negative	C03058/5
FALSE	→ VMas start single cycle	C03058/6
FALSE	→ VMas start continuous operation	C03058/7
FALSE	→ VMas 2. master speed	C03058/8
0	→ VMaster handwheel	C03056

- ▶ Configuration: Tab **FB editor** → FB *VirtualMaster*

## 12.3.4.2 Master value source: Digital frequency input

To use the digital frequency input as master value source, the controller must be provided with digital frequency extension module (E94AYFLF).

To ensure the integration of the extension module in the application, the TA "Synchronism with mark synchronisation" must be used as technology application.



### Note!

The technology application "Synchronism with mark synchronisation" *MotionBus* which can also be selected in the application catalog does not contain any interfaces to the digital frequency extension module.



### Tip!

Detailed information on the digital frequency extension module can be found in the User Manual "Digital frequency extension module (E94AYFLF) – parameter setting & configuration".

## 12.3.4.3 Master value source: Bus system

When the master value is selected via a bus system as e.g. system bus (CAN) it is possible to first extrapolate the received position information to compensate higher bus transmission cycles.

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Synchronism* → *Master value extrapolation*

Parameters		Lenze setting	
		Value	Unit
C03550	Number of extrapolation cycles	1	


  

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
FALSE	→ Activate extrapolation	C03058/9

- ▶ Configuration: Tab **FB editor** → FB *MotionBusIn*

## 12.3.5 "Synchronism" mode"

In the "Synchronism" (C03006 = "0") operating mode the drive follows the master value of the electrical shaft if the clutch is engaged.



[12-26] "Synchronism" mode (schematic diagram)

### Functions in the "Synchronism" operating mode

- ▣ A Master value processing
- ▣ B Mark synchronisation (master value)
- ▣ C Virtual clutch
- ▣ D Master value adjustment
- ▣ E Setpoint conditioning
- ▣ F Mark synchronisation (setpoint)




#### Tip!

A description of the different functions for conditioning the master value can be found in the following subchapters.



**12.3.5.1 Master value processing**



[12-27] "Master value processing" function in the signal flow (schematic diagram)

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Synchronism* → *Master value conditioning*

Parameters		Lenze setting	
		Value	Unit
C03587	Master value	-	Unit
C03000	Stretch factor - numerator	1000000000	
C03001	Stretch factor - denominator	1000000000	
C03025	Master value - direction of rotation	Not inverted	
C03034	Starting position	0.0000	Unit
C03938	Master value cycle (register)	360.0000	Unit
C03672	Master value with stretch factor	-	Unit

Setpoint inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Setpoint input	
DIGIN CINH	→ Set starting position of master shaft	C03058/11
C03034	→ Master shaft starting position	C03053/1
C03000	→ Stretch factor - numerator	C03050/1
C03001	→ Stretch factor - denominator	C03050/2


► Configuration: Tab **FB editor** → FB *ElectricalShaftVal*

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | "Synchronism" mode"

## 12.3.5.2 Mark synchronisation (master value)



[12-28] "Mark synchronisation" function in signal flow (schematic diagram)

This function serves to carry out a mark synchronisation of the master value via touch probe sensor.



### Note!

For this purpose, the touch probe sensor must be connected to the digital input DI3!

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Synchronism* → *Master value conditioning*

Parameters		Lenze setting	
		Value	Unit
C03023	Master value synchronisation (TP)	Deactivated	
C03612	TP position (register)	0.0000	Unit
C03651	TP limit	1.0000	Unit
C03656	Hysteresis	0.0000	Unit/t <sup>2</sup>

- ▶ Configuration: Tab **FB editor** → FB *ElectricalShaftVal*

### TP profile parameters

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *TP profile parameter*

Parameters		Lenze setting	
		Value	Unit
C03620	Positioning mode	0	
C03621	Deactivation mode	0	
C03623/1	Positive speed	3600.0000	Unit/t
C03623/2	Negative speed	3600.0000	Unit/t
C03626/1	Acceleration ramp	1.000	s
C03626/2	Deceleration ramp	1.000	s
C03626/3	Stop ramp	1.000	s

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
FALSE	→ Activate master value TP correction	C03058/12

- ▶ Configuration: Tab **FB editor** → *FB MarkSynchronizationShaft*

### TP interface

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *TP interface*


Parameters		Lenze setting	
		Value	Unit
C02810/3	Signal delay TP3	0	µs
C03022	Edge evaluation of positive edge	TRUE	
C03024	Edge evaluation of negative edge	FALSE	

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | "Synchronism" mode"

## 12.3.5.3 Virtual clutch



[12-29] Function "Virtual clutch" in the signal flow (schematic diagram)


► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Virtual clutch*

Parameters		Lenze setting	
		Value	Unit
C03672	Master value with stretch factor	-	Unit
C03021	Activate clutch	Deactivated	
C03665/1	Clutch in ramp	1.000	s
C03665/2	Decoupling ramp	2.000	s
C03665/3	Stop ramp	1.000	s
C03674	Master value with clutch	-	Unit

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
DigIn 4	→ Close clutch	C03058/13
FALSE	→ Clutch - positive opening operation	C03058/14

► Configuration: Tab **FB editor** → FB *ClutchElectricalShaft*

## 12.3.5.4 Master value trimming



[12-30] "Master value trimming" function in the signal flow (schematic diagram)

This function serves to adjust the master value.

- Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Synchronism* → *Master value trimming*

Parameters		Lenze setting	
		Value	Unit
C03674	Master value with clutch	-	Unit
C03026	Activate trimming	Deactivated	
C03676	Adjustable range	0.0000	Unit/t
C03685	Positioning mode	0	
C03686	Deactivation mode	1	
C03688/1	Positive speed	1000.0000	Unit/t
C03688/2	Negative speed	1000.0000	Unit/t
C03691/1	Acceleration ramp	0.500	s
C03691/2	Deceleration ramp	0.500	s
C03691/3	Stop ramp	1.000	s
C03723	Master value with trimming	-	Unit

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
FALSE	→ Start trimming	C03058/15
C03026	→ Activate trimming	C03058/16
FALSE	→ Set trimming setpoint to 0	C03058/17


- Configuration: Tab **FB editor** → *FB Trimming*

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | "Synchronism" mode"

## 12.3.5.5 Setpoint conditioning



[12-31] "Setpoint conditioning" function in the signal flow (schematic diagram)

This function is used for position ratio between the master shaft and the machine axis.


- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Synchronism* → *Setpoint conditioning*

Parameters		Lenze setting	
		Value	Unit
C02527	Motor mounting direction	Motor rotating CW	
C02536	Cycle	360.0000	Unit

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
Controller inhibit active	→ Delete following error	C03058/20

- ▶ Configuration: Tab **FB editor** → *FB ToolControl*

### 12.3.5.6 Mark synchronisation (setpoint)



[12-32] "Mark synchronisation" function in signal flow (schematic diagram)

This function serves to carry out a mark synchronisation of the setpoint via touch probe sensor.



#### Note!

For this purpose, the touch probe sensor must be connected to the digital input DI2!

► Parameter setting: Tab **Application parameter** → Dialog level *Synchronism* → *Overview* → *Setpoint conditioning*

Parameters		Lenze setting	
		Value	Unit
C03033	Tool synchronisation (TP)	Deactivated	
C03851	Positive TP limit	1.0000	Unit
C03876	TP limit - hysteresis	0.0000	Unit

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
FALSE	→ Set TP position	C03058/24

► Configuration: Tab **FB editor** → FB *ElectricalShaftVal*

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | "Synchronism" mode"

## TP profile parameters

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Synchronism* → *TP profile parameter*

Parameters		Lenze setting	
		Value	Unit
C03855	Positioning mode	0	
C03856	Deactivation mode	0	
C03858/1	Positive speed	1000.0000	Unit/t
C03858/2	Negative speed	1000.0000	Unit/t
C03861/1	Acceleration ramp	1.000	s
C03861/2	Deceleration ramp	1.000	s
C03861/3	Stop ramp	1.000	s

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
FALSE	→ Activate tool TP correction	C03058/23

- ▶ Configuration: Tab **FB editor** → *FB MarkSynchronizationTool*

## TP interface


- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Synchronism* → *TP interface*

Parameters		Lenze setting	
		Value	Unit
C02810/2	Signal delay TP2	0	µs
C03031	Edge evaluation of positive edge	TRUE	
C03032	Edge evaluation of negative edge	FALSE	



## 12.3.6 "Homing" mode

In the "Homing" mode (C03006 = "2") the drive is decoupled from the electrical shaft and the basic function "Homing" is enabled:



[12-33] "Homing" mode (schematic diagram)

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Homing*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02528</a>	Traversing range	Modulo	
<a href="#">C02640</a>	Ref. mode	Set home pos. directly	
<a href="#">C02642</a>	HM position	0.0000	Unit
<a href="#">C02643</a>	HM target position	0.0000	Unit
<a href="#">C02644</a>	Ref. speed 1	360.0000	Unit/s
<a href="#">C02645</a>	Home acceleration 1	720.0000	Unit/s <sup>2</sup>
<a href="#">C02646</a>	Ref. speed 2	180.0000	Unit/s
<a href="#">C02647</a>	Ref. acceleration 2	360.0000	Unit/s <sup>2</sup>
<a href="#">C02648</a>	Home S-ramp time	100	ms
<a href="#">C02649</a>	HM torque limit	10.00	%
<a href="#">C02650</a>	Homing inhibit time	1.000	s
<a href="#">C02652</a>	Home position after mains switching	Delete	
<a href="#">C02653</a>	Max. rot. angle after mains sw.	180	°
C3011	Set home position	Inactive	
C3012	Home position	0.0000	Unit

## 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | "Homing" mode

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
FALSE	→ Start homing	C03160/2
DigIn 2	→ Home mark	C03160/3
C03011	→ Set home position	C03160/4
C03012	→ Home position	C03163
FALSE	→ Reset home position	C03160/5




### Tip!

Detailed information on homing can be found in chapter "Basic drive functions" → subchapter "[Homing](#)". (📖 164)

### 12.3.7 "Manual jog" mode

In the "Manual jog" mode (C03006 = "4") the drive is decoupled from the electrical shaft and the basic function "Manual jog" is enabled:



[12-34] "Manual jog" mode (schematic diagram)

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Manual jog*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02620</a>	Manual jog speed 1	360.0000	Unit/s
<a href="#">C02621</a>	Manual jog speed 2	720.0000	Unit/s
<a href="#">C02622</a>	Manual acceleration	360.0000	Unit/s <sup>2</sup>
<a href="#">C02623</a>	Manual deceleration	1440.0000	Unit/s <sup>2</sup>
<a href="#">C02624</a>	Inaccuracy time of manual traversing	0.100	s
C03007	Positive manual jog	Inactive	
C03008	Negative manual jog	Inactive	

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
C03007	→ Activate positive manual jog	C03155/2
C03008	→ Activate negative manual jog	C03155/3
FALSE	→ Activate 2. speed	C03155/4
FALSE	→ Retract limit switch	C03155/5



**Tip!**

Detailed information on the manual jog function can be found in chapter "Basic drive functions" → subchapter "[Manual jog](#)". (156)


# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | "Positioning" mode"

## 12.3.8 "Positioning" mode"

In the "Positioning" mode (C03006 = "8") the drive is decoupled from the electrical shaft and the basic function "Positioning" is enabled:



[12-35] "Positioning" mode (schematic diagram)

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Positioning*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C00070</a>	Speed controller gain	0.00700	Nm/rpm
<a href="#">C00071</a>	Speed controller reset time	10.0	ms
<a href="#">C00072</a>	D component - speed controller	0.00	ms
<a href="#">C02570</a>	Controller configuration	Phase control	
<a href="#">C02554</a>	Integral-action time of position controller	60.000	s
<a href="#">C02553</a>	Position controller gain	20.00	1/s
C03040	Positioning - profile no.	0	
C03041	Positioning - teach profile no.	0	

Control/setpoint inputs of the function		Signal configuration
Lenze setting	Control/setpoint input	(Multiplexer parameters)
FALSE	→ Start positioning step	C03185/2
FALSE	→ Abort positioning step	C03185/3
FALSE	→ Restart positioning step	C03185/4
FALSE	→ Activate override	C03185/5
0 %	→ Speed override	C03186/1
0 %	→ Acceleration override	C03186/2
FALSE	→ Inhibit touch probe evaluation	C03185/6
FALSE	→ Teach position	C03185/7

## Profile data record management

For the profile data record management the FB **L\_PosProfileTable** is used. This FB serves to file and manage up to four (travel) profiles and to "teach" target positions.

- ▶ A profile describes a motion request which can be implemented by the **SB LS\_Positioner** into a rotary motion.
- ▶ A profile is described via the following profile parameters: Mode (type of positioning), position, speed, acceleration, deceleration, S-ramp time, standard sequence profile, TP sequence profile and TP selection.
- ▶ The data of the profile parameters is directly input in the assigned codes:

Profile parameters	Unit	Profile no. 1	Profile no. 2	Profile no. 3	Profile no. 4
Positioning mode	-	C03970/1	C03970/2	C03970/3	C03970/4
Position	Unit	Set position	C03971/2	C03971/3	C03971/4
Speed	Unit/t	C03972/1	C03972/2	C03972/3	C03972/4
Acceleration	Unit/t <sup>2</sup>	C03973/1	C03973/2	C03973/3	C03973/4
Delay	Unit/t <sup>2</sup>	C03974/1	C03974/2	C03974/3	C03974/4
S-ramp time	s	C03975/1	C03975/2	C03975/3	C03975/4
TP sequence profile	-	C03976/1	C03976/2	C03976/3	C03976/4
TP selection	-	C03977/1	C03977/2	C03977/3	C03977/4



### Note!


For profile no. 1 the set position of the tool which belongs to the master position is always used as target position.

- Application: Returning the tool e.g. from a maintenance position to the network.

## "Teach" position

When the control input "Teach position" is set to TRUE, the current tool position is saved in the profile the number of which is set in C03041. After the control input is reset to FALSE the position saved last is maintained in the profile.

## 12.3.9 Quick stop



[12-36] Basic function "Quick stop" (schematic diagram)

The basic function "Quick stop" brakes the drive to standstill within the deceleration time set for the quick stop function after a corresponding request independent of the setpoint selection.

If the quick stop function is deactivated, the drive is led to the selected setpoint again via the set acceleration time.

- ▶ The quick stop function can be activated as follows in the Lenze setting:
  - By setting the digital input DI1 to LOW level.
  - By a master control via the port *LPortControl1*:  
By setting bit 2 of the bit-coded control word 1.
- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *All basic functions* → *Quick stop*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C00105</a>	Quick stop deceleration time	0.000	s
<a href="#">C00106</a>	Quick stop S-ramp time	0.00	%
<a href="#">C00107</a>	Reference for deceleration time "Quick stop"	Motor reference speed ( <a href="#">C00011</a> )	


Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
DigIn 1	→ Activate quick stop 1	C03135/1
Control word 1 bit 02	→ Activate quick stop 2	C03135/2
FALSE	→ Activate quick stop 3	C03135/3



**Tip!**

Detailed information on quick stop can be found in chapter "Basic drive functions" → subchapter "[Quick stop](#)". (152)

## 12.3.10 Limiter



The basic function "Limiter" monitors the travel range limits via limit switches and parameterised software limit positions and can lead the drive to defined limit ranges when being asked accordingly by the safety module.

[12-37] Basic function "Limiter" (schematic diagram)

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Limiter*

Parameters		Lenze setting	
		Value	Unit
<b>Limit values</b>			
<a href="#">C02707</a>	Permissible direction of rotation	Positive and negative	
<a href="#">C02700</a>	Software limit positions are active	Deactivated	
<a href="#">C02701/1</a>	Positive software limit position	0.0000	Unit
<a href="#">C02701/2</a>	Negative software limit position	0.0000	Unit
<b>Only for homing, positioning and manual jog</b>			
<a href="#">C02702</a>	Limitations effective	Deactivated	
<a href="#">C02703</a>	Max. speed	3600.0000	Unit/s
<a href="#">C02705</a>	Max. acceleration	3600.0000	Unit/s <sup>2</sup>
<a href="#">C02706</a>	Min. S-ramp time	100	ms
<b>Limited speed 1 ... 4 (only for homing, positioning, and manual jog)</b>			
<a href="#">C02708/1</a>	Limited speed 1	3600.0000	Unit/s
<a href="#">C02710/1</a>	Delay lim. speed 1	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/1</a>	S-ramp time lim. speed 1	100	ms
<a href="#">C02708/2</a>	Limited speed 2	7200.0000	Unit/s
<a href="#">C02710/2</a>	Delay lim. speed 2	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/2</a>	S-ramp time lim. speed 2	100	ms
<a href="#">C02708/3</a>	Limited speed 3	14400.0000	Unit/s
<a href="#">C02710/3</a>	Delay lim. speed 3	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/3</a>	S-ramp time lim. speed 3	100	ms
<a href="#">C02708/4</a>	Limited speed 4	28800.0000	Unit/s
<a href="#">C02710/4</a>	Delay lim. speed 4	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/4</a>	S-ramp time lim. speed 4	100	ms
<b>For manual jog only</b>			
<a href="#">C02713</a>	Max. path - manual jog	360.0000	Unit

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | Limiter

Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
FALSE	→ Positive limit switch	C03150/1
FALSE	→ Negative limit switch	C03150/2




## Tip!

Detailed information on the limiter function can be found in chapter "Basic drive functions" → subchapter "[Limiter](#)". (📖 200)



## 12.3.11 Brake control



[12-38] Basic function "Brake control" (schematic diagram)

The basic function "Brake control" serves to the wear free control and monitoring of a holding brake.

In the simplest case, an optionally available brake module is used.

Alternatively the holding brake can also be controlled and monitored via the digital inputs/outputs.



### Note!

In the Lenze setting the brake control is switched off to reach a safe status after mains connection.



### Tip!

Detailed information on brake control can be found in chapter "Basic drive functions" → subchapter "[Brake control](#)". (📖 211)

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | Brake control

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Brake control*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02580</a>	Operating mode - brake	Brake control off	
<a href="#">C02581</a>	Brake activation threshold	50	rpm
<a href="#">C02582</a>	Brake resp. to pulse inhibit	Activate the brake immediately	
<a href="#">C02583</a>	Status input monitoring	Not active	
<a href="#">C02585</a>	Brake control polarity	Not inverted	
<a href="#">C02586</a>	Starting torque 1	0.00	Nm
<a href="#">C02587</a>	Starting torque 2	0.00	Nm
<a href="#">C02588</a>	Source of starting torque	Starting torque 1/2	
<a href="#">C02589</a>	Brake closing time	100	ms
<a href="#">C02590</a>	Brake opening time	100	ms
<a href="#">C02591</a>	Waiting time - status monit.	100	ms
<a href="#">C02593</a>	Waiting time - brake active.	0.000	s
<a href="#">C02594</a>	Test torque	0.00	Nm
<a href="#">C02595</a>	Permissible angle of rotation	5	°
<a href="#">C02596</a>	Grinding speed	100	rpm
<a href="#">C02597</a>	Accel./decel. time - grinding	1.000	s
<a href="#">C02598</a>	Grinding ON time	0.5	s
<a href="#">C02599</a>	Grinding OFF time	0.5	s

Control/setpoint inputs of the function		Signal configuration
Lenze setting	Control/setpoint input	(Multiplexer parameters)
FALSE	→ Release brake	C03165/1
FALSE	→ Activate starting torque 2	C03165/2
FALSE	→ Brake status signal	C03165/3
FALSE	→ Activate brake test	C03165/4
FALSE	→ Grind brake	C03165/5
0 %	→ Additional torque	C03166

## 12.3.12 Signal configuration of drive and motor interface

If required, the preset signal configuration of the control and setpoint inputs of the drive and motor interface can be easily reconfigured per parameter setting of the assigned multiplexer parameters.

### Drive interface

Signal (Lenze setting)	Control input	Signal configuration
FALSE	→ Set controller inhibit	C03130/1
DigIn 5	→ Reset error 1	C03130/2
Control word 1 bit 07	→ Reset error 2	C03130/3
FALSE	→ Reset error 3	C03130/4
FALSE	→ Set error	C03130/5
Control word 1 bit 00	→ Switch on drive	C03130/6

### Motor interface

Signal (Lenze setting)	Setpoint input	Signal configuration
100 %	→ Position controller adaption	C03141/1
100 %	→ Phase controller adaption	C03141/2
100 %	→ Adaptation of speed controller	C03141/3
100 %	→ Upper torque limit value	C03141/4
-100 %	→ Lower torque limit value	C03141/5
100 %	→ Flux setpoint	C03141/6

## 12.3.13 Signal configuration of the output ports

If required, the preset signal configuration of the output ports can be easily reconfigured per parameter setting of the assigned multiplexer parameters.

### "LPortAxisOut1" output port

The output port **LPortAxisOut1** is intended for the connection with a following axis.

Signal (Lenze setting)	Output port	Signal configuration
<b>Axis status word</b>		
• Application-specific signals can be supplemented.		
FALSE	→ Axis status word bit 00	C03120/1
FALSE	→ Axis status word bit 01	C03120/2
FALSE	→ Axis status word bit 02	C03120/3
FALSE	→ Axis status word bit 03	C03120/4
FALSE	→ Axis status word bit 04	C03120/5
FALSE	→ Axis status word bit 05	C03120/6
FALSE	→ Axis status word bit 06	C03120/7
FALSE	→ Axis status word bit 07	C03120/8
FALSE	→ Axis status word bit 08	C03120/9
FALSE	→ Axis status word bit 09	C03120/10
FALSE	→ Axis status word bit 10	C03120/11
FALSE	→ Axis status word bit 11	C03120/12
FALSE	→ Axis status word bit 12	C03120/13
FALSE	→ Axis status word bit 13	C03120/14
FALSE	→ Axis status word bit 14	C03120/15
FALSE	→ Axis status word bit 15	C03120/16
<b>Setpoints for horizontal communication</b>		
0 %	→ Axis-Port Out 1	C03124/1
Master value	→ Axis-Port Out 2	C03054/1

## Output port "LPortStatus1"

The output port **LPortStatus1** is intended for the connection with a higher-level control.

Signal (Lenze setting)	Output port	Signal configuration
<b>Status word 1</b>		
Drive ready	→ Status word 1 bit 00	C03121/1
FALSE	→ Status word 1 bit 01	C03121/2
Drive is ready to start	→ Status word 1 bit 02	C03121/3
Error is active.	→ Status word 1 bit 03	C03121/4
FALSE	→ Status word 1 bit 04	C03121/5
Stop active	→ Status word 1 bit 05	C03121/6
Switch-on inhibit is active	→ Status word 1 bit 06	C03121/7
Warning active	→ Status word 1 bit 07	C03121/8
FALSE	→ Status word 1 bit 08	C03121/9
FALSE	→ Status word 1 bit 09	C03121/10
FALSE	→ Status word 1 bit 10	C03121/11
Drive in the limitation	→ Status word 1 bit 11	C03121/12
Homing complete	→ Status word 1 bit 12	C03121/13
Home position available	→ Status word 1 bit 13	C03121/14
FALSE	→ Status word 1 bit 14	C03121/15
FALSE	→ Status word 1 bit 15	C03121/16

## Output port "LPortStatus2"

The output port **LPortStatus2** is intended for the connection with a higher-level control.

Signal (Lenze setting)	Output port	Signal configuration
<b>Status word 2</b>		
FALSE	→ Status word 2 bit 00	C03122/1
FALSE	→ Status word 2 bit 01	C03122/2
FALSE	→ Status word 2 bit 02	C03122/3
FALSE	→ Status word 2 bit 03	C03122/4
FALSE	→ Status word 2 bit 04	C03122/5
FALSE	→ Status word 2 bit 05	C03122/6
FALSE	→ Status word 2 bit 06	C03122/7
FALSE	→ Status word 2 bit 07	C03122/8
FALSE	→ Status word 2 bit 08	C03122/9
FALSE	→ Status word 2 bit 09	C03122/10
FALSE	→ Status word 2 bit 10	C03122/11
FALSE	→ Status word 2 bit 11	C03122/12
FALSE	→ Status word 2 bit 12	C03122/13
FALSE	→ Status word 2 bit 13	C03122/14
FALSE	→ Status word 2 bit 14	C03122/15
FALSE	→ Status word 2 bit 15	C03122/16

# 9400 HighLine | Parameter setting & configuration

TAs for interconnection via electrical shaft

TA "Synchronism with mark synchronisation" | Application error messages

## 12.3.14 Application error messages

For the output of application-specific error messages an FB instance *ApplicationError* of the function block **L\_DevApplErr** is available in the network.

- ▶ Via the 8 boolean inputs up to 8 different application error messages with parameterisable module ID, error ID and error response can be released by the application.
- ▶ The first four inputs can be connected to the multiplexer parameters with the desired tripping signals. The next four inputs are firmly connected to the tripping signals of the application.

Error message	Error-ID	Error response
1 Free (configurable via C03060/1)	8001	Error
2 Free (configurable via C03060/2)	8002	Error
3 Free (configurable via C03060/3)	8003	Error
4 Activate Modulo mode	8004	Warning
5 Following error	8005	Warning
6 Drive cannot follow	8006	No reaction
7 Drive system interrupted	8007	Quick stop by trouble
8 Reserved	8008	Warning



### ▶ Parameter setting: Tab **All parameters**

Parameters	Lenze setting
C03990 Module-ID	999
C03991/1...8 Error ID 1 ... 8	See table above
C03992/1...8 Error response 1 ... 8	See table above

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
FALSE	→ Application fault 1	C03060/1
FALSE	→ Application fault 2	C03060/2
FALSE	→ Application fault 3	C03060/3


## 13 TAs for positioning tasks

The technology applications described in this chapter are available for positioning tasks.


Technology application/application ranges	Required license/delivery
<a href="#">TA "Multi-purpose positioning" (📖 371)</a>	
 <p><b>Note:</b> In this TA the sequence control is carried out through the controller.</p> <ul style="list-style-type: none"> <li>• Transport units</li> <li>• Rotary tables</li> <li>• Storage and retrieval units</li> <li>• Feed drives</li> <li>• Dosing machines</li> <li>• Hoists</li> </ul>	<p>License stage Motion Control TopLevel or higher required. The technology application can be selected in the »Engineer« application catalog.</p>
<a href="#">TA "Table positioning" (📖 411)</a>	
 <p><b>Note:</b> This TA requires an external sequence control.</p> <ul style="list-style-type: none"> <li>• Transport units</li> <li>• Rotary tables</li> <li>• Storage and retrieval units</li> <li>• Feed drives</li> <li>• Dosing machines</li> <li>• Hoists</li> </ul>	<p>Available in every license stage. The technology application can be selected in the »Engineer« application catalog.</p>

## 13.1 Introduction

Positioning means to move a workpiece/tool or a piece of material from a starting position ❶ to a defined target ❷.



For this purpose a travel profile is to be provided in the controller, for which at least the following profile parameters are required:




Icon	Profile parameters
Ⓐ	<b>Position</b> Target position or path distance to be traversed.
Ⓑ	<b>Speed</b> Maximum speed with which the target is to be approached.
Ⓒ	<b>Acceleration</b> Selection of the change in speed by which acceleration is to be carried out maximally.
Ⓓ	<b>Deceleration</b> Selection of the change in speed by means of which deceleration to standstill is to be maximally effected again.

- ▶ A positioning can consist of several profiles which are executed in a specified mode.
- ▶ A detailed explanation of all profile parameters can be found in the description of the TA in subchapter "[Profile parameters](#)". (📖 390)



## 13.1.1 Application examples


### Multi-purpose positioning



[13-1] Example: Multi-purpose positioning with networking via PROFIBUS

- ▶ The sequential positioning control utilises the traversing blocks of the table positioning and like this activates the basic function "Positioning" containing the profile generation.
- ▶ Here, the multi-purpose positioning only control the "own motor".
- ▶ The sequence of the motor/tool/material control are defined in the multi-purpose positioning.

## Table positioning with higher-level positioning control



[13-2] Example: Table positioning with higher-level positioning control and networking via PROFIBUS

## 13.2 TA "Multi-purpose positioning"

The technology application "Multi-purpose positioning" enables the drive to execute parameterisable travel profiles. The program sequence is defined by a sequence table.

### Functions

- ▶ Sequence control for several successive positioning steps with a break and stop functions and different auxiliary functions (e. g. deriving, counting, waiting).
- ▶ Positioning in different positioning modes
  - Point-to-point positioning
  - Touch probe positioning (residual path positioning)
  - Profile chaining with velocity changeover (overchange)
- ▶ Homing in different homing modes
- ▶ Profile data management
  - Support of S profiles (jerk limitation)
  - Separate setting for acceleration and deceleration
  - "Teach" function
- ▶ Speed-/acceleration override
- ▶ Path-dependent switching of outputs
- ▶ Following error monitoring
- ▶ Support of absolute value encoders
- ▶ Support of the basic drive functions "Manual jog" and "Quick stop"
- ▶ Monitoring of travel range limits with the basic drive function "Limiter"
- ▶ Optional control of a holding brake with the basic drive function "Brake control"


# 9400 HighLine | Parameter setting & configuration

TAs for positioning tasks

TA "Multi-purpose positioning" | Basic signal flow

## 13.2.1 Basic signal flow

The functional core of the multi-purpose positioning is formed by the sequence table and the profile data management, which transmit the required control signals and profile data to the basic drive function "Positioning".



[13-3] Signal flow of the TA "Multi-purpose positioning" (schematic diagram)

### Multi-purpose positioning

- Ⓐ Sequence table
- Ⓑ Profile data management
- Ⓒ Speed/acceleration override

### Basic drive functions


- Ⓓ Homing
- Ⓔ Positioning
- Ⓕ Manual jog
- Ⓖ Stop
- Ⓗ Quick stop
- Ⓘ Limiter
- Ⓙ Brake control (optional)

## 13.2.2 Assignment of the I/O terminals


### 13.2.2.1 Setpoint and control signals

The following tables contain the Lenze assignment of the analog and digital inputs for the technology application "Multi-purpose positioning".

#### Analog inputs

Terminal X3	Signal (Lenze setting)
	<b>AI1-</b> <b>AI1+</b> Selection for speed override ▶ <a href="#">Speed/acceleration override</a> (📖 399)
	<b>AI2-</b> <b>AI2+</b> Selection for acceleration override ▶ <a href="#">Speed/acceleration override</a> (📖 399)
▶ <a href="#">I/O terminals</a> ▶ <a href="#">Analog inputs</a> (📖 117)	

#### Digital inputs

Terminal X5	Signal (Lenze setting)
	<b>DI1</b> Quick stop <ul style="list-style-type: none"> <li>If DI1 is set to LOW level, the positioning program is interrupted and drive is decelerated to standstill within the deceleration time set for the quick stop function independent of the setpoint selection.</li> <li>After the quick stop function is deactivated, a new LOW/HIGH edge is required at DI6 in order that the positioning program is continued with the next step.</li> </ul> ▶ <a href="#">Quick stop</a> (📖 402)
	<b>DI2</b> Connection of reference switch/touch probe sensor ▶ <a href="#">Action type "Homing"</a> (📖 382)
	<b>DI3</b> Connection of travel range limit switch for basic function " <a href="#">Limiter</a> ". (📖 403)
	<b>DI4</b> <ul style="list-style-type: none"> <li>DI3 = positive travel range limit switch, DI4 = negative travel range limit switch.</li> <li>The inputs respond to the FALSE state (fail-safe).</li> </ul>
	<b>DI5</b> Reset error and positioning program <ul style="list-style-type: none"> <li>By means of a LOW-HIGH edge an existing error status can be reset if the cause of the fault is removed. At the same time the positioning program is reset.</li> </ul>
	<b>DI6</b> Start positioning program ▶ <a href="#">Control of the sequence table</a> (📖 389)
	<b>DI7</b> Stop positioning program (break) ▶ <a href="#">Control of the sequence table</a> (📖 389)
	<b>DI8</b> Sequencer input 8 for positioning program <ul style="list-style-type: none"> <li>The action types "Positioning", "Branching", "Waiting" and "Stand-by" have the parameter "Input for...". If this is non-zero, it describes the number of the sequencer input where the positioning program awaits the level defined before it executes the action. In the Lenze assignment the terminal DI8 is available as sequencer input 8.</li> </ul> ▶ <a href="#">Program flow</a> (📖 378)
▶ <a href="#">I/O terminals</a> ▶ <a href="#">Digital inputs</a> (📖 123)	

# 9400 HighLine | Parameter setting & configuration

TAs for positioning tasks


TA "Multi-purpose positioning" | Assignment of the I/O terminals

## 13.2.2.2 Actual value and status signals

The following tables contain the Lenze assignment of the analog and digital outputs for the technology application "Multi-purpose positioning".


- The default signal configuration if required can be easily changed by parameterising the multiplexer parameters assigned.

### Analog outputs

Terminal X3	Signal (Lenze setting)	Signal configuration
	<b>AO1</b> Motor speed • Scaling: $\pm 10\text{ V} \equiv$ motor reference speed ( <a href="#">C00011</a> )	C03110/1
	<b>AO2</b> Motor torque (setpoint) • Scaling: $10\text{ V} \equiv$ Motor reference torque ( <a href="#">C00057/2</a> )	C03110/2


► [I/O terminals](#) ► [Analog outputs](#) ([120](#))

### Digital outputs

Terminal X4	Signal (Lenze setting)	Signal configuration
	<b>DO1</b> Status "Drive ready" • This operating state is active if the controller is enabled by setting the digital input RFR to HIGH level and no error has occurred.	C03100/1
	<b>DO2</b> Status "Positioner active"	C03100/2
	<b>DO3</b> Status "Limitation active" • At the moment a setpoint is limited or a software or hardware limit switch has been reached.	C03100/3
	<b>DO4</b> Status "Error active acknowledgement is required" • Monitoring with the error response "Error" or "Quick stop by trouble" has been activated, and the controller is in the device state "Error active" or "Quick stop by trouble active".	C03100/4


► [I/O terminals](#) ► [Digital outputs](#) ([125](#))

### State bus

Terminal X2	Signal (Lenze setting)	Signal configuration
	<b>SB</b> Status "Error active acknowledgement is required" • Monitoring with the error response "Error" or "Quick stop by trouble" has been activated, and the controller is in the device state "Error active" or "Quick stop by trouble active". • The state bus is put in the "error" status.	C03100/5

► [I/O terminals](#) ► [Monitoring function "State bus"](#) ([127](#))


### Display elements

User LED	Signal (Lenze setting)	Signal configuration
	Status "Sequence control active"	C03100/6

► [Drive interface](#) ► [LED status displays](#) ([34](#))

## 13.2.3 Basic settings

### 13.2.3.1 Machine parameters



The machine parameters describe e.g. the motor end of the mechanics used.

The setting of the machine parameters in the »Engineer« is carried out on the **Application parameters** tab in the dialog level *Overview* → *Machine parameters*.



#### Tip!

In the »Engineer« the most important machine parameters can be adapted to the machine on the **Application parameter** tab directly in the topmost *Overview* dialog level:




Detailed information for selecting and entering the machine parameters can be found in the chapter "[Drive interface](#)". ▶ [Machine parameters](#) (35)

### Short overview of machine parameters

Parameters		Lenze setting	
		Value	Unit
<a href="#">C00173</a>	Mains - voltage	400/415	V
<a href="#">C00174</a>	Threshold undervoltage (LU)	285	V
<a href="#">C00600</a>	Resp. to DC bus overvoltage	Trouble	
<a href="#">C02520</a>	Gearbox fact. numer. motor	1	
<a href="#">C02521</a>	Gearbox fact. denom. motor	1	
<a href="#">C02527</a>	Motor mounting direction	Motor rotating CW	
<a href="#">C02570</a>	Controller configuration	Phase control	
<a href="#">C02522</a>	Gearbox fact. numer. load	1	
<a href="#">C02523</a>	Gearbox fact. denom. load	1	
<a href="#">C02529</a>	Mounting direction of position encoder	Encoder rotating CW	
<b>Description of the mechanics (load, tool)</b>			
<a href="#">C02528</a>	Traversing range	Unlimited	
<a href="#">C02524</a>	Feed constant	360.0000	Unit
<a href="#">C02525</a>	Unit		°
<a href="#">C02526</a>	User-defined unit		°
<a href="#">C02533</a>	Time unit		s
<a href="#">C00273/1</a>	Motor moment of inertia	Motor-dependent	kg cm <sup>2</sup>
<a href="#">C00273/2</a>	Load moment of inertia	0.00	kg cm <sup>2</sup>

## 13.2.3.2 Traversing range

By setting the traversing range the machine type/measuring system is set:

Traversing range	
<p><b>Unlimited</b></p> 	<p>The drive can traverse optionally in both directions without reaching limitations.</p> <ul style="list-style-type: none"> <li>Positionings here generally are effected in the positioning modes "Relative with/without TP" or "Speed with/without TP".</li> <li>The positioning measuring system is reset to zero with every new positioning process.</li> <li>By homing, the positioning measuring system receives a fixed reference point (zero point), so that also the positioning modes "Absolute with/without TP" can be used. Then also the software limit positions for limiting the traversing range are provided. ▶ <a href="#">Software limit positions</a> (☞ 202)</li> </ul>
<p><b>Limited</b></p> 	<p>After reaching the position limits, the drive must travel in the opposite direction again.</p> <ul style="list-style-type: none"> <li>For positioning, the home position has to be known. By homing, the positioning measuring system receives a fixed reference point (zero point).</li> <li>Basically, monitoring to the internally maximum usable value range (<math>\pm 2^{31}</math> increments) takes place (software limit position monitoring of the internal value range). An overflow of the value range results in the loss of the home position.</li> <li>Additionally parameterisable software limit positions can be activated on the user side for limiting the travel range. ▶ <a href="#">Software limit positions</a> (☞ 202)</li> </ul>
<p><b>Modulo</b></p> 	<p>The measuring system is repeated.</p> <ul style="list-style-type: none"> <li>If the cycles ① set are exceeded a defined overflow occurs. The cycle typically corresponds to a rotation or tool distance in a rotative system.</li> <li>For positioning, the home position has to be known.</li> <li>Software limit positions are not effective</li> <li>Absolute targets can be approached by exceeding the measuring system limit, e.g. from 10° via 0° to 350°.</li> </ul>

▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02528</a>	Traversing range	Unlimited	
<a href="#">C02536</a>	Cycle (only relevant for traversing range "Modulo")	360.0000	Unit




### 13.2.3.3 Position control

The dialog level *Overview* → *S\_Positioner* and the subordinated and dialog levels serve to adapt the parameters relevant for the position control, if required.

Parameters		Lenze setting	
		Value	Unit
<a href="#">C00254</a>	Phase controller gain	20.00	1/s
<a href="#">C02553</a>	Position controller gain	20.00	1/s
<a href="#">C02556</a>	Pos. contr. limitation	214748.3647	Unit/s

## 13.2.4 Program flow

The program flow of the multi-purpose positioning is selected according to a sequence table which can contain up to 100 references to "actions".



[13-4] Sequence table (schematic diagram)




### What is an action?

- ▶ An action comprises a clear functionality which is described with a few parameters.
- ▶ Different action types are available which serve to implement, for instance, program branching, switching operations, waiting times and counters.



- ▶ Before every action type a defined number of actions is available which can be individually parameterised. The parameters of the actions of the same type only differ in the subcode.
- ▶ An action can be used in several steps if always exactly the same task is to be carried out.
- ▶ After an action has been processed, the action in the next step of the sequence table is automatically processed unless it is jumped to another step in the sequence table due to a branch.
- ▶ One action can be maximally processed per computing cycle.




## 13.2.4.1 Overview of action types





Action type	Function/parameter															
<b>Homing</b>																
	<p>In order to execute a homing process, the action type "Homing" is available which activates the basic function "Homing".</p> <p><b>Note:</b> The "Homing" action does not have its own parameters. The settings for homing are made via the parameters of the basic function "Homing".</p> <p>▶ <a href="#">Homing</a> (📖 164)</p>															
<b>Positioning</b>																
	<p>To execute a profile, 50 actions of type "Positioning" are available.</p> <ul style="list-style-type: none"> <li>The execution of the adjusted profile is only started with activated waiting function if the sequencer input selected for the waiting function accepts the selected signal state. ▶ <a href="#">Sequencer inputs</a> (📖 386)</li> </ul>															
<table border="1"> <thead> <tr> <th colspan="2">Parameters</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>C04513/1...50</td> <td>Profile number</td> <td>Specification of the profile to be executed.                             <ul style="list-style-type: none"> <li>Press the "Set up profile" button to open a dialog box to enter the corresponding profile parameters.</li> <li>In this dialog a sequence profile can also be set.</li> </ul> </td> </tr> <tr> <td>C04511/1...50</td> <td>Input for waiting function</td> <td>Sequence input 1 ... 32 to be evaluated.                             <ul style="list-style-type: none"> <li>With the default setting "0" the waiting function is skipped and the profile execution is started immediately.</li> </ul> </td> </tr> <tr> <td>C04512/1...50</td> <td>Signal state for waiting function</td> <td>Only when the sequencer input to be evaluated has this state, the profile is executed.</td> </tr> <tr> <td>C04514/1...50</td> <td>Sequence step</td> <td>Step inside the sequence table which will be processed after the profile has been executed.</td> </tr> </tbody> </table>		Parameters		Information	C04513/1...50	Profile number	Specification of the profile to be executed. <ul style="list-style-type: none"> <li>Press the "Set up profile" button to open a dialog box to enter the corresponding profile parameters.</li> <li>In this dialog a sequence profile can also be set.</li> </ul>	C04511/1...50	Input for waiting function	Sequence input 1 ... 32 to be evaluated. <ul style="list-style-type: none"> <li>With the default setting "0" the waiting function is skipped and the profile execution is started immediately.</li> </ul>	C04512/1...50	Signal state for waiting function	Only when the sequencer input to be evaluated has this state, the profile is executed.	C04514/1...50	Sequence step	Step inside the sequence table which will be processed after the profile has been executed.
Parameters		Information														
C04513/1...50	Profile number	Specification of the profile to be executed. <ul style="list-style-type: none"> <li>Press the "Set up profile" button to open a dialog box to enter the corresponding profile parameters.</li> <li>In this dialog a sequence profile can also be set.</li> </ul>														
C04511/1...50	Input for waiting function	Sequence input 1 ... 32 to be evaluated. <ul style="list-style-type: none"> <li>With the default setting "0" the waiting function is skipped and the profile execution is started immediately.</li> </ul>														
C04512/1...50	Signal state for waiting function	Only when the sequencer input to be evaluated has this state, the profile is executed.														
C04514/1...50	Sequence step	Step inside the sequence table which will be processed after the profile has been executed.														
<b>Branching</b>																
	<p>25 actions of type "Branching" are available for conditional and unconditional branches (jumps).</p> <ul style="list-style-type: none"> <li>A branch to the indicated step is executed when the selected sequencer input has the selected signal state at the time of processing. If not, the sequence step is processed in the sequence table. ▶ <a href="#">Sequencer inputs</a> (📖 386)</li> </ul>															
<table border="1"> <thead> <tr> <th colspan="2">Parameters</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>C04530/1...25</td> <td>Input for comparison</td> <td>Sequence input 1 ... 32 to be evaluated.                             <ul style="list-style-type: none"> <li>With the default setting "0" a branch to the adjusted sequence step is executed.</li> </ul> </td> </tr> <tr> <td>C04531/1...25</td> <td>Comparison value</td> <td>State in which the sequencer input to be evaluated is compared.</td> </tr> <tr> <td>C04532/1...25</td> <td>Sequence step in case of equality</td> <td>If the sequencer input to be evaluated equals the comparison value, a branch to the step set here is executed. In the case of inequality or "0" setting, the next step in the sequence table is processed instead.</td> </tr> </tbody> </table>		Parameters		Information	C04530/1...25	Input for comparison	Sequence input 1 ... 32 to be evaluated. <ul style="list-style-type: none"> <li>With the default setting "0" a branch to the adjusted sequence step is executed.</li> </ul>	C04531/1...25	Comparison value	State in which the sequencer input to be evaluated is compared.	C04532/1...25	Sequence step in case of equality	If the sequencer input to be evaluated equals the comparison value, a branch to the step set here is executed. In the case of inequality or "0" setting, the next step in the sequence table is processed instead.			
Parameters		Information														
C04530/1...25	Input for comparison	Sequence input 1 ... 32 to be evaluated. <ul style="list-style-type: none"> <li>With the default setting "0" a branch to the adjusted sequence step is executed.</li> </ul>														
C04531/1...25	Comparison value	State in which the sequencer input to be evaluated is compared.														
C04532/1...25	Sequence step in case of equality	If the sequencer input to be evaluated equals the comparison value, a branch to the step set here is executed. In the case of inequality or "0" setting, the next step in the sequence table is processed instead.														

# 9400 HighLine | Parameter setting & configuration

TAs for positioning tasks


TA "Multi-purpose positioning" | Program flow

Action type	Function/parameter															
<b>Variable branching</b>																
	<p>For variable branches (jumps) 5 actions of type "Variable branching" are available.</p> <ul style="list-style-type: none"> <li>The branch to one of 20 possible steps is executed depending on the value in C03001 ... C03005 at the time of processing.</li> <li>The parameters C03001 ... C03005 are firmly assigned to the five available actions: <ul style="list-style-type: none"> <li>-C03001 determines the branch for action 1.</li> <li>-C03002 determines the branch for action 2, etc.</li> </ul> </li> </ul> <p><b>Example:</b> If C03002 is assigned to the value "15" at the time of processing the action no. 2, it is branched to the step which is entered in the parameter "Sequence step at branch value 15" for action no. 2 (C04554/2).</p> <table border="1"> <thead> <tr> <th>Parameters</th> <th colspan="2">Information</th> </tr> </thead> <tbody> <tr> <td>C04540/1...5</td> <td>Sequence step at branch value 1</td> <td>Step which is executed next when C03001 ... C03005 = "1". <ul style="list-style-type: none"> <li>With the default setting "0" the branching is deactivated (sequence step is processed).</li> </ul> </td> </tr> <tr> <td>C04541/1...5</td> <td>Sequence step at branch value 2</td> <td>Step which is executed next when C03001 ... C03005 = "2". <ul style="list-style-type: none"> <li>In the default setting "0", branching is deactivated and the next step in the sequence table is processed.</li> </ul> </td> </tr> <tr> <td>...</td> <td>...</td> <td>...</td> </tr> <tr> <td>C04559/1...5</td> <td>Sequence step at branch value 20</td> <td>Step which is executed next when C03001 ... C03005 = "20". <ul style="list-style-type: none"> <li>In the default setting "0", branching is deactivated and the next step in the sequence table is processed.</li> </ul> </td> </tr> </tbody> </table>	Parameters	Information		C04540/1...5	Sequence step at branch value 1	Step which is executed next when C03001 ... C03005 = "1". <ul style="list-style-type: none"> <li>With the default setting "0" the branching is deactivated (sequence step is processed).</li> </ul>	C04541/1...5	Sequence step at branch value 2	Step which is executed next when C03001 ... C03005 = "2". <ul style="list-style-type: none"> <li>In the default setting "0", branching is deactivated and the next step in the sequence table is processed.</li> </ul>	...	...	...	C04559/1...5	Sequence step at branch value 20	Step which is executed next when C03001 ... C03005 = "20". <ul style="list-style-type: none"> <li>In the default setting "0", branching is deactivated and the next step in the sequence table is processed.</li> </ul>
Parameters	Information															
C04540/1...5	Sequence step at branch value 1	Step which is executed next when C03001 ... C03005 = "1". <ul style="list-style-type: none"> <li>With the default setting "0" the branching is deactivated (sequence step is processed).</li> </ul>														
C04541/1...5	Sequence step at branch value 2	Step which is executed next when C03001 ... C03005 = "2". <ul style="list-style-type: none"> <li>In the default setting "0", branching is deactivated and the next step in the sequence table is processed.</li> </ul>														
...	...	...														
C04559/1...5	Sequence step at branch value 20	Step which is executed next when C03001 ... C03005 = "20". <ul style="list-style-type: none"> <li>In the default setting "0", branching is deactivated and the next step in the sequence table is processed.</li> </ul>														
<b>Switching</b>																
	<p>In order to switch digital output signals 25 actions of type "Switching" are available.</p> <ul style="list-style-type: none"> <li>Each action can set two selectable sequencer outputs to FALSE or TRUE independently of each other. <a href="#">▶ Sequencer outputs (p 386)</a></li> </ul> <table border="1"> <thead> <tr> <th>Parameters</th> <th colspan="2">Information</th> </tr> </thead> <tbody> <tr> <td>C04520/1...25</td> <td>Output A switching</td> <td>Sequencer output 1 ... 32 to be switched. <ul style="list-style-type: none"> <li>With the setting "0" switching is deactivated.</li> </ul> </td> </tr> <tr> <td>C04521/1...25</td> <td>Signal state for A switching</td> <td>State to which the sequencer output is to be set.</td> </tr> <tr> <td>C04522/1...25</td> <td>Output for B switching</td> <td>Sequencer output 1 ... 32 to be switched. <ul style="list-style-type: none"> <li>With the setting "0" switching is deactivated.</li> </ul> </td> </tr> <tr> <td>C04523/1...25</td> <td>Signal state for B switching</td> <td>State to which the sequencer output is to be set.</td> </tr> </tbody> </table>	Parameters	Information		C04520/1...25	Output A switching	Sequencer output 1 ... 32 to be switched. <ul style="list-style-type: none"> <li>With the setting "0" switching is deactivated.</li> </ul>	C04521/1...25	Signal state for A switching	State to which the sequencer output is to be set.	C04522/1...25	Output for B switching	Sequencer output 1 ... 32 to be switched. <ul style="list-style-type: none"> <li>With the setting "0" switching is deactivated.</li> </ul>	C04523/1...25	Signal state for B switching	State to which the sequencer output is to be set.
Parameters	Information															
C04520/1...25	Output A switching	Sequencer output 1 ... 32 to be switched. <ul style="list-style-type: none"> <li>With the setting "0" switching is deactivated.</li> </ul>														
C04521/1...25	Signal state for A switching	State to which the sequencer output is to be set.														
C04522/1...25	Output for B switching	Sequencer output 1 ... 32 to be switched. <ul style="list-style-type: none"> <li>With the setting "0" switching is deactivated.</li> </ul>														
C04523/1...25	Signal state for B switching	State to which the sequencer output is to be set.														
<b>Set counter</b>																
	<p>10 actions of type "Set counter" are available for setting one of the 10 available counters to a certain starting value.</p> <ul style="list-style-type: none"> <li>The 10 actions of type "Set counter" are not firmly assigned to the 10 actions of the "Counting" type.</li> <li>You can use, for instance, an action of type "Set counter" to set a counter to a value and later you can set the same counter with another action of type "Set counter" to another value.</li> </ul> <table border="1"> <thead> <tr> <th>Parameters</th> <th colspan="2">Information</th> </tr> </thead> <tbody> <tr> <td>C04580/1...10</td> <td>Counter selection</td> <td>With the setting "0" the setting of the counter is deactivated.</td> </tr> <tr> <td>C04581/1...10</td> <td>New counter content</td> <td>-2147483648 ... 2147483648</td> </tr> <tr> <td>C04582/1...10</td> <td>Current counter content</td> <td>Read only</td> </tr> </tbody> </table>	Parameters	Information		C04580/1...10	Counter selection	With the setting "0" the setting of the counter is deactivated.	C04581/1...10	New counter content	-2147483648 ... 2147483648	C04582/1...10	Current counter content	Read only			
Parameters	Information															
C04580/1...10	Counter selection	With the setting "0" the setting of the counter is deactivated.														
C04581/1...10	New counter content	-2147483648 ... 2147483648														
C04582/1...10	Current counter content	Read only														

Action type	Function/parameter																		
<b>Count</b>																			
	<p>25 actions of type "Count" are available for counting processes.</p> <ul style="list-style-type: none"> <li>• With each action processing the counter content of the counter selected is increased or reduced by the specified step value depending on the setting (count upwards or downwards).</li> <li>• When the comparison condition for comparing the counter content with an adjustable comparison value is fulfilled, a branch to any step is possible.</li> <li>• 10 actions of type "Set counter" are available for setting a counter to a starting value.</li> </ul>																		
	<table border="1"> <thead> <tr> <th colspan="2">Parameters</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>C04590/1...25</td> <td>Counter selection</td> <td>With the setting "0" the setting of the counter is deactivated.</td> </tr> <tr> <td>C04591/1...25</td> <td>Step value</td> <td>Value by which the counter is increased or reduced.                             <ul style="list-style-type: none"> <li>• Range: -2147483648 ... 2147483648</li> </ul> </td> </tr> <tr> <td>C04592/1...25</td> <td>Comparison value</td> <td>Value with which the counter is compared.                             <ul style="list-style-type: none"> <li>• Range: -2147483648 ... 2147483648</li> </ul> </td> </tr> <tr> <td>C04593/1...25</td> <td>Sequence step</td> <td>When the set comparison condition is met, a branch to the step set here is executed. If the condition is not met, the next step in the sequence table is processed instead.</td> </tr> <tr> <td>C04594/1...25</td> <td>Comparison condition</td> <td>Selection of the condition for the comparison of the counter content with the comparison value.</td> </tr> </tbody> </table>	Parameters		Information	C04590/1...25	Counter selection	With the setting "0" the setting of the counter is deactivated.	C04591/1...25	Step value	Value by which the counter is increased or reduced. <ul style="list-style-type: none"> <li>• Range: -2147483648 ... 2147483648</li> </ul>	C04592/1...25	Comparison value	Value with which the counter is compared. <ul style="list-style-type: none"> <li>• Range: -2147483648 ... 2147483648</li> </ul>	C04593/1...25	Sequence step	When the set comparison condition is met, a branch to the step set here is executed. If the condition is not met, the next step in the sequence table is processed instead.	C04594/1...25	Comparison condition	Selection of the condition for the comparison of the counter content with the comparison value.
	Parameters		Information																
	C04590/1...25	Counter selection	With the setting "0" the setting of the counter is deactivated.																
	C04591/1...25	Step value	Value by which the counter is increased or reduced. <ul style="list-style-type: none"> <li>• Range: -2147483648 ... 2147483648</li> </ul>																
	C04592/1...25	Comparison value	Value with which the counter is compared. <ul style="list-style-type: none"> <li>• Range: -2147483648 ... 2147483648</li> </ul>																
	C04593/1...25	Sequence step	When the set comparison condition is met, a branch to the step set here is executed. If the condition is not met, the next step in the sequence table is processed instead.																
C04594/1...25	Comparison condition	Selection of the condition for the comparison of the counter content with the comparison value.																	
<b>Wait</b>																			
	<p>25 actions of type "Wait" are available for the insertion into the program flow.</p> <ul style="list-style-type: none"> <li>• The sequence step is only processed after the waiting time has elapsed or when the selected sequencer input has the selected signal state at the time of processing. ▶ <a href="#">Sequencer inputs</a> (□ 386)</li> </ul>																		
	<table border="1"> <thead> <tr> <th colspan="2">Parameters</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>C04571/1...25</td> <td>Waiting time</td> <td>With setting "0", the waiting time is deactivated.</td> </tr> <tr> <td>C04572/1...25</td> <td>Input for waiting function</td> <td>Sequence input 1 ... 32 to be evaluated.                             <ul style="list-style-type: none"> <li>• The sequence step will be processed when this input has the set state, but no later than after the set waiting time has elapsed.</li> </ul> </td> </tr> <tr> <td>C04573/1...25</td> <td>Signal state for waiting function</td> <td>Required state for completing the waiting function.</td> </tr> </tbody> </table>	Parameters		Information	C04571/1...25	Waiting time	With setting "0", the waiting time is deactivated.	C04572/1...25	Input for waiting function	Sequence input 1 ... 32 to be evaluated. <ul style="list-style-type: none"> <li>• The sequence step will be processed when this input has the set state, but no later than after the set waiting time has elapsed.</li> </ul>	C04573/1...25	Signal state for waiting function	Required state for completing the waiting function.						
	Parameters		Information																
	C04571/1...25	Waiting time	With setting "0", the waiting time is deactivated.																
C04572/1...25	Input for waiting function	Sequence input 1 ... 32 to be evaluated. <ul style="list-style-type: none"> <li>• The sequence step will be processed when this input has the set state, but no later than after the set waiting time has elapsed.</li> </ul>																	
C04573/1...25	Signal state for waiting function	Required state for completing the waiting function.																	
<b>Stand-by</b>																			
	<p>5 actions of type "Stand-by" are available for the temporary activation of a setpoint follower.</p> <ul style="list-style-type: none"> <li>• For a sensible use of the "Standby" action, appropriate signal combinations are required in the (enabled) function block editor.</li> <li>• The setpoint follower is enabled until the condition for exiting the stand-by is met.</li> </ul>																		
	<table border="1"> <thead> <tr> <th colspan="2">Parameters</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>C04601/1...5</td> <td>Input for "Stand-by" end</td> <td>Sequence input 1 ... 32 to be evaluated.</td> </tr> <tr> <td>C04602/1...5</td> <td>Signal state for "Stand-by" end</td> <td>Only if the sequencer input to be evaluated has this state, the standby step is exited, and the next step in the sequence table is processed.</td> </tr> </tbody> </table>	Parameters		Information	C04601/1...5	Input for "Stand-by" end	Sequence input 1 ... 32 to be evaluated.	C04602/1...5	Signal state for "Stand-by" end	Only if the sequencer input to be evaluated has this state, the standby step is exited, and the next step in the sequence table is processed.									
	Parameters		Information																
C04601/1...5	Input for "Stand-by" end	Sequence input 1 ... 32 to be evaluated.																	
C04602/1...5	Signal state for "Stand-by" end	Only if the sequencer input to be evaluated has this state, the standby step is exited, and the next step in the sequence table is processed.																	
<b>Program end</b>																			
	<p>To define the program end in the sequence table or delete a program step, the action of type "Program end" is available.</p>																		

## 13.2.4.2 Action type "Homing"

In order to execute a homing process, the action type "Homing" is available for the sequence table which activates the basic function "Homing".



[13-5] "Homing" (schematic diagram for limited traversing range)



### Note!

The "Homing" action for the sequence table does not have its own parameters. The settings for homing are made via the parameters of the basic function "Homing".

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Homing*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02528</a>	Traversing range	Unlimited	
<a href="#">C02640</a>	Ref. mode	Set home pos. directly	
<a href="#">C02642</a>	HM position	0.0000	Unit
<a href="#">C02643</a>	HM target position	0.0000	Unit
<a href="#">C02644</a>	Ref. speed 1	360.0000	Unit/s
<a href="#">C02645</a>	Home acceleration 1	720.0000	Unit/s <sup>2</sup>
<a href="#">C02646</a>	Ref. speed 2	180.0000	Unit/s
<a href="#">C02647</a>	Home acceleration 2	360.0000	Unit/s <sup>2</sup>
<a href="#">C02648</a>	Home S-ramp time	100	ms
<a href="#">C02649</a>	HM torque limit	10.00	%
<a href="#">C02650</a>	Homing inhibit time	1.000	s
<a href="#">C02652</a>	Home position after mains switching	Delete	
<a href="#">C02653</a>	Max. rot. angle after mains sw.	180	°

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
Sequencer Enable Homing	→ Request homing	C03160/1
Sequencer Activate Homing	→ Start homing	C03160/2
DigIn 2	→ Home mark	C03160/3
FALSE	→ Set home position	C03160/4
FALSE	→ Reset home position	C03160/5
Zero position	→ Home position	C03163




### Tip!

Detailed information on homing can be found in chapter "Basic drive functions" → subchapter "[Homing](#)". (📖 164)

## 13.2.4.3 Action type "Positioning"

In order to execute a positioning process, 50 actions of "Positioning" type are available for the sequence table which activates the basic function "Positioning":



[13-6] "Positioning" (schematic diagram for limited traversing range)

- ▶ Use the parameter **Profile number** of the action to select the number or the table position of the profile to be executed. The final profile data are then given to the basic function by the [Profile data management](#). (📖 390)
- ▶ The execution of the adjusted profile is only started with activated waiting function if the sequencer input selected for the waiting function accepts the selected signal state. ▶ [Sequencer inputs](#) (📖 386)




**Tip!**

Detailed information on positioning can be found in the chapter "Basic drive functions" → subchapter "[Positioning](#)". (📖 176)



## 13.2.4.4 Action type "Variable branching"

For variable branches (jumps) 5 actions of type "Variable branching" are available for the sequence table.



- ▶ The branch to one of 20 possible steps is executed in the Lenze setting depending on the value in C03001 ... C03005 at the time or processing.
- ▶ The parameters C03001 ... C03005 are firmly assigned to the five available actions, i.e. C03001 determines the branch for action 1, C03002 for action 2, etc.

[13.1] Principle of the variable branch (here for action no. 1)



**Tip!**

Instead of the parameters C03001 ... C03005 you can also assign other signal sources of the application to the "branch" inputs via multiplexer parameters.


- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → L\_Sequencer

Parameters		Lenze setting	
		Value	Unit
C03001	Branch value 1	1	
C03002	Branch value 2	1	
C03003	Branch value 3	1	
C03004	Branch value 4	1	
C03005	Branch value 5	1	

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
C03001	→ Sequencer branch 1	C03079/1
C03002	→ Sequencer branch 2	C03079/2
C03003	→ Sequencer branch 3	C03079/3
C03004	→ Sequencer branch 4	C03079/4
C03005	→ Sequencer branch 5	C03079/5

## Example

The following example illustrates the function of the variable branch based on a program flow which contains, among other things, two actions of the "Variable branching" type.



[13.2] Example "Variable branch"

### 13.2.4.5 Sequencer inputs

In order to control conditional branches and the optional waiting function of some action types during the program flow, 32 sequencer inputs of "BOOL" type.

- ▶ The sequencer inputs 1 ... 16 can be linked with the signal sources of the application or device interfaces in the dialog level *Overview* → *L\_Sequencer* → *Program inputs* via multiplexer parameters.
- ▶ In case of the action types "positioning", "branching", "waiting" and "stand-by" it can be defined for each action which of the sequencer inputs can be called during the program sequence for the corresponding function.



#### Note!

The sequencer input 8 in the Lenze setting is linked with the digital input DI8.

▶ [Parameterise signal combinations](#) (📖 237)

### 13.2.4.6 Sequencer outputs

Via a DWORD-to-BIT-converter, 32 sequencer outputs of type "BOOL" are available for "switching" which can be set to FALSE or TRUE with the action type "switching".

- ▶ These sequencer outputs can be connected with the inputs of the application or device interfaces via multiplexer parameters.


- ▶ The following table lists the corresponding module outputs of the FB interconnection and the corresponding selection numbers for the multiplexer parameters:

Module output	Signal type	Selection no.	Selection text
SequencerOutput.bBit0	□	551	Sequencer output 1
SequencerOutput.bBit1		552	Sequencer output 2
SequencerOutput.bBit2		553	Sequencer output 3
...		...	...
SequencerOutput.bBit31		582	Sequencer output 32

- ▶ [Parameterise signal combinations](#) (📖 237)

## 13.2.4.7 Parameter setting of the program flow in the Engineer

Go to the »Engineer« to the **Application parameter** tab and click **Program flow** in the topmost dialog level to change to the dialog for the sequence table:



### Basic procedure

In the default setting the sequence table contains a small "Positioning program", which first rotates the axis 360° clockwise and afterwards 360° counter-clockwise.

Proceed as follows to define the desired program flow:

1. Select the program step (1 .... 100) to be edited on the left in the sequence table.
2. Select the action type for the selected program step by clicking it.
3. If the selected action type provides more than one action, select the action to be parameterised from the list field **Selection of action number**.
  - The next free action is suggested automatically.
4. Enter a comment about the action (optional).
5. Set parameters of the action.
  - If required, call the corresponding subsequent dialogs.
6. Repeat step 1 ... 5 until all actions required for the program flow are parameterised.

## 13.2.4.8 Control of the sequence table

A LOW/HIGH edge at the digital input DI6 starts the parameterised program flow if the controller is enabled and no error is pending.

- ▶ The first step set in C03000 of the sequence table is executed.
- ▶ By setting the digital input DI7 to HIGH level, the program flow can be stopped, if required (break).



### Note!

In the following cases the program flow is interrupted:

- The controller inhibit is activated.
- Quick stop is activated.
- The drive interface changes to an error status.

If the controller is not inhibited, a shutdown of the drive via the basic function "Quick stop" is effected.


After the interruption is deactivated again (e.g. because an activated quick stop has been deactivated again), a renewed LOW/HIGH edge is required at the digital input DI6 in order that the positioning program can be continued with the sequence step.

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → L\_Sequencer

Parameters		Lenze setting	
		Value	Unit
C03000	Starting step	1	
C04504	Jump destination	0	

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
C03000	→ First step	C03079/6
DigIn 6	→ Sequencer start	C03070/1
DigIn 7	→ Sequencer break	C03070/2
Controller inhibit or Quick stop active or Error is active.	→ Sequencer abort	C03070/6
FALSE	→ Sequencer jump	C03070/7
DigIn 5	→ Reset program/error status	C03070/8

## 13.2.5 Profile data management




[13-7] Profile data management (schematic diagram)

The profile data management serves to file and manage up to 100 (travel) profiles.





- ▶ A profile describes a motion request which can be converted by the basic drive function "Positioning" into a rotary motion.
- ▶ To execute a profile, 50 actions of type "Positioning" are available for the sequence table.
- ▶ The profile data management also enables the "teaching" of speed, acceleration/ deceleration and S-ramp times. ▶ ["Teach" function](#) (p. 398)





### 13.2.5.1 Profile parameters

A profile is described by the following profile parameters:



[13-8] Profile parameters

Icon	Profile parameters
▲	<p><b>(Standard) profile</b> Profile data set (profile no. 1 ... 100) in which the profile data are stored.</p>
	<p><b>Mode</b> Selection of the positioning mode. ▶ <a href="#">Positioning modes (📖 395)</a></p>
Ⓐ	<p><b>Position</b> Target position or path distance to be traversed. The position is either indicated as absolute or relative position.</p> <ul style="list-style-type: none"> <li>An absolute position always specifies the distance to the zero position defined: absolute position = target position</li> </ul>  <ul style="list-style-type: none"> <li>A relative position indicates the distance to the starting position (current position): Relative position = target position - starting position</li> </ul> 
Ⓑ	<p><b>Speed</b> Maximum speed with which the target is to be approached.</p> <ul style="list-style-type: none"> <li>Depending on the profile parameter position, acceleration and deceleration, it is possible that the drive may not reach the maximum speed. In this case, the graph would display a triangle instead of a trapezium.</li> </ul>  <ul style="list-style-type: none"> <li>1 Acceleration</li> <li>2 Travelling speed (is not reached here)</li> <li>3 Deceleration</li> <li>4 Target position (or feed distance)</li> </ul>
Ⓒ	<p><b>Acceleration</b> Selection of the change in speed by which acceleration is to be carried out maximally.</p> <ul style="list-style-type: none"> <li>The following two acceleration types are distinguished: <ul style="list-style-type: none"> <li>– Constant acceleration: the speed increases linearly.</li> <li>– Linearly increasing acceleration: The speed increases in S-shapes.</li> </ul> </li> </ul>  <ul style="list-style-type: none"> <li>1 Constant acceleration</li> <li>2 Linearly increasing acceleration</li> </ul>
Ⓓ	<p><b>Deceleration</b> Selection of the change in speed by means of which deceleration to standstill is to be maximally effected again.</p>

Icon	Profile parameters
<p><b>E</b></p>	<p><b>S-ramp time</b></p> <p>When the S-ramp time is selected for a profile, it is executed with S-shaped ramps, e.g. acceleration and deceleration processes are started smoothly to reduce the jerk and thus prevent the drive components from damage.</p> <ul style="list-style-type: none"> <li>• The acceleration/deceleration specified in the profile are only reached after the defined S-ramp time has elapsed.</li> <li>• This type of acceleration/deceleration is required for e.g. sensitive machine parts with clearance.</li> <li>• The slower acceleration increase with the S profile prolongs the positioning time compared to the time optimal L profile.</li> </ul> <div style="display: flex; align-items: flex-start;">  <div style="margin-left: 20px;"> <p>1 without jerk limitation (L profile) 2 with jerk limitation (S profile)</p> </div> </div>
<p><b>F</b></p>	<p><b>Final speed</b></p> <p>Selection of the speed by which the drive is to start the next profile after reaching the target position. "Velocity changeover" or "Overchange" can be implemented with a final speed that is non-zero, i.e. when the target position is reached, a second positioning process is started immediately without the drive being decelerated to standstill at the first target position:</p> <div style="display: flex; align-items: flex-start;">  <div style="margin-left: 20px;"> <p>1 Target position 2 Final speed (here non zero)</p> </div> </div>
<p><b>G H</b></p>	<p><b>Start of TP window / End of TP window</b></p> <p>These profile parameters serve to restrict the range for a touch probe positioning (residual path positioning) in which touch probes are to be detected.</p>
	<p><b>Sequence profile with TP</b></p> <p>Profile data set (profile no. 1 ... 100) in which the profile data of the profile are stored which is to be executed after a touch probe has been detected.</p> <ul style="list-style-type: none"> <li>• For the setting "0" no further profile connection by touch probe is effected.</li> </ul>
	<p><b>Sequence profile without TP</b></p> <p>Profile data set (profile no. 1 ... 100) in which the profile data of the profile is stored which is to be executed after the standard profile has been executed (profile chaining).</p> <ul style="list-style-type: none"> <li>• With the setting "0" no profile chaining is carried out.</li> <li>• The sequence profile defined in this profile parameter is executed even if no touch probe has been detected within the defined TP window.</li> </ul>



## 13.2.5.2 Variable tables

To simplify parameter handling, the four most important physical sizes for profile parameters are stored in separate "variable tables".


	VTPos Positions	VTSpeed Speeds	VTAcc Acceleration/ deceleration	VTJerk S-ramp times
Unit	Unit	Unit/s	Unit/s <sup>2</sup>	s
Data format	DINT with four decimal positions			
Memory locations	100	50	50	50
Code	C04711/1...100	C04712/1...50	C04713/1...50	C04714/1...50
For profile parameters	Target position TP window starting position TP window end position	Speed Final speed	Acceleration Deceleration	S-ramp time



### Note!

A value is assigned to a profile parameter by referring to a table position of the assigned variable table.

- Hence, not the value itself is entered into the profile parameter but the index of the table position which contains the value to be used.
- See the example in the illustration [\[13-9\]](#). (📖 393)



[13-9] Principle: References to variable tables (here: References to VTSPEED)

- In case of several references to the same table position, a change of the value in this table position affects several profiles at the same time. Thus, recurring profile parameters only need to be changed on one position.

## 9400 HighLine | Parameter setting & configuration

TAs for positioning tasks

TA "Multi-purpose positioning" | Profile data management

- ▶ If e.g. in case of a profile chaining, several profiles are to be executed with the same speed, the corresponding profile parameters "speed" can all refer to the same table position.
- ▶ For an easier assignment and identification of the entered values, each table position can be optionally provided with a comment in the »Engineer«.

## 13.2.5.3 Positioning modes

According to the traversing range/application, different position modes are available for a positioning function which are described in the following table.



### Note!

For absolute positioning the home position must be known!

If an absolute positioning (positioning modes 1 ... 2 and 11 ... 16) is started although the home position is not known, an error message is output.

- In this case a programming error has occurred and the program flow must be reset.
- If the error only occurs in a sequence profile, the last valid deceleration is used to decelerate the drive to standstill.


### Positioning mode

1	<b>Absolute</b> The axis travels to an absolute position. <ul style="list-style-type: none"> <li>• Reference for the absolute position is zero position.</li> <li>• The home position must be known.</li> <li>• The traversing range is limited:                             <ul style="list-style-type: none"> <li>–to 214748.3647 [unit]</li> <li>–by the internal display area (<math>\pm 2^{31}</math> increments)</li> </ul> </li> <li>• Not possible with "modulo" traversing range.</li> </ul>
2	<b>Absolute TP</b> Like mode 1, but with profile change when a touch probe is detected. <a href="#">▶ Touch probe positioning. (📖 397)</a>
5	<b>Relative</b> The axis is traversed by a distance. <ul style="list-style-type: none"> <li>• Reference for the distance is the target position of the profile executed before.</li> <li>• The feed per positioning is limited:                             <ul style="list-style-type: none"> <li>–to 214748.3647 [unit]</li> <li>–by the internal display area (<math>\pm 2^{31}</math> increments)</li> </ul> </li> </ul>
6	<b>Relative TP</b> Like mode 5, but with profile change when a touch probe is detected. <a href="#">▶ Touch probe positioning. (📖 397)</a>
7	<b>Speed</b> Continuous constant travel. <ul style="list-style-type: none"> <li>• Only possible with "unlimited" and "limited" traversing range</li> <li>• This mode does not approach a defined position, but follows the profile.</li> <li>• Acceleration and deceleration are based on profile values.</li> <li>• The traversing direction is defined by the sign of the traversing speed.</li> <li>• Stopped through break signal.</li> </ul>
8	<b>Speed TP</b> Like mode 7, but with profile change when a touch probe is detected. <a href="#">▶ Touch probe positioning. (📖 397)</a>
11	<b>Absolute CW</b> The axis travels in CW direction to an absolute position. <ul style="list-style-type: none"> <li>• Only possible with "modulo" traversing range</li> <li>• Reference for the absolute position is zero position.</li> <li>• In this direction the zero position of the axis can be overtravelled.</li> </ul>
12	<b>Absolute CW TP</b> Like mode 11, but with profile change when a touch probe is detected. <a href="#">▶ Touch probe positioning. (📖 397)</a>

# 9400 HighLine | Parameter setting & configuration

TAs for positioning tasks


TA "Multi-purpose positioning" | Profile data management

Positioning mode	
13	<b>Absolute CCW</b> The axis travels in CCW direction to an absolute position. <ul style="list-style-type: none"><li>• Only possible with "modulo" traversing range</li><li>• Reference for the absolute position is zero position.</li><li>• In this direction the zero position of the axis can be overtravelled.</li></ul>
14	<b>Absolute CCW TP</b> Like mode 13, but with profile change when a touch probe is detected. ▶ <a href="#">Touch probe positioning.</a> (📖 397)
15	<b>Absolute ShortestWay</b> The axis travels in best time to an absolute position. <ul style="list-style-type: none"><li>• Only possible with "modulo" traversing range</li><li>• Reference for the absolute position is zero position.</li><li>• The rotary table positioning is basically an absolute positioning with target positions between 0 and 360 angular degree [°]. In this mode the zero point can also be overtravelled if this is the shortest way to the target position:</li></ul> 
16	<b>Absolute ShortestWay TP</b> Like mode 15, but with profile change when a touch probe is detected. ▶ <a href="#">Touch probe positioning.</a> (📖 397)

## 13.2.5.4 Touch probe positioning

In the touch probe positioning mode, the profile is first executed according to the [Profile parameters](#) set. If a touch probe is detected during the process, it is automatically changed to the profile specified in the profile parameter "Sequence profile with TP".

- ▶ Here the current actual position is stored at the time of the touch probe activation (by a touch probe sensor).
- ▶ In the following relative positioning process, the "residual path" to this stored position is travelled according to the increments.



[13-10] Examples for a "residual path positioning" after a touch probe is detected

- ▶ The profile parameters "TP window start" and "TP window end" the range in which touch probes are to be detected can be restricted.
  - If both profile parameters = "0", touch probe detection will be active for the whole profile/the whole traversing range.
- ▶ If no touch probe is detected and after the profile is executed, the positioning is continued with the profile defined in the profile parameter "Sequence profile without TP" (profile chaining).

### **i** Note!

If a profile is travelled with high speed and touch probe positioning is started, the residual path of which is smaller than the result from current speed and set deceleration ramp, the target position is "overtravelled".

- Normally a reversing movement occurs, i.e. the drive returns.
- If, for instance, a CCW rotation of the drive is forbidden by the safety module, the target cannot be approached since in this case the reversing movement is not permissible.

Further constellations are possible in connection with profile chaining in which an approach of the target position is impossible.

## 13.2.5.5 "Teach" function

The "Teach" function of the profile data management enables the teaching of positions, speeds, accelerations and S-ramp times.

The basic function "Manual jog" serves, for instance to approach the desired position manually and transmits it via "Teaching" to the variable table for positions.

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → L\_PositionerTable


Control/setpoint inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control/setpoint input	
FALSE	→ Teach position	C03020/1
C03016	→ Selection of table position for position	C03029/1
Zero position	→ Teach position	C03125
FALSE	→ Teach speed	C03020/2
C03017	→ Selection of table position for speed	C03029/2
Speed setpoint	→ Teach speed	C03024
FALSE	→ Teach acceleration	C03020/3
C03018	→ Selection of table position for acceleration	C03029/3
0	→ Teach acceleration	C03027
FALSE	→ Teach S-ramp time	C03020/4
C03019	→ Selection of table position for S-ramp time	C03029/4
0	→ Teach S-ramp time	C03028



### Note!

After the function block editor is enabled the "Teach" function must be configured directly in the FB interconnection instead of via the parameters mentioned before!


## 13.2.6 Speed/acceleration override



[13-11] Speed/acceleration override (schematic diagram)

"Override" is the change of profile parameters and their acceptance during the positioning process.

In this case the travel profile is adapted accordingly so that if the speed is changed during the positioning process ("speed override"), the specified target position is still positioned exactly.




- ❶ The speed is reduced during the positioning process.
- ❷ To reach the defined position, the missing surface must be "attached" to the profile.
- ❸ When the speed is reduced the positioning process takes a longer time ( $\Delta t$ ).

[13-12] Override (here: Speed override)

► Parameter setting: Tab **Application parameter** → Dialog level **Overview** → **LS\_Positioner**

Control/setpoint inputs of the function		Signal configuration
Lenze setting	Control/setpoint input	(Multiplexer parameters)
C03013	→ Activate override	C03185/5
AIn 1	→ Speed override	C03186/1
AIn 2	→ Acceleration override	C03186/2

## 13.2.7 Following error monitoring



In the Lenze setting a two-stage following error monitoring is active.

If the parameterisable switching threshold 1 is exceeded, a warning appears. If the higher-set switching threshold 2 is exceeded, a "warning locked" appears.

[13-13] Following error monitoring


► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Following error*

Parameters		Lenze setting	
		Value	Unit
C03911	Switching threshold 1	100.0000	Unit
C03914	Switching threshold 2	200.0000	Unit
C03917	Hysteresis 1	0.0000	Unit
C03920	Hysteresis 2	0.0000	Unit
C05902/1	Error response - following error 1	Warning	
C05902/2	Error response - following error 2	Warning locked	

Control inputs of the function		Signal configuration (Multiplexer parameters)
Lenze setting	Control input	
TRUE	→ Activate following error limit 1	C03058/1
TRUE	→ Activate following error limit 2	C03058/2



## 13.2.8 Manual jog



[13-14] Basic function "Manual jog" (schematic diagram)

For the setting-up operation and "Teaching" of positions the basic function "Manual jog" is available.

Manual jog is controlled via parameters (e. g. via HMI).

Manual jog can always be carried out if the sequence control is not active and no other basic function and no error status are active. The request of manual jog then is effected automatically with the travel commands.

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Manual jog*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02620</a>	Manual jog speed 1	360.0000	Unit/s
<a href="#">C02621</a>	Manual jog speed 2	720.0000	Unit/s
<a href="#">C02622</a>	Manual acceleration	360.0000	Unit/s <sup>2</sup>
<a href="#">C02623</a>	Manual deceleration	1440.0000	Unit/s <sup>2</sup>
<a href="#">C02624</a>	Inaccuracy time of manual traversing	0.100	s
C03007	Activate positive manual jog	FALSE	
C03008	Activate negative manual jog	FALSE	
C03009	Activate "Retract limit switch"	FALSE	


Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
Automatic activation	→ Request manual jog	C03155/1
C03007	→ Activate positive manual jog	C03155/2
C03008	→ Activate negative manual jog	C03155/3
FALSE	→ Activate 2. speed	C03155/4
C03009	→ Activate "Retract limit switch"	C03155/5



**Tip!**

Detailed information on the manual jog function can be found in chapter "Basic drive functions" → subchapter "[Manual jog](#)". (156)

## 13.2.9 Quick stop



[13-15] Basic function "Quick stop" (schematic diagram)

The basic function "Quick stop" brakes the drive to standstill within the deceleration time set for the quick stop function after a corresponding request independent of the setpoint selection. The sequence control is interrupted.

If the quick stop is deactivated, the drive remains in standstill until the sequence control is started again and takes over the drive control.

- ▶ The quick stop function can be activated as follows in the Lenze setting:
  - By setting the digital input DI1 to LOW level.
  - By a master control via the port *LPortControl*:  
By setting bit 2 of the bit-coded control word 1.
- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *All basic functions* → *Quick stop*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C00105</a>	Quick stop deceleration time	0.000	s
<a href="#">C00106</a>	Quick stop S-ramp time	0.00	%
<a href="#">C00107</a>	Reference for deceleration time "Quick stop"	Motor reference speed ( <a href="#">C00011</a> )	


Control inputs of the function		Signal configuration
Lenze setting	Control input	(Multiplexer parameters)
DigIn 1	→ Activate quick stop 1	C03135/1
Control word 1 bit 02	→ Activate quick stop 2	C03135/2
FALSE	→ Activate quick stop 3	C03135/3



### Tip!

Detailed information on quick stop can be found in chapter "Basic drive functions" → subchapter "[Quick stop](#)". (📖 152)

## 13.2.10 Limiter



[13-16] Basic function "Limiter" (schematic diagram)

The basic function "Limiter" monitors the travel range limits via limit switches and parameterisable software limit positions and after an according request from the safety module can lead the drive into defined limit ranges. Furthermore higher-level limit values for travel profiles can be entered and activated.

- ▶ The software limit positions which can be set via parameters serve to limit the travel range by means of software and prevent that travel commands are executed which would cause an exit of the permissible travel range.
- ▶ Moreover, the travel range limits are monitored via limit switches via the digital inputs **DI3** and **DI4**.



### Note!

The digital inputs **DI3** and **DI4** are configured fail-safe in [C00114/3](#) and [C00114/4](#), i.e. a HIGH level is expected at both inputs in idle state.

- If the travel range limits should not be monitored (e.g. in case of a rotary axis), set the limit switch inputs of the basic function "Limiter" permanently to FALSE.

The parameterised limit values for travel profiles are not effective for the basic functions "[Speed follower](#)", "[Torque follower](#)" and "[Position follower](#)"!

- For the exceeding of the limit values an error response can be set.

- ▶ Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Limiter*

Parameters	Lenze setting	
	Value	Unit
<b>Limit values</b>		
<a href="#">C02707</a>	Permissible direction of rotation	Positive and negative
<a href="#">C02700</a>	Software limit positions are active	Deactivated
<a href="#">C02701/1</a>	Positive software limit position	0.0000 Unit
<a href="#">C02701/2</a>	Negative software limit position	0.0000 Unit
<b>Only for homing, positioning and manual jog</b>		
<a href="#">C02702</a>	Limitations effective	Deactivated
<a href="#">C02703</a>	Max. speed	3600.0000 Unit/s
<a href="#">C02705</a>	Max. acceleration	3600.0000 Unit/s <sup>2</sup>
<a href="#">C02706</a>	Min. S-ramp time	100 ms

# 9400 HighLine | Parameter setting & configuration

TAs for positioning tasks

TA "Multi-purpose positioning" | Limiter


Parameters		Lenze setting	
		Value	Unit
<b>For manual jog only</b>			
<a href="#">C02713</a>	Max. path -manual jog	360.0000	Unit
<b>Limited speed 1 ... 4 (only for homing, positioning, and manual jog)</b>			
<a href="#">C02708/1</a>	Limited speed 1	3600.0000	Unit/s
<a href="#">C02710/1</a>	Delay lim. speed 1	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/1</a>	S-ramp time lim. speed 1	100	ms
<a href="#">C02708/2</a>	Limited speed 2	7200.0000	Unit/s
<a href="#">C02710/2</a>	Delay lim. speed 2	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/2</a>	S-ramp time lim. speed 2	100	ms
<a href="#">C02708/3</a>	Limited speed 3	14400.0000	Unit/s
<a href="#">C02710/3</a>	Delay lim. speed 3	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/3</a>	S-ramp time lim. speed 3	100	ms
<a href="#">C02708/4</a>	Limited speed 4	28800.0000	Unit/s
<a href="#">C02710/4</a>	Delay lim. speed 4	0.0100	Unit/s <sup>2</sup>
<a href="#">C02711/4</a>	S-ramp time lim. speed 4	100	ms
<b>Control inputs of the function</b>		<b>Signal configuration</b>	
<b>Lenze setting</b>	<b>Control input</b>	<b>(Multiplexer parameters)</b>	
DigIn 3	→ Positive limit switch	C03150/1	
DigIn 4	→ Negative limit switch	C03150/2	



## Tip!

Detailed information on the limiter function can be found in chapter "Basic drive functions" → subchapter "[Limiter](#)". (📖 200)

## 13.2.11 Brake control



[13-17] Basic function "Brake control" (schematic diagram)

The basic function "Brake control" serves to the wear free control and monitoring of a holding brake.

In the simplest case, an optionally available brake module is used.

Alternatively the holding brake can also be controlled and monitored via the digital inputs/outputs.

**Note!**

In the Lenze setting the brake control is switched off to reach a safe status after mains connection.

If the automatic operation (operating mode 2 or 12) is selected in [C02580](#), the brake is controlled automatically, i.e. if the multi-purpose positioning or another basic function is activated which causes the drive to traverse, the brake is opened automatically and the operation is enabled.

**Tip!**

Detailed information on brake control can be found in chapter "Basic drive functions" → subchapter "[Brake control](#)". (📖 211)

# 9400 HighLine | Parameter setting & configuration

TAs for positioning tasks

TA "Multi-purpose positioning" | Brake control

► Parameter setting: Tab **Application parameter** → Dialog level *Overview* → *Brake control*

Parameters		Lenze setting	
		Value	Unit
<a href="#">C02580</a>	Operating mode - brake	Brake control off	
<a href="#">C02581</a>	Brake activation threshold	50	rpm
<a href="#">C02582</a>	Brake resp. to pulse inhibit	Activate the brake immediately	
<a href="#">C02583</a>	Status input monitoring	Not active	
<a href="#">C02585</a>	Brake control polarity	Not inverted	
<a href="#">C02586</a>	Starting torque 1	0.00	Nm
<a href="#">C02587</a>	Starting torque 2	0.00	Nm
<a href="#">C02588</a>	Source of starting torque	Starting torque 1/2	
<a href="#">C02589</a>	Brake closing time	100	ms
<a href="#">C02590</a>	Brake opening time	100	ms
<a href="#">C02591</a>	Waiting time - status monit.	100	ms
<a href="#">C02593</a>	Waiting time - brake active.	0.000	s
<a href="#">C02594</a>	Test torque	0.00	Nm
<a href="#">C02595</a>	Permissible angle of rotation	5	°
<a href="#">C02596</a>	Grinding speed	100	rpm
<a href="#">C02597</a>	Accel./decel. time - grinding	1.000	s
<a href="#">C02598</a>	Grinding ON time	0.5	s
<a href="#">C02599</a>	Grinding OFF time	0.5	s

Control/setpoint inputs of the function		Signal configuration
Lenze setting	Control/setpoint input	(Multiplexer parameters)
FALSE	→ Open brake (release)	C03165/1
FALSE	→ Activate starting torque 2	C03165/2
FALSE	→ Brake status signal	C03165/3
FALSE	→ Activate brake test	C03165/4
FALSE	→ Grind brake	C03165/5
0 %	→ Additional torque	C03166

## 13.2.12 Signal configuration of drive and motor interface

If required, the preset signal configuration of the control and setpoint inputs of the drive and motor interface can be easily reconfigured per parameter setting of the assigned multiplexer parameters.

### Drive interface

Signal (Lenze setting)	Control input	Signal configuration
FALSE	→ Set controller inhibit	C03130/1
DigIn 5	→ Reset error 1	C03130/4
FALSE	→ Reset error 2	C03130/5
FALSE	→ Reset error 3	C03130/6
FALSE	→ Set error	C03130/2
FALSE	→ Switch on drive	C03130/3

### Motor interface

Signal (Lenze setting)	Setpoint input	Signal configuration
100 %	→ Position controller adaption	C03141/1
100 %	→ Phase controller adaption	C03141/2
100 %	→ Adaptation of speed controller	C03141/3
100 %	→ Upper torque limit value	C03141/4
-100 %	→ Lower torque limit value	C03141/5
100 %	→ Flux setpoint	C03141/6

## 13.2.13 Signal configuration of the output ports

If required, the preset signal configuration of the output ports can be easily reconfigured per parameter setting of the assigned multiplexer parameters.

### "LPortAxisOut1" output port

The output port **LPortAxisOut1** is intended for the connection with a following axis.

Signal (Lenze setting)	Output port	Signal configuration
<b>Axis status word</b>		
<ul style="list-style-type: none"> <li>The bits are assigned as in case of status word 1/2.</li> <li>Application-specific signals can be supplemented.</li> </ul>		
Drive ready	→ Axis status word bit 00	C03120/1
FALSE	→ Axis status word bit 01	C03120/2
Operation enabled	→ Axis status word bit 02	C03120/3
Error is active.	→ Axis status word bit 03	C03120/4
FALSE	→ Axis status word bit 04	C03120/5
Quick stop active	→ Axis status word bit 05	C03120/6
Drive is ready to start	→ Axis status word bit 06	C03120/7
Warning active	→ Axis status word bit 07	C03120/8
FALSE	→ Axis status word bit 08	C03120/9
FALSE	→ Axis status word bit 09	C03120/10
FALSE	→ Axis status word bit 10	C03120/11
Motor control limited	→ Axis status word bit 11	C03120/12
FALSE	→ Axis status word bit 12	C03120/13
FALSE	→ Axis status word bit 13	C03120/14
FALSE	→ Axis status word bit 14	C03120/15
FALSE	→ Axis status word bit 15	C03120/16
<b>Setpoints for horizontal communication</b>		
Motor torque	→ Axis-Port Out 1	C03124/1
Motor speed	→ Axis-Port Out 2	C03124/2



## Output port "LPortStatus1"

The output port **LPortStatus1** is intended for the connection with a higher-level control.

Signal (Lenze setting)	Output port	Signal configuration
<b>Status word 1</b>		
Drive ready	→ Status word 1 bit 00	C03121/1
FALSE	→ Status word 1 bit 01	C03121/2
Operation enabled	→ Status word 1 bit 02	C03121/3
Error is active.	→ Status word 1 bit 03	C03121/4
FALSE	→ Status word 1 bit 04	C03121/5
Quick stop active	→ Status word 1 bit 05	C03121/6
Drive is ready to start	→ Status word 1 bit 06	C03121/7
Warning active	→ Status word 1 bit 07	C03121/8
FALSE	→ Status word 1 bit 08	C03121/9
FALSE	→ Status word 1 bit 09	C03121/10
FALSE	→ Status word 1 bit 10	C03121/11
Motor control limited	→ Status word 1 bit 11	C03121/12
FALSE	→ Status word 1 bit 12	C03121/13
FALSE	→ Status word 1 bit 13	C03121/14
FALSE	→ Status word 1 bit 14	C03121/15
FALSE	→ Status word 1 bit 15	C03121/16

## Output port "LPortStatus2"

Signal (Lenze setting)	Output port	Signal configuration
<b>Status word 2</b>		
FALSE	→ Status word 2 bit 00	C03122/1
FALSE	→ Status word 2 bit 01	C03122/2
FALSE	→ Status word 2 bit 02	C03122/3
FALSE	→ Status word 2 bit 03	C03122/4
FALSE	→ Status word 2 bit 04	C03122/5
FALSE	→ Status word 2 bit 05	C03122/6
FALSE	→ Status word 2 bit 06	C03122/7
FALSE	→ Status word 2 bit 07	C03122/8
FALSE	→ Status word 2 bit 08	C03122/9
FALSE	→ Status word 2 bit 09	C03122/10
FALSE	→ Status word 2 bit 10	C03122/11
FALSE	→ Status word 2 bit 11	C03122/12
FALSE	→ Status word 2 bit 12	C03122/13
FALSE	→ Status word 2 bit 13	C03122/14
FALSE	→ Status word 2 bit 14	C03122/15
FALSE	→ Status word 2 bit 15	C03122/16

# 9400 HighLine | Parameter setting & configuration

TAs for positioning tasks

TA "Multi-purpose positioning" | Application error messages

## 13.2.14 Application error messages

For the output of application-specific error messages, the FB instances *ApplicationError1* and *ApplicationError2* of the function block **L\_DevApplErr** are available in the network.

- ▶ Via the boolean inputs up to 16 different application error messages with parameterisable module ID, error ID and error response can be released by the application.

Error message		Error-ID	Error response
<b>FB instance "ApplicationError1"</b>			
1	Following error limit 1	8001	Warning
2	Following error limit 2	8002	Warning locked
3	Positioner: Home position is not known	8003	Warning
4	Positioner: Cycle is not known	8004	Warning
5	Positioner: Wrong positioning mode	8005	Warning
6	Positioner: Invalid change of the positioning mode	8006	Warning
7	Positioner: Profile data is not plausible or faulty	8007	Warning
8	Positioner: Error in profile generation	8008	Warning
<b>FB instance "ApplicationError2"</b>			
1	Free fault message 1	8011	Information
2	Free fault message 2	8012	Information
3	PositionerTable: Invalid axis data structure	8013	Warning
4	PositionerTable: Invalid profile no.	8014	Information
5	PositionerTable: Invalid table no.	8015	Warning
6	Watch-Dog	8016	Quick stop by trouble
7	Sequencer: Error due to variable branch	8017	Warning
8	Sequencer: Pause	8018	Information

- ▶ Parameter setting: Tab **All parameters**

Parameters		Lenze setting
<b>FB instance "ApplicationError1"</b>		
C05900	Function block ID	999
C05901/1...8	Error ID 1 ... 8	See table above
C05902/1...8	Error response 1 ... 8	See table above
<b>FB instance "ApplicationError2"</b>		
C05903	Function block ID	998
C05904/1...8	Error ID 1 ... 8	See table above
C05905/1...8	Error response 1 ... 8	See table above

### Reset of error message

In the Lenze setting the digital input DI5 for resetting (acknowledging) an error message is connected to the input *DI\_bResetError1* of the drive interface.

### 13.3 TA "Table positioning"

The technology application "table positioning" enables the drive to execute parameterisable travel profiles. The sequence is controlled by a superimposed control (e.g. PLC).

#### Functions

- ▶ Control of the program flow via predefined ports
- ▶ Positioning in different positioning modes
  - Point-to-point positioning
  - Touch probe positioning (residual path positioning)
  - Profile chaining with velocity changeover (overchange)
- ▶ Homing in different homing modes
- ▶ Profile data management
  - Support of S profiles (jerk limitation)
  - Separate setting for acceleration and deceleration
  - "Teach" function
- ▶ Speed-/acceleration override
- ▶ Following error monitoring
- ▶ Support of absolute value encoders
- ▶ Support of the basic drive functions "Manual jog" and "Quick stop"
- ▶ Monitoring of travel range limits with the basic drive function "Limiter"
- ▶ Optional control of a holding brake with the basic drive function "Brake control"



#### Note!

With the exception of the sequence table, the functionality of the table positioning is identical to the multi-purpose positioning.

The different functions are described in the previous chapter on [TA "Multi-purpose positioning"](#). (□ 371)


# 9400 HighLine | Parameter setting & configuration

TAs for positioning tasks

TA "Table positioning" | Basic signal flow

## 13.3.1 Basic signal flow

The functional core of the table positioning is the profile data management which transmits the required profile data to the basic drive function "Positioning". The true sequence control is carried out by a master control (e.g. PLC) which communicates with the application via predefined ports.



[13-18] Signal flow of the TA "Table positioning" (schematic diagram)

### Table positioning

- A** Predefined ports for the communication with a master control
- B** Profile data management
- C** Speed/acceleration override

### Basic drive functions


- D** Homing
- E** Positioning
- F** Manual jog
- G** Stop
- H** Quick stop
- I** Brake control (optional)
- J** Limiter (optional)

## 13.3.2 Assignment of the I/O terminals


### 13.3.2.1 Setpoint and control signals

The following tables contain the Lenze assignment of the analog and digital inputs for the technology application "Table positioning".

#### Analog inputs

Terminal X3	Signal (Lenze setting)	
	<b>AI1-</b> <b>AI1+</b> Selection for speed override <a href="#">▶ Speed/acceleration override (📖 399)</a>	
	<b>AI2-</b> <b>AI2+</b> Selection for acceleration override <a href="#">▶ Speed/acceleration override (📖 399)</a>	
	<a href="#">▶ I/O terminals ▶ Analog inputs (📖 117)</a>	

#### Digital inputs


Terminal X5	Signal (Lenze setting)
	<b>DI1</b> Quick stop <ul style="list-style-type: none"> <li>If DI1 is set to LOW level, the drive is decelerated to standstill within the deceleration time set for the quick stop function independent of the setpoint selection.</li> <li>If the quick stop function is deactivated, the drive is led to the selected setpoint again via the set acceleration time.</li> </ul> <a href="#">▶ Quick stop (📖 402)</a>
	<b>DI2</b> Connection of reference switch/touch probe sensor <a href="#">▶ Action type "Homing" (📖 382)</a>
	<b>DI3</b> Connection of travel range limit switch positive/negative for basic function " <a href="#">Limiter</a> ". <a href="#">(📖 403)</a>
	<b>DI4</b> <ul style="list-style-type: none"> <li>The inputs respond to the FALSE state (fail-safe).</li> </ul>
	<b>DI5</b> Reset error <ul style="list-style-type: none"> <li>By means of a LOW-HIGH edge an existing error status can be reset if the cause of the fault is removed.</li> </ul>
	<b>DI6</b> -
	<b>DI7</b> -
	<b>DI8</b> -
<a href="#">▶ I/O terminals ▶ Digital inputs (📖 123)</a>	

## 13.3.2.2 Actual value and status signals

The following tables contain the Lenze assignment of the analog and digital outputs for the technology application "Table positioning".


- The default signal configuration if required can be easily changed by parameterising the multiplexer parameters assigned.

### Analog outputs

Terminal X3	Signal (Lenze setting)	Signal configuration
	AO1	Scaled following error
	AO2	Motor torque (setpoint) <ul style="list-style-type: none"> <li>• Scaling: <math>\pm 10 \text{ V} \equiv \text{Motor reference torque}</math> (<a href="#">C00057/2</a>)</li> </ul>


► [I/O terminals](#) ► [Analog outputs](#) ([120](#))

### Digital outputs

Terminal X4	Signal (Lenze setting)	Signal configuration
	DO1	Status "Drive ready" <ul style="list-style-type: none"> <li>• This operating state is active if the controller is enabled by setting the digital input RFR to HIGH level and no error has occurred.</li> </ul>
	DO2	-
	DO3	Status "Limitation active" <ul style="list-style-type: none"> <li>• At the moment a setpoint is limited or a software or hardware limit switch has been reached.</li> </ul>
	DO4	Status "Error active acknowledgement is required" <ul style="list-style-type: none"> <li>• Monitoring with the error response "Error" or "Quick stop by trouble" has been activated, and the controller is in the device state "Error active" or "Quick stop by trouble active".</li> </ul>


► [I/O terminals](#) ► [Digital outputs](#) ([125](#))

### State bus

Terminal X2	Signal (Lenze setting)	Signal configuration
	SB	Status "Error active acknowledgement is required" <ul style="list-style-type: none"> <li>• Monitoring with the error response "Error" or "Quick stop by trouble" has been activated, and the controller is in the device state "Error active" or "Quick stop by trouble active".</li> <li>• The state bus is put in the "error" status.</li> </ul>

► [I/O terminals](#) ► [Monitoring function "State bus"](#) ([127](#))

### Display elements

User LED	Signal (Lenze setting)	Signal configuration
	Status "Positioning enabled"	C03100/6

► [Drive interface](#) ► [LED status displays](#) ([34](#))

## 13.3.3 Control of the program flow via predefined ports

For a sequence control by a higher-level control (e.g. PLC) the application is provided with predefined ports the signals of which are linked with the setpoint and control inputs of the application via multiplexer parameters.

### Input port "LPortAxisIn1" for control and setpoint signals

Element variable/data type	Information/possible settings
nIn1 INT	Profile number (1 .... 100) of the profile of the profile data management to be executed

### Input port "LPortControl1" for control signals

The input port **LPortControl1** is intended for the connection with a master control.

Element variable/data type	Information/possible settings												
LPortControl1 WORD	Control word (bit coded) • Bits which are not listed are not assigned with a function.												
	<table border="1"> <tr> <td>Bit 3</td> <td>                     Activate quick stop                     <ul style="list-style-type: none"> <li>The is decelerated to standstill within the deceleration time set for the quick stop function independent of the setpoint selection.</li> <li>If the quick stop function is deactivated, the drive is led to the selected setpoint again via the set acceleration time.</li> </ul> </td> </tr> <tr> <td>Bit 7</td> <td>                     Reset error                     <ul style="list-style-type: none"> <li>An existing error status is reset if the cause of the fault is removed.</li> </ul> </td> </tr> <tr> <td>Bit 11</td> <td>                     Requesting control via the basic function "Positioning"                     <ul style="list-style-type: none"> <li>If no other basic function is active, it is changed to the "Positioning" function state and positioning can be executed via the control inputs.</li> <li>If bit 11 is reset, an active positioning is stopped, i.e. it is changed from the active function state "Positioning" to the basic function "Standstill" via the function state "Stopping".</li> </ul> </td> </tr> <tr> <td>Bit 12</td> <td>                     Start positioning/restart                     <ul style="list-style-type: none"> <li>The profile with the profile number defined via <i>nIn2</i> is executed.</li> <li>During an active positioning process, another profile can be defined via <i>nIn2</i> which is executed after restart (renewed state change of bit 12 from "0" to "1").</li> </ul> </td> </tr> <tr> <td>Bit 14</td> <td>                     Continuing an interrupted positioning process                     <ul style="list-style-type: none"> <li>The positioning process interrupted before is completed.</li> <li>Distance already covered in a relative positioning process will be considered.</li> </ul> </td> </tr> <tr> <td>Bit 15</td> <td>                     Request control via the basic function "Homing" and start reference search in the selected homing mode (<a href="#">C02640</a>).                 </td> </tr> </table>	Bit 3	Activate quick stop <ul style="list-style-type: none"> <li>The is decelerated to standstill within the deceleration time set for the quick stop function independent of the setpoint selection.</li> <li>If the quick stop function is deactivated, the drive is led to the selected setpoint again via the set acceleration time.</li> </ul>	Bit 7	Reset error <ul style="list-style-type: none"> <li>An existing error status is reset if the cause of the fault is removed.</li> </ul>	Bit 11	Requesting control via the basic function "Positioning" <ul style="list-style-type: none"> <li>If no other basic function is active, it is changed to the "Positioning" function state and positioning can be executed via the control inputs.</li> <li>If bit 11 is reset, an active positioning is stopped, i.e. it is changed from the active function state "Positioning" to the basic function "Standstill" via the function state "Stopping".</li> </ul>	Bit 12	Start positioning/restart <ul style="list-style-type: none"> <li>The profile with the profile number defined via <i>nIn2</i> is executed.</li> <li>During an active positioning process, another profile can be defined via <i>nIn2</i> which is executed after restart (renewed state change of bit 12 from "0" to "1").</li> </ul>	Bit 14	Continuing an interrupted positioning process <ul style="list-style-type: none"> <li>The positioning process interrupted before is completed.</li> <li>Distance already covered in a relative positioning process will be considered.</li> </ul>	Bit 15	Request control via the basic function "Homing" and start reference search in the selected homing mode ( <a href="#">C02640</a> ).
Bit 3	Activate quick stop <ul style="list-style-type: none"> <li>The is decelerated to standstill within the deceleration time set for the quick stop function independent of the setpoint selection.</li> <li>If the quick stop function is deactivated, the drive is led to the selected setpoint again via the set acceleration time.</li> </ul>												
Bit 7	Reset error <ul style="list-style-type: none"> <li>An existing error status is reset if the cause of the fault is removed.</li> </ul>												
Bit 11	Requesting control via the basic function "Positioning" <ul style="list-style-type: none"> <li>If no other basic function is active, it is changed to the "Positioning" function state and positioning can be executed via the control inputs.</li> <li>If bit 11 is reset, an active positioning is stopped, i.e. it is changed from the active function state "Positioning" to the basic function "Standstill" via the function state "Stopping".</li> </ul>												
Bit 12	Start positioning/restart <ul style="list-style-type: none"> <li>The profile with the profile number defined via <i>nIn2</i> is executed.</li> <li>During an active positioning process, another profile can be defined via <i>nIn2</i> which is executed after restart (renewed state change of bit 12 from "0" to "1").</li> </ul>												
Bit 14	Continuing an interrupted positioning process <ul style="list-style-type: none"> <li>The positioning process interrupted before is completed.</li> <li>Distance already covered in a relative positioning process will be considered.</li> </ul>												
Bit 15	Request control via the basic function "Homing" and start reference search in the selected homing mode ( <a href="#">C02640</a> ).												

See also: [▶ Signal configuration of the output ports \(408\)](#)

## 14 Oscilloscope

The integrated oscilloscope function of the 9400 High Line controller can be used as support for commissioning, maintenance and troubleshooting.

### Typical applications

- ▶ Graphical representation of any measured values (e.g. speed setpoint, actual speed and torque)
- ▶ Detection of process values without additional measuring instruments (e.g. oscilloscope, voltmeter and ammeter)
- ▶ Convenient documentation for fine tuning of control circuits or parameter changes of the controller
- ▶ Documentation of production quality in the context of product liability and quality assurance

### Special features

- ▶ Recording and saving measured values in the controller
- ▶ Measuring on eight independent channels at the same time
- ▶ Measuring fast and slow signals by adjustable sample rate
- ▶ Triggering on channel, variable or error message
- ▶ Detecting measured values before and after a trigger event (pre-/post-trigger)
- ▶ Graphical representation and evaluation of measured values on a PC
- ▶ Cursor and zoom function for the measurement analysis
- ▶ Saving & loading of oscilloscope configurations
- ▶ Exporting measured values via the clipboard for further processing

### 14.1 Technical data

9400 HighLine	
Memory depth	Max. 16384 measured values, depending on the number of channels and the size of the variables to be recorded.
Memory capacity	32768 bytes
Data width of a channel	1 ... 4 bytes, corresponding to the size of the variables to be recorded
Number of channels	1 ... 8
Trigger level	Corresponding to the value range of the variable to be triggered
Trigger selection	Immediate triggering, rising/falling edge, signal change
Trigger delay	-100 % ... +400 %
Trigger source	Channels 1 ... 8, any variable or error message
Max. time base	8 channels 32 bits each $\equiv$ 26 hours
Max. recording time	8 channels 32 bits each $\equiv$ 10 days



## 14.2 Function description

With an online connection to the controller, use the oscilloscope user interface of the »Engineer« to set the trigger condition and the sample rate and select the variables to be recorded.

When the measurement is started, the set parameters are transferred to the controller and checked. If invalid settings are found, the oscilloscope sends an error. Otherwise, the measurement is started.

With an online connection, the measured controller data are transferred to the »Engineer« and graphically represented on the oscilloscope user interface as soon as the measurement has been completed.

### Recording variable values

The operating system scans the oscilloscope in fixed 1 ms-cycles, i.e. the oscilloscope can record variable values with a sample rate of max. 1 kHz.

### Recording system variable values of the internal motor control

Unlike the variables declared in the application, the system variables of the internal motor control (MCTRL) can also be recorded with a sample rate higher than 1 kHz.



#### Note!

In the servo operating modes, recordings with a time-based resolution of 31.25  $\mu$ s and 125  $\mu$ s are not possible!

### Recording I/O variable values referring to a task

When selecting the variables to be measured, it is possible to indicate a task reference for the variables. If the behaviour of a certain task is to be examined, you can indicate the task reference to exactly record the values valid for the task run-time.

- The variable values are recorded during the process output image generation of the task.


## 14.3 User interface



**How to go to the oscilloscope user interface:**

1. Go to *Project view* and select the 9400 HighLine controller.
2. Select the **Oscilloscope** tab from the *Workspace*.

The oscilloscope user interface contains the following control and function elements:






- [A Oscilloscope toolbar](#)
- [B Oscilloscope function bar](#)
- [C Oscillograph](#)
- [D Vertical settings](#)
- [E Status bar](#)
- [F Trigger/cursor settings](#)
- [G Horizontal settings](#)
- [H Recording settings](#)

### 14.3.1 Oscilloscope toolbar

Icon	Function
	<a href="#">Loading/importing a data record (428)</a>
	<a href="#">Saving/exporting a data record (427)</a>
	<a href="#">Copying data record to clipboard (430)</a>
	Print oscillogram

### 14.3.2 Oscilloscope function bar

Icon	Function
	Activate zoom function ▶ <a href="#">Adjusting the representation</a> (424)
	Activate automatic scaling function ▶ <a href="#">Adjusting the representation</a> (424)
	Delete offline data record

### 14.3.3 Oscillograph

The oscillograph is used to visualise data records.

- ▶ Use the zoom and the automatic scaling function to adjust the representation.
- ▶ The measured data represented in the form of interpolated curves can be optionally shown and hidden, represented in any colour or overlaid with the signal characteristics of other variables recorded.

### 14.3.4 Vertical settings

Use the **Vertical** list field to configure the variables to be recorded.

- ▶ Simply click into a field to change the corresponding setting.

Column	Designation	Meaning
1	-	Curve colour for representation in the oscillograph
2	Ch	Channel number
3	On	On/off
4	Inv	Inversion on/off
5	Variable	Selection of variable to be recorded
6	Unit	Scaling
7	1/div	Vertical scale factor
8	Offset	Offset value <ul style="list-style-type: none"> <li>• The offset value depends on the scale factor and is designated by a dotted line in curve colour at the left edge of the oscillograph.</li> </ul>
9	Position	Position value <ul style="list-style-type: none"> <li>• The position value is independent of the scale factor and designated by a line at the left edge of the oscillograph.</li> </ul>

### 14.3.5 Status bar

The status messages are displayed in the status bar.

## 14.3.6 Trigger/cursor settings

### Trigger

Use the **Trigger** tab to configure the trigger condition.

▶ [Selecting the trigger condition](#) (📖 422)

### Cursor

If the **Cursor** tab is on top, you can use a vertical measuring line to read individual measured values of a selectable channel in the oscilloscope. Using a second vertical measuring line, it is possible to indicate the difference between two measured values.

▶ [Reading individual measured values](#) (📖 426)

Group box	Meaning
Channel	Channel selection
Value	Display of the value measured at the position of the active measuring line
Difference	Display of the difference between the values measured at the two measuring lines

## 14.3.7 Horizontal settings

Use the **Horizontal** group box to select the time base and the horizontal position.

▶ [Selecting the recording time/sample rate](#) (📖 422)

Input field	Meaning
Time base [1/Div]	Selection of time base <ul style="list-style-type: none"><li>• The current time base setting multiplied by ten results in the recording time.</li><li>• Change the time base to stretch or compress measurements that have already been completed.</li></ul>
Position	Selection of the horizontal display position <ul style="list-style-type: none"><li>• The position value can be directly entered into the input field or selected by using the arrow buttons.</li><li>• When the arrow buttons are used and the &lt;Ctrl&gt; key is pressed, you can increase the step width to accelerate the shift.</li></ul>

## 14.3.8 Recording settings

Use the **Recording** group box to select the sample rate and start recording.

▶ Since the measured data memory has a limited capacity, a compromise must be found between the sample rate and the recording time that results from the time base setting. ▶ [Selecting the recording time/sample rate](#) (📖 422)

## 14.4 Operation

This chapter describes step-by-step how to record the signal characteristics of controller variables and represent, analyse, document and process them in the oscilloscope.



### Note!

In the oscilloscope, settings can only be selected and recording can only be started, when the controller is connected online.

### 14.4.1 Selecting the variables to be recorded

The oscilloscope supports up to eight channels, i.e. max. eight variables can be recorded in a data record. Use the **Vertical** group box to select the variables.



#### How to select a variable for recording:

1. Go to the **Variable** column in the **Vertical** group box and double-click in the yellow field to open the *Select variable* dialog box.
  - The dialog box lists all variables declared in the PLC program of the controller and the system variables of the internal motor (MCTRL).
2. Select the variable to be recorded from the list field.
3. Click **OK**.
  - The dialog box is closed and the selection is accepted.
4. Repeat steps 1 ... 3 to select up to seven more variables to be recorded.

Of course, it is any time possible to change or delete a selection later.



#### How to change a selection:

1. Go to the **Vertical** group box and double-click the variable to be changed in the **Variable** column.
2. Select a new variable in the *Select variable* dialog box.
3. Click **OK**.
  - The dialog box is closed and the selection is accepted.



## How to delete a selection:

1. Go to the **Vertical** group box and double-click the variable to be removed in the **Variable** column.
2. Click **Delete channel** in the *Select variable* dialog box.
  - The dialog box is closed and the selection is deleted.

### 14.4.2 Selecting the recording time/sample rate



## How to select the recording time and the sample rate:

1. Go to the **Horizontal** group box and select the desired time base from the **Time base** list field.
  - The current time base setting multiplied by ten results in the recording time.
  - Since the measured data memory of the controller has a limited capacity, usually a compromise is made between sample rate and recording time.
2. Enter the desired sample rate [ms] in the **Record** group box in the **Device sample rate** input field.

### 14.4.3 Selecting the trigger condition

With the trigger condition, you can select when recording is to be started in the controller.

- ▶ The oscilloscope provides different trigger conditions that can be used to control measured value recording.




Select the corresponding settings in the **Trigger** tab to define the trigger condition.

Setting	Function
<b>Source</b>	Selection of trigger source:
Variable	The oscilloscope triggers on any variable of the PLC program. <ul style="list-style-type: none"> <li>• Unlike triggering on a channel, triggering on a variable requires no recording channel.</li> </ul>
Channel	The oscilloscope triggers on a channel configured in the <b>Vertical</b> table.
System event	Triggering is started on occurrence of a selectable controller event (e.g. TRIP, message or warning). <ul style="list-style-type: none"> <li>• Select a negative trigger delay to record signals prior to occurrence of the event.</li> </ul>
Force trigger	No trigger condition, recording starts immediately after the start.
<b>Trigger value</b>	Value from which on triggering is activated. <ul style="list-style-type: none"> <li>• The trigger level is not effective for triggering on Boolean variables.</li> </ul>

Setting	Function
<b>Delay</b>	Delay between recording and trigger event.
Pre-trigger	Select a negative delay time to detect signals <b>prior</b> to the trigger event. <div style="text-align: center;"> </div> <ul style="list-style-type: none"> <li>• In the oscillograph, the trigger time is designated by a dotted line.</li> <li>• With triggering on occurrence of an event, it is thus possible to detect the values that have caused the event.</li> </ul>
Post-trigger	Select a positive delay time to detect signals occurring a certain time <b>after</b> the trigger event. <div style="text-align: center;"> </div>
<b>Edge</b>	If the trigger source is a channel or a variable, you can choose between the following trigger modes:
Positive edge	For triggering on a BOOL variable: <ul style="list-style-type: none"> <li>• Trigger activation requires a FALSE-TRUE transition.</li> </ul> For triggering on a different variable: <ul style="list-style-type: none"> <li>• For trigger activation, the selected trigger value must be exceeded.</li> </ul>
Negative edge	For triggering on a BOOL variable: <ul style="list-style-type: none"> <li>• Trigger activation requires a TRUE-FALSE transition.</li> </ul> For triggering on a different variable: <ul style="list-style-type: none"> <li>• For trigger activation, the selected trigger value must be fallen below.</li> </ul>
Change	For triggering on a BOOL variable: <ul style="list-style-type: none"> <li>• Trigger activation requires a status change.</li> </ul> For triggering on a different variable: <ul style="list-style-type: none"> <li>• For trigger activation, the current value must be different than the last value.</li> </ul>

## 14.4.4 Starting recording

 Click **Start** to start recording.



For obtaining a maximum sample rate when recording the variable values, the data is first stored in the measured data memory of the controller and then transferred as a data record to the PC.






- The current recording status is displayed in the status bar.

## 14.4.5 Adjusting the representation




After the variable values have been recorded and the online data record has been transferred to the PC, the data record is visualised in the oscillograph. If required, the representation can now be adjusted by using the zoom or the automatic scaling function.

### Zoom function

 Go to the *oscilloscope function bar* and click the  icon to activate the zoom function.

Zoom function	Procedure	
Zoom selection		<p>Hold down the left mouse button and draw the oscilloscope section to be zoomed:</p>  <ul style="list-style-type: none"> <li>• The selection is shown with a frame.</li> <li>• When the left mouse button is released, the selection is zoomed in the oscilloscope.</li> </ul>
Horizontal/vertical shift of selection		<p>Hold down the left and right mouse button and move the mouse pointer on the horizontal scale to the left or right or on the vertical scale to the top or bottom to shift the selection accordingly.</p> <ul style="list-style-type: none"> <li>• With a three-button mouse, you can use the mouse button in the middle.</li> </ul>
Horizontal stretching		<p>Hold down the left mouse button and move the mouse pointer on the horizontal scale to the left to stretch the shown selection from the right edge.</p> <ul style="list-style-type: none"> <li>• Moving the mouse pointer in opposite direction continuously reduces the stretching.</li> </ul>
		<p>Hold down the right mouse button and move the mouse pointer on the horizontal scale to the right to stretch the shown selection from the left edge.</p> <ul style="list-style-type: none"> <li>• Moving the mouse pointer in opposite direction continuously reduces the stretching.</li> </ul>




Zoom function	Procedure	
Vertical stretching		Hold down the left mouse button and move the mouse pointer on the vertical scale to the bottom to stretch the shown selection from the top. <ul style="list-style-type: none"> <li>• Moving the mouse pointer in opposite direction continuously reduces the stretching.</li> </ul>
		Hold down the right mouse button and move the mouse pointer on the vertical scale to the top to stretch the shown selection from the bottom. <ul style="list-style-type: none"> <li>• Moving the mouse pointer in opposite direction continuously reduces the stretching.</li> </ul>
Return to original representation		Click the right mouse button in the oscillograph to return step-by-step to the original representation.

### Automatic scaling function

Use the automatic scaling function to automatically scale and reposition the representation of selectable signal characteristics in the oscillograph and reset the offset to "0".



#### How to carry out automatic scaling:

1. Go to the *oscilloscope function bar* and click the  icon to activate the automatic scaling function.
2. Select the channels/variables for automatic scaling in the *Select variable* dialog box.
3. Click **OK**.
  - The dialog box is closed and the selected channels/variables are scaled automatically.

## 14.4.6 Reading individual measured values

In addition to the zoom and the scaling function, the oscilloscope offers a "cursor function" that can be used to display individual measured values of a selectable channel or the difference between two measured values.

- ▶ If the **Cursor** tab is on top, the cursor function is active and two movable vertical measuring lines are shown in the oscillograph.



### How to use the cursor function:

1. Select the **Cursor** tab.
2. Select the channel for which individual measured values are to be indicated from the **Channel** list field.
3. Hold down the left mouse button and drag the red vertical measuring line to the desired position.
  - The active measuring line is represented by a continuous line, the inactive measuring line is indicated by a dotted line.
  - If you position the mouse pointer over the inactive measuring line, the measuring line automatically becomes active.
  - The value measured at the position of the active measuring line is indicated in the **Value** group box.
  - The difference between the values measured at the two measuring lines is indicated in the **Difference** group box.

## 14.5 Data records

If several data records are loaded in the oscilloscope at the same time, the data record to be displayed is selected via the list field **Data record**. There are three types of data records:

### Online data record

The online data record is the only data record serving to establish a connection to the target system. When the online data record has established the connection completely, it can communicate with the target system.

- ▶ In the list field **Data record** the online data record is marked with a prefixed asterisk (\*).

### Offline data record

The offline data record is already stored in the project and loaded in the oscilloscope again, or imported from a file.

### Merge data record

The merge data record is automatically available in the list field **Data record** if two or more data records are loaded in the oscilloscope at the same time.


- ▶ In the merge data record, several characteristics from the currently loaded data records can be laid on top of each other, e.g. to compare signal characteristics from different recordings. ▶ [Overlay function](#) (429)

### 14.5.1 Saving/exporting a data record

After the variables to be recorded have been selected and the required settings have been entered, you can save the configuration and recording, if already executed, for future use in the project or export them to a file.



#### How to save the data record in the project:

1. Go to *Oscilloscope toolbar* and click .
  - The *Save data record* dialog box appears.
2. Enter a name in the **Name of the data record to be stored** input field.
3. Click **Filing in the project**.
  - The dialog box is closed and the current data record is filed in the project.




#### Note!

The data record is only saved if the entire project is saved!



## How to export the data record to a file:


1. Go to *Oscilloscope toolbar* and click .
  - The *Save data record* dialog box appears.
2. Enter a name in the **Name of the data record to be stored** input field.
3. Click the **Export to file** button.
4. Specify the data record to be stored and the filing folder in the *Save as* dialog box.
5. Click **Save**.
  - The dialog box is closed and the current data record is saved.

## 14.5.2 Loading/importing a data record

Configurations/data records already stored can be loaded in the oscilloscope any time again, e.g. for the superposition function.




## How to load a data record from the project:

1. Go to *Oscilloscope toolbar* and click .
  - The *Load data record* dialog box appears.
2. Select the data record to be loaded from the **Data record** list field.
3. Click **Open**.
  - The dialog box is closed and the selected data record is saved.
  - If the configuration to be loaded contains variables that are no longer available in the controller, these variables are automatically removed from the configuration.




## How to import a data record from a file:

1. Go to *Oscilloscope toolbar* and click .
  - The *Load data record* dialog box appears.
2. Click the **Import** button.
3. Select the file to be imported within the desktop environment from the *Open* dialog box.
4. Click **Open**.
  - The dialog box is closed and the selected data record is imported.
  - If the configuration to be loaded contains variables that are no longer available in the controller, these variables are automatically removed from the configuration.

### 14.5.3 Deleting data record in the project



**How to delete a data record to be saved in the project:**

1. Go to *Oscilloscope toolbar* and click .
  - The *Load data record* dialog box appears.
2. Click the data record to be deleted with the right mouse key in the **Data record list** field to open the *Context menu* for the data record.
3. Select the **Delete data record** in the *Context menu*.
4. Click **Abort** to close the dialog box again.

### 14.5.4 Overlay function

The overlay function serves to lay several characteristics from the currently loaded data records on top of each other, e.g. to compare signal characteristics from different recordings.


- ▶ If two or several data records are loaded in the oscilloscope, e.g. an online data record and a data record saved before in the project, a "merge" data record is available in the **Data record list** field.
- ▶ When the merge data record is selected, the desired characteristics can be selected from the loaded data records in the **Vertical channel settings** group field which are to be overlaid or compared.
- ▶ If an online data record is used in the merge data record, an update is carried out in the merge data record in case of a renewed recording.
- ▶ Removing variables from an offline or online data record causes the characteristics in the merge data record to be deleted.

## 14.5.5 Copying data record to clipboard

For documentation purposes, it is possible to copy the measured data of a data record as a table or, alternatively, the oscilloscope user interface as a picture, to the clipboard for use in other programs.



### How to copy measured data or a picture of the user interface to the clipboard:

1. Go to *Oscilloscope toolbar* and click .
  - The *Clipboard* dialog box appears.
2. Select **Curve points** if the measured data is to be copied to the clipboard as a table, or select **Screen shot** if the oscilloscope user interface is to be copied as a picture.
3. Click **OK**.
  - The dialog box is closed and the selected option is copied to the clipboard.

## 14.6 Variables of the motor control (oscilloscope signals)

The internal variables of the motor control listed in the following table can be recorded with the oscilloscope for diagnostic and documentation purposes.



### Tip!

The exact position of a variable in the motor control can be obtained from the corresponding signal flow.

No.	Variable or the motor control	Meaning
<a href="#">▶ Signal flow - motor interface</a>		
	Common.dnActualFlux	Actual flux value
	Common.dnFluxSet	Flux setpoint
	Current.dnActualCurrentPhaseU	Actual motor current (phase U)
	Current.dnActualCurrentPhaseV	Actual motor current (phase V)
	Current.dnActualCurrentPhaseW	Actual motor current (phase W)
	Current.dnActualDirectCurrent	Actual D current
	Current.dnActualQuadratureCurrent	Actual Q-current
	Current.dnDirectCurrentSet	D current setpoint
	Current.dnQuadratureCurrentSet	Q current setpoint
	Torque.dnActualMotorTorque	Actual torque
	Torque.dnFilteredTorqueSetpoint	Filtered torque setpoint
	Torque.dnInputNotchFilter1	Torque setpoint at the band-stop filter input 1
	Torque.dnInputNotchFilter2	Torque setpoint at the band-stop filter input 2
	Voltage.dnActualDCBusVoltage	Actual DC-bus voltage
	Voltage.dnActualMotorVoltage	Current motor voltage
	Voltage.dnDirectVoltage	D voltage
	Voltage.dnQuadratureVoltage	Q voltage
<a href="#">▶ Signal flow - encoder evaluation</a>		
	Position.dnActualLoadPos	Actual position
	Position.dnActualMotorPos	Current motor position
	Speed.dnActualMotorSpeed	Current motor speed
<a href="#">▶ Signal flow - position follower</a>		
	Position.dnActualLoadPos	Actual position
	Position.dnActualMotorPos	Current motor position
	Position.dnContouringError	Following error
	Position.dnPositionSetpoint	Position setpoint
	Speed.dnActualMotorSpeed	Current motor speed
	Speed.dnOutputPosCtrl	Output signal - phase controller
	Speed.dnSpeedSetpoint	Speed setpoint
	Torque.dnTorqueSetpoint	Torque setpoint
	Torque.dnTotalTorqueAdd	Additive torque precontrol value

# 9400 HighLine | Parameter setting & configuration

Oscilloscope

Variables of the motor control (oscilloscope signals)


No.	Variable or the motor control	Meaning
<a href="#">▶ Signal flow - speed follower</a>		
	Speed.dnActualMotorSpeed	Current motor speed
	Speed.dnSpeedSetpoint	Speed setpoint
	Speed.dnTotalSpeedAdd	Additive speed setpoint
	Torque.dnTorqueSetpoint	Torque setpoint
	Torque.dnTotalTorqueAdd	Additive torque precontrol value
<a href="#">▶ Signal flow - torque follower</a>		
	Speed.dnActualMotorSpeed	Current motor speed
	Speed.dnSpeedSetpoint	Speed setpoint



## 15 Diagnostics & error analysis

### 15.1 Drive diagnostics with the »Engineer«


With an online connection to the controller, you can use the »Engineer« to carry out a diagnostics for the connected controller and get a clear visualisation of important controller states:



- ▶ Use the **Reset error** button to acknowledge an existing error message if the cause of the error has been eliminated.
- ▶ Use the **Logbook** button to display the logbook of the controller. For detailed information about the logbook, please see the chapter "[Logbook](#)". (436)




#### How to carry out a drive diagnostics with the »Engineer«:

1. Select the 9400 HighLine controller to be diagnosed in the *Project view*.
2. Click the  icon or select the command **Online→Go online** to build up an online connection with the controller.
3. Select the **Diagnostics** tab.
  - With an online connection, the **Diagnostics** tab displays current status information about the controller.

## 15.2 Drive diagnostics via keypad/bus system

### Keypad display of the controller state



- ▶ When the keypad at the front of the controller is connected to the diagnostic interface X6, the status of the controller is displayed via different symbols on the LDC display in the area ❶.

Icon	Meaning	Note
<b>RDY</b>	Controller is ready for operation.	
<b>RUN</b>	Controller is enabled.	
<b>STP</b>	Application in the controller is stopped.	
<b>QSP</b>	Quick stop is active	
<b>CINH</b>	Controller is inhibited.	The power outputs are inhibited.
<b>OFF</b>	Controller is ready to start.	
<b>Mmax</b>	Speed controller 1 in the limitation.	The drive is torque-controlled.
<b>I<sub>max</sub></b>	Set current limit has been exceeded in motor or generator mode.	
<b>IMP</b>	Pulse inhibit is active	The power outputs are inhibited.
<b>ISFLT</b>	System fault is active	
<b>IFLT</b>	Fault is active	
<b>ITRB</b>	Trouble is active	
<b>ITosp</b>	Quick stop by trouble is active	
<b>WRN</b>	Warning is active	

### Display parameters

Via the parameters listed in the following tables current states and actual values of the controller can be queried for diagnostic purposes, e.g. by using the keypad, a bus system or the »Engineer« (with an online connection to the controller).

- ▶ These parameters are listed in the »Engineer« parameter list and the keypad in the **Diagnostics** category.
- ▶ For a detailed parameter description, please see the chapter "[Parameter reference](#)".  
([□](#) 537)

Parameters	Display
<a href="#">C00183</a>	Device state
<a href="#">C00168</a>	Error number
<a href="#">C00051</a>	Actual speed
<a href="#">C00052</a>	Motor voltage

Parameters	Display
<a href="#">C00054</a>	Motor current
<a href="#">C00057/1</a>	Maximum torque
<a href="#">C00057/2</a>	Torque at maximum current
<a href="#">C00059</a>	Motor - number of pole pairs
<a href="#">C00060</a>	Rotor position
<a href="#">C00061</a>	Heatsink temperature
<a href="#">C00062</a>	Temperature inside the controller
<a href="#">C00063</a>	Motor temperature
<a href="#">C00064</a>	Controller load (I x t) during the last 180 seconds
<a href="#">C00065</a>	External. 24-V voltage
<a href="#">C00066</a>	Thermal motor load (I <sup>2</sup> x t)
<a href="#">C00068</a>	Electrolytic capacitor temperature
<a href="#">C00069</a>	CPU temperature
<a href="#">C00178</a>	Time the controller was enabled (elapsed-hour meter)
<a href="#">C00179</a>	Power-up time (power-on time meter)
<a href="#">C00186</a>	ENP: detected motor type

## Identification data

The parameters listed in the following table which are entered in the »Engineer« parameter list and in the keypad in the **Identification** → **Controller** category, serve to display the identification data of the controller:

Parameters	Display
<a href="#">C00099</a>	Firmware version
<a href="#">C00200</a>	Firmware product type
<a href="#">C00201</a>	Firmware - compile date
<a href="#">C00203/1...9</a>	HW product types
<a href="#">C00204/1...9</a>	HW serial numbers
<a href="#">C00205/1...6</a>	HW descriptions
<a href="#">C00206/1...6</a>	HW manufacturing data
<a href="#">C00208/1...6</a>	HW manufacturer
<a href="#">C00209/1...6</a>	HW countries of origin
<a href="#">C00210/1...6</a>	HW versions
<a href="#">C02113</a>	Program name

#### 15.3 Logbook

The integrated logbook function of the controller chronologically logs important events within the system and plays an important role for troubleshooting and controller diagnostics.

##### Events that can be logged

The following events can be logged in the logbook:

- ▶ [Error messages of the operating system](#) (□ 443)
- ▶ Error messages generated by the application
- ▶ Controller enable
- ▶ Starting / stopping the application
- ▶ Loading/saving of parameter sets, loading of the Lenze setting
- ▶ Transmitting an application or firmware to the controller
- ▶ Connection/disconnection of the controller
- ▶ Formatting of the file system



##### Tip!

Use a parameterisable filter to exclude certain events from logbook entry.

- ▶ [Filtering logbook entries](#) (□ 437)

##### Information saved

For each event, the following information are saved in the logbook:

- ▶ Type of response (e.g. fault, warning or information) to the event
- ▶ Module that activated the event (e.g. MCTRL or TEMPCONTROL).
- ▶ Event
- ▶ Date/time (for memory module with real-time clock)
- ▶ Value of power-on time meter


##### Memory depth

The number of possible logbook entries depends on the memory module used:

- ▶ MM1xx, MM2xx: 7 entries
- ▶ MM3xx, MM4xx: 439 entries

## 15.3.1 Function description

The structure of the logbook corresponds to a ring buffer structure:



[15-1] Ring buffer structure


- ▶ As long as free logbook memory capacity is available, the entries will be saved at the next free memory location.
- ▶ If all memory locations are occupied, the oldest entries will be deleted to save new entries.

## 15.3.2 Filtering logbook entries

Before the logbook logs new entries in the ring buffer, the entries are filtered by a parameterisable filter.

This filter is used to exclude events with a certain error response (fault, warning, information, etc.) from entry into the logbook.

- ▶ The filter parameters are set under [C00169](#) by means of a bit mask:




[15-2] Bit mask for event-type filter

### Meaning:

- |   |  |
|---|--|
| <input type="checkbox"/> A System error   | <input type="checkbox"/> E Quick stop by trouble |
| <input type="checkbox"/> B Information    | <input type="checkbox"/> F Trouble               |
| <input type="checkbox"/> C Warning        | <input type="checkbox"/> G Fault                 |
| <input type="checkbox"/> D Warning locked | <input type="checkbox"/> H Not assigned          |

- ▶ Example: Bit 6 must be set to "1" to exclude all events with "Information" response from entry into the logbook:



[15-3] Example: Bit mask for hiding events with "Information" response

### Meaning:

- |  |  |
|--|--|
| <input type="checkbox"/> A System error                  | <input type="checkbox"/> E Quick stop by trouble |
| <input checked="" type="checkbox"/> B <b>Information</b> | <input type="checkbox"/> F Trouble               |
| <input type="checkbox"/> C Warning                       | <input type="checkbox"/> G Fault                 |
| <input type="checkbox"/> D Warning locked                | <input type="checkbox"/> H Not assigned          |



### Note!


Events with the set "None" response are not entered into the logbook.


#### 15.3.3 Reading logbook entries

With an online connection, the existing logbook entries can simply be displayed in the »Engineer«. Alternatively, the logbook entries can also be read via the corresponding parameters (e.g. using the keypad).



#### How to display logbook entries in the »Engineer«:

1. Go to the *Project view* and select the 9400 HighLine controller whose logbook entries are to be read.
2. Click the  icon or select the command **Online→Go online** to build up an online connection with the controller.
3. Select the **Diagnostics** tab from the *Workspace*.
4. Click **Logbook**.
  - The *Logbook* dialog box appears:








- Click **Delete** to delete an entry from the logbook.
  - Click **Export** to export the entries from the logbook into a \*.log file.
  - Activating the **Hide system messages** checkbox, hides all "Information" system messages in the logbook.
5. Click **Previous** to close the *Logbook* dialog box.

## 15.4 Monitoring

The controller includes different monitoring functions that protect the drive against impermissible operating conditions.

- ▶ If a monitoring function responds,
  - an entry will be made into the [Logbook](#) of the controller,
  - the response (quick stop by trouble, warning, fault, etc.) selected for the monitoring function will be activated,
  - the status of the internal device control changes according to the selected response, controller inhibit is set, and the "DRIVE ERROR" LED on the front of the controller goes on:

Response	Logbook entry	Display under <a href="#">C00168</a>	Pulse inhibit	Controller inhibit	Acknowledgement required	LED "DRIVE ERROR"
None						OFF
Fault	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Trouble	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> (after 0.5 s)		
Quick stop by trouble	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Warning locked	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Warning	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>				
Information	<input checked="" type="checkbox"/>					OFF
System error	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Mains switching is required!	

See also: [▶ LED status displays \(34\)](#)  
[▶ Device states \(45\)](#)

### 15.4.1 Setting the error response

When a monitoring function is addressed, the response set for this monitoring function (quick stop by trouble, warning, fault, etc.) will be activated.

- ▶ For many monitoring functions the response can be individually parameterised via parameters.

/	C	S	Name	Value	Unit
	580	0	Resp. to encoder open circuit	Error	
	581	0	Resp. to external fault	1: Error	
	582	0	Resp. to heatsink temp. > C00122	0: No response	
	583	0	Resp. to motor overtemp. KTY	1: Error	
	584	0	Resp. to motor temp. > C00121	2: Fault	
	585	0	Resp. to motor overtemp. PTC	3: Quick stop by trouble	
	586	0	Resp. to resolver open circuit	4: Warning locked	
	587	0	Status · fan control	5: Warning	
				6: Info	
				0x00	



#### Tip!

When the response can be set for a monitoring function, the parameter for the setting and the preset response is listed in the description of the corresponding error message. ▶ [Error list](#) (448)

#### Short overview of the parameters for setting error responses:

Parameters	Selection of the error response for:
<a href="#">C00573</a>	Brake chopper overload
<a href="#">C00574</a>	Overtemperature of brake resistor
<a href="#">C00579</a>	Speed monitoring
<a href="#">C00580</a>	Encoder - open circuit
<a href="#">C00581</a>	External error
<a href="#">C00582</a>	Heatsink temperature > C00122
<a href="#">C00583</a>	Motor overtemperature - KTY
<a href="#">C00584</a>	Motor temperature > C00121
<a href="#">C00585</a>	Motor overtemperature - PTC
<a href="#">C00586</a>	Resolver - open circuit
<a href="#">C00588</a>	Failure of controller temperature sensor
<a href="#">C00589</a>	CPU temperature > C00126
<a href="#">C00591</a>	CAN RPDOx error
<a href="#">C00594</a>	Failure of motor temperature sensor
<a href="#">C00595</a>	CAN bus-off
<a href="#">C00597</a>	Motor phase failure
<a href="#">C00598</a>	Open circuit AIN1
<a href="#">C00600</a>	DC bus overvoltage
<a href="#">C00601</a>	Encoder communication error
<a href="#">C00604</a>	Device overload
<a href="#">C00606</a>	Motor overload
<a href="#">C00607</a>	Maximum speed reached
<a href="#">C00610</a>	Failure of heatsink fan
<a href="#">C00611</a>	Failure of integral fan
<a href="#">C00612</a>	CAN node-guarding error
<a href="#">C00613</a>	CAN heartbeat error
<a href="#">C00614</a>	CAN life guarding error
<a href="#">C00615</a>	Impermissible device configuration
<a href="#">C00619</a>	Maximum motor current
<a href="#">C00635</a>	new firmware - standard device
<a href="#">C00636</a>	New module in MXI1
<a href="#">C00637</a>	New module in MXI2
<a href="#">C01501</a>	Communication error with MXI1
<a href="#">C01502</a>	Communication error with MXI2



## Warning thresholds

Some of the monitoring functions are activated if a defined warning threshold (e.g. temperature) have been exceeded.

- ▶ The corresponding preset threshold values can be changed via the following parameters:

Parameters	Information
<a href="#">C00120</a>	Motor overload protection ( $I^2 \times t$ )
<a href="#">C00121</a>	Warning threshold - motor temperature
<a href="#">C00122</a>	Warning threshold - heatsink temperature
<a href="#">C00123</a>	Warning threshold - device utilisation
<a href="#">C00126</a>	Warning threshold - CPU temperature
<a href="#">C00127</a>	Warning threshold - motor overload
<a href="#">C00128</a>	Thermal motor time constant
<a href="#">C00132</a>	Max. temperature of brake resistor
<a href="#">C00174</a>	Undervoltage (LU) threshold
<a href="#">C00185</a>	Threshold - mains recovery recognition
<a href="#">C00576</a>	Window - speed monitoring
<a href="#">C00596</a>	Threshold of maximum speed reached
<a href="#">C00599</a>	Threshold - motor phase failure
<a href="#">C00620</a>	Max. motor current threshold

## 15.5 Maloperation of the drive

### The motor does not rotate.

Cause	Remedy
DC-bus voltage is too low.	Check mains voltage.
Controller is inhibited.	Deactivate controller inhibit (can be set by several sources).
Holding brake is not released	Release holding brake.
Quick stop is active	Deactivate quick stop.
Setpoint = 0	Select setpoint.

### With a positive speed setpoint selection, the motor rotates clockwise instead of counter-clockwise (when looking at the motor shaft).

Cause	Remedy
Feedback system is not connected in correct phase relation.	Connect feedback system in correct phase relation.

### The maximum current (C00022) flows and the motor does not rotate according to the defined speed setpoint.

Cause	Remedy
Two motor phases are interchanged, i.e. an anti-clockwise rotating field is applied to the motor.	<p>Proceed the following steps for verification:</p> <ol style="list-style-type: none"> <li>1. Ensure that the motor shaft is not blocked and can rotate freely without damaging the system.</li> <li>2. Activate "U rotation test mode" for the motor control (<a href="#">C00398</a> = "1"). <ul style="list-style-type: none"> <li>– In this test mode a voltmeter is applied to the machine with the frequency set in <a href="#">C00399/1</a> and the amplitude from the linear characteristic of rated voltage and rated frequency. This corresponds to a clockwise rotating field.</li> </ul> </li> <li>3. Increase the frequency step by step for the test mode in <a href="#">C00399/1</a> until the motor shaft starts to rotate. <ul style="list-style-type: none"> <li>– If the motor shaft does not rotate, check the electrical connection.</li> </ul> </li> <li>4. While the motor shaft is rotating check if it rotates clockwise when looking at the A end shield. If not, two motor phases are interchanged.</li> <li>5. Additionally check if the actual speed value displayed in <a href="#">C00051</a> is positive and corresponds to the defined frequency in consideration of the number of pole pairs of the machine (<a href="#">C00059</a>). If not, the connection and the parameter setting of the feedback system must be checked.</li> <li>6. Deactivate the test mode for the motor control again (<a href="#">C00398</a> = "0").</li> </ol>

## 15.6 Error messages of the operating system

This chapter describes all error messages of the controller operating system and possible causes & remedies.




### Tip!

All error messages are saved in chronological order in the logbook. For detailed information about the logbook, please see the chapter "Diagnostics & error analysis". ▶ [Logbook](#) (436)

### 15.6.1 Format of the error numbers saved in the fault memory

If an error occurs in the controller, a 32-bit value will be saved in decimal format in the internal history buffer ([C00168](#)) which contains the following information:



[15-4] Structure of the error number

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### 15.6.1.1 Response



Bit 31	Bit 30	Bit 29	Response
0	0	0	0: No response
0	0	1	1: Fault
0	1	0	2: Trouble
0	1	1	3: Quick stop by trouble
1	0	0	4: Warning locked
1	0	1	5: Warning
1	1	0	6: Information
1	1	1	7: System error

The status of the internal device control changes according to the selected response to an error, controller inhibit is set and the "DRIVE ERROR" LED at the front of the controller goes on:

Response	Logbook entry	Display under <a href="#">C00168</a>	Pulse inhibit	Controller inhibit	Acknowledgement required	LED "DRIVE ERROR"
None						OFF
Fault	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
Trouble	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/> (after 0.5 s)		
Quick stop by trouble	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Warning locked	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>			<input checked="" type="checkbox"/>	
Warning	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>				
Information	<input checked="" type="checkbox"/>					OFF
System error	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	Mains switching is required!	

#### 15.6.1.2 Instance-ID




The instance-ID is dynamically assigned by the operating system.

Bit 28	Bit 27	Bit 26	Meaning
0	0	0	Instance-ID 0
0	0	1	Instance-ID 1
0	1	0	Instance-ID 2
0	1	1	Instance-ID 3
1	0	0	Instance-ID 4
1	0	1	Instance-ID 5

Bit 28	Bit 27	Bit 26	Meaning
1	1	0	Instance-ID 6
1	1	1	Instance-ID 7

### 15.6.1.3 Module ID



Use the module-ID to identify the module in which the error has occurred.

► The following table lists the module-ID in hexadecimal format:

Module-ID	Module
0x0065	Logbook module
0x0068	Module identification
0x0069	Error check of the program memory during runtime
0x006a	Run-time environment for IEC 61131-3 programs
0x006e	Supply voltage monitoring
0x0072	SERVICEREGISTER
0x0075	Device control
0x0077	Temperature monitoring
0x0078	Analog signal monitoring
0x0079	Motor data interface
0x007a	Processing of digital inputs/outputs
0x007b	Motor control
0x007d	Processing of analog inputs/outputs
0x007f	Intelligent communication module
0x0083	CAN dispatcher
0x0084	CAN NMT handler
0x0085	CAN emergency handler
0x0086	CAN NMT master
0x0087	CAN PDO handler
0x0088	CAN SDO server
0x0089	CAN SDO client
0x008c	Application Project Manager
0x008e	Communication interface for internal communication
0x0090	Parameter Manager
0x0091	Lenze run-time system
0x0092	Interface for safety module
0x0093	Sync signal generation

### 15.6.1.4 Error ID




16-bit value (0 ... 65535<sub>dec</sub>) for error identification.

## 15.6.1.5 Example for bit coding of the error number

[C00168](#) displays the error number "1148911631".

► This decimal value corresponds to the following bit sequence:



Assignment	Information	Meaning in the example
010	<a href="#">Response</a>	2: Trouble
001	<a href="#">Instance-ID</a>	1: Instance ID 1
0001111011	<a href="#">Module ID</a>	Module ID 0x007b: MCTRL
0000000000001111	<a href="#">Error ID</a>	Error ID 0x000f for MCTRL: <a href="#">DC-bus undervoltage</a>

► Error number "1148911631" thus means:  
 The "DC-bus undervoltage" error with the response "Trouble" occurred in the MCTRL module with the instance ID 1.

## 15.6.2 Reset of error message

An error message with the response "Fault", "Trouble", "Quick stop by trouble" or "Warning locked" must be explicitly reset (acknowledged) after the cause of the error has been eliminated.



To reset (acknowledge) a pending error message execute the device command [C00002](#) = "43".




### Tip!

With an online connection to the controller, use the **Diagnostics** tab of the »Engineer« and click **Error message reset** to reset a pending error message.

#### 15.6.3 Error list

The following sections describe all error messages of the controller operating system.

- ▶ The error messages are described in ascending order of the hexadecimal number resulting from the **Module-ID** **C** and the **Error-ID** **D**.



#### Tip!

The index of this online documentation which contains all error numbers (in the entry "Error numbers") and all error messages allows you to quickly find a description of an error message.



#### Note!

Please observe that depending on the [Instance-ID](#) and the selected [Response](#) the first two hexadecimal places of the hexadecimal number indicated in the internal history buffer ([C00168](#)) may differ from the following error messages.

Example:

For information about the error message for the value "0x20077002" indicated under C00168, please see the index entry "error number 0x00077002".

#### Structure of the system error message descriptions

All error message descriptions have a uniform structure:

1. **Error message** and associated **module ID & error ID** in hexadecimal format.
2. Information on the **Response** to the error message
3. Information on the **cause** and possible **remedies**.



## Logbook: overflow [0x00650000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Too many events/errors have occurred in a very short time. It was therefore not possible to list all of them in the logbook.	Check if application generates too many error messages.

## Logbook: reset (read error) [0x00650001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The logbook has been reset due to a read error..	-(is irreversible)

## Logbook: reset (version error) [0x00650002]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The logbook has been reset due to a version conflict.	-(is irreversible)

## Memory module missing [0x00650003]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Memory module is defective or not available.	Use a different memory module.

## Control card is defective [0x00680000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Operating system could not identify the control card.	Mains switching <ul style="list-style-type: none"> <li>• Please contact Lenze, if the error occurs again.</li> </ul>

## Power section is defective [0x00680001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Operating system could not identify the power stage.	Mains switching <ul style="list-style-type: none"> <li>• Please contact Lenze, if the error occurs again.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Memory module is defective or missing [0x00680002]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause	Remedy
Operating system could not identify the memory module.	Mains switching <ul style="list-style-type: none"><li>• If the error occurs again: Switch off the controller, remove memory module and plug in again, switch on the controller again.</li><li>• If the error still occurs: Switch off controller and use a different memory module.</li></ul>

#### Safety module is defective or missing [0x00680003]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause	Remedy
Operating system could not identify the safety module.	Mains switching <ul style="list-style-type: none"><li>• If the error occurs again: Switch off the controller, remove safety module and plug in again, switch on the controller again.</li><li>• If the error still occurs: Switch off controller and use a different safety module.</li></ul>

#### MXI1: Module changed during operation [0x00680004]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

Cause	Remedy
The extension module you have tried to plug into the module receptacle MXI1 is not "hot plug" capable.	Plug in valid module and restart controller. <ul style="list-style-type: none"><li>• Through mains switching, the system accepts modules without "hot plug" capability in the following switch-on phase.</li></ul>

#### MXI2: Module changed during operation [0x00680005]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

Cause	Remedy
The extension module you have tried to plug into the module receptacle MXI2 is not "hot plug" capable.	Plug in valid module and restart controller. <ul style="list-style-type: none"><li>• Through mains switching, the system accepts modules without "hot plug" capability in the following switch-on phase.</li></ul>

#### Memory module has been removed [0x00680006]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause	Remedy
You have tried to remove or change the memory module during operation.	Switch off the controller, plug in memory module and switch on the controller again. <ul style="list-style-type: none"><li>• If the error occurs again, the memory module is defective and must be replaced.</li></ul>

## Safety module has been removed [0x00680007]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
You have tried to remove or change the safety module during operation.	Switch off the controller, plug in safety module and switch on the controller again. <ul style="list-style-type: none"> <li>• If the error occurs again, the safety module is defective and must be replaced.</li> </ul>

## Control card is defective [0x00680008]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Operating system could not identify the control card.	Please contact Lenze.

## Power section is defective [0x00680009]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Operating system could not identify the power stage.	Please contact Lenze.

## MXI1: Module is defective or missing [0x0068000a]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Operating system could not identify extension module in module receptacle MXI1.	<ul style="list-style-type: none"> <li>• Use a different extension module.</li> <li>• Please contact Lenze.</li> </ul>

## MXI2: Module is defective or missing [0x0068000b]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Operating system could not identify extension module in module receptacle MXI2.	<ul style="list-style-type: none"> <li>• Use a different extension module.</li> <li>• Please contact Lenze.</li> </ul>

## Memory module is defective or missing [0x0068000c]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Operating system could not identify the memory module.	<ul style="list-style-type: none"> <li>• Use a different memory module.</li> <li>• Please contact Lenze.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Safety module is defective or missing [0x0068000d]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Operating system could not identify the safety module.

Remedy

- Use a different safety module.
- Please contact Lenze.

#### Control card is not compatible [0x0068000e]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The control card is not supported by the operating system.

Remedy

Please contact Lenze.

#### Power section is not compatible [0x0068000f]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The power section is not supported by the operating system.

Remedy

Please contact Lenze.

#### MX11: Wrong module [0x00680010]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The extension module in the module receptacle MX11 is not supported by the operating system.

Remedy

- Use a different module.
- Please contact Lenze.

#### MX12: Wrong module [0x00680011]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The extension module in the module receptacle MX12 is not supported by the operating system.

Remedy

- Use a different module.
- Please contact Lenze.

#### Wrong memory module [0x00680012]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The memory module is not supported by the operating system.

Remedy

- Use a different module.
- Please contact Lenze.

## Wrong safety module [0x00680013]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The safety module is not supported by the operating system.

Remedy

- Use a different module.
- Please contact Lenze.

## Power section has been changed [0x00680014]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  **Information**

Cause

"The power section has changed since the last mains switching."

Remedy

- (Only information or warning locked if the hardware type has changed as well)

## MXI1: Module has been changed [0x00680015]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  **Information**

Cause

"The extension module in the module receptacle MXI1 has changed since the last mains switching."

Remedy

- (Only information or warning locked if the hardware type has changed as well)

## MXI2: Module has been changed [0x00680016]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  **Information**

Cause

"The extension module in the module receptacle MXI2 has changed since the last mains switching."

Remedy

- (Only information or warning locked if the hardware type has changed as well)

## Memory module has been changed [0x00680017]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  **Information**

Cause

"The memory module has changed since the last mains switching."

Remedy

- (Only information or warning locked if the hardware type has changed as well)

## Safety module has been changed [0x00680018]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  **Information**

Cause

"The safety module has changed since the last mains switching."

Remedy

- (Only information or warning locked if the hardware type has changed as well)

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Combination MXI1/MXI2 not possible [0x00680019]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The combinations of the extension modules plugged into the module receptacles MXI1 & MXI2 is not supported.

Remedy

Create permitted module combination.

#### Firmware has been changed [0x0068001a]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

The firmware of the operating system has been updated.

Remedy

- (Information only)

#### Electronic nameplate: Communication error [0x0068001b]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  **Warning**  Information

Cause

Communication with the electronic nameplate is disrupted, the data could not be read.

Remedy

Check correct connection of the encoder cable.

#### Memory module: File system is faulty [0x0068001c]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Memory module is plugged in incorrectly or is defective.

Remedy

- Plug in the memory module correctly.
- Exchange defective memory module.

#### Electronic nameplate: Checksum error [0x0068001d]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  **Warning**  Information

Cause

The checksum of the electronic nameplate is defective.

Remedy

Please contact Lenze.

#### Firmware is not compatible [0x0068001e]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Firmware is not compatible with the hardware.

Remedy

Transfer the compatible firmware.

### Combination memory module/device not possible [0x0068001f]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The memory module used is not supported by the controller according to the license model.	Plug in supported module and switch the mains. <ul style="list-style-type: none"> <li>• Only memory module MM220 or MM330 may be plugged in the 9400 HighLine.</li> </ul>

### Combination module in MX11/device not possible [0x00680020]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The extension module in the module receptacle MX11 is not supported by the controller.	<ul style="list-style-type: none"> <li>• Remove the extension module and switch the mains.</li> <li>• Plug in supported extension module and switch the mains.</li> </ul>

### Combination module in MX12/device not possible [0x00680021]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The extension module in the module receptacle MX12 is not supported by the controller.	<ul style="list-style-type: none"> <li>• Remove the extension module and switch the mains.</li> <li>• Plug in supported extension module and switch the mains.</li> </ul>

### Internal error (CRC code - RAM) [0x00690000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"> <li>• Please contact Lenze, if the problem occurs again.</li> </ul>

### Internal error (logbook memory area) [0x00690001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"> <li>• Please contact Lenze, if the problem occurs again.</li> </ul>

### Internal error (LDS instance data) [0x00690002]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"> <li>• Please contact Lenze, if the problem occurs again.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Internal error (LDS tasks) [0x00690003]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"><li>• Please contact Lenze, if the problem occurs again.</li></ul>

#### Internal error (storage blocks) [0x00690004]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"><li>• Please contact Lenze, if the problem occurs again.</li></ul>

#### Internal error (task queue) [0x00690005]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"><li>• Please contact Lenze, if the problem occurs again.</li></ul>

#### Internal error (message memory) [0x00690006]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"><li>• Please contact Lenze, if the problem occurs again.</li></ul>

#### Internal error (message queue) [0x00690007]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"><li>• Please contact Lenze, if the problem occurs again.</li></ul>

#### Internal error (name data base) [0x00690008]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"><li>• Please contact Lenze, if the problem occurs again.</li></ul>



## Internal error (event mechanism) [0x00690009]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"> <li>• Please contact Lenze, if the problem occurs again.</li> </ul>

## Internal error (event mechanism) [0x0069000a]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"> <li>• Please contact Lenze, if the problem occurs again.</li> </ul>

## Internal error (semaphores) [0x0069000b]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"> <li>• Please contact Lenze, if the problem occurs again.</li> </ul>

## Internal error (faulty binary semaphores) [0x0069000c]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Serious device error or component failure.	Switch off and on controller. <ul style="list-style-type: none"> <li>• Please contact Lenze, if the problem occurs again.</li> </ul>

## Internal error (file system) [0x0069000d]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
In case of the memory module the maximum number of permissible writing cycles has been reached.	Exchange memory module, otherwise data may get lost.

## General application error [0x006a0000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
General application error.	Mains switching. Transmit the application to the controller again. <ul style="list-style-type: none"> <li>• Please contact Lenze, if the problem occurs again.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Program download is faulty [0x006a0001]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

**Remedy**

Transmission of the application to the controller is faulty (checksum error).

Repeat transmission.

#### Error during input and output update [0x006a0002]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

**Remedy**

Internal error

Mains switching. Transmit the application to the controller again.

- Please contact Lenze, if the problem occurs again.

#### New application loaded [0x006a0003]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

**Remedy**

Application has been changed by transmission from the engineer or loading from the memory module.

- (Information only)

#### User task 1: Overflow [0x006a0004]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

**Remedy**

Program runtime in user task 1 is too high.

Reduce program runtime by means of:

- Omitting functions (e.g. by reducing the number of active FBs).
- Optimising the computing time of specific functions

#### User task 2: Overflow [0x006a0005]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

**Remedy**

Program runtime in user task 2 is too high.

See remedy for "[Overflow of user task 1](#)".

#### User task 3: Overflow [0x006a0006]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

**Remedy**

Program runtime in user task 3 is too high.

See remedy for "[Overflow of user task 1](#)".

## User task 4: Overflow [0x006a0007]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Program runtime in user task 4 is too high.	See remedy for " <a href="#">Overflow of user task 1</a> ".

## User task 5: Overflow [0x006a0008]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Program runtime in user task 5 is too high.	See remedy for " <a href="#">Overflow of user task 1</a> ".

## User task 6: Overflow [0x006a0009]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Program runtime in user task 6 is too high.	See remedy for " <a href="#">Overflow of user task 1</a> ".

## User task 7: Overflow [0x006a000a]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Program runtime in user task 7 is too high.	See remedy for " <a href="#">Overflow of user task 1</a> ".

## User task 8: Overflow [0x006a000b]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Program runtime in user task 8 is too high.	See remedy for " <a href="#">Overflow of user task 1</a> ".

## User task 9: Overflow [0x006a000c]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Program runtime in user task 9 is too high.	See remedy for " <a href="#">Overflow of user task 1</a> ".

## Runtime error [0x006a000d]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
A run-time error has occurred in the application. The application processing has been interrupted.	Remove run-time error in the application and retransmit the application to the controller.

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Application has been stopped [0x006a000e]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

The application has been stopped using the device command `C00002="32"`. All user tasks are stopped.

Remedy

Restart application with controller command `C00002="31"`.

#### Breakpoint has been reached [0x006a000f]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

The application has reached a set breakpoint and the user task with the breakpoint has stopped.

Remedy

Delete breakpoint and restart application.

#### Faulty application parameter [0x006a0010]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

An invalid parameter description has occurred.

Remedy

Transmit application and parameter set to the controller again.

#### Division by zero [0x006a0011]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

A forbidden division by zero occurred in the application. The division has been intercepted and the divisor has been replaced by the value "1".

Remedy

Exchange application.

#### Pointer access in impermissible memory area [0x006a0012]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

An invalid pointer access to a protected area occurred in the application.

Remedy

Exchange application.

#### Application has been started [0x006a0013]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

The application in the controller has been started.

Remedy

- (Information only)

## Application has been stopped [0x006a0014]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

**Remedy**

The application in the controller has been stopped.

- (Information only)

## PDO mapping (MXI1): Faulty configuration [0x006a0015]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

**Remedy**

CANopen communication module in MXI1: Incorrectly configured process data mapping.

- The corresponding PDO channel is not installed, since, for instance, no communication module has been selected for the module receptacle MXI1 in the Engineer project.
- The communication module selected for the module receptacle MXI1 in the Engineer project does not support PDO mapping.
- The mapping information downloaded to the controller is faulty.

- Integrate suitable communication module into the Engineer project for the module receptacle MXI1.
- Check the configuration of the network. Then recompile the project and transmit it to the controller.

## PDO mapping (MXI2): Faulty configuration [0x006a0016]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

**Remedy**

CANopen communication module in MXI2: Incorrectly configured process data mapping.

- The corresponding PDO channel is not installed, since, for instance, no communication module has been selected for the module receptacle MXI2 in the Engineer project.
- The communication module selected for the module receptacle MXI2 in the Engineer project does not support PDO mapping.
- The mapping information downloaded to the controller is faulty.

- Integrate suitable communication module into the Engineer project for the module receptacle MXI2.
- Check the configuration of the network. Then recompile the project and transmit it to the controller.

## Control card: Supply voltage (24 V DC) too low [0x006f0000]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  **Trouble**  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

**Remedy**

External supply voltage UB24 of the control card is lower than 18 V.

Check external supply voltage.

- If the external supply voltage is available and the error message does not disappear, please contact Lenze.

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Read error - service register [0x00720000]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An error has occurred while reading or writing the service register.	Mains switching • Please contact Lenze, if the problem occurs again.

#### External error [0x00750000]

<b>Response</b> (Lenze setting printed in bold) <input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Setting: <a href="#">C00581</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
The drive interface has activated the error message "External error". • The input <i>DI_bSetExternError</i> of the system block <b>LS_DriveInterface</b> has been set to TRUE.	• Check external device to be monitored. • Check assignment of the input <i>DI_bSetExternError</i> in the application.

#### Controller is enabled [0x00750001]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The controller is enabled and has the "Operation" state.	- (Information only)

#### Controller has been initialised [0x00750002]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The controller has left the "Initialisation active" state.	- (Information only)

#### Controller in STO state [0x00750003]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The controller has received the "safe torque off" request and is now in the "Safe Torque Off active" state.	- (Information only)

#### Controller: Pulse inhibit is active [0x00750005]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The pulse inhibit is active in the controller.	- (Information only)

## PLC configuration is invalid [0x00750006]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An invalid control configuration has occurred.	Load other application.

## Heatsink: Temperature > C00122 [0x00770000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00582</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Heatsink temperature higher than variable limit temperature ( <a href="#">C00122</a> ). <ul style="list-style-type: none"> <li>Controller ambient temperature too high.</li> <li>Dirty fan or ventilation slots.</li> <li>Value set under C00122 is too low.</li> </ul>	<ul style="list-style-type: none"> <li>Check control cabinet temperature.</li> <li>Clean filter.</li> <li>Clean controller.</li> <li>Set a higher value under <a href="#">C00122</a>.</li> </ul>	

## Heatsink: Overtemperature [0x00770001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Heatsink temperature higher than fixed limit temperature (90 °C). <ul style="list-style-type: none"> <li>Controller ambient temperature too high.</li> <li>Dirty fan or ventilation slots.</li> </ul>	<ul style="list-style-type: none"> <li>Check control cabinet temperature.</li> <li>Clean filter.</li> <li>Clean controller.</li> </ul>

## Motor: Temperature > C00121 [0x00770002]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00584</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Motor temperature higher than variable limit temperature ( <a href="#">C00121</a> ). <ul style="list-style-type: none"> <li>Motor too hot due to impermissibly high currents or frequent and too long acceleration.</li> <li>No PTC connected.</li> <li>Value set under <a href="#">C00121</a> is too low.</li> </ul>	<ul style="list-style-type: none"> <li>Check drive dimensioning.</li> <li>Connect PTC or switch off monitoring (<a href="#">C00584</a>="3").</li> <li>Set a higher value under <a href="#">C00121</a>.</li> </ul>	

## Motor: Overtemperature [0x00770003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00583</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Motor temperature higher than fixed limit temperature (150 °C). <ul style="list-style-type: none"> <li>Motor too hot due to impermissibly high currents or frequent and too long acceleration.</li> <li>No PTC connected.</li> </ul>	<ul style="list-style-type: none"> <li>Check drive dimensioning.</li> <li>Connect PTC or switch off monitoring (<a href="#">C00584</a>="3").</li> </ul>	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### DC-bus capacitor: Temperature > CXXXXX [0x00770004]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  **Warning**  Information

**Cause**

Electrolytic capacitor temperature higher than warning threshold.

**Remedy**

- Check control cabinet temperature.
- Clean filter.
- Clean controller.

#### DC-bus capacitor: overtemperature [0x00770005]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Electrolytic capacitor temperature higher than limit temperature (120 °C).

**Remedy**

- Check control cabinet temperature.
- Clean filter.
- Clean controller.

#### Inside the device: Temperature > CXXXXX [0x00770006]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  **Warning**  Information

**Cause**

Inside temperature higher than warning threshold.

**Remedy**

- Check control cabinet temperature.
- Clean filter.
- Clean controller.

#### Inside the device: Overtemperature [0x00770007]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Inside temperature higher than limit temperature (85 °C).

**Remedy**

- Check control cabinet temperature.
- Clean filter.
- Clean controller.

#### CPU: Temperature > C00126 [0x00770008]

**Response** (Lenze setting printed in bold)

**Setting:** [C00589](#) ( Adjustable response)

**None**  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  **Warning**  Information

**Cause**

CPU temperature higher than variable limit temperature ([C00126](#)).

- Controller ambient temperature too high.
- Dirty fan or ventilation slots.
- Value set under C00126 is too low.

**Remedy**

- Check control cabinet temperature.
- Clean filter.
- Clean controller.
- Set a higher value under [C00126](#).



## CPU: Overtemperature [0x00770009]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CPU temperature higher than fixed limit temperature (85 °C). <ul style="list-style-type: none"> <li>• Controller ambient temperature too high.</li> <li>• Dirty fan or ventilation slots.</li> </ul>	<ul style="list-style-type: none"> <li>• Check control cabinet temperature.</li> <li>• Clean filter.</li> <li>• Clean controller.</li> </ul>

## Heatsink: Temperature sensor defective [0x0077000a]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00588</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Encoder for heatsink temperature supplies undefined values.	Check control cabinet temperature, maybe it is too low.	

## Inside the device: Temperature sensor defective [0x0077000b]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00588</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Encoder for interior temperature supplies undefined values.	Check control cabinet temperature, maybe it is too low.	

## Motor: Temperature sensor defective [0x0077000c]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00594</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The signals of the connected encoder of the motor temperature detection (resolver at X7 or encoder at X8) are outside the defined operating range of detection.	<ul style="list-style-type: none"> <li>• Check bonding of the encoder cable at the motor and controller.</li> <li>• Check selection of the motor temperature sensor in <a href="#">C01190</a> and make sure that it complies with the assembly in the motor.</li> <li>• Possibly switch off temperature sensor monitoring (<a href="#">C00594</a>="0").</li> <li>• If a PTC is in the motor, activate the monitoring of the PTC temperature in <a href="#">C00585</a> instead.</li> </ul>	

## DC-bus capacitor: Temperature sensor defective [0x0077000d]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00588</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Encoder for capacitor temperature supplies undefined values.	Check control cabinet temperature, maybe it is too low.	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CPU: Temperature sensor defective [0x0077000e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00588</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Encoder for CPU temperature supplies undefined values.	Check control cabinet temperature, maybe it is too low.	

#### Motor: PTC has triggered [0x0077000f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00585</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The motor temperature detected via the terminals T1/T2 is too high. <ul style="list-style-type: none"><li>• Motor is too hot due to an increased effective current that results from an operation with too high/too frequent acceleration.</li><li>• Motor too hot due to increased ambient conditions.</li><li>• Motor too hot due to lacking cooling in case of self-ventilation and continuous operation with speeds lower than the rated speed.</li><li>• Terminals T1/T2 are not assigned.</li><li>• Open circuit of the supply cables for terminals T1/T2</li></ul>	<ul style="list-style-type: none"><li>• Check drive dimensioning.</li><li>• Connect PTC or thermal contact to terminals T1/T2.</li><li>• In case of a motor without integrated temperature monitoring switch off the monitoring function (<a href="#">C00585</a>="0").</li></ul>	

#### Heatsink: Fan is defective [0x00770010]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00610</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Speed of heatsink fan too low, e.g. due to dirt.	Check/clean fan.	

#### Inside the device: Fan is defective [0x00770011]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00611</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Speed of internal fan is too low, e.g. due to dirt.	Check/clean fan.	

#### Device utilisation Ixt > C00123 [0x00780000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00604</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Frequent and too long acceleration with overcurrent > <a href="#">C00123</a> .	Check drive dimensioning.	

#### Device utilisation Ixt > 100 % [0x00780001]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Frequent and too long acceleration with overcurrent.	Check drive dimensioning.	

## Motor load I<sup>xt</sup> > C00127 [0x00780002]

<b>Response</b> (Lenze setting printed in bold)		Setting: <a href="#">C00606</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Motor is thermally overloaded, e.g. due to: <ul style="list-style-type: none"> <li>impermissible continuous current</li> <li>frequent or too long acceleration</li> </ul>	<ul style="list-style-type: none"> <li>Check drive dimensioning.</li> <li>Check setting under <a href="#">C00127</a>.</li> </ul>	

## Motor load I<sup>xt</sup> > C00120 [0x00780003]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Motor is thermally overloaded, e.g. due to: <ul style="list-style-type: none"> <li>impermissible continuous current</li> <li>frequent or too long acceleration</li> </ul>	<ul style="list-style-type: none"> <li>Check drive dimensioning.</li> <li>Check setting under <a href="#">C00120</a>.</li> </ul>	

## Control card is defective (UB24) [0x00780004]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Device error	Please contact Lenze.	

## Control card is defective (VCC15) [0x00780005]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Device error	Please contact Lenze.	

## Control card is defective (UB8) [0x00780006]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Device error	Please contact Lenze.	

## Control card is defective (VCC15 neg.) [0x00780007]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Device error	Please contact Lenze.	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Control card is defective (UB18 neg.) [0x00780008]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Device error

Remedy

Please contact Lenze.

#### Control card is defective (VCC5) [0x00780009]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Device error

Remedy

Please contact Lenze.

#### Electronic nameplate: Data incompatible [0x0078000a]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

The connected motor with feedback is not supported by the controller firmware.

Remedy

Check drive dimensioning.

#### Device command transmitted incorrectly [0x00790000]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Internal error

Remedy

If the error occurs frequently, please contact Lenze.

#### Time error - controller interface [0x00790001]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Internal error

Remedy

If the error occurs frequently, please contact Lenze.

#### Violation of the time dial [0x00790002]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Internal error

Remedy

If the error occurs frequently, please contact Lenze.

#### Motor: Calculated motor impedance unrealistic [0x007b0001]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Faulty motor parameterisation.

Remedy

Check motor parameters.

## Motor: Calculated mutual inductance unrealistic [0x007b0002]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Faulty motor parameterisation.	Check motor parameters.

## Motor data is inconsistent [0x007b0003]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Faulty motor parameterisation.	Check motor parameters.

## Motor: Phase resistance is too high [0x007b0004]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Faulty motor parameterisation.	Check motor parameters.

## Motor: Device current is too low for rated magnetisation [0x007b0006]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Controller current is too low for rated magnetisation, i.e. the controller cannot energise the motor sufficiently.	Check drive dimensioning.

## Motor: Rated current < rated magnetisation current [0x007b0007]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Faulty motor parameterisation.	Check motor parameters and setting of <a href="#">C00022</a> .

## Motor: Calculated rotor resistance unrealistic [0x007b0009]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Faulty motor parameterisation.	Check motor parameters.

## Motor: Calculated mutual inductance unrealistic [0x007b000a]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Faulty motor parameterisation.	Check motor parameters.

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Motor: Calculated electromotive force factor unrealistic [0x007b000b]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Faulty motor parameterisation.	Check motor parameters.

#### Motor: Calculated rotor time constant unrealistic [0x007b000c]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Faulty motor parameterisation.	Check motor parameters.

#### Motor: Calculated flux factor unrealistic [0x007b000d]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Faulty motor parameterisation.	Check motor parameters.

#### DC-bus overvoltage [0x007b000e]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input checked="" type="checkbox"/> <b>Trouble</b> <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
<ul style="list-style-type: none"><li>Since the braking energy is too high, the DC-bus voltage is higher than the overvoltage threshold which results from the mains setting in <a href="#">C00173</a>.</li></ul>	<ul style="list-style-type: none"><li>Use brake resistor or feedback module.</li><li>Check setting under <a href="#">C00173</a>.</li></ul>

#### DC-bus undervoltage [0x007b000f]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input checked="" type="checkbox"/> <b>Trouble</b> <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
DC bus voltage is lower than the undervoltage threshold resulting from the mains setting under <a href="#">C00173</a> .	<ul style="list-style-type: none"><li>Check mains voltage.</li><li>Check setting under <a href="#">C00173</a>.</li></ul>

#### Overcurrent detected [0x007b0010]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
<ul style="list-style-type: none"><li>Short circuit/earth fault in motor cable.</li><li>Excessive capacitive charging current in the motor cable.</li></ul>	<ul style="list-style-type: none"><li>Check motor cable.</li><li>Use motor cable which is shorter or has a lower capacitance.</li></ul>

## Earth fault detected [0x007b0011]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
<ul style="list-style-type: none"> <li>• Earth fault in motor cable.</li> <li>• Excessive capacitive charging current in the motor cable.</li> </ul>	<ul style="list-style-type: none"> <li>• Check motor cable.</li> <li>• Use motor cable which is shorter or has a lower capacitance.</li> </ul>

## Actual speed value out of monitoring window C00576 [0x007b0012]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00579</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Difference between actual and setpoint speed is too big.	<ul style="list-style-type: none"> <li>• Increase speed tolerance margin under <a href="#">C00576</a>.</li> <li>• Check drive dimensioning.</li> </ul>	

## Motor control: Task overflow [0x007b0013]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error (motor control).	Please contact Lenze.

## Internal communication error (host MCTRL) [0x007b0014]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error (motor control).	Please contact Lenze.

## Motor data is inconsistent [0x007b0017]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Faulty motor parameterisation.	Check motor parameters.

## Resolver: Open circuit [0x007b0018]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
<ul style="list-style-type: none"> <li>• Resolver cable interrupted.</li> <li>• Resolver defective.</li> </ul>	<ul style="list-style-type: none"> <li>• Check resolver cable.</li> <li>• Check resolver.</li> <li>• Switch off monitoring, if necessary (<a href="#">C00586</a>="3").</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Motor: Calculated leakage inductance unrealistic [0x007b0019]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Faulty motor parameterisation.

Check motor parameters.

#### Absolute value encoder: Communication error [0x007b001a]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Absolute value encoder does not send any data.

- Check supply cable.
- Check encoder.
- Check voltage supply ([C00421](#)).

#### Encoder: Open circuit [0x007b001b]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

- Encoder cable interrupted.
- Encoder defective.
- Faulty parameter setting of the encoder.

- Check encoder cable.
- Check encoder.
- Check parameter setting ([C00422](#)).
- Switch off monitoring, if necessary ([C00580](#)="3").

#### Brake chopper: Ixt overload [0x007b001c]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Too frequent and too long brake operations.

Check drive dimensioning.

#### Brake resistor: Ixt overload [0x007b001d]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

Cause

Remedy

Too frequent and too long brake operations.

- Check drive dimensioning.
- Check parameter setting ([C00129](#), [C00130](#), [C00131](#), [C00132](#)).

#### Motor: Actual current value > C00620 [0x007b001e]

Response (Lenze setting printed in bold)

Setting: [C00619](#) ( Adjustable response)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

The instantaneous value of the motor current has exceeded the value set in [C00620](#).

- Set a higher value in [C00620](#).
- Reduce maximum current ([C00022](#)).
- Change response ([C00619](#)).



## Resolver: Calculated acceleration unrealistic [0x007b001f]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Resolver evaluation faulty (implausible acceleration at the resolver).	Check set-up.

## Motor: Actual speed value > C00596 [0x007b0020]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00607</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Threshold for speed monitoring set in <a href="#">C00596</a> has been exceeded.	Check drive dimensioning.	

## Brake chopper: Overcurrent [0x007b0021]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00573</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Brake chopper short circuit/earth fault detected.	Check brake chopper cable and brake resistor.	

## Position encoder: Module selected under C00490 not available [0x007b0023]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The position encode selected under <a href="#">C00490</a> has not been recognised.	<ul style="list-style-type: none"> <li>• Check position encoder.</li> <li>• Check parameter setting (<a href="#">C00490</a>).</li> </ul>

## Motor encoder: Module selected under C00495 not available [0x007b0024]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The motor encoder selected under <a href="#">C00495</a> has not been recognised.	<ul style="list-style-type: none"> <li>• Check motor encoder.</li> <li>• Check parameter setting (<a href="#">C00495</a>).</li> </ul>

## Motor temperature: Module selected under C01193 not available [0x007b0025]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The module for temperature feedback selected in <a href="#">C01193</a> has not been recognised.	<ul style="list-style-type: none"> <li>• Check feedback module.</li> <li>• Check parameter setting (<a href="#">C01193</a>).</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### EnDat encoder: Lamp error [0x007b0026]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

#### EnDat encoder: Signal error [0x007b0027]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

#### EnDat encoder: Position error [0x007b0028]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

#### EnDat encoder: Overvoltage [0x007b0029]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

#### EnDat encoder: Undervoltage [0x007b002a]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

#### EnDat encoder: Overcurrent [0x007b002b]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

#### EnDat encoder: Flat battery [0x007b002c]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

EnDat encoder defective.

**Remedy**

Check EnDat encoder.

## Failure of motor phase U [0x007b002d]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00597</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
U phase interruption of motor cable.	<ul style="list-style-type: none"> <li>• Check cabling between controller and motor.</li> <li>• Check parameter setting (<a href="#">C00599</a>).</li> </ul>	

## Failure of motor phase V [0x007b002e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00597</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
V phase interruption of the motor cable.	<ul style="list-style-type: none"> <li>• Check cabling between controller and motor.</li> <li>• Check parameter setting (<a href="#">C00599</a>).</li> </ul>	

## Failure of motor phase W [0x007b002f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00597</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
W phase interruption of the motor cable.	<ul style="list-style-type: none"> <li>• Check cabling between controller and motor.</li> <li>• Check parameter setting (<a href="#">C00599</a>).</li> </ul>	

## Electronic nameplate: Data loaded [0x007b0030]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
New electronic nameplate (ENP) has been found.	- (Information only)	

## Electronic nameplate: Not found [0x007b0031]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
Electronic nameplate (ENP) is not available.	- (Information only)	

## Electronic nameplate: Unknown encoder protocol [0x007b0032]

<b>Response</b> (Lenze setting printed in bold)		
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
The connected motor with feedback is not supported by the controller firmware.	Check drive dimensioning.	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Electronic nameplate: Unknown encoder signal [0x007b0033]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The connected motor with feedback is not supported by the controller firmware.

Remedy

Check drive dimensioning.

#### Internal communication error (DMA) [0x007b0034]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Internal error.

Remedy

Please contact Lenze.

#### Internal communication error (MCTRL host) [0x007b0036]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Internal error.

Remedy

Please contact Lenze.

#### Invalid PLC configuration [0x007b0037]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

An invalid control configuration has occurred.

Remedy

Load other application.

#### Motor parameter identification has been cancelled [0x007b0038]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The motor current during identification was too high.

Remedy

- The motor must not move during identification.
- Check motor parameters

#### Electronic nameplate: Data out of parameter limits [0x007b0039]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The motor parameters of the electronic nameplate are out of the limit values of the controller and therefore cannot be accepted.

Remedy

Please contact Lenze.

### Memory module: File system has been formatted [0x007c0000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
File system of the memory module has been formatted.	- (Information only)

### Memory module: File system has been restored [0x007c0001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
File system of the memory module has been restored.	- (Information only)

### Analog input 1: Master current < 4 mA [0x007d0000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00598</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
Master current is in the impermissible range -4 ... +4 mA, e.g. due to a line break or a defective master current value encoder. <ul style="list-style-type: none"> <li>Only for parameterisation as master current input (see <a href="#">C00034</a>).</li> </ul>	Remove open circuit.	

### Invalid PLC configuration [0x007d0001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An invalid control configuration has occurred.	Load other application.

### Communication error between device and device module [0x007f0002]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C01501</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Communication between controller and extension module is interrupted, e.g. due to disturbances in the ambience (EMC), a defective hardware or loose contact. <ul style="list-style-type: none"> <li>This monitoring is designed for safe process data communication.</li> </ul>	<ul style="list-style-type: none"> <li>Remove EMC fault.</li> <li>Properly connect module.</li> <li>Switch the mains or restart controller.</li> <li>Exchange module/controller.</li> <li>Please contact Lenze, if the problem occurs again.</li> </ul>	

### CAN on board: Bus-off [0x00830000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00595</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: "Bus-off" state <ul style="list-style-type: none"> <li>Too many faulty telegrams received.</li> <li>Cable defective (e.g. loose contact).</li> <li>Two nodes with the same ID.</li> </ul>	<ul style="list-style-type: none"> <li>Remove fault (e.g. EMC).</li> <li>Remove loose contact, screw down adapter.</li> <li>Assign different node IDs.</li> </ul>	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN on board: Invalid node address 0 [0x00830001]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: Initialisation error <ul style="list-style-type: none"><li>The node address has been selected via DIP switch by means of hardware and the DIP switches of the node address are set to zero.</li><li>Note: Instead of the impermissible node address 0 the node address 1 is used.</li></ul>	<ul style="list-style-type: none"><li>Use the DIP switches to set a node address unequal 0 and restart the controller.</li><li>Activate the node number assignment by means of software by changing the position of DIP switch 2 and restart the controller.</li></ul>

#### CAN on board: Invalid basic configuration [0x00830002]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: Configuration error <ul style="list-style-type: none"><li>Faulty download of an Engineer or PLC Designer project</li><li>Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li></ul>	<ul style="list-style-type: none"><li>Repeat download</li><li>Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN on board: Heartbeat error index 1 [0x00840000]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C00613/1</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: Cyclic node monitoring <ul style="list-style-type: none"><li>Node device has not received a heartbeat telegram from node 1 within the defined time.</li></ul>	<ul style="list-style-type: none"><li>Reactivate CAN node by restarting the controller, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li><li>Select a different heartbeat producer monitoring time or switch off monitoring and reset locked error status, if necessary.</li></ul> <p>Tip: Save the current parameter set before mains switching and restart (<a href="#">C00002</a>="11").</p>

#### CAN on board: Heartbeat error index 2 [0x00840001]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C00613/2</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 2.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN on board: Heartbeat error index 3 [0x00840002]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C00613/3</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 3.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

## CAN on board: Heartbeat error index 4 [0x00840003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/4</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 4.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 5 [0x00840004]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/5</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 5.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 6 [0x00840005]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/6</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 6.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 7 [0x00840006]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/7</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 7.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 8 [0x00840007]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/8</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 8.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 9 [0x00840008]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/9</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 9.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN on board: Heartbeat error index 10 [0x00840009]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/10</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 10.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN on board: Heartbeat error index 11 [0x0084000a]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/11</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 11.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN on board: Heartbeat error index 12 [0x0084000b]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/12</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 12.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN on board: Heartbeat error index 13 [0x0084000c]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/13</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 13.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN on board: Heartbeat error index 14 [0x0084000d]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/14</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 14.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN on board: Heartbeat error index 15 [0x0084000e]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/15</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 15.	See remedy for " <a href="#">Heartbeat error index 1</a> ".



## CAN on board: Heartbeat error index 16 [0x0084000f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/16</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information			
<b>Cause</b>		<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 16.		See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 17 [0x00840010]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/17</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information			
<b>Cause</b>		<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 17.		See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 18 [0x00840011]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/18</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information			
<b>Cause</b>		<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 18.		See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 19 [0x00840012]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/19</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information			
<b>Cause</b>		<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 19.		See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 20 [0x00840013]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/20</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information			
<b>Cause</b>		<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 20.		See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 21 [0x00840014]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/21</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information			
<b>Cause</b>		<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 21.		See remedy for " <a href="#">Heartbeat error index 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN on board: Heartbeat error index 22 [0x00840015]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/22</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 22.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN on board: Heartbeat error index 23 [0x00840016]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/23</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 23.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN on board: Heartbeat error index 24 [0x00840017]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/24</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 24.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN on board: Heartbeat error index 25 [0x00840018]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/25</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 25.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN on board: Heartbeat error index 26 [0x00840019]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/26</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 26.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN on board: Heartbeat error index 27 [0x0084001a]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00613/27</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: No heartbeat telegram received from node 27.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

## CAN on board: Heartbeat error index 28 [0x0084001b]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/28</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 28.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 29 [0x0084001c]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/29</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 29.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 30 [0x0084001d]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/30</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 30.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 31 [0x0084001e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/31</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 31.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Heartbeat error index 32 [0x0084001f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00613/32</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: No heartbeat telegram received from node 32.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

## CAN on board: Life guarding error [0x00840020]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00614</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN on board: Cyclic node monitoring <ul style="list-style-type: none"> <li>Slave response: Maximum time between two node guarding telegrams (remote transmission request telegram) from the master has been exceeded.</li> </ul>	Select a different life guarding monitoring time or switch off monitoring.	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN on board: Faulty NMT slave configuration [0x00840021]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: A configuration error has occurred in the network management of the CAN slave. <ul style="list-style-type: none"><li>Faulty download of an Engineer or PLC Designer project</li><li>Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li><li>Incorrect parameterisation of node guarding or heartbeat.</li></ul>	<ul style="list-style-type: none"><li>Repeat download</li><li>Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN on board: Faulty emergency configuration [0x00850000]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: A configuration error has occurred in the CAN emergency module. <ul style="list-style-type: none"><li>Faulty download of an Engineer or PLC Designer project</li><li>Invalid CAN emergency settings according to DS301V402 in the Engineer or PLC Designer.</li></ul>	<ul style="list-style-type: none"><li>Repeat download</li><li>Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN on board: Node guarding error 1 [0x00860000]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C00612/1</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN on board: Cyclic node monitoring <ul style="list-style-type: none"><li>CAN master has not received a response to a node guarding telegram (remote transmission request telegram) from node 1 within the defined time.</li></ul>	<ul style="list-style-type: none"><li>Reactivate CAN node by restarting the controller, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li><li>Select a different node guarding monitoring time or switch off monitoring.</li><li>Reset error state if latched.</li></ul> <p>Tip: Safe the current parameter set before mains switching and restarting the controller (<a href="#">C00002</a>="11").</p>

#### CAN on board: Node guarding error 2 [0x00860001]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C00612/2</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 2.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN on board: Node guarding error 3 [0x00860002]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C00612/3</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 3.	See remedy for " <a href="#">Node guarding error 1</a> ".

### CAN on board: Node guarding error 4 [0x00860003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/4</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 4.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN on board: Node guarding error 5 [0x00860004]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/5</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 5.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN on board: Node guarding error 6 [0x00860005]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/6</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 6.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN on board: Node guarding error 7 [0x00860006]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/7</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 7.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN on board: Node guarding error 8 [0x00860007]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/8</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 8.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN on board: Node guarding error 9 [0x00860008]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/9</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 9.	See remedy for " <a href="#">Node guarding error 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN on board: Node guarding error 10 [0x00860009]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/10</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 10.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN on board: Node guarding error 11 [0x0086000a]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/11</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 11.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN on board: Node guarding error 12 [0x0086000b]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/12</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 12.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN on board: Node guarding error 13 [0x0086000c]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/13</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 13.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN on board: Node guarding error 14 [0x0086000d]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/14</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 14.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN on board: Node guarding error 15 [0x0086000e]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/15</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 15.	See remedy for " <a href="#">Node guarding error 1</a> ".

## CAN on board: Node guarding error 16 [0x0086000f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/16</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 16.	See remedy for " <a href="#">Node guarding error 1</a> ".	

## CAN on board: Node guarding error 17 [0x00860010]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/17</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 17.	See remedy for " <a href="#">Node guarding error 1</a> ".	

## CAN on board: Node guarding error 18 [0x00860011]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/18</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 18.	See remedy for " <a href="#">Node guarding error 1</a> ".	

## CAN on board: Node guarding error 19 [0x00860012]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/19</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 19.	See remedy for " <a href="#">Node guarding error 1</a> ".	

## CAN on board: Node guarding error 20 [0x00860013]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/20</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 20.	See remedy for " <a href="#">Node guarding error 1</a> ".	

## CAN on board: Node guarding error 21 [0x00860014]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/21</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 21.	See remedy for " <a href="#">Node guarding error 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN on board: Node guarding error 22 [0x00860015]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/22</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 22.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN on board: Node guarding error 23 [0x00860016]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/23</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 23.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN on board: Node guarding error 24 [0x00860017]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/24</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 24.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN on board: Node guarding error 25 [0x00860018]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/25</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 25.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN on board: Node guarding error 26 [0x00860019]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/26</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 26.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN on board: Node guarding error 27 [0x0086001a]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C00612/27</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CAN master has not received a response to a node guarding telegram from node 27.	See remedy for " <a href="#">Node guarding error 1</a> ".



### CAN on board: Node guarding error 28 [0x0086001b]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/28</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 28.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN on board: Node guarding error 29 [0x0086001c]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/29</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 29.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN on board: Node guarding error 30 [0x0086001d]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/30</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 30.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN on board: Node guarding error 31 [0x0086001e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/31</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 31.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN on board: Node guarding error 32 [0x0086001f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00612/32</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CAN master has not received a response to a node guarding telegram from node 32.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN on board: Faulty NMT master configuration [0x00860020]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
<p>CAN on board: A configuration error has occurred in the network management of the CAN master.</p> <ul style="list-style-type: none"> <li>• Faulty download of an Engineer or PLC Designer project.</li> <li>• Invalid CAN master settings according to DS301V402 and DS405 in the Engineer or PLC Designer.</li> <li>• Incorrect parameterisation of node guarding or heartbeat.</li> </ul>	<ul style="list-style-type: none"> <li>• Repeat download</li> <li>• Correct CAN settings in the project and regenerate project.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN on board RPDO1: Telegram not received or faulty [0x00870000]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C00591/1</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CAN on board: CAN-IN 1 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• PDO time monitoring has released.</li></ul>	<ul style="list-style-type: none"><li>• Set the correct telegram length for the CAN master (transmitter).</li><li>• Remove electromagnetic interference (e.g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN on board RPDO2: Telegram not received or faulty [0x00870001]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C00591/2</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CAN on board: CAN-IN 2 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• PDO time monitoring has released.</li></ul>	<ul style="list-style-type: none"><li>• Set the correct telegram length for the CAN master (transmitter).</li><li>• Remove electromagnetic interference (e.g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN on board RPDO3: Telegram not received or faulty [0x00870002]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C00591/3</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CAN on board: CAN-IN 3 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• PDO time monitoring has released.</li></ul>	<ul style="list-style-type: none"><li>• Set the correct telegram length for the CAN master (transmitter).</li><li>• Remove electromagnetic interference (e.g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN on board RPDO4: Telegram not received or faulty [0x00870003]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;"><b>Setting:</b> <a href="#">C00591/4</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
Cause	Remedy
CAN on board: CAN-IN 4 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• PDO time monitoring has released.</li></ul>	<ul style="list-style-type: none"><li>• Set the correct telegram length for the CAN master (transmitter).</li><li>• Remove electromagnetic interference (e.g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN on board PDO manager: Faulty configuration [0x00870008]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
Cause	Remedy
CAN on board: CAN-PDO configuration error <ul style="list-style-type: none"><li>• Faulty project download.</li><li>• Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li><li>• Mapping variables have incorrect CANopen indices according to DS405.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download.</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

## CAN on board SDO server: Faulty configuration [0x00880000]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

**Cause**

CAN on board: A configuration error has occurred in the CAN SDO server.

- Faulty project download.
- Invalid SDO server settings according to DS301V402 in the Engineer or PLC Designer.

**Remedy**

- Repeat download.
- Correct CAN settings in the project and regenerate project.

## CAN on board SDO client: Faulty configuration [0x00890000]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

**Cause**

CAN on board: A configuration error has occurred in the CAN SDO client.

- Faulty project download.
- Invalid SDO client settings according to DS301V402 in the Engineer or PLC Designer.

**Remedy**

- Repeat download
- Correct CAN settings in the project and regenerate project.

## ProjectSelection.dat file faulty [0x008c0000]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Internal error

**Remedy**

Reformat memory module ([C00002](#)="1030") and repeat project download.

## ProjectList.dat file faulty [0x008c0001]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Internal error

**Remedy**

Reformat memory module ([C00002](#)="1030") and repeat project download.

## DeviceCFG.dat file faulty [0x008c0002]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Internal error

**Remedy**

Reformat memory module ([C00002](#)="1030") and repeat project download.

## ProjectSelection.dat missing [0x008c0003]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Internal error

**Remedy**

Reformat memory module ([C00002](#)="1030") and repeat project download.

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### ProjectList.dat file missing [0x008c0004]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	Reformat memory module ( <a href="#">C00002</a> ="1030") and repeat project download.

#### DeviceCFG.dat file missing [0x008c0005]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	Reformat memory module ( <a href="#">C00002</a> ="1030") and repeat project download.

#### ProjectSelection.dat file invalid [0x008c0006]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	Reformat memory module ( <a href="#">C00002</a> ="1030") and repeat project download.

#### ProjectList.dat file invalid [0x008c0007]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	Reformat memory module ( <a href="#">C00002</a> ="1030") and repeat project download.

#### DeviceCFG.dat file invalid [0x008c0008]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Internal error	Reformat memory module ( <a href="#">C00002</a> ="1030") and repeat project download.

#### Project is not loaded [0x008c0009]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Application could not be loaded because of a file error.	Load new or different application.

### Project is not available [0x008c000a]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Application not available.	<ul style="list-style-type: none"> <li>• Download application with the Engineer</li> <li>• Switch off controller and use a different memory module with an existing application.</li> </ul>

### Required license missing [0x008c000b]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Memory module could not be initialised.	Two possibilities: <ul style="list-style-type: none"> <li>• Use the Engineer to download and activate an application suitable for the memory module.</li> <li>• Switch off controller and use memory module suitable for the application.</li> </ul>

### MXI1: Module missing or incompatible [0x008c000d]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The extension module in module receptacle MXI1 is incompatible with the application.	Use extension module supported by the application.

### MXI2: Module missing or incompatible [0x008c000e]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The extension module in module receptacle MXI2 is incompatible with the application.	Use extension module supported by the application.

### MXI1: PROFIBUS module missing or incompatible [0x008c000f]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The communication module E94AYCPM (PROFIBUS) in module receptacle MXI1 is incompatible with the application.	Use communication module supported by the application.

### MXI2: PROFIBUS module missing or incompatible [0x008c0010]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The communication module E94AYCPM (PROFIBUS) in module receptacle MXI2 is incompatible with the application.	Use communication module supported by the application.

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### MXI1: Ethernet module missing or incompatible [0x008c0011]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The communication module E94AYCEN (Ethernet) in the module receptacle MXI1 is incompatible with the application.

Remedy

Use communication module supported by the application.

#### MXI2: Ethernet module missing or incompatible [0x008c0012]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The communication module E94AYCEN (Ethernet) in the module receptacle MXI2 is incompatible with the application.

Remedy

Use communication module supported by the application.

#### MXI1: Digital frequency module missing or incompatible [0x008c0013]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The digital frequency extension module in module receptacle MXI1 is incompatible with the application.

Remedy

Use extension module supported by the application.

#### MXI2: Digital frequency module missing or incompatible [0x008c0014]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The digital frequency extension module in module receptacle MXI2 is incompatible with the application.

Remedy

Use extension module supported by the application.

#### MXI1: ICM module missing or incompatible [0x008c0015]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The ICM extension module in module receptacle MXI1 is incompatible with the application.

Remedy

Use extension module supported by the application.

#### MXI2: ICM module missing or incompatible [0x008c0016]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The ICM extension module in module receptacle MXI2 is incompatible with the application.

Remedy

Use extension module supported by the application.

## MXI1: CAN module missing or incompatible [0x008c0017]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

The CANopen communication module in module receptacle MXI1 is incompatible with the application.

**Remedy**

Use communication module supported by the application.

## MXI2: CAN module missing or incompatible [0x008c0018]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

The CANopen communication module in module receptacle MXI2 is incompatible with the application.

**Remedy**

Use communication module supported by the application.

## Connection table in use [0x008c001a]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

This application is provided with a connection table which means that connections can be changed online without executing a completely new download.

**Remedy**

- (Information only)

## Internal error (CRC application) [0x008c001d]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

The checksum of the application is faulty.

**Remedy**

Retransmit the application to the controller.

## Parameter set faulty [0x00900000]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Parameter set is invalid.

**Remedy**

Transfer parameter set from Engineer to the controller and save with `C00002="11"`.

## Lenze setting loaded [0x00900001]

**Response** (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  **Information**

**Cause**

"Lenze setting has been loaded."

**Remedy**

- (Information only)

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Parameter set saved [0x00900002]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Parameter set has been saved.	- (Information only)

#### Parameter set loaded [0x00900003]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Parameter set has been loaded.	- (Information only)

#### Loading of Lenze setting failed [0x00900004]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Lenze setting of a parameter is not within the valid limits.	Remove error in the application and retransmit the application to the controller.

#### Parameter set restored [0x00900005]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An error has occurred while loading the selected parameter set.	Transfer parameter set from Engineer to the controller and save with <code>C00002="11"</code> .

#### Saving of parameters failed [0x00900006]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
An error has occurred while saving the current parameter set.	Use a different memory module.

#### Parameter set: Version conflict [0x00900007]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
The parameter set version on the memory module is not compatible with the firmware of the controller.	Transfer parameter set from Engineer to the controller and save with <code>C00002="11"</code> .



## Code number assigned twice [0x00900008]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
Code number of the operating system has been assigned to the application.	Remove error in the application and retransmit the application to the controller.

## Parameter set: Variant conflict [0x00900009]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
The firmware has loaded a parameter set the type code of which does not comply with the type code of the controller.	Load a suitable parameter set.

## No parameters for module in MXI1 [0x0090000a]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00615/2</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The parameter set contains no parameters for the module inserted in MXI1.	Integrate the module inserted in MXI1 into the Engineer project and then retransmit the parameter set to the controller.	

## No parameters for module in MXI2 [0x0090000b]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C00615/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The parameter set contains no parameters for the module inserted in MXI2.	Integrate the module inserted in MXI2 into the Engineer project and then retransmit the parameter set to the controller.	

## Mains voltage switched on [0x00910000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Mains voltage has been switched on.	- (Information only)

## Mains voltage switched off [0x00910001]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
Mains voltage has been switched off.	- (Information only)

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### No heartbeat signal detected [0x00910002]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

#### Heartbeat not periodic [0x00910003]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

#### Internal error: See C00180 [0x00910004]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

#### Internal error: See C00180 [0x00910005]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

Please contact Lenze.

#### Internal error: See C00180 [0x00910006]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Divisor of division was "0".

Exchange application.

#### Internal error: See C00180 [0x00910008]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

#### Internal error: See C00180 [0x00910009]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

## System task 1: Task overflow [0x0091000a]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
System overload.	Please contact Lenze.

## System task 2: Task overflow [0x0091000b]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
System overload.	Please contact Lenze.

## System task 3: Task overflow [0x0091000c]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input checked="" type="checkbox"/> <b>System fault</b> <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
System overload.	Please contact Lenze.

## System task: Task overflow [0x0091000d]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
System overload.	Please contact Lenze.

## Communication task: Standstill > 3 s [0x0091000e]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
System overload or communication task crash.	Reduce system load. <ul style="list-style-type: none"> <li>This is possible in the application or data transfer of the communication interfaces.</li> </ul>

## Cyclic task: Standstill > 60 s [0x0091000f]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>	
<b>Cause</b>	<b>Remedy</b>
System overload or CRC check task crash.	Reduce system load. <ul style="list-style-type: none"> <li>This is possible in the application or data transfer of the communication interfaces.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Position value faulty [0x00910010]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

#### Error during initialisation [0x00910011]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

#### Blocking function in MEC task [0x00910012]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Internal error

If the error occurs frequently, please contact Lenze.

#### Safety module: Incompatible to setting under C00214 [0x00920000]

Response (Lenze setting printed in bold)

None  **System fault**  Fault  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

The controller has detected a safety module which does not match the setting under [C00214](#).

Change setting under [C00214](#) or use a suitable safety module.

- Then, restart the controller.

#### DFIN (MXI1): A-/A track error [0x00990000]

Response (Lenze setting printed in bold)

Setting: [C13040](#) ( Adjustable response)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Digital frequency extension module in MXI1:  
Interruption (open circuit) of the signal cable for track A.

- Check signal cable for track A.
- Check encoder.

#### DFIN (MXI1): B-/B track error [0x00990001]

Response (Lenze setting printed in bold)

Setting: [C13040](#) ( Adjustable response)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

Remedy

Digital frequency extension module in MXI1:  
Interruption (open circuit) of the signal cable for track B.

- Check signal cable for track B.
- Check encoder.

### DFIN (MXI1): Z-/Z track error [0x00990002]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13040</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in MXI1: Interruption (open circuit) of the signal cable for track Z.	<ul style="list-style-type: none"> <li>• Check signal cable for track Z.</li> <li>• Check encoder.</li> </ul>	

### DFIN (MXI1): Enable/lamp control signal error [0x00990003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13041</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in MXI1: Interruption (open circuit) of the signal cable for the "Enable" signal or no "Enable" signal available.	<ul style="list-style-type: none"> <li>• Check signal cable for "Enable" signal.</li> <li>• Check encoder.</li> </ul>	

### DFIN (MXI1): Supply cannot be corrected anymore [0x00990004]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13042</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in MXI1: The encoder voltage controlled by the digital frequency input has reached the voltage limit.	Check encoder.	

### DFOUT (MXI1): Maximum frequency reached [0x00990005]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13080</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in MXI1: Limit frequency at the digital frequency output reached. <ul style="list-style-type: none"> <li>• The digital frequency has reached the limit value set in <a href="#">C013053</a>.</li> </ul>	Check set limit value.	

### CAN module (MXI1): Bus-off [0x009d0000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13595</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: "Bus-off" state <ul style="list-style-type: none"> <li>• Too many faulty telegrams received.</li> <li>• Cable defective (e.g. loose contact).</li> <li>• Two nodes with the same ID.</li> </ul>	<ul style="list-style-type: none"> <li>• Remove fault (e.g. EMC).</li> <li>• Remove loose contact, screw down adapter.</li> <li>• Assign different node IDs.</li> </ul>	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI1): Invalid node address 0 [0x009d0001]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: Initialisation error <ul style="list-style-type: none"><li>The node address has been selected via DIP switch by means of hardware and the DIP switches of the node address are set to zero.</li><li>Note: Instead of the impermissible node address 0 the node address 1 is used.</li></ul>	<ul style="list-style-type: none"><li>Use the DIP switches to set a node address unequal 0 and restart the controller.</li><li>Activate the node number assignment by means of software by changing the position of DIP switch 2 and restart the controller.</li></ul>

#### CAN module (MXI1): Basic configuration invalid [0x009d0002]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: Configuration error <ul style="list-style-type: none"><li>Faulty download of an Engineer or PLC Designer project</li><li>Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li></ul>	<ul style="list-style-type: none"><li>Repeat download</li><li>Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN module (MXI1): Heartbeat error index 1 [0x009e0000]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C13613/1</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: Cyclic node monitoring <ul style="list-style-type: none"><li>Node device has not received a heartbeat telegram from node 1 within the defined time.</li></ul>	<ul style="list-style-type: none"><li>Reactivate CAN node by restarting the controller, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li><li>Select a different heartbeat producer monitoring time or switch off monitoring and reset locked error status, if necessary.</li></ul> <p>Tip: Safe the current parameter set before mains switching and restarting the controller (<a href="#">C00002</a>="11").</p>

#### CAN module (MXI1): Heartbeat error index 2 [0x009e0001]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C13613/2</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 2.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI1): Heartbeat error index 3 [0x009e0002]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C13613/3</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 3.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

### CAN module (MXI1): Heartbeat error index 4 [0x009e0003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/4</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 4.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 5 [0x009e0004]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/5</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 5.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 6 [0x009e0005]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/6</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 6.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 7 [0x009e0006]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/7</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 7.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 8 [0x009e0007]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/8</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 8.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 9 [0x009e0008]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/9</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 9.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI1): Heartbeat error index 10 [0x009e0009]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/10</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 10.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI1): Heartbeat error index 11 [0x009e000a]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/11</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 11.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI1): Heartbeat error index 12 [0x009e000b]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/12</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 12.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI1): Heartbeat error index 13 [0x009e000c]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/13</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 13.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI1): Heartbeat error index 14 [0x009e000d]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/14</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 14.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI1): Heartbeat error index 15 [0x009e000e]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/15</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 15.	See remedy for " <a href="#">Heartbeat error index 1</a> ".



### CAN module (MXI1): Heartbeat error index 16 [0x009e000f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/16</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 16.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 17 [0x009e0010]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/17</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 17.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 18 [0x009e0011]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/18</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 18.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 19 [0x009e0012]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/19</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 19.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 20 [0x009e0013]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/20</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 20.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 21 [0x009e0014]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/21</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 21.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI1): Heartbeat error index 22 [0x009e0015]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/22</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 22.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI1): Heartbeat error index 23 [0x009e0016]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/23</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 23.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI1): Heartbeat error index 24 [0x009e0017]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/24</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 24.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI1): Heartbeat error index 25 [0x009e0018]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/25</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 25.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI1): Heartbeat error index 26 [0x009e0019]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/26</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 26.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI1): Heartbeat error index 27 [0x009e001a]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13613/27</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: No heartbeat telegram received from node 27.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

### CAN module (MXI1): Heartbeat error index 28 [0x009e001b]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/28</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 28.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 29 [0x009e001c]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/29</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 29.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 30 [0x009e001d]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/30</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 30.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 31 [0x009e001e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/31</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 31.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Heartbeat error index 32 [0x009e001f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13613/32</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: No heartbeat telegram received from node 32.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI1): Life guarding error [0x009e0020]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13614</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: Cyclic node monitoring <ul style="list-style-type: none"> <li>Slave response: Maximum time between two node guarding telegrams (remote transmission request telegram) from the master has been exceeded.</li> </ul>	Select a different life guarding monitoring time or switch off monitoring.	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI1): Faulty NMT slave configuration [0x009e0021]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: A configuration error has occurred in the network management of the CAN slave. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project</li><li>• Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li><li>• Incorrect parameterisation of node guarding or heartbeat.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN module (MXI1): Faulty emergency configuration [0x009f0000]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: In the CAN emergency module a configuration error has occurred. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project</li><li>• Invalid CAN emergency settings according to DS301V402 in the Engineer or PLC Designer.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN module (MXI1): Node guarding error 1 [0x00a00000]

<b>Response</b> (Lenze setting printed in bold) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Setting:</b> <a href="#">C13612/1</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: Cyclic node monitoring <ul style="list-style-type: none"><li>• CAN master has not received a response to a node guarding telegram (remote transmission request telegram) from node 1 within the defined time.</li></ul>	<ul style="list-style-type: none"><li>• Reactivate CAN node by restarting the controller, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li><li>• Select a different node guarding monitoring time or switch off monitoring.</li><li>• Reset error state if latched.</li></ul> <p>Tip: Safe the current parameter set before mains switching and restarting the controller (<a href="#">C00002</a>="11").</p>

#### CAN module (MXI1): Node guarding error 2 [0x00a00001]

<b>Response</b> (Lenze setting printed in bold) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Setting:</b> <a href="#">C13612/2</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 2.	See remedy for " <a href="#">Node guarding error 1</a> ".

### CAN module (MXI1): Node guarding error 3 [0x00a00002]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 3.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 4 [0x00a00003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/4</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 4.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 5 [0x00a00004]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/5</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 5.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 6 [0x00a00005]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/6</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 6.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 7 [0x00a00006]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/7</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 7.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 8 [0x00a00007]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/8</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 8.	See remedy for " <a href="#">Node guarding error 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI1): Node guarding error 9 [0x00a00008]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/9</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 9.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI1): Node guarding error 10 [0x00a00009]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/10</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 10.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI1): Node guarding error 11 [0x00a0000a]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/11</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 11.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI1): Node guarding error 12 [0x00a0000b]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/12</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 12.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI1): Node guarding error 13 [0x00a0000c]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/13</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 13.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI1): Node guarding error 14 [0x00a0000d]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/14</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 14.	See remedy for " <a href="#">Node guarding error 1</a> ".

### CAN module (MXI1): Node guarding error 15 [0x00a0000e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/15</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 15.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 16 [0x00a0000f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/16</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 16.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 17 [0x00a00010]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/17</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 17.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 18 [0x00a00011]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/18</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 18.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 19 [0x00a00012]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/19</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 19.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 20 [0x00a00013]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/20</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 20.	See remedy for " <a href="#">Node guarding error 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI1): Node guarding error 21 [0x00a00014]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/21</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 21.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI1): Node guarding error 22 [0x00a00015]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/22</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 22.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI1): Node guarding error 23 [0x00a00016]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/23</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 23.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI1): Node guarding error 24 [0x00a00017]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/24</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 24.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI1): Node guarding error 25 [0x00a00018]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/25</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 25.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI1): Node guarding error 26 [0x00a00019]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C13612/26</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 26.	See remedy for " <a href="#">Node guarding error 1</a> ".



### CAN module (MXI1): Node guarding error 27 [0x00a0001a]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/27</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 27.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 28 [0x00a0001b]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/28</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 28.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 29 [0x00a0001c]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/29</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 29.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 30 [0x00a0001d]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/30</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 30.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 31 [0x00a0001e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/31</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 31.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI1): Node guarding error 32 [0x00a0001f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13612/32</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI1: CAN master has not received a response to a node guarding telegram from node 32.	See remedy for " <a href="#">Node guarding error 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI1): Faulty NMT master configuration [0x00a00020]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: A configuration error has occurred in the network management of the CAN master. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project.</li><li>• Invalid CAN master settings according to DS301V402 and DS405 in the Engineer or PLC Designer.</li><li>• Incorrect parameterisation of node guarding or heartbeat.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN module (MXI1) RPDO1: Telegram not received or faulty [0x00a10000]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C13591/1</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN-IN 1 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• PDO time monitoring has released.</li></ul>	<ul style="list-style-type: none"><li>• Set the correct telegram length for the CAN master (transmitter).</li><li>• Remove electromagnetic interference (e.g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN module (MXI1) RPDO2: Telegram not received or faulty [0x00a10001]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C13591/2</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN-IN 2 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• PDO time monitoring has released.</li></ul>	<ul style="list-style-type: none"><li>• Set the correct telegram length for the CAN master (transmitter).</li><li>• Remove electromagnetic interference (e.g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN module (MXI1) RPDO3: Telegram not received or faulty [0x00a10002]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C13591/3</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN-IN 3 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• PDO time monitoring has released.</li></ul>	<ul style="list-style-type: none"><li>• Set the correct telegram length for the CAN master (transmitter).</li><li>• Remove electromagnetic interference (e.g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

### CAN module (MXI1) RPDO4: Telegram not received of faulty [0x00a10003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13591/4</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI1: CAN-IN 4 error	<ul style="list-style-type: none"> <li>• Set the correct telegram length for the CAN master (transmitter).</li> <li>• Remove electromagnetic interference (e.g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• PDO time monitoring has released.</li> </ul>		

### CAN module (MXI1) RPDO5: Telegram not received or faulty [0x00a10004]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13591/5</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI1: CAN-IN 5 error	<ul style="list-style-type: none"> <li>• Set the correct telegram length for the CAN master (transmitter).</li> <li>• Remove electromagnetic interference (e.g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• PDO time monitoring has released.</li> </ul>		

### CAN module (MXI1) RPDO6: Telegram not received or faulty [0x00a10005]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13591/6</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI1: CAN-IN 6 error	<ul style="list-style-type: none"> <li>• Set the correct telegram length for the CAN master (transmitter).</li> <li>• Remove electromagnetic interference (e.g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• PDO time monitoring has released.</li> </ul>		

### CAN module (MXI1) RPDO7: Telegram not received or faulty [0x00a10006]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13591/7</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI1: CAN-IN 7 error	<ul style="list-style-type: none"> <li>• Set the correct telegram length for the CAN master (transmitter).</li> <li>• Remove electromagnetic interference (e.g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• PDO time monitoring has released.</li> </ul>		

### CAN module (MXI1) RPDO8: Telegram not received or faulty [0x00a10007]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C13591/8</a> (☑ Adjustable response)
☑ <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI1: CAN-IN 8 error	<ul style="list-style-type: none"> <li>• Set the correct telegram length for the CAN master (transmitter).</li> <li>• Remove electromagnetic interference (e.g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• PDO time monitoring has released.</li> </ul>		

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI1) PDO manager: Faulty configuration [0x00a10008]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: CAN-PDO configuration error <ul style="list-style-type: none"><li>• Faulty project download.</li><li>• Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li><li>• Mapping variables have incorrect CANopen indices according to DS405.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download.</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN module (MXI1) SDO server: Faulty configuration [0x00a20000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: In the CAN SDP server a configuration error has occurred. <ul style="list-style-type: none"><li>• Faulty project download.</li><li>• Invalid SDO server settings according to DS301V402 in the Engineer or PLC Designer.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download.</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN module (MXI1) SDO client: Faulty configuration [0x00a30000]

<b>Response</b> (Lenze setting printed in bold)	
<input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI1: In the CAN SDP client a configuration error has occurred. <ul style="list-style-type: none"><li>• Faulty project download.</li><li>• Invalid SDO client settings according to DS301V402 in the Engineer or PLC Designer.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

#### DFIN (MXI2): A-/A track error [0x00aa0000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14040</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for track A.	<ul style="list-style-type: none"><li>• Check signal cable for track A.</li><li>• Check encoder.</li></ul>	

#### DFIN (MXI2): B-/B track error [0x00aa0001]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14040</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for track B.	<ul style="list-style-type: none"><li>• Check signal cable for track B.</li><li>• Check encoder.</li></ul>	

## DFIN (MXI2): Z-/Z track error [0x00aa0002]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14040</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for track Z.	<ul style="list-style-type: none"> <li>• Check signal cable for track Z.</li> <li>• Check encoder.</li> </ul>	

## DFIN (MXI2): Enable/lamp control signal error [0x00aa0003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14041</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in MXI2: Interruption (open circuit) of the signal cable for the "Enable" signal or no "Enable" signal available.	<ul style="list-style-type: none"> <li>• Check signal cable for "Enable" signal.</li> <li>• Check encoder.</li> </ul>	

## DFIN (MXI2): Supply cannot be corrected anymore [0x00aa0004]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14042</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in MXI2: The encoder voltage controlled by the digital frequency input has reached the voltage limit.	Check encoder.	

## DFOUT (MXI2): Maximum frequency reached [0x00aa0005]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14080</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Digital frequency extension module in MXI2: Limit frequency at the digital frequency output reached. <ul style="list-style-type: none"> <li>• The digital frequency has reached the limit value set in <a href="#">C014053</a>.</li> </ul>	Check set limit value.	

## CAN module (MXI2): Bus-off [0x00ac0000]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14595</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> <b>Information</b>		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: "Bus-off" state <ul style="list-style-type: none"> <li>• Too many faulty telegrams received.</li> <li>• Cable defective (e.g. loose contact).</li> <li>• Two nodes with the same ID.</li> </ul>	<ul style="list-style-type: none"> <li>• Remove fault (e.g. EMC).</li> <li>• Remove loose contact, screw down adapter.</li> <li>• Assign different node IDs.</li> </ul>	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI2): Invalid node address 0 [0x00ac0001]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input type="checkbox"/> Warning locked <input checked="" type="checkbox"/> <b>Warning</b> <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: Initialisation error <ul style="list-style-type: none"><li>The node address has been selected via DIP switch by means of hardware and the DIP switches of the node address are set to zero.</li><li>Note: Instead of the impermissible node address 0 the node address 1 is used.</li></ul>	<ul style="list-style-type: none"><li>Use the DIP switches to set a node address unequal 0 and restart the controller.</li><li>Activate the node number assignment by means of software by changing the position of DIP switch 2 and restart the controller.</li></ul>

#### CAN module (MXI2): Basic configuration invalid [0x00ac0002]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: Configuration error <ul style="list-style-type: none"><li>Faulty download of an Engineer or PLC Designer project</li><li>Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li></ul>	<ul style="list-style-type: none"><li>Repeat download</li><li>Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN module (MXI2): Heartbeat error index 1 [0x00ad0000]

<b>Response</b> (Lenze setting printed in bold) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Setting:</b> <a href="#">C14613/1</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: Cyclic node monitoring <ul style="list-style-type: none"><li>Node device has not received a heartbeat telegram from node 1 within the defined time.</li></ul>	<ul style="list-style-type: none"><li>Reactivate CAN node by restarting the controller, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li><li>Select a different heartbeat producer monitoring time or switch off monitoring and reset locked error status, if necessary.</li></ul> <p>Tip: Safe the current parameter set before mains switching and restarting the controller (<a href="#">C00002</a>="11").</p>

#### CAN module (MXI2): Heartbeat error index 2 [0x00ad0001]

<b>Response</b> (Lenze setting printed in bold) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Setting:</b> <a href="#">C14613/2</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 2.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI2): Heartbeat error index 3 [0x00ad0002]

<b>Response</b> (Lenze setting printed in bold) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Setting:</b> <a href="#">C14613/3</a> ( <input checked="" type="checkbox"/> Adjustable response)	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 3.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

### CAN module (MXI2): Heartbeat error index 4 [0x00ad0003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/4</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 4.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 5 [0x00ad0004]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/5</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 5.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 6 [0x00ad0005]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/6</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 6.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 7 [0x00ad0006]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/7</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 7.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 8 [0x00ad0007]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/8</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 8.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 9 [0x00ad0008]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/9</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 9.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI2): Heartbeat error index 10 [0x00ad0009]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/10</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 10.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI2): Heartbeat error index 11 [0x00ad000a]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/11</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 11.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI2): Heartbeat error index 12 [0x00ad000b]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/12</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 12.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI2): Heartbeat error index 13 [0x00ad000c]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/13</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 13.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI2): Heartbeat error index 14 [0x00ad000d]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/14</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 14.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI2): Heartbeat error index 15 [0x00ad000e]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/15</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 15.	See remedy for " <a href="#">Heartbeat error index 1</a> ".



### CAN module (MXI2): Heartbeat error index 16 [0x00ad000f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/16</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 16.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 17 [0x00ad0010]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/17</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 17.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 18 [0x00ad0011]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/18</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 18.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 19 [0x00ad0012]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/19</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 19.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 20 [0x00ad0013]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/20</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 20.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 21 [0x00ad0014]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/21</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 21.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI2): Heartbeat error index 22 [0x00ad0015]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/22</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 22.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI2): Heartbeat error index 23 [0x00ad0016]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/23</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 23.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI2): Heartbeat error index 24 [0x00ad0017]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/24</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 24.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI2): Heartbeat error index 25 [0x00ad0018]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/25</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 25.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI2): Heartbeat error index 26 [0x00ad0019]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/26</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 26.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

#### CAN module (MXI2): Heartbeat error index 27 [0x00ad001a]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14613/27</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: No heartbeat telegram received from node 27.	See remedy for " <a href="#">Heartbeat error index 1</a> ".

### CAN module (MXI2): Heartbeat error index 28 [0x00ad001b]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/28</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 28.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 29 [0x00ad001c]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/29</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 29.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 30 [0x00ad001d]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/30</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 30.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 31 [0x00ad001e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/31</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 31.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Heartbeat error index 32 [0x00ad001f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14613/32</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: No heartbeat telegram received from node 32.	See remedy for " <a href="#">Heartbeat error index 1</a> ".	

### CAN module (MXI2): Life guarding error [0x00ad0020]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14614</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: Cyclic node monitoring <ul style="list-style-type: none"> <li>Slave response: Maximum time between two node guarding telegrams (remote transmission request telegram) from the master has been exceeded.</li> </ul>	Select a different life guarding monitoring time or switch off monitoring.	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI2): Faulty NMT slave configuration [0x00ad0021]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: A configuration error has occurred in the network management of the CAN slave. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project</li><li>• Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.</li><li>• Incorrect parameterisation of node guarding or heartbeat.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN module (MXI2): Faulty emergency configuration [0x00ae0000]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: In the CAN emergency module a configuration error has occurred. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project</li><li>• Invalid CAN emergency settings according to DS301V402 in the Engineer or PLC Designer.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN module (MXI2): Node guarding error 1 [0x00af0000]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C14612/1</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: Cyclic node monitoring <ul style="list-style-type: none"><li>• CAN master has not received a response to a node guarding telegram (remote transmission request telegram) from node 1 within the defined time.</li></ul>	<ul style="list-style-type: none"><li>• Reactivate CAN node by restarting the controller, restart of the controller (<a href="#">C00002</a>="11000") or CAN reset node.</li><li>• Select a different node guarding monitoring time or switch off monitoring.</li><li>• Reset error state if latched.</li></ul> <p>Tip: Safe the current parameter set before mains switching and restarting the controller (<a href="#">C00002</a>="11").</p>

#### CAN module (MXI2): Node guarding error 2 [0x00af0001]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C14612/2</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 2.	See remedy for " <a href="#">Node guarding error 1</a> ".

### CAN module (MXI2): Node guarding error 3 [0x00af0002]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 3.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 4 [0x00af0003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/4</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 4.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 5 [0x00af0004]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/5</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 5.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 6 [0x00af0005]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/6</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 6.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 7 [0x00af0006]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/7</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 7.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 8 [0x00af0007]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/8</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 8.	See remedy for " <a href="#">Node guarding error 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI2): Node guarding error 9 [0x00af0008]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/9</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 9.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI2): Node guarding error 10 [0x00af0009]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/10</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 10.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI2): Node guarding error 11 [0x00af000a]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/11</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 11.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI2): Node guarding error 12 [0x00af000b]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/12</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 12.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI2): Node guarding error 13 [0x00af000c]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/13</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 13.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI2): Node guarding error 14 [0x00af000d]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/14</a> (<input checked="" type="checkbox"/> Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 14.	See remedy for " <a href="#">Node guarding error 1</a> ".

### CAN module (MXI2): Node guarding error 15 [0x00af000e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/15</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 15.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 16 [0x00af000f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/16</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 16.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 17 [0x00af0010]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/17</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 17.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 18 [0x00af0011]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/18</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 18.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 19 [0x00af0012]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/19</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 19.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 20 [0x00af0013]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/20</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 20.	See remedy for " <a href="#">Node guarding error 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI2): Node guarding error 21 [0x00af0014]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/21</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 21.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI2): Node guarding error 22 [0x00af0015]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/22</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 22.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI2): Node guarding error 23 [0x00af0016]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/23</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 23.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI2): Node guarding error 24 [0x00af0017]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/24</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 24.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI2): Node guarding error 25 [0x00af0018]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/25</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 25.	See remedy for " <a href="#">Node guarding error 1</a> ".

#### CAN module (MXI2): Node guarding error 26 [0x00af0019]

<b>Response</b> (Lenze setting printed in bold) <span style="float: right;">Setting: <a href="#">C14612/26</a> (☑ Adjustable response)</span>	
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 26.	See remedy for " <a href="#">Node guarding error 1</a> ".



### CAN module (MXI2): Node guarding error 27 [0x00af001a]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/27</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 27.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 28 [0x00af001b]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/28</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 28.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 29 [0x00af001c]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/29</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 29.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 30 [0x00af001d]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/30</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 30.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 31 [0x00af001e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/31</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 31.	See remedy for " <a href="#">Node guarding error 1</a> ".	

### CAN module (MXI2): Node guarding error 32 [0x00af001f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14612/32</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
CANopen communication module in MXI2: CAN master has not received a response to a node guarding telegram from node 32.	See remedy for " <a href="#">Node guarding error 1</a> ".	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI2): Faulty NMT master configuration [0x00af0020]

<b>Response</b> (Lenze setting printed in bold) <input type="checkbox"/> None <input type="checkbox"/> System fault <input type="checkbox"/> Fault <input type="checkbox"/> Trouble <input type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> <b>Warning locked</b> <input type="checkbox"/> Warning <input type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: A configuration error has occurred in the network management of the CAN master. <ul style="list-style-type: none"><li>• Faulty download of an Engineer or PLC Designer project.</li><li>• Invalid CAN master settings according to DS301V402 and DS405 in the Engineer or PLC Designer.</li><li>• Incorrect parameterisation of node guarding or heartbeat.</li></ul>	<ul style="list-style-type: none"><li>• Repeat download</li><li>• Correct CAN settings in the project and regenerate project.</li></ul>

#### CAN module (MXI2) RPDO1: Telegram not received or faulty [0x00b00000]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C14591/1</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN-IN 1 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• PDO time monitoring has released.</li></ul>	<ul style="list-style-type: none"><li>• Set the correct telegram length for the CAN master (transmitter).</li><li>• Remove electromagnetic interference (e.g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN module (MXI2) RPDO2: Telegram not received or faulty [0x00b00001]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C14591/2</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN-IN 2 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• PDO time monitoring has released.</li></ul>	<ul style="list-style-type: none"><li>• Set the correct telegram length for the CAN master (transmitter).</li><li>• Remove electromagnetic interference (e.g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

#### CAN module (MXI2) RPDO3: Telegram not received or faulty [0x00b00002]

<b>Response</b> (Lenze setting printed in bold) <b>Setting:</b> <a href="#">C14591/3</a> ( <input checked="" type="checkbox"/> Adjustable response) <input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> <b>Fault</b> <input checked="" type="checkbox"/> <b>Trouble</b> <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information	
<b>Cause</b>	<b>Remedy</b>
CANopen communication module in MXI2: CAN-IN 3 error <ul style="list-style-type: none"><li>• Incorrect PDO telegram length.</li><li>• Transmission error.</li><li>• PDO time monitoring has released.</li></ul>	<ul style="list-style-type: none"><li>• Set the correct telegram length for the CAN master (transmitter).</li><li>• Remove electromagnetic interference (e.g. EMC).</li><li>• Select a different time monitoring or switch off time monitoring.</li></ul>

### CAN module (MXI2) RPDO4: Telegram not received or faulty [0x00b00003]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14591/4</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: CAN-IN 4 error	<ul style="list-style-type: none"> <li>• Set the correct telegram length for the CAN master (transmitter).</li> <li>• Remove electromagnetic interference (e.g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• PDO time monitoring has released.</li> </ul>		

### CAN module (MXI2) RPDO5: Telegram not received or faulty [0x00b00004]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14591/5</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: CAN-IN 5 error	<ul style="list-style-type: none"> <li>• Set the correct telegram length for the CAN master (transmitter).</li> <li>• Remove electromagnetic interference (e.g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• PDO time monitoring has released.</li> </ul>		

### CAN module (MXI2) RPDO6: Telegram not received or faulty [0x00b00005]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14591/6</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: CAN-IN 6 error	<ul style="list-style-type: none"> <li>• Set the correct telegram length for the CAN master (transmitter).</li> <li>• Remove electromagnetic interference (e.g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• PDO time monitoring has released.</li> </ul>		

### CAN module (MXI2) RPDO7: Telegram not received or faulty [0x00b00006]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14591/7</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: CAN-IN 7 error	<ul style="list-style-type: none"> <li>• Set the correct telegram length for the CAN master (transmitter).</li> <li>• Remove electromagnetic interference (e.g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• PDO time monitoring has released.</li> </ul>		

### CAN module (MXI2) RPDO8: Telegram not received or faulty [0x00b00007]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C14591/8</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
Cause	Remedy	
CANopen communication module in MXI2: CAN-IN 8 error	<ul style="list-style-type: none"> <li>• Set the correct telegram length for the CAN master (transmitter).</li> <li>• Remove electromagnetic interference (e.g. EMC).</li> <li>• Select a different time monitoring or switch off time monitoring.</li> </ul>	
<ul style="list-style-type: none"> <li>• Incorrect PDO telegram length.</li> <li>• Transmission error.</li> <li>• PDO time monitoring has released.</li> </ul>		

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### CAN module (MXI2) PDO manager: Faulty configuration [0x00b00008]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

Cause

CANopen communication module in MXI2: CAN-PDO configuration error

- Faulty project download.
- Invalid CAN settings according to DS301V402 in the Engineer or PLC Designer.
- Mapping variables have incorrect CANopen indices according to DS405.

Remedy

- Repeat download.
- Correct CAN settings in the project and regenerate project.

#### CAN module (MXI2) SDO server: Faulty configuration [0x00b10000]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

Cause

CANopen communication module in MXI2: In the CAN SDP server a configuration error has occurred.

- Faulty project download.
- Invalid SDO server settings according to DS301V402 in the Engineer or PLC Designer.

Remedy

- Repeat download.
- Correct CAN settings in the project and regenerate project.

#### CAN module (MXI2) SDO client: Faulty configuration [0x00b20000]

Response (Lenze setting printed in bold)

None  System fault  Fault  Trouble  Quick stop by trouble  **Warning locked**  Warning  Information

Cause

CANopen communication module in MXI2: In the CAN SDP client a configuration error has occurred.

- Faulty project download.
- Invalid SDO client settings according to DS301V402 in the Engineer or PLC Designer.

Remedy

- Repeat download
- Correct CAN settings in the project and regenerate project.

#### Invalid PLC configuration [0x00b80000]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

An invalid control configuration has occurred.

Remedy

Load other application.

#### Positive limit switch has tripped [0x00b80001]

Response (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

Cause

The [travel range limit switch](#) in positive traversing direction has tripped.

Remedy

Reset error message and [retract limit switch](#).

## Negative limit switch has tripped [0x00b80002]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

The [travel range limit switch](#) in negative traversing direction has tripped.

**Remedy**

Reset error message and [retract limit switch](#).

## Motor brake: Angular drift with closed brake is too large [0x00b80003]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Despite the applied brake, the stop position of the motor axis has changed by more than the permissible angle of rotation set in [C02595](#).

**Remedy**

- Deactivate standstill monitoring ([C02595](#) = 0).
- Increase waiting time for status monitoring ([C02591](#)). The standstill monitoring only starts after this waiting time has elapsed.
- Increase brake closing time ([C02589](#)) since during the brake closing time the standstill monitoring is not active.
- Reduce threshold for brake activation ([C02581](#)).

## Motor brake: Automatically activated when the waiting time has elapsed [0x00b80004]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

This time monitoring will only be active if the speed setpoint has reached the threshold for brake activation ([C02581](#)).  
If the actual speed value does not reach/fall below the threshold set in [C02581](#) within the parameterised waiting time for brake activation ([C02593](#)), the brake will be closed due to time-out.

**Remedy**

- Increase waiting time for brake activation ([C02593](#)).
- Reduce threshold for brake activation ([C02581](#)).

## Motor brake: Status monitoring error [0x00b80005]

**Response** (Lenze setting printed in bold)

None  System fault  **Fault**  Trouble  Quick stop by trouble  Warning locked  Warning  Information

**Cause**

Faulty external feedback of the brake status to the brake control.

**Remedy**

- Check brake configuration with regard to the control selection in [C02580](#).
- Check setting for status input monitoring in [C02583](#). When monitoring is active, the `bBrakeApplied` input must be triggered correctly (`bBrakeApplied = bBrakeReleased`).
- Check voltage supply of the brake module.

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Positive software limit switch has been overtravelled [0x00b80007]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/2</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The positive software limit position parameterised in <a href="#">C02702/2</a> has been overtravelled.	<ul style="list-style-type: none"><li>• Position within the software limit positions.</li><li>• Increase permissible traversing range (change setting of the software limit positions).</li><li>• Deactivate monitoring of the software limit positions by the basic function "Limiter".</li></ul>	

#### Negative software limit switch has been overtravelled [0x00b80008]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/2</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The negative software limit position parameterised in <a href="#">C02702/1</a> has been overtravelled.	<ul style="list-style-type: none"><li>• Position within the software limit positions.</li><li>• Increase permissible traversing range (change setting of the software limit positions).</li><li>• Deactivate monitoring of the software limit positions by the basic function "Limiter".</li></ul>	

#### Positive direction of rotation has been limited [0x00b80009]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/1</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Due to the setting of <a href="#">C02707</a> it was tried to traverse in the impermissible positive direction of rotation.	<ul style="list-style-type: none"><li>• Only traverse in permissible (negative) direction of rotation.</li><li>• Change setting of the permissible direction of rotation (<a href="#">C02707</a>).</li></ul>	

#### Negative direction of rotation has been limited [0x00b8000a]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/1</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
Due to the setting of <a href="#">C02707</a> it was tried to traverse in the impermissible negative direction of rotation.	<ul style="list-style-type: none"><li>• Only traverse in permissible (positive) direction of rotation.</li><li>• Change setting of the permissible direction of rotation (<a href="#">C02707</a>).</li></ul>	

#### Speed has been limited [0x00b8000b]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The requested profile speed is higher than the maximum speed set in <a href="#">C02703</a> and has been limited to this speed.	<ul style="list-style-type: none"><li>• Reduce speed of the traversing profile of the basic function (manual jog, referencing or positioning).</li><li>• Increase maximum speed (<a href="#">C02703</a>).</li><li>• Deactivate monitoring of the limit values by the basic function "Limiter".</li></ul>	

### Acceleration has been limited [0x00b8000c]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The requested profile acceleration is higher than the maximum acceleration set in <a href="#">C02705</a> and has been limited to this acceleration.	<ul style="list-style-type: none"> <li>• Reduce acceleration of the traversing profile of the basic function (manual jog, referencing or positioning).</li> <li>• Increase maximum acceleration (<a href="#">C02705</a>).</li> <li>• Deactivate monitoring of the limit values by the basic function "Limiter".</li> </ul>	

### Deceleration has been limited [0x00b8000d]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The requested profile deceleration is higher than the maximum acceleration set in <a href="#">C02705</a> and has been limited to this acceleration.	<ul style="list-style-type: none"> <li>• Reduce acceleration of the traversing profile of the basic function (manual jog, referencing or positioning).</li> <li>• Increase maximum acceleration (<a href="#">C02705</a>).</li> <li>• Deactivate monitoring of the limit values by the basic function "Limiter".</li> </ul>	

### Jerk has been limited [0x00b8000e]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The requested S-ramp time is lower than the minimum S-ramp time set in <a href="#">C02706</a> and has been limited to this S-ramp time.	<ul style="list-style-type: none"> <li>• Increase S-ramp time of the traversing profile of the basic function (manual jog, referencing or positioning).</li> <li>• Reduce minimum S-ramp time (<a href="#">C02706</a>).</li> <li>• Deactivate monitoring of the limit values by the basic function "Limiter".</li> </ul>	

### Position target is outside software limit positions [0x00b8000f]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/2</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> None <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
It was tried to position to a target outside the software limit positions.	<ul style="list-style-type: none"> <li>• Select position target inside the software limit positions.</li> <li>• Increase permissible traversing range (change setting of the software limit positions).</li> <li>• Deactivate monitoring of the software limit positions by the basic function "Limiter".</li> </ul>	

# 9400 HighLine | Parameter setting & configuration

## Diagnostics & error analysis

### Error messages of the operating system

#### Maximum speed has been exceeded [0x00b80010]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The max. speed parameterised in <a href="#">C02703</a> has been exceeded.	<ul style="list-style-type: none"><li>• Reduce speed.</li><li>• Increase maximum speed (<a href="#">C02703</a>).</li><li>• Deactivate monitoring of the limit values by the basic function "Limiter".</li></ul>	

#### Maximum acceleration has been exceeded [0x00b80011]

<b>Response</b> (Lenze setting printed in bold)		<b>Setting:</b> <a href="#">C02716/3</a> ( <input checked="" type="checkbox"/> Adjustable response)
<input checked="" type="checkbox"/> <b>None</b> <input type="checkbox"/> System fault <input checked="" type="checkbox"/> Fault <input checked="" type="checkbox"/> Trouble <input checked="" type="checkbox"/> Quick stop by trouble <input checked="" type="checkbox"/> Warning locked <input checked="" type="checkbox"/> Warning <input checked="" type="checkbox"/> Information		
<b>Cause</b>	<b>Remedy</b>	
The max. acceleration parameterised in <a href="#">C02705</a> has been exceeded.	<ul style="list-style-type: none"><li>• Reduce acceleration.</li><li>• Increase maximum acceleration (<a href="#">C02705</a>).</li><li>• Deactivate monitoring of the limit values by the basic function "Limiter".</li></ul>	



## 16 Parameter reference

All parameters for controller parameter setting or monitoring are stored within so-called "codes".

- ▶ The codes are numbered and designated by a "C" in front of the code, e.g. "C00002".
- ▶ For the sake of clarity, some codes contain "subcodes" for saving parameters. This Manual uses a slash "/" as a separator between code and subcode, e.g. C00118/3".



### Tip!

For quick reference of a parameter with a certain name simply use the **index** of the online documentation. The index always contains the corresponding code in parentheses behind the name.

For general information on how to read and change parameters please see the online documentation for the »Engineer«.

### 16.1 Structure of the parameter descriptions

Each parameter is described in the [Parameter list](#) in the form of a table which consists of the following three areas:

#### Table header

The table header contains the following general notes:

- ▶ Parameter number (Cxxxxx)
- ▶ Parameter name (display text in the »Engineer« and keypad)
- ▶ [Data type](#)
- ▶ Decimal and hexadecimal parameter index for access via bus systems

#### Table contents

The table contains further general explanations & notes on the parameter and the possible settings the representation of which depends on the parameter type:

- ▶ [Parameters with read-only access](#)
- ▶ [Parameters with write access](#)

#### Table footer

The table footer contains the [Parameter attributes](#).

#### 16.1.1 Data type

The following data types are available for parameters:

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Structure of the parameter descriptions

Data type	Meaning
INTEGER_8	8-bit value with sign
INTEGER_16	16-bit value with sign
INTEGER_32	32-bit value with sign
INTEGER_64	64-bit value with sign
UNSIGNED_8	8-bit value without sign
UNSIGNED_16	16-bit value without sign
UNSIGNED_32	32-bit value without sign
UNSIGNED_64	64-bit value without sign
FLOATING_POINT	32-bit floating point number
VISIBLE_STRING	String of digits from printable digits
OCTET_STRING	String of digits from any digits
BITFIELD_8	8-bit value bit coded
BITFIELD_16	16-bit value bit coded
BITFIELD_32	32-bit value bit coded

## 16.1.2 Parameters with read-only access

Parameters for which the "write access" attribute has not been set can only be read and not be changed by the user.

### Description structure

Parameter Name: Cxxxxx   _____	Data type: _____ Index: _____
Description	
Display range (min. value   unit   max. value)	
_____	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

### Representation in the »Engineer«

- ▶ The »Engineer« displays these parameters with a grey background or, with an online connection, with a pale-yellow background:

	C	S...	Name	Value	Unit
	61	0	Heatsink temperature	30	°C

## 16.1.3 Parameters with write access

Only parameters with a check mark (☑) in front of the "write access" attribute can be changed by the user. The Lenze setting for these parameters is **printed in bold**.

- ▶ The settings are either selected by means of a selection list or through direct value entry.
- ▶ Values outside the valid setting range are represented in red in the »Engineer«.

### 16.1.3.1 Parameters with setting range

#### Description structure

Parameter   Name: Cxxxxx   _____	Data type: _____ Index: _____
Description	
<b>Setting range (min. value   unit   max. value)</b>	<b>Lenze setting</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

#### Parameter setting in the »Engineer«

- ▶ In the »Engineer«, parameters are set by entering the desired value into the input field or by means of the arrow buttons:

✓	C	S...	Name	Value	Unit
		0	Encoder voltage	5	V

- ▶ Alternatively, the indicated value can be step-by-step increased or reduced by means of the arrow buttons.

### 16.1.3.2 Parameters with selection list

#### Description structure

Parameter   Name: Cxxxxx   _____	Data type: _____ Index: _____
Description	
<b>Selection list (Lenze setting printed in bold)</b>	
<b>1</b>	
2	
3	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

#### Parameter setting in the »Engineer«

- ▶ In the »Engineer«, a list field is used for parameter setting:

✓	C	S...	Name	Value	Unit
		0	Encoder type	1: Sin/cos encoder	

0: Incremental encoder (TTL signal)

**1: Sin/cos encoder**

2: Absolute value encoder (Hiperface)

3: Absolute value encoder (EnDat)


## 16.1.3.3 Parameters with bit-code setting

### Description structure

Parameter   Name: Cxxxxx   _____	Data type: _____ Index: _____
Description	
<b>Value is bit-coded:</b>	
Bit 0	
...	
Bit 31	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

### Parameter setting in the »Engineer«

- ▶ The »Engineer« uses a dialog box for parameter setting in which the individual bits can be set or reset or, alternatively, the value can be entered as a decimal or hexadecimal value:



16.1.3.4 Parameters with subcodes

Description structure

Parameter   Name: Cxxxxx   _____		Data type: _____ Index: _____
Description		
Setting range (min. value   unit   max. value)		
<b>Subcodes</b>	<b>Lenze setting</b>	
Cxxxxx/1		
Cxxxxx/2		
Cxxxxx/3		
Cxxxxx/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

Parameter setting in the »Engineer«

- ▶ The »Engineer« parameter list lists all subcodes separately:

		C	S...	Name	Value	Unit
114	1			Dlx terminal polarity	0	
114	2			Dlx terminal polarity	0	
114	3			Dlx terminal polarity	0	
114	4			Dlx terminal polarity	0	

- ▶ The parameters are set as described in the previous chapters.

## 16.1.4 Parameter attributes

### Type of access

► The first four attributes provide information about the parameter access:

Attribute	Meaning
<input checked="" type="checkbox"/> Read access	Read access to parameter possible.
<input checked="" type="checkbox"/> Write access	Write access to parameter possible. <ul style="list-style-type: none"><li>• Please also observe the following attributes:</li></ul>
<input checked="" type="checkbox"/> CINH	Parameter value can only be changed when the controller is inhibited.
<input checked="" type="checkbox"/> PLC STOP	Change of the parameter value is only possible when the application is stopped.

### Additional features

► The following attributes refer to the parameter set transfer to the controller:

Attribute	Meaning
<input checked="" type="checkbox"/> No transfer	Parameter is <b>not</b> transferred to controller when the command <b>Download parameter set</b> is executed.
<input checked="" type="checkbox"/> COM	"PC communication parameter" <ul style="list-style-type: none"><li>• In the <i>Download parameter set</i> or <i>Download application</i> dialog box, you can select that PC communication parameters are <b>not</b> to be transferred to the controller.</li></ul>
<input checked="" type="checkbox"/> MOT	"Motor data parameter" <ul style="list-style-type: none"><li>• In the <i>Download parameter set</i> or <i>Download application</i> dialog box, you can select that motor data parameters are <b>not</b> to be transferred to the controller.</li></ul>

### Scaling factor

► The "scaling factor" is important for parameter access via bus systems. It is only indicated for parameters using a data format with decimal positions:

$$\text{Read value (via bus system)} = \text{Scaling factor} \cdot \text{indicated value (Engineer)}$$

## 16.2 Abbreviations used in parameter & selection texts

Since the parameter/selection texts are limited to 31 characters, the following abbreviations are used:

Abbreviation	Meaning
CAN module	CANopen communication module (type E94AYCCA)
DF module	Digital frequency extension module (type E94AYFLF)
ETS	Electronic nameplate
Ethernet module	Ethernet communication module (type E94AYCEN)
MXI1	<i>eXtension Interface module 1</i> - module receptacle for extension 1
MXI2	<i>eXtension Interface module 2</i> - module receptacle for extension 2
Profibus module	PROFIBUS communication module (type E94AYCPM)

### Abbreviated units

Abbreviation	Meaning
Incr.	Increments
Rev.	Revolutions

## 16.3 Parameter list

This chapter describes all parameters of the operating system in numerically ascending order.

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00002

C00002

Parameter   Name: <b>C00002   Controller commands</b>		Data type: UNSIGNED_32 Index: 24573 <sub>d</sub> = 5FFD <sub>h</sub>
Controller commands		
<ul style="list-style-type: none"> <li>• <a href="#">C00003</a> shows the status of the last executed controller command.</li> <li>• Under <a href="#">C00150</a> you can query the current status of the device control.</li> </ul>		
Selection list (Lenze setting printed in bold)		Information
0	Load Lenze setting	Resets parameters to Lenze setting. <ul style="list-style-type: none"> <li>• Only possible when the application has stopped and the controller is inhibited.</li> </ul>
1	Load start parameters	Loads parameters from the memory module. <ul style="list-style-type: none"> <li>• Only possible when the application has stopped and the controller is inhibited.</li> </ul>
5	Activate application	Activates the application selected under <a href="#">C00005</a> . <ul style="list-style-type: none"> <li>• If the application is also started, depends on the auto-start setting selected.</li> <li>• Only possible when the application has stopped.</li> </ul>
7	Save selected application	Selects the active application as start application.
11	Save start parameters	Saves parameters fail-safe in the memory module.
20	Delete logbook	Deletes all logbook entries.
21	Archive log file	Exports logbook entries to file.
31	Start application	
32	Stop application	
33	Reset program	Executes a reset <ul style="list-style-type: none"> <li>• All variables except for the RETAIN variables are reset to their initialisation value.</li> <li>• The situation corresponds to a power failure or deactivation/activation of the controller (warm start) while the program is running.</li> </ul>
34	Delete program	Executes a reset (original) <ul style="list-style-type: none"> <li>• All variables including RETAIN and PERSISTENT variables are reset to their initialisation value.</li> <li>• The application program is deleted and the controller is reset to its original status.</li> </ul>
35	Restart program	Executes a reset (warm start) <ul style="list-style-type: none"> <li>• All variables except for the PERSISTENT variables are reset to their initialisation value.</li> <li>• The situation corresponds to the start of a new program loaded into the control (cold start).</li> </ul>
36	Reset runtime measurement	
41	Inhibit controller	
42	Enable controller	
43	Reset error	
45	Activate quick stop	▶ " <a href="#">Basic functionQuick stop</a> "
46	Quick stop reset	▶ " <a href="#">Basic functionQuick stop</a> "
47	Internal command 47	For Lenze service only
48	Internal command 48	For Lenze service only



Parameter   Name: <b>C00002   Controller commands</b>		Data type: UNSIGNED_32 Index: 24573 <sub>d</sub> = 5FFD <sub>h</sub>
51	Set rotor displacement angle	<p>Executes rotor position adjustment</p> <ul style="list-style-type: none"> <li>The function can only be activated when the controller is inhibited.</li> <li>After this, the adjustment starts automatically when the controller is enabled.</li> <li>During the rotor position adjustment, the motor makes one electrical revolution. This leads to a mechanical rotation of the motor shaft.</li> <li>The determined rotor angle is indicated under code <a href="#">C00058</a>.</li> </ul> <p>► <a href="#">Motor interface</a></p>
71	Calculate inv. characteristic	<p>Detects inverter error characteristic</p> <ul style="list-style-type: none"> <li>The function can only be activated when the controller is inhibited.</li> <li>After this, the adjustment starts automatically when the controller is enabled.</li> </ul> <p>► <a href="#">Motor interface</a></p>
72	Set motor parameters	<p>Automatically detects motor parameter</p> <ul style="list-style-type: none"> <li>The function can only be activated when the controller is inhibited.</li> <li>After this, the adjustment starts automatically when the controller is enabled.</li> </ul> <p>► <a href="#">Motor interface</a></p>
91	CAN on board: reset node	<p>Reinitialises the "CAN on-board" interface.</p> <ul style="list-style-type: none"> <li>Required when the baud rate, node address or identifiers are changed.</li> </ul>
92	CAN module: reset node	<p>Reinitialises CANopen interface of the CANopen communication module.</p> <ul style="list-style-type: none"> <li>Required when the baud rate, node address or identifiers are changed.</li> </ul>
93	CAN on-board: Pred.Connect.Set	<p>Sets basic identifier for the "CAN on board" interface according to the "Predefined Connection Set" (DS301V402).</p>
94	CAN module: Pred.Connect.Set	<p>Sets basic identifier for the CANopen interface of the CANopen communication module according to the "Predefined Connection Set" (DS301V402).</p>
95	CAN on-board: Identify node	<p>Detects nodes connected to the "CAN on board" interface.</p> <ul style="list-style-type: none"> <li>The result of the CAN bus scan is displayed in <a href="#">C00393</a>.</li> </ul>
96	CAN module: Identify node	<p>Detects the nodes connected to the CANopen interface of the CANopen communication module.</p> <ul style="list-style-type: none"> <li>The result of the CAN bus scan is displayed in <a href="#">C00393</a>.</li> </ul>
101	Unbind/bind Ethernet module MXI1	<p>Reinitialises the Ethernet interface of the Ethernet communication module in the module receptacle MXI1.</p> <ul style="list-style-type: none"> <li>Required when a new IP or gateway address is to be accepted without mains switching.</li> </ul>
102	Unbind/bind Ethernet module MXI2	<p>Reinitialises the Ethernet interface of the Ethernet communication module in the module receptacle MXI2.</p> <ul style="list-style-type: none"> <li>Required when a new IP or gateway address is to be accepted without mains switching.</li> </ul>
201	Activate parameter set 1	<p>Loads parameter set 1 from the memory module.</p> <ul style="list-style-type: none"> <li>Only possible when the application has stopped and the controller is inhibited.</li> </ul>
202	Activate parameter set 2	<p>Loads parameter set 2 from the memory module.</p> <ul style="list-style-type: none"> <li>Only possible when the application has stopped and the controller is inhibited.</li> </ul>

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00003

Parameter   Name:		Data type: UNSIGNED_32 Index: 24573 <sub>d</sub> = 5FFD <sub>h</sub>
<b>C00002   Controller commands</b>		
203	Activate parameter set 3	Loads parameter set 3 from the memory module. • Only possible when the application has stopped and the controller is inhibited.
204	Activate parameter set 4	Loads parameter set 4 from the memory module. • Only possible when the application has stopped and the controller is inhibited.
301	Archive parameter set 1	Stores the current parameter set as parameter set 1 in the memory module.
302	Archive parameter set 2	Stores the current parameter set as parameter set 2 in the memory module.
303	Archive parameter set 3	Stores the current parameter set as parameter set 3 in the memory module.
304	Archive parameter set 4	Stores the current parameter set as parameter set 4 in the memory module.
401	Internal command 401	For Lenze service only
730	Internal command 730	For Lenze service only
731	Internal command 731	For Lenze service only
732	Internal command 732	For Lenze service only
733	Internal command 733	For Lenze service only
800	Internal command 800	For Lenze service only
1001	Internal command 1001	For Lenze service only
1020	Internal command 1020	For Lenze service only
1021	Export parameters to file	Export current parameter set to file.
1030	Format file system	Format file system of the memory module.
1040	Restore file system	
10000	Prepare firmware update	
11000	Restart controller	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00003

Parameter   Name:		Data type: UNSIGNED_32 Index: 24572 <sub>d</sub> = 5FFC <sub>h</sub>
<b>C00003   Controller command status</b>		
Display of the number/status of the device command last executed ( <a href="#">C00002</a> ).		
<ul style="list-style-type: none"> <li>The number of the command stands in the upper 16 bits (for the meaning of the number, see code <a href="#">C00002</a>).</li> <li>The result of the command stands in the lower 16 bits.</li> </ul>		
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00004

Parameter   Name:		Data type: UNSIGNED_32 Index: 24571 <sub>d</sub> = 5FFB <sub>h</sub>
<b>C00004   Service password</b>		
Service code to unlock protected device commands ( <a href="#">C00002</a> ).		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0		4294967295
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00005

Parameter   Name: <b>C00005   Application selection</b>		Data type: INTEGER_32 Index: 24570 <sub>d</sub> = 5FFA <sub>h</sub>
Application selection		
• Use the controller command <a href="#">C00002</a> ="5" to activate the selected application.		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
-1		16 <b>0</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00006

Parameter   Name: <b>C00006   Motor control selection</b>		Data type: UNSIGNED_32 Index: 24569 <sub>d</sub> = 5FF9 <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>		<b>Information</b>
<b>1</b>	<b>Servo control with SM</b>	For synchronous motors with speed sensor
2	Servo controller with ASM	For asynchronous motors with speed sensor
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C00007

Parameter   Name: <b>C00007   Active application</b>		Data type: UNSIGNED_32 Index: 24568 <sub>d</sub> = 5FF8 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00011

Parameter   Name: <b>C00011   Motor reference speed</b>		Data type: UNSIGNED_32 Index: 24564 <sub>d</sub> = 5FF4 <sub>h</sub>
For parameter setting via interface: In case of bigger changes, only change the setting in one step when the controller is inhibited!		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
50	rpm	50000 <b>3000 rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C00018

Parameter   Name: <b>C00018   Chopper frequency</b>		Data type: UNSIGNED_32 Index: 24557 <sub>d</sub> = 5FED <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>		<b>Information</b>
2	1 kHz fixed	<b>Note:</b> The maximum output frequency of the controller is limited to 1/8 of the switching frequency selected here!
3	2 kHz fixed	
4	4 kHz fixed	
5	8 kHz fixed	
8	2 kHz variable	
9	4 kHz variable	
<b>10</b>	<b>8 kHz variable</b>	
11	16 kHz variable	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C00019

Parameter   Name: <b>C00019   Zero speed detection threshold</b>		Data type: UNSIGNED_32 Index: 24556 <sub>d</sub> = 5FEC <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	rpm	450 <b>5 rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00022

C00022

Parameter   Name: <b>C00022   Maximum current</b>			Data type: UNSIGNED_32 Index: 24553 <sub>d</sub> = 5FE9 <sub>h</sub>
<b>Note:</b> In order that the motor does not start unintentionally without adjusting the route data, the maximum current in the Lenze setting is set to "0 A"!			
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0.00	A	21474836.47	<b>0.00 A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                 Scaling factor: 100			

C00034

Parameter   Name: <b>C00034   Config. analog input 1</b>			Data type: UNSIGNED_32 Index: 24541 <sub>d</sub> = 5FDD <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>			
<b>0</b>	<b>-10 ... +10 V</b>		
1	-20...-4 mA, +4...+20 mA		
2	-20 ... +20 mA		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00050

Parameter   Name: <b>C00050   Speed setpoint</b>			Data type: INTEGER_32 Index: 24525 <sub>d</sub> = 5FCD <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
-480000	rpm	480000	
<b>Subcodes</b>			<b>Information</b>
C00050/1			Speed setpoint 1
C00050/2			Speed setpoint 2
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00051

Parameter   Name: <b>C00051   Actual speed</b>			Data type: INTEGER_32 Index: 24524 <sub>d</sub> = 5FCB <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
-480000	rpm	480000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00052

Parameter   Name: <b>C00052   Motor voltage</b>			Data type: UNSIGNED_32 Index: 24523 <sub>d</sub> = 5FCB <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
0	V	21474836.47	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00053

Parameter   Name: <b>C00053   DC bus voltage</b>			Data type: UNSIGNED_32 Index: 24522 <sub>d</sub> = 5FCA <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
0	V	21474836.47	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00054

Parameter   Name: <b>C00054   Motor current</b>			Data type: UNSIGNED_32 Index: 24521 <sub>d</sub> = 5FC9 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
0.00	A	500.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 100			

## C00055

Parameter   Name: <b>C00055   Phase currents</b>		Data type: INTEGER_32 Index: 24520 <sub>d</sub> = 5FC8 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
-500.00	A	500.00
<b>Subcodes</b>	<b>Information</b>	
C00055/1	Zero phase-sequence system	
C00055/2	Phase U	
C00055/3	Phase V	
C00055/4	Phase W	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

## C00056

Parameter   Name: <b>C00056   Torque setpoint</b>		Data type: INTEGER_32 Index: 24519 <sub>d</sub> = 5FC7 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

## C00057

Parameter   Name: <b>C00057   Torque</b>		Data type: UNSIGNED_32 Index: 24518 <sub>d</sub> = 5FC6 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0.000	Nm	2147483.647
<b>Subcodes</b>	<b>Information</b>	
C00057/1	Maximum torque	
C00057/2	Torque at maximum current ( <a href="#">C00022</a> )	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 1000		

## C00058

Parameter   Name: <b>C00058   Rotor displacement angle</b>		Data type: INTEGER_32 Index: 24517 <sub>d</sub> = 5FC5 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
-179.9	°	179.9
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00058/1	-90.0 °	Rotor displ. angle resolver
C00058/2	0.0 °	Rotor displ. angle encoder
C00058/3	0.0 °	Rotor displ. angle module
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 10		

## C00059

Parameter   Name: <b>C00059   Motor - pole pair number</b>		Data type: UNSIGNED_32 Index: 24516 <sub>d</sub> = 5FC4 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0		200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00060

Parameter   Name: <b>C00060   Rotor position</b>		Data type: INTEGER_32 Index: 24515 <sub>d</sub> = 5FC3 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0		2047
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00061

C00061

Parameter   Name: <b>C00061   Heatsink temperature</b>		Data type: INTEGER_32 Index: 24514 <sub>d</sub> = 5FC2 <sub>h</sub>
Display range (min. value   unit   max. value)		
-200	°C	200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00062

Parameter   Name: <b>C00062   Temp. inside the controller</b>		Data type: INTEGER_32 Index: 24513 <sub>d</sub> = 5FC1 <sub>h</sub>
Display range (min. value   unit   max. value)		
-200	°C	200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00063

Parameter   Name: <b>C00063   Motor temperature</b>		Data type: INTEGER_32 Index: 24512 <sub>d</sub> = 5FC0 <sub>h</sub>
Display range (min. value   unit   max. value)		
-200	°C	200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00064

Parameter   Name: <b>C00064   Device utilisation (Ixt)</b>		Data type: UNSIGNED_32 Index: 24511 <sub>d</sub> = 5FBF <sub>h</sub>
Controller load during the last 180 seconds		
<ul style="list-style-type: none"><li>• C00064 &gt; 100 % activates error (OC5).</li><li>• Error reset only possible if C00064 &lt; 95 %.</li></ul>		
Display range (min. value   unit   max. value)		
0	%	250
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00065

Parameter   Name: <b>C00065   Ext. 24-V voltage</b>		Data type: INTEGER_32 Index: 24510 <sub>d</sub> = 5FBE <sub>h</sub>
Display range (min. value   unit   max. value)		
0.0	V	1000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT    Scaling factor: 10		

C00066

Parameter   Name: <b>C00066   Thermal motor load (I<sup>2</sup>xt)</b>		Data type: UNSIGNED_32 Index: 24509 <sub>d</sub> = 5FBD <sub>h</sub>
A 100 % load corresponds to a permanently flowing rated motor current		
Display range (min. value   unit   max. value)		
0	%	250
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00068

Parameter   Name: <b>C00068   Capacitor temperature</b>		Data type: INTEGER_32 Index: 24507 <sub>d</sub> = 5FBB <sub>h</sub>
Display range (min. value   unit   max. value)		
-200	°C	200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00069

Parameter   Name: <b>C00069   CPU temperature</b>		Data type: INTEGER_32 Index: 24506 <sub>d</sub> = 5FB4 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
-200	°C	200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00070

Parameter   Name: <b>C00070   Speed controller gain</b>		Data type: UNSIGNED_32 Index: 24505 <sub>d</sub> = 5FB9 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	Nm/rpm	2000000000 <b>44 Nm/rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 100000		

C00071

Parameter   Name: <b>C00071   Speed contr. reset time</b>		Data type: UNSIGNED_32 Index: 24504 <sub>d</sub> = 5FB8 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
1.0	ms	6000.0 <b>14.4 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 10		

C00072

Parameter   Name: <b>C00072   Speed controller D component</b>		Data type: UNSIGNED_32 Index: 24503 <sub>d</sub> = 5FB7 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.00	ms	3.00 <b>0.00 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 100		

C00074

Parameter   Name: <b>C00074   current controller feedforward control</b>		Data type: UNSIGNED_8 Index: 24501 <sub>d</sub> = 5FB5 <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Deactivate feedforward control</b>	
1	Activate feedforward control	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00075

Parameter   Name: <b>C00075   Current controller gain</b>		Data type: UNSIGNED_32 Index: 24500 <sub>d</sub> = 5FB4 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.00	V/A	750.00 <b>105.00 V/A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 100		

C00076

Parameter   Name: <b>C00076   Current contr. integr.-act. time</b>		Data type: UNSIGNED_32 Index: 24499 <sub>d</sub> = 5FB3 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.01	ms	2000.00 <b>2.00 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 100		

C00077

Parameter   Name: <b>C00077   Field controller gain</b>		Data type: UNSIGNED_32 Index: 24498 <sub>d</sub> = 5FB2 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.00	A/Vs	50000.00 <b>165.84 A/Vs</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 100		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00078

C00078

Parameter   Name: <b>C00078   Field contr. reset time</b>			Data type: UNSIGNED_32 Index: 24497 <sub>d</sub> = 5FB1 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
1.0	ms	6000.0	<b>15.1 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 10			

C00079

Parameter   Name: <b>C00079   Motor - mutual inductance</b>			Data type: UNSIGNED_32 Index: 24496 <sub>d</sub> = 5FB0 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
0.0	mH	214748364.7	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10			

C00080

Parameter   Name: <b>C00080   Resolver - number of pole pairs</b>			Data type: UNSIGNED_32 Index: 24495 <sub>d</sub> = 5FAF <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
1		10	<b>1</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT			

C00081

Parameter   Name: <b>C00081   Rated motor power</b>			Data type: UNSIGNED_32 Index: 24494 <sub>d</sub> = 5FAE <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.01	kW	500.00	<b>0.25 kW</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 100			

C00082

Parameter   Name: <b>C00082   Motor rotor resistance</b>			Data type: UNSIGNED_32 Index: 24493 <sub>d</sub> = 5FAD <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
0.0000	Ohm	214748.3647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000			

C00083

Parameter   Name: <b>C00083   Motor - rotor time constant</b>			Data type: UNSIGNED_32 Index: 24492 <sub>d</sub> = 5FAC <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
0.00	ms	21474836.47	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100			

C00084

Parameter   Name: <b>C00084   Motor stator resistance</b>			Data type: UNSIGNED_32 Index: 24491 <sub>d</sub> = 5FAB <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Ohm	125.0000	<b>18.2200 Ohm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 10000			

C00085

Parameter   Name: <b>C00085   Motor stator leakage induct.</b>			Data type: UNSIGNED_32 Index: 24490 <sub>d</sub> = 5FAA <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.000	mH	500.000	<b>51.000 mH</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 1000			



C00087

Parameter   Name: <b>C00087   Rated motor speed</b>		Data type: UNSIGNED_32 Index: 24488 <sub>d</sub> = 5FA8 <sub>h</sub>	
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
50	rpm	50000	<b>4050 rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT			

C00088

Parameter   Name: <b>C00088   Motor - rated current</b>		Data type: UNSIGNED_32 Index: 24487 <sub>d</sub> = 5FA7 <sub>h</sub>	
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.01	A	1500.00	<b>1.30 A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 100			

C00089

Parameter   Name: <b>C00089   Rated motor frequency</b>		Data type: UNSIGNED_32 Index: 24486 <sub>d</sub> = 5FA6 <sub>h</sub>	
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.1	Hz	1000.0	<b>270.0 Hz</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 10			

C00090

Parameter   Name: <b>C00090   Rated motor voltage</b>		Data type: UNSIGNED_32 Index: 24485 <sub>d</sub> = 5FA5 <sub>h</sub>	
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
50	V	15000	<b>225 V</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT			

C00091

Parameter   Name: <b>C00091   Motor - cosine phi</b>		Data type: UNSIGNED_32 Index: 24484 <sub>d</sub> = 5FA4 <sub>h</sub>	
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.50		1.00	<b>0.80</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 100			

C00092

Parameter   Name: <b>C00092   Motor - magnetising current</b>		Data type: UNSIGNED_32 Index: 24483 <sub>d</sub> = 5FA3 <sub>h</sub>	
<b>Display range (min. value   unit   max. value)</b>			
0.00	A	500.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100			

C00099

Parameter   Name: <b>C00099   Firmware version</b>		Data type: VISIBLE_STRING Index: 24476 <sub>d</sub> = 5F9C <sub>h</sub>	
Format: "xx.xx.xx.xx" (main version, subversion, release version, build number)			
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00100

Parameter   Name: <b>C00100   Service code</b>		Data type: UNSIGNED_32 Index: 24475 <sub>d</sub> = 5F9B <sub>h</sub>	
<b>This code is used internally by the controller and must not be overwritten by the user!</b>			

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00105

C00105

Parameter   Name: <b>C00105   Quick stop decel. time</b>		Data type: UNSIGNED_32 Index: 24470 <sub>d</sub> = 5F96 <sub>h</sub>
Time between quick stop activation and standstill plus relative inaccuracy time ( <a href="#">C00106</a> ). <span style="float: right;">▶ "<a href="#">Basic functionQuick stop</a>"</span>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.000	s	999.999 <b>0.000 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 1000		

C00106

Parameter   Name: <b>C00106   Quick stop S-ramp time</b>		Data type: UNSIGNED_32 Index: 24469 <sub>d</sub> = 5F95 <sub>h</sub>
S-ramp time in [%] referred to the deceleration time set under <a href="#">C00105</a> . <span style="float: right;">▶ "<a href="#">Basic functionQuick stop</a>"</span>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.00	%	100.00 <b>0.00 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

C00107

Parameter   Name: <b>C00107   Ref. quick stop decel. time</b>		Data type: UNSIGNED_8 Index: 24468 <sub>d</sub> = 5F94 <sub>h</sub>
Reference for the deceleration time set in <a href="#">C00105</a> . <span style="float: right;">▶ "<a href="#">Basic functionQuick stop</a>"</span>		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Reference = reference speed (C00011)</b>	
1	Ref. = Current speed	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00114

Parameter   Name: <b>C00114   DIx terminal polarity</b>		Data type: UNSIGNED_8 Index: 24461 <sub>d</sub> = 5F8D <sub>h</sub>
"0" = positive logic (HIGH level = TRUE, LOW level = FALSE) "1" = negative logic (HIGH level = FALSE, LOW level = TRUE)		
<b>Setting range (min. value   unit   max. value)</b>		
0		1
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00114/1	0	Terminal polarity of digital inputs 1 ... 8
C00114/...		
C00114/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00118

Parameter   Name: <b>C00118   DOx terminal polarity</b>		Data type: UNSIGNED_8 Index: 24457 <sub>d</sub> = 5F89 <sub>h</sub>
"0" ≡ positive logic (TRUE ≡ HIGH level, FALSE ≡ LOW level) "1" ≡ negative logic (FALSE ≡ HIGH level, TRUE ≡ LOW level)		
<b>Setting range (min. value   unit   max. value)</b>		
0		1
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00118/1	0	Terminal polarity of digital outputs 1 ... 4
C00118/...		
C00118/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

#### C00120

Parameter   Name:		Data type: UNSIGNED_32	
<b>C00120   Mot. overload protection (I<sup>2</sup>t)</b>		Index: 24453 <sub>d</sub> = 5F87 <sub>h</sub>	
Threshold for I <sup>2</sup> x t disconnection			
<ul style="list-style-type: none"> <li>Disconnection is carried out if the thermal motor load (<a href="#">C00066</a>) is higher than the set threshold.</li> <li>A 100 % thermal motor load corresponds to a permanently flowing rated motor current</li> </ul>			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	%	200	<b>105 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT			

#### C00121

Parameter   Name:		Data type: UNSIGNED_32	
<b>C00121   Motor temp. warning threshold</b>		Index: 24454 <sub>d</sub> = 5F86 <sub>h</sub>	
Temperature threshold for motor temperature advance warning			
<ul style="list-style-type: none"> <li>The reaction for reaching the threshold can be selected in <a href="#">C00584</a>.</li> </ul>			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	°C	150	<b>120 °C</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT			

#### C00122

Parameter   Name:		Data type: UNSIGNED_32	
<b>C00122   Heatsink temp. warn. threshold</b>		Index: 24453 <sub>d</sub> = 5F85 <sub>h</sub>	
Temperature threshold for heatsink temperature advance warning			
<ul style="list-style-type: none"> <li>The reaction for reaching the threshold can be selected in <a href="#">C00582</a>.</li> </ul>			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	°C	85	<b>85 °C</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

#### C00123

Parameter   Name:		Data type: UNSIGNED_32	
<b>C00123   Device util. warning threshold</b>		Index: 24452 <sub>d</sub> = 5F84 <sub>h</sub>	
Adjustable threshold for I x t advance warning			
<ul style="list-style-type: none"> <li>The advance warning is sent if the controller load (<a href="#">C00064</a>) is higher than the set threshold.</li> <li>The reaction for reaching the threshold can be selected in <a href="#">C00604</a>.</li> </ul>			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	%	100	<b>90 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

#### C00126

Parameter   Name:		Data type: UNSIGNED_32	
<b>C00126   CPU temp. warning threshold</b>		Index: 24449 <sub>d</sub> = 5F81 <sub>h</sub>	
Temperature threshold for advance warning of CPU temperature on the control card			
<ul style="list-style-type: none"> <li>The reaction for reaching the threshold can be selected in <a href="#">C00589</a>.</li> </ul>			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	°C	85	<b>70 °C</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

#### C00127

Parameter   Name:		Data type: UNSIGNED_32	
<b>C00127   Mot. overload warning threshold</b>		Index: 24448 <sub>d</sub> = 5F80 <sub>h</sub>	
Adjustable threshold for I <sup>2</sup> x t advance warning			
<ul style="list-style-type: none"> <li>The advance warning is sent if the thermal motor load (<a href="#">C00066</a>) is higher than the set threshold.</li> <li>The reaction for reaching the threshold can be selected in <a href="#">C00606</a>.</li> </ul>			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	%	200	<b>100 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT			

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00128

## C00128

Parameter   Name:		Data type: UNSIGNED_32 Index: 24447 <sub>d</sub> = 5F7F <sub>h</sub>	
<b>C00128   Therm. motor time constant</b>			
Setting range (min. value   unit   max. value)			
0.1	min	600.0	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>	
C00128/1	1.0 min	Therm. time constant coil	
C00128/2	5.0 min	Therm. time constant plates	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 10			

## C00129

Parameter   Name:		Data type: INTEGER_32 Index: 24446 <sub>d</sub> = 5F7E <sub>h</sub>	
<b>C00129   Brake resistance value</b>			
Required for monitoring of the brake resistor temperature.			
Setting range (min. value   unit   max. value)		Lenze setting	
0	Ohm	500	<b>180 Ohm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C00130

Parameter   Name:		Data type: INTEGER_32 Index: 24445 <sub>d</sub> = 5F7D <sub>h</sub>	
<b>C00130   Max. power of brake resistor</b>			
Required for monitoring of the brake resistor temperature.			
Setting range (min. value   unit   max. value)		Lenze setting	
0	W	800000	<b>5600 W</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C00131

Parameter   Name:		Data type: INTEGER_32 Index: 24444 <sub>d</sub> = 5F7C <sub>h</sub>	
<b>C00131   Therm. capacity of brake resistor</b>			
Required for monitoring of the brake resistor temperature.			
Setting range (min. value   unit   max. value)		Lenze setting	
0	kWs	1000	<b>485 kW</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C00132

Parameter   Name:		Data type: INTEGER_32 Index: 24443 <sub>d</sub> = 5F7B <sub>h</sub>	
<b>C00132   Max. temp. of brake resistor</b>			
When this temperature is reached, the brake resistor will be switched off and switched on again if the temperature is fallen below with a hysteresis of 5 K.			
Setting range (min. value   unit   max. value)		Lenze setting	
0	°C	1000	<b>200 °C</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C00142

Parameter   Name:		Data type: UNSIGNED_32 Index: 24433 <sub>d</sub> = 5F71 <sub>h</sub>	
<b>C00142   Autom. restart after mains ON</b>			
Starting performance of the controller after mains connection or fault			
Selection list (Lenze setting printed in bold)			
0	Inhibited		
1	<b>Enabled</b>		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C00150

Parameter | Name: **C00150 | Status word 1** Data type: BITFIELD\_16  
Index: 24425<sub>d</sub> = 5F69<sub>h</sub>

Status word 1 of the [drive interface](#)

Value is bit-coded:

Bit 0	User-defined status (bit 0)
Bit 1	Pulse inhibit active
Bit 2	User-defined status (bit 2)
Bit 3	User-defined status (bit 3)
Bit 4	User-defined status (bit 4)
Bit 5	User-defined status (bit 5)
Bit 6	Actual speed value = 0
Bit 7	Controller inhibit active
Bit 8	Device state - Bit 1
Bit 9	Device state - Bit 2
Bit 10	Device state - Bit 3
Bit 11	Device state - Bit 4
Bit 12	Warning active
Bit 13	Trouble active
Bit 14	User-defined status (bit 14)
Bit 15	User-defined status (bit 15)

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

## C00155

Parameter | Name: **C00155 | Status word 2** Data type: BITFIELD\_16  
Index: 24420<sub>d</sub> = 5F64<sub>h</sub>

Status word 2 of the [drive interface](#)

Value is bit-coded:

Bit 0	Error status active
Bit 1	Torque limit reached
Bit 2	Current limit reached
Bit 3	Reserved
Bit 4	Drive switched on/in operation
Bit 5	Drive ready for operation
Bit 6	Error active
Bit 7	Drive initialisation
Bit 8	Motor CCW rotation active
Bit 9	Quick stop by trouble active
Bit 10	Safe torque off active
Bit 11	Application active
Bit 12	Reserved
Bit 13	Reserved
Bit 14	Quick stop active
Bit 15	Reserved

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00156

## C00156

Parameter   Name: <b>C00156   Status/Control word MCTRL</b>		Data type: UNSIGNED_32 Index: 24419 <sub>d</sub> = 5F63 <sub>h</sub>
Status and control word of the <a href="#">motor interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<b>Subcodes</b>		<b>Information</b>
C00156/1		Status word motor control
C00156/2		Control word motor control
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00158

Parameter   Name: <b>C00158   Controller inhibit by (source)</b>		Data type: BITFIELD_16 Index: 24417 <sub>d</sub> = 5F61 <sub>h</sub>
<b>Value is bit-coded:</b>		
Bit 0	Terminal	
Bit 1	Reserved	
Bit 2	Reserved	
Bit 3	Reserved	
Bit 4	Application	
Bit 5	Controller command	
Bit 6	Error response	
Bit 7	Internal PLC	
Bit 8	Reserved	
Bit 9	Reserved	
Bit 10	Operating system	
Bit 11	Identification program	
Bit 12	Brake	
Bit 13	Limiter	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00159

Parameter   Name: <b>C00159   Quick stop by (source)</b>		Data type: BITFIELD_16 Index: 24416 <sub>d</sub> = 5F60 <sub>h</sub>
<b>Value is bit-coded:</b>		
Bit 0	Reserved	
Bit 1	Reserved	
Bit 2	Reserved	
Bit 3	Reserved	
Bit 4	Application	
Bit 5	Controller command	
Bit 6	Error response	
Bit 7	Internal PLC	
Bit 8	Reserved	
Bit 9	Reserved	
Bit 10	Reserved	
Bit 11	Reserved	
Bit 12	Reserved	
Bit 13	Reserved	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00166

Parameter   Name: <b>C00166   Error status</b>		Data type: VISIBLE_STRING Index: 24409 <sub>d</sub> = 5F59 <sub>h</sub>
Error message for error number indicated in <a href="#">C00168</a>		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00167

Parameter   Name: <b>C00167   Service code</b>		Data type: VISIBLE_STRING Index: 24408 <sub>d</sub> = 5F58 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

## C00168

Parameter   Name: <b>C00168   Error number</b>		Data type: UNSIGNED_32 Index: 24407 <sub>d</sub> = 5F57 <sub>h</sub>
Display of the error number of the first error with highest priority		
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00169

Parameter   Name: <b>C00169   Logbook event filter</b>		Data type: UNSIGNED_32 Index: 24406 <sub>d</sub> = 5F56 <sub>h</sub>
Bit coded word for the filtering of system events (fault, warning, info)		
<ul style="list-style-type: none"> <li>A set filter bit inhibits entry into the log file.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0		4294967295 <b>0</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00171

Parameter   Name: <b>C00171   Service code</b>		Data type: UNSIGNED_32 Index: 24404 <sub>d</sub> = 5F54 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00173

C00173

Parameter   Name:		Data type: UNSIGNED_8 Index: 24402 <sub>d</sub> = 5F52 <sub>h</sub>
<b>C00173   Mains voltage</b>		
Adaptation of the DC bus voltage thresholds		
<ul style="list-style-type: none"><li>• Check during commissioning and adapt, if necessary.</li><li>• All drive components in DC bus connections must have the same thresholds.</li><li>• LU = Undervoltage threshold, OU = Overvoltage threshold</li></ul>		
<b>Note:</b> Altering this setting also has an impact on the permissible device utilisation! In the chapter "Rated data" of the Hardware Manual the corresponding permissible device utilisation for the different device types at a certain mains voltage and switching frequency is specified.		
Selection list (Lenze setting printed in bold)		Information
0	230 V, LU = 150 V	Operation on 230 V mains • LU = 150 V, OU = 400 V • Brake chopper threshold = 390 V
<b>1</b>	<b>400/415 V, LU = 285 V</b>	Operation on 400 V mains/415 V mains • LU = 285 V, OU = 800 V • Brake chopper threshold = 725 V
2	460/480 V, LU = 328 V	Operation on 460 V mains/480 V mains • LU = 328 V, OU = 800 V • Brake chopper threshold = 765 V
3	500 V, LU = 342 V	Operation on 500 V mains • LU = 342 V, OU = 800 V • Brake chopper threshold = 790 V
4	230 V, LU configurable	Operation on 230 V mains • LU is selected under <a href="#">C00174</a> • OU = 400 V • Brake chopper threshold = 390 V
5	400/415 V, LU configurable	Operation on 400 V mains/415 V mains • LU is selected under <a href="#">C00174</a> • OU = 800 V • Brake chopper threshold = 725 V
6	460/480 V, LU configurable	Operation on 460 V mains/480 V mains • LU is selected under <a href="#">C00174</a> • OU = 800 V • Brake chopper threshold = 765 V
7	500 V, LU configurable	Operation on 500 V mains • LU is selected under <a href="#">C00174</a> • OU = 800 V • Brake chopper threshold = 790 V
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00174

Parameter   Name:		Data type: UNSIGNED_32 Index: 24401 <sub>d</sub> = 5F51 <sub>h</sub>
<b>C00174   Threshold - undervoltage (LU)</b>		
With <a href="#">C00173</a> = 4 ... 7 the LU threshold can be freely selected		
Setting range (min. value   unit   max. value)		Lenze setting
15	V	342 <b>285 V</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00175

Parameter   Name:		Data type: UNSIGNED_32 Index: 24400 <sub>d</sub> = 5F50 <sub>h</sub>
<b>C00175   Service code</b>		
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00176

Parameter   Name:		Data type: UNSIGNED_32 Index: 24399 <sub>d</sub> = 5F4F <sub>h</sub>
<b>C00176   Service code</b>		
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		



C00177

Parameter   Name: <b>C00177   Service code</b>	Data type: UNSIGNED_32 Index: 24398 <sub>d</sub> = 5F4E <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C00178

Parameter   Name: <b>C00178   Elapsed-time meter</b>	Data type: UNSIGNED_32 Index: 24397 <sub>d</sub> = 5F4D <sub>h</sub>	
<b>Display range (min. value   unit   max. value)</b>		
0	s	4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00179

Parameter   Name: <b>C00179   Power-on time meter</b>	Data type: UNSIGNED_32 Index: 24396 <sub>d</sub> = 5F4C <sub>h</sub>	
<b>Display range (min. value   unit   max. value)</b>		
0	s	4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00180

Parameter   Name: <b>C00180   Service code</b>	Data type: VISIBLE_STRING Index: 24395 <sub>d</sub> = 5F4B <sub>h</sub>
For Lenze service only	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

C00181

Parameter   Name: <b>C00181   Red. brake chopper threshold</b>	Data type: UNSIGNED_32 Index: 24394 <sub>d</sub> = 5F4A <sub>h</sub>	
<b>Setting range (min. value   unit   max. value)</b>		
0	V	100
		<b>Lenze setting</b>
		0 V
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00183

Parameter   Name: <b>C00183   Device state</b>	Data type: UNSIGNED_32 Index: 24392 <sub>d</sub> = 5F48 <sub>h</sub>
Display of the device state for controller diagnostics.	
<b>Selection list (display only)</b>	
0	Operation
1	Operation/Warning active
2	Operation/warning locked active
3	Operation/Quick stop active
4	Operation/Application stopped
10	Initialisation active
20	System error active
90	Drive switched on
91	Device switched-on/QSP fault
101	Safe torque off active
102	Error active
104	Trouble active
141	Drive ready to start
151	Quick stop by trouble active
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00185

C00185

Parameter   Name: <b>C00185   Threshold - mains recov. detect.</b>		Data type: UNSIGNED_32 Index: 24390 <sub>d</sub> = 5F46 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	%	100 <b>90 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00186

Parameter   Name: <b>C00186   ENP: Identified motor type</b>		Data type: VISIBLE_STRING Index: 24389 <sub>d</sub> = 5F45 <sub>h</sub>
Motor type read from the electronic nameplate (ENP)		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

C00187

Parameter   Name: <b>C00187   ENP: Identified serial number</b>		Data type: VISIBLE_STRING Index: 24388 <sub>d</sub> = 5F44 <sub>h</sub>
Serial number read from the electronic nameplate (ENP)		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

C00188

Parameter   Name: <b>C00188   ENP: Status</b>		Data type: UNSIGNED_8 Index: 24387 <sub>d</sub> = 5F43 <sub>h</sub>
<b>Selection list (display only)</b>		
0	No ENP found	
1	ENP data loaded	
2	Known ENP found	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

C00199

Parameter   Name: <b>C00199   Device name</b>		Data type: VISIBLE_STRING Index: 24376 <sub>d</sub> = 5F38 <sub>h</sub>
Device name to be defined by the user (e.g. "Cross cutter" or "hoist axis 1") with max. 128 characters		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00200

Parameter   Name: <b>C00200   Firmware product type</b>		Data type: VISIBLE_STRING Index: 24375 <sub>d</sub> = 5F37 <sub>h</sub>
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00201

Parameter   Name: <b>C00201   Firmware - compile date</b>		Data type: VISIBLE_STRING Index: 24374 <sub>d</sub> = 5F36 <sub>h</sub>
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00203

Parameter   Name: <b>C00203   HW product types</b>		Data type: VISIBLE_STRING Index: 24372 <sub>d</sub> = 5F34 <sub>h</sub>
Subcodes	Information	
C00203/1	Type: Control card	
C00203/2	Type: Power section	
C00203/3	Type: Module in MXI1	
C00203/4	Type: Module in MXI2	
C00203/5	Type: Memory module	
C00203/6	Type: Safety module	
C00203/7	Type: Standard device	
C00203/8	Type: Complete device	
C00203/9	Type: ENP	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00204

Parameter   Name: <b>C00204   HW serial numbers</b>		Data type: VISIBLE_STRING Index: 24371 <sub>d</sub> = 5F33 <sub>h</sub>
Subcodes	Information	
C00204/1	Serial no.: Control card	
C00204/2	Serial no.: Power section	
C00204/3	Serial no.: Module in MXI1	
C00204/4	Serial no.: Module in MXI2	
C00204/5	Serial no.: Memory module	
C00204/6	Serial no.: Safety module	
C00204/7	Serial no.: Standard device	
C00204/8	Serial no.: Complete device	
C00204/9	Serial No.: ENP	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00205

Parameter   Name: <b>C00205   HW descriptions</b>		Data type: VISIBLE_STRING Index: 24370 <sub>d</sub> = 5F32 <sub>h</sub>
Subcodes	Information	
C00205/1	Info: Control card	
C00205/2	Info: Power section	
C00205/3	Info: Module in MXI1	
C00205/4	Info: Module in MXI2	
C00205/5	Info: Memory module	
C00205/6	Info: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00206

## C00206

Parameter   Name: <b>C00206   HW manufacturing data</b>		Data type: VISIBLE_STRING Index: 24369 <sub>d</sub> = 5F31 <sub>h</sub>
Subcodes	Information	
C00206/1	Date: Control card	
C00206/2	Date: Power section	
C00206/3	Date: Module in MXI1	
C00206/4	Date: Module in MXI2	
C00206/5	Date: Memory module	
C00206/6	Date: Safety module	
C00206/7	Date: Standard device	
C00206/8	Date: Complete device	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00208

Parameter   Name: <b>C00208   HW manufacturer</b>		Data type: VISIBLE_STRING Index: 24367 <sub>d</sub> = 5F2F <sub>h</sub>
Subcodes	Information	
C00208/1	Manufacturer: Control card	
C00208/2	Manufacturer: Power section	
C00208/3	Manufacturer: Module in MXI1	
C00208/4	Manufacturer: Module in MXI2	
C00208/5	Manufacturer: Memory module	
C00208/6	Manufacturer: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00209

Parameter   Name: <b>C00209   HW countries of origin</b>		Data type: VISIBLE_STRING Index: 24366 <sub>d</sub> = 5F2E <sub>h</sub>
Subcodes	Information	
C00209/1	Country: Control card	
C00209/2	Country: Power section	
C00209/3	Country: Module in MXI1	
C00209/4	Country: Module in MXI2	
C00209/5	Country: Memory module	
C00209/6	Country: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00210

Parameter   Name: <b>C00210   HW versions</b>		Data type: VISIBLE_STRING Index: 24365 <sub>d</sub> = 5F2D <sub>h</sub>
Subcodes	Information	
C00210/1	HW version: Control card	
C00210/2	HW version: Power section	
C00210/3	HW version: Module in MXI1	
C00210/4	HW version: Module in MXI2	
C00210/5	HW version: Memory module	
C00210/6	HW version: Safety module	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00211

Parameter | Name: **C00211 | Application: Version** Data type: VISIBLE\_STRING  
Index: 24364<sub>d</sub> = 5F2C<sub>h</sub>

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C00212

Parameter | Name: **C00212 | Application: Type code** Data type: VISIBLE\_STRING  
Index: 24363<sub>d</sub> = 5F2B<sub>h</sub>

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C00213

Parameter | Name: **C00213 | Application: Compilation date** Data type: VISIBLE\_STRING  
Index: 24362<sub>d</sub> = 5F2A<sub>h</sub>

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C00214

Parameter | Name: **C00214 | Required safety module** Data type: UNSIGNED\_8  
Index: 24361<sub>d</sub> = 5F29<sub>h</sub>

Setting of the expected safety module

- If a different safety module is detected, an error (trouble) will be activated. The error can only be eliminated by restarting the controller.

Selection list (Lenze setting printed in bold)	
1	<b>SM0</b>
2	SM100
4	SM300

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C00217

Parameter | Name: **C00217 | Parameter error information** Data type: UNSIGNED\_32  
Index: 24358<sub>d</sub> = 5F26<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00218

Parameter | Name: **C00218 | Application: ID number** Data type: UNSIGNED\_32  
Index: 24357<sub>d</sub> = 5F25<sub>h</sub>

Display range (min. value | unit | max. value)

0		0
---	--	---

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C00225

Parameter | Name: **C00225 | Check configuration** Data type: UNSIGNED\_32  
Index: 24350<sub>d</sub> = 5F1E<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00254

Parameter | Name: **C00254 | Phase controller gain** Data type: UNSIGNED\_32  
Index: 24321<sub>d</sub> = 5F01<sub>h</sub>

Setting range (min. value   unit   max. value)			Lenze setting
0.00	1/s	1000.00	<b>20.00 1/s</b>

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT Scaling factor: 100

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00270

## C00270

Parameter   Name: <b>C00270   Freq. - current setpoint filter</b>		Data type: UNSIGNED_32 Index: 24305 <sub>d</sub> = 5EF1 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
1.0	Hz	1000.0
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00270/1	200.0 Hz	Freq. current setpoint filter 1
C00270/2	400.0 Hz	Freq. current setpoint filter 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10		

## C00271

Parameter   Name: <b>C00271   Width - current setpoint filter</b>		Data type: UNSIGNED_32 Index: 24304 <sub>d</sub> = 5EF0 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
0.0	Hz	500.0
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00271/1	20.0 Hz	Width current setp. filter 1
C00271/2	40.0 Hz	Width current setp. filter 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10		

## C00272

Parameter   Name: <b>C00272   Depth - current setpoint filter</b>		Data type: UNSIGNED_32 Index: 24303 <sub>d</sub> = 5EEF <sub>h</sub>
With the setting "0 dB" the current setpoint filter is deactivated		
<b>Setting range (min. value   unit   max. value)</b>		
0	db	100
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00272/1	0 db	Depth current setp. filter 1
C00272/2	0 db	Depth current setp. filter 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00273

Parameter   Name: <b>C00273   Moment of inertia</b>		Data type: UNSIGNED_32 Index: 24302 <sub>d</sub> = 5EEE <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
0.00	kg cm <sup>2</sup>	10000.00
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00273/1	0.14 kg cm <sup>2</sup>	Motor moment of inertia
C00273/2	0.00 kg cm <sup>2</sup>	Load moment of inertia
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

## C00274

Parameter   Name: <b>C00274   Max. acceleration change</b>		Data type: UNSIGNED_32 Index: 24301 <sub>d</sub> = 5EEF <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.0	%/ms	400.0 <b>400.0 %/ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10		

C00275

Parameter   Name: <b>C00275   Signal source - speed setpoint</b>		Data type: UNSIGNED_16 Index: 24300 <sub>d</sub> = 5EECh
<b>Selection list</b> (Lenze setting printed in bold)		
0	<b>SpeedAdd signal</b>	
1	Differentiated PosSet signal	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00276

Parameter   Name: <b>C00276   Signal source - torque setpoint</b>		Data type: UNSIGNED_16 Index: 24299 <sub>d</sub> = 5EEBh
<b>Selection list</b> (Lenze setting printed in bold)		
0	<b>TorqueAdd/AccAdd signal</b>	
1	Differentiated SpeedSet signal	
2	2x diff. PosSet signal	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00280

Parameter   Name: <b>C00280   Filter time const. DC detection</b>		Data type: UNSIGNED_32 Index: 24295 <sub>d</sub> = 5EE7h
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
1.0	ms	1000.0 <b>25.0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10		

C00308

Parameter   Name: <b>C00308   Service code</b>		Data type: UNSIGNED_16 Index: 24267 <sub>d</sub> = 5ECBh
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00309

Parameter   Name: <b>C00309   Service code</b>		Data type: UNSIGNED_32 Index: 24266 <sub>d</sub> = 5ECAh
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00310

Parameter   Name: <b>C00310   Service code</b>		Data type: UNSIGNED_8 Index: 24265 <sub>d</sub> = 5EC9h
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00311

Parameter   Name: <b>C00311   CAN TPDO1 mask byte x</b>		Data type: BITFIELD_8 Index: 24264 <sub>d</sub> = 5EC8h
A mask can be parameterised for each byte of the TPDO1 in the assigned subcode. <ul style="list-style-type: none"> <li>• In case of an event-controlled PDO transmission, only the masked bits will be considered for event control.</li> <li>• Mask "0x0" means that no bit of the corresponding byte activates PDO transmission.</li> <li>• Mask "0xff" means that each bit of the corresponding byte can activate PDO transmission.</li> </ul>		
<b>Value is bit-coded:</b>		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00311/1	0x00	Mask for byte 1 ... byte 8 of TPDO1
C00311/...		
C00311/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00312

## C00312

Parameter   Name: <b>C00312   CAN TPDO2 mask byte x</b>		Data type: BITFIELD_8 Index: 24263 <sub>d</sub> = 5EC7 <sub>h</sub>
<p>A mask can be parameterised for each byte of the TPDO2 in the assigned subcode.</p> <ul style="list-style-type: none"> <li>• In case of an event-controlled PDO transmission, only the masked bits will be considered for event control.</li> <li>• Mask "0x0" means that no bit of the corresponding byte activates PDO transmission.</li> <li>• Mask "0xff" means that each bit of the corresponding byte can activate PDO transmission.</li> </ul>		
<b>Value is bit-coded:</b>		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00312/1	0x00	Mask for byte 1 ... byte 8 of TPDO2
C00312/...		
C00312/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00313

Parameter   Name: <b>C00313   CAN TPDO3 mask byte x</b>		Data type: BITFIELD_8 Index: 24262 <sub>d</sub> = 5EC6 <sub>h</sub>
<p>A mask can be parameterised for each byte of the TPDO3 in the assigned subcode.</p> <ul style="list-style-type: none"> <li>• In case of an event-controlled PDO transmission, only the masked bits will be considered for event control.</li> <li>• Mask "0x0" means that no bit of the corresponding byte activates PDO transmission.</li> <li>• Mask "0xff" means that each bit of the corresponding byte can activate PDO transmission.</li> </ul>		
<b>Value is bit-coded:</b>		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00313/1	0x00	Mask for byte 1 ... byte 8 of TPDO3
C00313/...		
C00313/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00314

Parameter   Name: <b>C00314   CAN TPDO4 mask byte x</b>		Data type: BITFIELD_8 Index: 24261 <sub>d</sub> = 5EC5 <sub>h</sub>
<p>A mask can be parameterised for each byte of the TPDO4 in the assigned subcode.</p> <ul style="list-style-type: none"> <li>• In case of an event-controlled PDO transmission, only the masked bits will be considered for event control.</li> <li>• Mask "0x0" means that no bit of the corresponding byte activates PDO transmission.</li> <li>• Mask "0xff" means that each bit of the corresponding byte can activate PDO transmission.</li> </ul>		
<b>Value is bit-coded:</b>		
Bit 0	Mask bit 0	
...	...	
Bit 7	Mask bit 7	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00314/1	0x00	Mask for byte 1 ... byte 8 of TPDO4
C00314/...		
C00314/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		



## C00320

Parameter   Name: <b>C00320   CAN TPDOx identifier</b>		Data type: BITFIELD_32 Index: 2425 <sub>d</sub> = 5EB <sub>F<sub>h</sub></sub>
Identifier for TPDO1 ... TPDO4		
<ul style="list-style-type: none"> <li>• If bit 31 is set (0x8nnnnnnn), the TPDO is deactivated (see DS301V402).</li> <li>• The basic setting is according to the "Predefined Connection Set" of DS301V402.</li> </ul>		
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>• Bit 0 ... 10: COB-ID</li> <li>• Bit 11 ... 30: Reserved</li> <li>• Bit 31: SDO invalid</li> </ul>
...	...	
Bit 31	PDO invalid	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00320/1	0x00000181	Identifier TPDO1 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x180 + node address will be set by default.</li> </ul>
C00320/2	0x00000281	Identifier TPDO2 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x280 + node address will be set by default.</li> </ul>
C00320/3	0x00000381	Identifier TPDO3 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x380 + node address will be set by default.</li> </ul>
C00320/4	0x00000481	Identifier TPDO4 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x480 + node address will be set by default.</li> </ul>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00321

Parameter   Name: <b>C00321   CAN RPDOx identifier</b>		Data type: BITFIELD_32 Index: 2425 <sub>d</sub> = 5EB <sub>F<sub>h</sub></sub>
Identifier for RPDO1 ... RPDO4		
<ul style="list-style-type: none"> <li>• If bit 31 is set (0x8nnnnnnn), the RPDO is deactivated (see DS301V402).</li> <li>• The basic setting is according to the "Predefined Connection Sets" of DS301V402.</li> </ul>		
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>• Bit 0 ... 10: COB-ID</li> <li>• Bit 11 ... 30: Reserved</li> <li>• Bit 31: SDO invalid</li> </ul>
...	...	
Bit 31	PDO invalid	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00321/1	0x00000201	Identifier RPDO1 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x200 + node address will be set by default.</li> </ul>
C00321/2	0x00000301	Identifier RPDO2 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x300 + node address will be set by default.</li> </ul>
C00321/3	0x00000401	Identifier RPDO3 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x400 + node address will be set by default.</li> </ul>
C00321/4	0x00000501	Identifier RPDO4 <ul style="list-style-type: none"> <li>• After a node address change and CAN reset node, the value 0x500 + node address will be set by default.</li> </ul>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00322

C00322

Parameter   Name: <b>C00322   CAN TPDOx Tx mode</b>		Data type: UNSIGNED_8 Index: 24253 <sub>d</sub> = 5EBD <sub>h</sub>
<p>TPDO transmission mode according to DS301V402</p> <ul style="list-style-type: none"> <li>Types 0 (acyclic sync), 1-240 (cyclic sync), 254 (event-controlled manufacturer-specific), 255 (event-controlled device-profile-specific) are supported.</li> <li>The basic PDO setting is "254" (event-controlled).</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		
0		255
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00322/1	254	Transmission mode for TPDO1 ... TPDO4
C00322/...		
C00322/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00323

Parameter   Name: <b>C00323   CAN RPDOx Rx mode</b>		Data type: UNSIGNED_8 Index: 24252 <sub>d</sub> = 5EBD <sub>h</sub>
<p>RPDO transmission mode according to DS301V402</p> <ul style="list-style-type: none"> <li>With the RPDO used as monitoring setting for sync-controlled PDOs.</li> <li>Types 0 (acyclic sync), 1-240 (cyclic sync), 254 (event-controlled manufacturer-specific), 255 (event-controlled device-profile-specific) are supported.</li> <li>The basic PDO setting is "254" (event-controlled).</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		
0		255
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00323/1	254	Transmission mode for RPDO1 ... RPDO4
C00323/...		
C00323/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00324

Parameter   Name: <b>C00324   CAN TPDOx delay time</b>		Data type: UNSIGNED_16 Index: 24251 <sub>d</sub> = 5EBA <sub>h</sub>
<p>Minimum time between the sending of two identical TPDOs (see DS301V402).</p> <ul style="list-style-type: none"> <li>The delay time is entered in 1/10 ms and automatically rounded to full milliseconds by the code.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		
0	1/10 ms	65535
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00324/1	0 1/10 ms	Delay time for TPDO1 ... TPDO4
C00324/...		
C00324/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00325

Parameter   Name: <b>C00325   Service code</b>		Data type: UNSIGNED_8 Index: 24250 <sub>d</sub> = 5EBA <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00326

Parameter   Name: <b>C00326   Service code</b>		Data type: UNSIGNED_8 Index: 24249 <sub>d</sub> = 5EB9 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00327

Parameter | Name: **C00327 | Service code** Data type: BITFIELD\_32  
Index: 24248<sub>d</sub> = 5EB8<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00328

Parameter | Name: **C00328 | Service code** Data type: BITFIELD\_32  
Index: 24247<sub>d</sub> = 5EB7<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00329

Parameter | Name: **C00329 | Service code** Data type: BITFIELD\_32  
Index: 24246<sub>d</sub> = 5EB6<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00330

Parameter | Name: **C00330 | Service code** Data type: BITFIELD\_32  
Index: 24245<sub>d</sub> = 5EB5<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00335

Parameter | Name: **C00335 | Service code** Data type: BITFIELD\_32  
Index: 24240<sub>d</sub> = 5EB0<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00336

Parameter | Name: **C00336 | Service code** Data type: BITFIELD\_32  
Index: 24239<sub>d</sub> = 5EAF<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00337

Parameter | Name: **C00337 | Service code** Data type: BITFIELD\_32  
Index: 24238<sub>d</sub> = 5EAE<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00338

Parameter | Name: **C00338 | Service code** Data type: BITFIELD\_32  
Index: 24237<sub>d</sub> = 5EAD<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00345

Parameter | Name: **C00345 | CAN error** Data type: UNSIGNED\_8  
Index: 24230<sub>d</sub> = 5EA6<sub>h</sub>

**Selection list (display only)**

0	No error
1	Guard Event
2	Warning
3	Bus off
4	Sync telegram error
6	Overrun

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00346

C00346

Parameter   Name: <b>C00346   CAN heartbeat activity</b>		Data type: BITFIELD_32 Index: 24229 <sub>d</sub> = 5EA5 <sub>h</sub>
<b>Value is bit-coded:</b>		
Bit 0	Heartbeat node 1	
...	...	
Bit 31	Heartbeat node 32	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00347

Parameter   Name: <b>C00347   CAN heartbeat status</b>		Data type: UNSIGNED_8 Index: 24228 <sub>d</sub> = 5EA4 <sub>h</sub>
<b>Selection list (display only)</b>		
0	Unknown	
4	Stopped	
5	Operational	
127	Pre-operational	
<b>Subcodes</b>		<b>Information</b>
C00347/1		Status node 1 ... 32
C00347/...		
C00347/32		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00348

Parameter   Name: <b>C00348   CAN status DIP switch</b>		Data type: UNSIGNED_8 Index: 24227 <sub>d</sub> = 5EA3 <sub>h</sub>
<ul style="list-style-type: none"> <li>The value "1" means that the CAN DIP switch has been identified after mains switching and a valid baud rate and node address have been set.</li> <li>"0" means that no CAN DIP switch or no valid setting has been identified or the setting has been overwritten by writing code <a href="#">C00350</a> or <a href="#">C00351</a>.</li> </ul>		
<b>Display range (min. value   unit   max. value)</b>		
0		1
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00349

Parameter   Name: <b>C00349   DIP switch CAN setting</b>		Data type: UNSIGNED_8 Index: 24226 <sub>d</sub> = 5EA2 <sub>h</sub>
Setting of the CAN DIP switch at the last mains connection		
<b>Display range (min. value   unit   max. value)</b>		
0		255
<b>Subcodes</b>		<b>Information</b>
C00349/1		Node address
C00349/2		Baud rate: 0: 10 kbit/s 1: 20 kbit/s 2: 50 kbit/s 3: 125 kbit/s 4: 250 kbit/s 5: 500 kbit/s 6: 800 kbit/s 7: 1000 kbit/s
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00350

Parameter   Name: <b>C00350   CAN node address</b>		Data type: UNSIGNED_8 Index: 24225 <sub>d</sub> = 5EA1 <sub>h</sub>
<ul style="list-style-type: none"> <li>• A change of the node address only gets active after a CAN reset node.</li> <li>• The basic server channel RX/TX is automatically provided by the node address (<a href="#">C00372</a> and <a href="#">C00373</a>; subcode 1).</li> <li>• Overwriting the value deactivates a possible node address selection entered by means of hardware.</li> </ul>		
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
1		127 <b>1</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input checked="" type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00351

Parameter   Name: <b>C00351   CAN baud rate</b>		Data type: UNSIGNED_8 Index: 24224 <sub>d</sub> = 5EA0 <sub>h</sub>
<ul style="list-style-type: none"> <li>• A change of the baud rate only gets active after a CAN reset node.</li> <li>• Overwriting the value deactivates a possible node address selection entered by means of hardware.</li> </ul>		
<b>Selection list</b> (Lenze setting printed in bold)		
<b>0</b>	<b>500 kbit/s</b>	
1	250 kbit/s	
2	125 kbit/s	
3	50 kbit/s	
4	1 mbit/s	
5	20 kbit/s	
6	10 kbit/s	
8	Reserved	
9	Reserved	
10	Reserved	
11	Reserved	
12	Reserved	
13	Reserved	
14	800 kbit/s	
15	Reserved	
255	Auto baud	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input checked="" type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00352

Parameter   Name: <b>C00352   CAN slave/master</b>		Data type: UNSIGNED_8 Index: 24223 <sub>d</sub> = 5E9F <sub>h</sub>
If "1" is entered and saved, the drive will start as CAN master after mains switching.		
<b>Selection list</b> (Lenze setting printed in bold)		
<b>0</b>	<b>Slave</b>	
1	Master	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00356

## C00356

Parameter   Name: <b>C00356   CAN TPDOx cycle time</b>		Data type: UNSIGNED_16 Index: 24219 <sub>d</sub> = 5E9B <sub>h</sub>
TPDO event time from DS301V402.		
<ul style="list-style-type: none"> <li>With a value unequal "0", the TPDO will be sent after the set time without considering the transmission type.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		
0	ms	65535
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00356/1	0 ms	Cycle time for TPDO1 ... TPDO4
C00356/...		
C00356/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00357

Parameter   Name: <b>C00357   CAN RPDOx monitoring time</b>		Data type: UNSIGNED_16 Index: 24218 <sub>d</sub> = 5E9A <sub>h</sub>
RPDO event time from DS301V402.		
<ul style="list-style-type: none"> <li>With a value unequal "0", the RPDO will be expected after the set time.</li> <li>If the RPDO is not received within this time, a parameterisable error message can be activated.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		
0	ms	65535
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00357/1	3000 ms	Monitoring time for RPDO1 ... RPDO4
C00357/...		
C00357/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00359

Parameter   Name: <b>C00359   CAN status</b>		Data type: UNSIGNED_8 Index: 24216 <sub>d</sub> = 5E98 <sub>h</sub>
<b>Selection list (display only)</b>		
0	Operational	
1	Pre-operational	
4	Boot up	
5	Stopped	
7	Reset	
8	INITIALISATION	
9	Unknown	
10	Autom. baud rate detection active	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00360

Parameter   Name: <b>C00360   CAN telegram and error counter</b>		Data type: UNSIGNED_16 Index: 24215 <sub>d</sub> = 5E97 <sub>h</sub>
<ul style="list-style-type: none"> <li>• After mains connection, counting restarts with "0".</li> <li>• After the maximum value has been reached, counting restarts with "0".</li> </ul>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<b>Subcodes</b>		<b>Information</b>
C00360/1	Stuffing bit error counter <ul style="list-style-type: none"> <li>• More than five identical bits have been detected.</li> </ul>	
C00360/2	Format error counter <ul style="list-style-type: none"> <li>• CAN frame has not been observed.</li> </ul>	
C00360/3	Acknowledge error counter <ul style="list-style-type: none"> <li>• No device has acknowledged the telegram.</li> </ul>	
C00360/4	Bit1 error counter <ul style="list-style-type: none"> <li>• "1" should be sent after bus arbitration, but "0" was read.</li> </ul>	
C00360/5	Bit0 error counter <ul style="list-style-type: none"> <li>• "0" should be sent after bus arbitration, but "1" was read.</li> </ul>	
C00360/6	CRC error counter <ul style="list-style-type: none"> <li>• Check sum check has indicated an error.</li> </ul>	
C00360/7	Tx telegram counter <ul style="list-style-type: none"> <li>• Correctly received telegrams.</li> </ul>	
C00360/8	Rx telegram counters <ul style="list-style-type: none"> <li>• Correctly transmitted telegrams.</li> </ul>	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00361

Parameter   Name: <b>C00361   CAN bus load</b>		Data type: UNSIGNED_32 Index: 24214 <sub>d</sub> = 5E96 <sub>h</sub>
Restart the controller or use the controller command "Reset node" ( <a href="#">C00002</a> ) to reset the display of the maximum node load.		
<b>Display range (min. value   unit   max. value)</b>		
0	%	100
<b>Subcodes</b>		<b>Information</b>
C00361/1	Current node load in Tx direction	
C00361/2	Current node load in Rx direction	
C00361/3	Current node load through faulty telegrams	
C00361/4	Maximum node load in Tx direction	
C00361/5	Maximum node load in Rx direction	
C00361/6	Maximum node load through faulty telegrams	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00367

Parameter   Name: <b>C00367   CAN SYNC Rx identifier</b>		Data type: UNSIGNED_32 Index: 24208 <sub>d</sub> = 5E90 <sub>h</sub>
Identifier with which the sync slave is to receive sync telegrams. <ul style="list-style-type: none"> <li>• Connected with CANopen index 0x1005 of DS301V402.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0		2047 <b>128</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00368

C00368

Parameter   Name: <b>C00368   CAN SYNC Tx identifier</b>		Data type: UNSIGNED_32 Index: 24207 <sub>d</sub> = 5E8F <sub>h</sub>
Identifier with which the sync master is to send sync telegrams. <ul style="list-style-type: none"> <li>Connected with CANopen index 0x1005 of DS301V402.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0		2047 <b>128</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00369

Parameter   Name: <b>C00369   CAN SYNC transmit cycle time</b>		Data type: UNSIGNED_16 Index: 24206 <sub>d</sub> = 5E8E <sub>h</sub>
Cycle in which the CAN sync master is to send its sync telegrams. <ul style="list-style-type: none"> <li>Connected with CANopen index 0x1006 of DS301V402.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		
0	ms	65535
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00369/1	0 ms	
C00369/2	0 ms	
C00369/3	0 ms	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00372

Parameter   Name: <b>C00372   CAN SDO server Rx identifier</b>		Data type: BITFIELD_32 Index: 24203 <sub>d</sub> = 5E8B <sub>h</sub>
Identifier which serves to reach the assigned SDO server. <ul style="list-style-type: none"> <li>Setting bit 31 (0x8nnnnnnn) deactivates the corresponding SDO server (see DS301V402).</li> </ul>		
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>Bit 0 ... 10: COB-ID</li> <li>Bit 11 ... 30: Reserved</li> <li>Bit 31: SDO invalid</li> </ul>
...	...	
Bit 31	SDO invalid	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00372/1	0x00000601	SDO server channel 1 RX <ul style="list-style-type: none"> <li>Subcode 1 contains the basic SDO channel which can neither be changed nor deactivated, according to DS301V402. Writing to the subcode is ineffective.</li> <li>The value under subcode 1 results from the node address (<a href="#">C00350</a>) + 0x600.</li> </ul>
C00372/2	0x80000000	SDO server channel 2 RX
C00372/3	0x80000000	SDO server channel 3 RX
C00372/4	0x80000000	SDO server channel 4 RX
C00372/5	0x80000000	SDO server channel 5 RX
C00372/6	0x80000000	SDO server channel 6 RX
C00372/7	0x80000000	SDO server channel 7 RX
C00372/8	0x80000000	SDO server channel 8 RX
C00372/9	0x80000000	SDO server channel 9 RX
C00372/10	0x80000000	SDO server channel 10 RX
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input checked="" type="checkbox"/> COM <input type="checkbox"/> MOT		



## C00373

Parameter   Name:		Data type: BITFIELD_32 Index: 24202 <sub>d</sub> = 5E8A <sub>h</sub>
<b>C00373   CAN SDO server Tx identifier</b>		
Identifier with which the assigned SDO server is able to transmit.		
<ul style="list-style-type: none"> <li>Setting bit 31 (0x8nnnnnn) deactivates the corresponding SDO server (see DS301V402).</li> </ul>		
Value is bit-coded:		Information
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>Bit 0 ... 10: COB-ID</li> <li>Bit 11 ... 30: Reserved</li> <li>Bit 31: SDO invalid</li> </ul>
...	...	
Bit 31	SDO invalid	
Subcodes	Lenze setting	Information
C00373/1	0x00000581	SDO server channel 1 TX <ul style="list-style-type: none"> <li>Subcode 1 contains the basic SDO channel which can neither be changed nor deactivated, according to DS301V402. Writing to the subcode is ineffective.</li> <li>The value under subcode 1 results from the node address (<a href="#">C00350</a>) + 0x580.</li> </ul>
C00373/2	0x80000000	SDO server channel 2 TX
C00373/3	0x80000000	SDO server channel 3 TX
C00373/4	0x80000000	SDO server channel 4 TX
C00373/5	0x80000000	SDO server channel 5 TX
C00373/6	0x80000000	SDO server channel 6 TX
C00373/7	0x80000000	SDO server channel 7 TX
C00373/8	0x80000000	SDO server channel 8 TX
C00373/9	0x80000000	SDO server channel 9 TX
C00373/10	0x80000000	SDO server channel 10 TX
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input checked="" type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00374

Parameter   Name:		Data type: UNSIGNED_8 Index: 24201 <sub>d</sub> = 5E89 <sub>h</sub>
<b>C00374   CAN SDO client node address</b>		
Node address of the client which is assigned to this server (see DS301V402).		
Setting range (min. value   unit   max. value)		
1		127
Subcodes	Lenze setting	Information
C00374/1	1	SDO server channel 1 remote client node address <ul style="list-style-type: none"> <li>Subcode 1 contains the basic SDO channel which does not include this entry, according to DS301V402. Writing to the subcode is ineffective.</li> <li>The value of subindex 1 results in 0.</li> </ul>
C00374/2	1	SDO server channel 2 remote client node address
C00374/3	1	SDO server channel 3 remote client node address
C00374/4	1	SDO server channel 4 remote client node address
C00374/5	1	SDO server channel 5 remote client node address
C00374/6	1	SDO server channel 6 remote client node address
C00374/7	1	SDO server channel 7 remote client node address
C00374/8	1	SDO server channel 8 remote client node address
C00374/9	1	SDO server channel 9 remote client node address
C00374/10	1	SDO server channel 10 remote client node address
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input checked="" type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00375

## C00375

Parameter   Name: <b>C00375   CAN SDO client Rx identifier</b>		Data type: BITFIELD_32 Index: 24200 <sub>d</sub> = 5E88 <sub>h</sub>
Identifier which serves to reach the assigned SDO client.		
<ul style="list-style-type: none"> <li>Setting bit 31 (0x8nnnnnn) deactivates the corresponding SDO client channel (see DS301V402).</li> <li>The client channels need not be parameterised right now. Their functionality will only be required when using the Gateway services.</li> </ul>		
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>Bit 0 ... 10: COB-ID</li> <li>Bit 11 ... 30: Reserved</li> <li>Bit 31: SDO invalid</li> </ul>
...	...	
Bit 31	SDO invalid	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00375/1	0x80000000	SDO client channel 1 RX ... 10 RX
C00375/...		
C00375/10		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00376

Parameter   Name: <b>C00376   CAN SDO client Tx identifier</b>		Data type: BITFIELD_32 Index: 24199 <sub>d</sub> = 5E87 <sub>h</sub>
Identifier with which the assigned SDO client is able to transmit.		
<ul style="list-style-type: none"> <li>Setting bit 31 (0x8nnnnnn) deactivates the corresponding SDO client channel (see DS301V402).</li> <li>The client channels need not be parameterised right now. Their functionality will only be required when using the Gateway services.</li> </ul>		
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>Bit 0 ... 10: COB-ID</li> <li>Bit 11 ... 30: Reserved</li> <li>Bit 31: SDO invalid</li> </ul>
...	...	
Bit 31	SDO invalid	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00376/1	0x80000000	SDO client channel 1 TX ... 10 TX
C00376/...		
C00376/10		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00377

Parameter   Name: <b>C00377   CAN SDO server node address</b>		Data type: UNSIGNED_8 Index: 24198 <sub>d</sub> = 5E86 <sub>h</sub>
Node address of the server with which the SDO client communicates via the selected client channel.		
<ul style="list-style-type: none"> <li>The client functionality need not be activated.</li> <li>Activation of the CAN SDO client channel requires an entry (see DS301V402).</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		
1		127
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00377/1	1	Remote server node address for SDO client channel 1 ... 10
C00377/...		
C00377/10		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00378

Parameter   Name:		Data type: UNSIGNED_16	
<b>C00378   CAN boot-up delay - operational</b>		Index: 24197 <sub>d</sub> = 5E85 <sub>h</sub>	
Time after mains switching after which the CAN NMT master sends the "Start remote node" telegram to the bus.			
<ul style="list-style-type: none"> <li>The delay time is only used when the master bit is activated (<a href="#">C00352</a>) and the controller has been restarted.</li> </ul>			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	ms	65535	<b>3000 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00379

Parameter   Name:		Data type: UNSIGNED_8	
<b>C00379   Service code</b>		Index: 24196 <sub>d</sub> = 5E84 <sub>h</sub>	
<b>This code is used internally by the controller and must not be overwritten by the user!</b>			

C00381

Parameter   Name:		Data type: UNSIGNED_16	
<b>C00381   CAN heartbeat producer time</b>		Index: 24194 <sub>d</sub> = 5E82 <sub>h</sub>	
Time interval at which the device sends a heartbeat telegram with its device status to the bus.			
<ul style="list-style-type: none"> <li>Selection of the "node guarding" monitoring function deactivates the "heartbeat" monitoring function.</li> </ul>			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	ms	65535	<b>0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00382

Parameter   Name:		Data type: UNSIGNED_16	
<b>C00382   CAN guard time</b>		Index: 24193 <sub>d</sub> = 5E81 <sub>h</sub>	
After the set guard time multiplied by the life time factor ( <a href="#">C00383</a> ), a node guarding telegram must have been received.			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	ms	65535	<b>0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00383

Parameter   Name:		Data type: UNSIGNED_8	
<b>C00383   CAN life time factor</b>		Index: 24192 <sub>d</sub> = 5E80 <sub>h</sub>	
The life time factor multiplied by the guard time ( <a href="#">C00382</a> ) results in the time in which a node guarding telegram must have been received.			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0		255	<b>0</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00385

## C00385

Parameter   Name: <b>C00385   CAN heartbeat consumer time</b>		Data type: BITFIELD_32 Index: 24190 <sub>d</sub> = 5E7E <sub>h</sub>
<p>The 32 subcodes represent the nodes to be monitored by means of heartbeat.</p> <ul style="list-style-type: none"> <li>• Each subcode entry contains the expected "heartbeat" time and the node ID (node address) from which the heartbeat telegram is expected in the form of a bit code.</li> <li>• The response to a non received heartbeat telegram can be parameterised.</li> </ul>		
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	Heartbeat time bit 0	<ul style="list-style-type: none"> <li>• Bit 0 ... 15: Heartbeat time</li> <li>• Bit 16 ... 23: Node address</li> <li>• Bit 24 ... 31: Reserved</li> </ul>
...	...	
Bit 31	Reserved	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00385/1	0x00000000	Monitoring entry 1 ... 32
C00385/...		
C00385/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00386

Parameter   Name: <b>C00386   CAN node guarding</b>		Data type: BITFIELD_32 Index: 24189 <sub>d</sub> = 5E7D <sub>h</sub>
<p>The 32 subcodes represent the nodes to be monitored by the master by means of node guarding.</p> <ul style="list-style-type: none"> <li>• Each subcode entry contains the guard time, the lifetime factor and the node ID (node address) from which the heartbeat telegram is expected in the form of a bit code.</li> <li>• The response to a non received node guarding response can be parameterised.</li> </ul>		
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	Guard time bit 0	<ul style="list-style-type: none"> <li>• Bit 0 ... 15: Guard time</li> <li>• Bit 16 ... 23: Node address</li> <li>• Bit 24 ... 31: Lifetime factor</li> </ul>
...	...	
Bit 31	Lifetime factor bit 7	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00386/1	0x00000000	Monitoring entry 1 ... 32
C00386/...		
C00386/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00387

Parameter   Name: <b>C00387   CAN node guarding activity</b>		Data type: BITFIELD_32 Index: 24188 <sub>d</sub> = 5E7C <sub>h</sub>
<b>Value is bit-coded:</b>		
Bit 0	Node guarding node 1	
...	...	
Bit 31	Node guarding node 32	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00388

Parameter   Name: <b>C00388   CAN node guarding status</b>		Data type: UNSIGNED_8 Index: 24187 <sub>d</sub> = 5E7B <sub>h</sub>
<b>Selection list (display only)</b>		
0	Unknown	
4	Stopped	
5	Operational	
127	Pre-operational	
<b>Subcodes</b>		<b>Information</b>
C00388/1		Status node 1 ... 32
C00388/...		
C00388/32		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00390

Parameter   Name: <b>C00390   CAN error register (DS301V402)</b>		Data type: BITFIELD_8 Index: 24185 <sub>d</sub> = 5E79 <sub>h</sub>
CAN error register according to DS301V402		
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	Generic error	Currently only bit 0 and bit 4 contain the corresponding information.
Bit 1	Current error (not used)	
Bit 2	Voltage error (not used)	
Bit 3	Temperature error (not used)	
Bit 4	Communication error	
Bit 5	Device profile-spec. error (not used)	
Bit 6	Reserved	
Bit 7	Manufacturer-spec. error (not used)	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00391

Parameter   Name: <b>C00391   CAN emergency object</b>		Data type: BITFIELD_32 Index: 24184 <sub>d</sub> = 5E78 <sub>h</sub>
Identifier of the emergency telegram		
<ul style="list-style-type: none"> <li>Setting bit 31 of this code (0x8nnnnnnn) deactivates the generation of emergency telegrams.</li> </ul>		
<b>Value is bit-coded:</b>		<b>Information</b>
Bit 0	COB-ID bit 0	<ul style="list-style-type: none"> <li>Bit 0 ... 10: COB-ID</li> <li>Bit 11 ... 30: Reserved</li> <li>Bit 31: Emergency stop</li> </ul>
...	...	
Bit 31	Emergency inactive/active	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00392

Parameter   Name: <b>C00392   CAN emergency delay time</b>		Data type: UNSIGNED_16 Index: 24183 <sub>d</sub> = 5E77 <sub>h</sub>
Minimum time between two successive emergency telegrams.		
<ul style="list-style-type: none"> <li>Setting "0" deactivates the inhibit time check.</li> <li>The inhibit time is entered in 1/10 ms. The code automatically rounds the entries down to the preceding full millisecond.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0		65535 0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00393

C00393

Parameter   Name: <b>C00393   CAN result - bus scan</b>		Data type: UNSIGNED_8 Index: 24182 <sub>d</sub> = 5E76 <sub>h</sub>
Result of CAN bus scanning (see controller commands under <a href="#">C00002</a> ). • Subcode number 1 ... 128 corresponds to CAN node address 1 ... 128.		
<b>Display range</b> (min. value   unit   max. value)		
0		1
<b>Subcodes</b>	<b>Information</b>	
C00393/1	Result of CAN bus scanning for CAN node address 1 ... 128	
C00393/...	• The value "1" means that a device with the corresponding node address has been found.	
C00393/128		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00395

Parameter   Name: <b>C00395   Service code</b>		Data type: UNSIGNED_32 Index: 24180 <sub>d</sub> = 5E74 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00396

Parameter   Name: <b>C00396   Service code</b>		Data type: UNSIGNED_32 Index: 24179 <sub>d</sub> = 5E73 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00397

Parameter   Name: <b>C00397   Service code</b>		Data type: UNSIGNED_32 Index: 24178 <sub>d</sub> = 5E72 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00398

Parameter   Name: <b>C00398   Test mode - motor control</b>		Data type: UNSIGNED_32 Index: 24177 <sub>d</sub> = 5E71 <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)		
<b>0</b>	<b>Test mode deactivated</b>	
1	U rotation test mode	
2	I rotation test mode	
3	Current controller optimisation mode	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00399

Parameter   Name: <b>C00399   Settings for test mode</b>		Data type: INTEGER_32 Index: 24176 <sub>d</sub> = 5E70 <sub>h</sub>
<b>Setting range</b> (min. value   unit   max. value)		
-1000.0	Hz/1°	1000.0
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00399/1	0.0 Hz/1°	Frequency [Hz] for test mode
C00399/2	0.0 Hz/1°	Start angle [°] for test mode
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10		

## C00416

Parameter   Name: <b>C00416   Resolver error correction</b>		Data type: UNSIGNED_32 Index: 24159 <sub>d</sub> = 5E5F <sub>h</sub>
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
0     99999999		<b>0</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C00420

Parameter   Name: <b>C00420   Number of increments of the encoder</b>		Data type: UNSIGNED_16 Index: 24155 <sub>d</sub> = 5E5B <sub>h</sub>
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
1     16384		<b>512</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C00421

Parameter   Name: <b>C00421   Encoder voltage</b>		Data type: UNSIGNED_16 Index: 24154 <sub>d</sub> = 5E5A <sub>h</sub>
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
5.0	V	9.0 <b>5.0 V</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 10		

## C00422

Parameter   Name: <b>C00422   Encoder type</b>		Data type: UNSIGNED_16 Index: 24153 <sub>d</sub> = 5E59 <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)		
<b>0</b>	<b>Incremental encoder (TTL signal)</b>	
1	Sin/cos encoder	
2	Absolute value encoder (Hiperface)	
3	Absolute value encoder (EnDat)	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C00427

Parameter   Name: <b>C00427   TTL encoder signal evaluation</b>		Data type: UNSIGNED_16 Index: 24148 <sub>d</sub> = 5E54 <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)		
<b>0</b>	<b>4x evaluation (A, B)</b>	
1	A:Increments B:Sign	
2	Increments A:pos. B:neg.	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00443

## C00443

Parameter   Name: <b>C00443   DIx status</b>		Data type: UNSIGNED_8 Index: 24132 <sub>d</sub> = 5E44 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0		1
<b>Subcodes</b>	<b>Information</b>	
C00443/1	Digital input 1	
C00443/2	Digital input 2	
C00443/3	Digital input 3	
C00443/4	Digital input 4	
C00443/5	Digital input 5	
C00443/6	Digital input 6	
C00443/7	Digital input 7	
C00443/8	Digital input 8	
C00443/9	Controller inhibit (inversion of input X5/RFR)	
C00443/10	Internal signal	
C00443/11	Feedback input of holding brake	
C00443/12	State bus input	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00444

Parameter   Name: <b>C00444   DOx status</b>		Data type: UNSIGNED_8 Index: 24131 <sub>d</sub> = 5E43 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0		1
<b>Subcodes</b>	<b>Information</b>	
C00444/1	Digital output 1	
C00444/2	Digital output 2	
C00444/3	Digital output 3	
C00444/4	Digital output 4	
C00444/5	Internal signal	
C00444/6	Internal signal	
C00444/7	Internal signal	
C00444/8	Internal signal	
C00444/9	User LED	
C00444/10	Internal signal	
C00444/11	Internal signal	
C00444/12	Internal signal	
C00444/13	Control output of holding brake	
C00444/14	Internal signal	
C00444/15	Internal signal	
C00444/16	Internal signal	
C00444/17	Internal signal	
C00444/18	State bus output	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		



C00465

Parameter   Name: <b>C00465   Keypad: Welcome screen time-out</b>		Data type: UNSIGNED_8 Index: 24110 <sub>d</sub> = 5E2E <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)		
0	<b>Never show welcome screen</b>	
5	5 min	
15	15 min	
30	30 min	
60	60 min	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00466

Parameter   Name: <b>C00466   Keypad: Default parameters</b>		Data type: UNSIGNED_16 Index: 24109 <sub>d</sub> = 5E2D <sub>h</sub>
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
0		65535 0
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00467

Parameter   Name: <b>C00467   Keypad: Default welcome screen</b>		Data type: UNSIGNED_8 Index: 24108 <sub>d</sub> = 5E2C <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)		
0	<b>Main menu</b>	
1	Parameter list	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00468

Parameter   Name: <b>C00468   Service code</b>		Data type: UNSIGNED_8 Index: 24107 <sub>d</sub> = 5E2B <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00469

Parameter   Name: <b>C00469   Keypad: Fct. STOP key</b>		Data type: UNSIGNED_8 Index: 24106 <sub>d</sub> = 5E2A <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)		
0	No function	
1	Inhibit controller	
2	<b>Activate quick stop</b>	
3	Stop application	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00490

Parameter   Name: <b>C00490   Position encoder</b>		Data type: UNSIGNED_16 Index: 24085 <sub>d</sub> = 5E15 <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)		
0	Resolver X7	
1	Encoder X8	
2	Encoder module in MXI1	
3	Encoder module in MXI2	
4	From application	
10	<b>Motor encoder</b>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00494

C00494

Parameter   Name: <b>C00494   Motor standstill time constant</b>		Data type: UNSIGNED_32 Index: 24081 <sub>d</sub> = 5E11 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	ms	100000 <b>0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00495

Parameter   Name: <b>C00495   Motor encoder</b>		Data type: UNSIGNED_16 Index: 24080 <sub>d</sub> = 5E10 <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>		
<b>0</b>	<b>Resolver X7</b>	
1	Encoder X8	
2	Encoder module in MXI1	
3	Encoder module in MXI2	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

C00497

Parameter   Name: <b>C00497   Speed act. val. time const.</b>		Data type: UNSIGNED_32 Index: 24078 <sub>d</sub> = 5E0E <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.0	ms	50.0 <b>2.0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT <input type="checkbox"/> Scaling factor: 10		

C00512

Parameter   Name: <b>C00512   Service code</b>		Data type: UNSIGNED_32 Index: 24063 <sub>d</sub> = 5DFF <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00513

Parameter   Name: <b>C00513   Service code</b>		Data type: VISIBLE_STRING Index: 24062 <sub>d</sub> = 5DFE <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00514

Parameter   Name: <b>C00514   Service code</b>		Data type: UNSIGNED_32 Index: 24061 <sub>d</sub> = 5DFD <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00515

Parameter   Name: <b>C00515   Service code</b>		Data type: UNSIGNED_32 Index: 24060 <sub>d</sub> = 5DFC <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

C00516

Parameter   Name: <b>C00516   Service code</b>		Data type: UNSIGNED_32 Index: 24059 <sub>d</sub> = 5DFB <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>		

## C00573

Parameter   Name: <b>C00573   Resp. to brake chopper overload</b>	Data type: UNSIGNED_32 Index: 24002 <sub>d</sub> = 5DC2 <sub>h</sub>
Response to release of brake chopper monitoring	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
1	Error
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT	

## C00574

Parameter   Name: <b>C00574   Resp. to overtemp. brake resist.</b>	Data type: UNSIGNED_32 Index: 24001 <sub>d</sub> = 5DC1 <sub>h</sub>
Response to release of brake resistor monitoring	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
1	Error
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT	

## C00576

Parameter   Name: <b>C00576   Window speed monitoring</b>	Data type: UNSIGNED_32 Index: 23999 <sub>d</sub> = 5DBF <sub>h</sub>		
Monitoring window for speed control error in [%] of nmax			
<b>Setting range</b> (min. value   unit   max. value)			
0	%	100	<b>100 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C00577

Parameter   Name: <b>C00577   Field weakening controller gain</b>	Data type: UNSIGNED_32 Index: 23998 <sub>d</sub> = 5DBE <sub>h</sub>		
With setting "0", the proportional component is deactivated and an integral-action controller is used.			
<b>Setting range</b> (min. value   unit   max. value)			
0.000	Vs/V	2147483.647	<b>0.000 Vs/V</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 1000			

## C00578

Parameter   Name: <b>C00578   Field weak. contr. reset time</b>	Data type: UNSIGNED_32 Index: 23997 <sub>d</sub> = 5DBD <sub>h</sub>		
With setting "240000.0 ms", the integral-action component of the field weakening controller is deactivated.			
<b>Setting range</b> (min. value   unit   max. value)			
1.0	ms	240000.0	<b>2000.0 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 10			

## C00579

Parameter   Name: <b>C00579   Resp. to speed monitoring</b>	Data type: UNSIGNED_32 Index: 23996 <sub>d</sub> = 5DBC <sub>h</sub>
Response to release of speed monitoring	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
1	Error
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C00580

Parameter   Name: <b>C00580   Resp. to encoder open circuit</b>	Data type: UNSIGNED_32 Index: 23995 <sub>d</sub> = 5DBB <sub>h</sub>
Response to open circuit in encoder	
<ul style="list-style-type: none"> <li>• <b>For the use of the encoder as motor encoder:</b> If an error occurs, the safe operation of the motor is no longer ensured, therefore for safety reasons always the "Error" response should be set!</li> </ul>	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
1	<b>Error</b>
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT	

## C00581

Parameter   Name: <b>C00581   Resp. to external fault</b>	Data type: UNSIGNED_32 Index: 23994 <sub>d</sub> = 5DBA <sub>h</sub>
Response to an external error	
<a href="#">▶ Drive interface</a>	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
1	<b>Error</b>
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
6	Information
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C00582

Parameter   Name: <b>C00582   Resp. to heatsink temp. &gt; C00122</b>		Data type: UNSIGNED_32 Index: 23993 <sub>d</sub> = 5DB9 <sub>h</sub>
Response, if heatsink temperature > variable limit temperature ( <a href="#">C00122</a> )		
<b>Selection list</b> (Lenze setting printed in bold)		
0	No response	
1	Error	
5	<b>Warning</b>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00583

Parameter   Name: <b>C00583   Resp. to motor overtemp. KTY</b>		Data type: UNSIGNED_32 Index: 23992 <sub>d</sub> = 5DB8 <sub>h</sub>
Response, if motor temperature > fixed limit temperature		
<b>Selection list</b> (Lenze setting printed in bold)		
0	No response	
1	<b>Error</b>	
5	Warning	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C00584

Parameter   Name: <b>C00584   Resp. to motor temp. &gt; C00121</b>		Data type: UNSIGNED_32 Index: 23991 <sub>d</sub> = 5DB7 <sub>h</sub>
Response, if motor temperature > variable limit temperature ( <a href="#">C00121</a> )		
<b>Selection list</b> (Lenze setting printed in bold)		
0	No response	
1	Error	
5	<b>Warning</b>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C00585

Parameter   Name: <b>C00585   Resp. to motor overtemp. PTC</b>		Data type: UNSIGNED_32 Index: 23990 <sub>d</sub> = 5DB6 <sub>h</sub>
Response, if motor temperature above PTC input T1/T2 too high		
<b>Selection list</b> (Lenze setting printed in bold)		
0	<b>No response</b>	
1	Error	
5	Warning	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00586

C00586

Parameter   Name:	Data type: UNSIGNED_32 Index: 23989 <sub>d</sub> = 5DB5 <sub>h</sub>
<b>C00586   Resp. to resolver open circuit</b>	
Response to open circuit in resolver	
• <b>For the use of the resolver as motor encoder:</b> If an error occurs, the safe operation of the motor is no longer ensured, therefore for safety reasons always the "Error" response should be set!	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
<b>1</b>	<b>Error</b>
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT	

C00587

Parameter   Name:	Data type: BITFIELD_8 Index: 23988 <sub>d</sub> = 5DB4 <sub>h</sub>
<b>C00587   Status - fan control</b>	
<b>Value is bit-coded:</b>	
Bit 0	Heatsink fan ON
Bit 1	Integral fan ON
Bit 2	Heatsink fan status 1
Bit 3	Heatsink fan status 2
Bit 4	Integral fan status
Bit 5	Reserved
Bit 6	Reserved
Bit 7	Reserved
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

C00588

Parameter   Name:	Data type: UNSIGNED_32 Index: 23987 <sub>d</sub> = 5DB3 <sub>h</sub>
<b>C00588   Resp. to t. sensor drive failure</b>	
Response, to error/failure of temperature sensor for heatsink/temperature inside the controller	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
<b>1</b>	<b>Error</b>
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

C00589

Parameter   Name:	Data type: UNSIGNED_32 Index: 23986 <sub>d</sub> = 5DB2 <sub>h</sub>
<b>C00589   Resp. to CPU temp. &gt; C00126</b>	
Response, if CPU temperature on the control card > variable limit temperature ( <a href="#">C00126</a> ).	
<b>Selection list</b> (Lenze setting printed in bold)	
<b>0</b>	<b>No response</b>
1	Error
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C00591

Parameter   Name: <b>C00591   Resp. to CAN-RPDOx error</b>		Data type: UNSIGNED_8 Index: 23984 <sub>d</sub> = 5DB0 <sub>h</sub>
Response, if the corresponding CAN RPDO has not been received in the configured time or with the configured sync.		
<b>Selection list</b>		
0	No response	
1	Error	
2	Trouble	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00591/1	0: No response	Response to non received RPDO1 ... RPDO4
C00591/...		
C00591/4		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00594

Parameter   Name: <b>C00594   Resp. to t. sensor motor failure</b>		Data type: UNSIGNED_32 Index: 23981 <sub>d</sub> = 5DAD <sub>h</sub>
Response to motor temperature sensor error.		
<b>Selection list (Lenze setting printed in bold)</b>		
0	No response	
<b>1</b>	<b>Error</b>	
5	Warning	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C00595

Parameter   Name: <b>C00595   Resp. to CAN bus off</b>		Data type: UNSIGNED_8 Index: 23979 <sub>d</sub> = 5DAC <sub>h</sub>
Response, if CAN node switches to the bus off status.		
<b>Selection list (Lenze setting printed in bold)</b>		
<b>0</b>	<b>No response</b>	
1	Error	
2	Trouble	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00596

Parameter   Name: <b>C00596   Threshold max. speed reached</b>		Data type: UNSIGNED_32 Index: 23979 <sub>d</sub> = 5DAB <sub>h</sub>
Threshold for speed monitoring		
<ul style="list-style-type: none"> <li>The reaction for reaching the threshold can be selected in <a href="#">C00607</a>.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
50	rpm	50000 <b>6500 rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00597

C00597

<b>Parameter   Name:</b> <b>C00597   Resp. to motor phase failure</b>	<b>Data type:</b> UNSIGNED_32 <b>Index:</b> 23978 <sub>d</sub> = 5DAA <sub>h</sub>
Response to release of motor phase failure monitoring	
<b>Selection list</b> (Lenze setting printed in bold)	
0	<b>No response</b>
1	Error
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

C00598

<b>Parameter   Name:</b> <b>C00598   Resp. to open circuit AIN1</b>	<b>Data type:</b> UNSIGNED_32 <b>Index:</b> 23977 <sub>d</sub> = 5DA9 <sub>h</sub>
Response if with master current at AIN1 and mode LifeZero ( $\pm 4... \pm 20$ mA) the current is in the non permitted range (-4...+4 mA).	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
1	<b>Error</b>
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
6	Information
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

C00599

<b>Parameter   Name:</b> <b>C00599   Threshold motor phase failure</b>	<b>Data type:</b> INTEGER_32 <b>Index:</b> 23976 <sub>d</sub> = 5DA8 <sub>h</sub>		
Threshold for motor phase failure monitoring			
<ul style="list-style-type: none"> <li>The response when reaching the threshold can be selected in <a href="#">C00597</a>.</li> </ul>			
<b>Setting range</b> (min. value   unit   max. value)			
1.0	%	10.0	<b>5.0 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10			

C00600

<b>Parameter   Name:</b> <b>C00600   Resp. to DC bus overvoltage</b>	<b>Data type:</b> UNSIGNED_32 <b>Index:</b> 23975 <sub>d</sub> = 5DA7 <sub>h</sub>
Response to DC bus overvoltage	
<b>Selection list</b> (Lenze setting printed in bold)	
1	Error
2	<b>Fault</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT	



## C00601

Parameter   Name: <b>C00601   Resp. to comm. encoder error</b>	Data type: UNSIGNED_32 Index: 23974 <sub>d</sub> = 5DA6 <sub>h</sub>
Response to release of encoder monitoring	
<ul style="list-style-type: none"> <li>• <b>For the use of the encoder as motor encoder:</b> If an error occurs, the safe operation of the motor is no longer ensured, therefore for safety reasons always the "Error" response should be set!</li> </ul>	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
<b>1</b>	<b>Error</b>
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT	

## C00604

Parameter   Name: <b>C00604   Resp. to device overload</b>	Data type: UNSIGNED_32 Index: 23974 <sub>d</sub> = 5DA3 <sub>h</sub>
Response, if adjustable "I x t" warning threshold ( <a href="#">C00123</a> ) is reached.	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
1	Error
5	<b>Warning</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C00606

Parameter   Name: <b>C00606   Resp. to motor overload</b>	Data type: UNSIGNED_32 Index: 23969 <sub>d</sub> = 5DA1 <sub>h</sub>
Response, if adjustable "I <sup>2</sup> x t" warning threshold ( <a href="#">C00127</a> ) is reached.	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
1	Error
5	<b>Warning</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT	

## C00607

Parameter   Name: <b>C00607   Resp. to max. speed reached</b>	Data type: UNSIGNED_32 Index: 23968 <sub>d</sub> = 5DA0 <sub>h</sub>
Response if adjustable speed threshold ( <a href="#">C00596</a> ) is reached.	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
<b>1</b>	<b>Error</b>
2	Trouble
3	Quick stop by trouble
4	Warning locked
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00610

## C00610

Parameter   Name: <b>C00610   Resp. to heatsink fan failure</b>	Data type: UNSIGNED_32 Index: 23965 <sub>d</sub> = 5D9D <sub>h</sub>
Response if fan speed of heatsink fan is too low.	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
<b>1</b>	<b>Error</b>
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C00611

Parameter   Name: <b>C00611   Resp. to integral fan failure</b>	Data type: UNSIGNED_32 Index: 23964 <sub>d</sub> = 5D9C <sub>h</sub>
Response if fan speed of interior fan is too low.	
<b>Selection list</b> (Lenze setting printed in bold)	
0	No response
<b>1</b>	<b>Error</b>
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C00612

Parameter   Name: <b>C00612   Resp. to CAN node guarding error</b>	Data type: UNSIGNED_8 Index: 23963 <sub>d</sub> = 5D9B <sub>h</sub>	
Response of master, if the corresponding node guarding response is not received.		
<b>Selection list</b>		
0	No response	
1	Error	
2	Trouble	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00612/1	0: No response	Response to non received telegram for monitoring entry 1 ... 32
C00612/...		
C00612/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00613

Parameter   Name: <b>C00613   Resp. to CAN heartbeat error</b>		Data type: UNSIGNED_8 Index: 23962 <sub>d</sub> = 5D9A <sub>h</sub>
Response, if the corresponding heartbeat telegram is not received.		
<b>Selection list</b>		
0	No response	
1	Error	
2	Trouble	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00613/1	0: No response	Response to non received telegram for monitoring entry 1 ... 32
C00613/...		
C00613/32		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00614

Parameter   Name: <b>C00614   Resp. to CAN life guarding error</b>		Data type: UNSIGNED_8 Index: 23961 <sub>d</sub> = 5D99 <sub>h</sub>
Response of slave if node guarding request is not sent.		
<b>Selection list (Lenze setting printed in bold)</b>		
<b>0</b>	<b>No response</b>	
1	Error	
2	Trouble	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00615

Parameter   Name: <b>C00615   Resp. to imp. device config.</b>		Data type: UNSIGNED_32 Index: 23960 <sub>d</sub> = 5D98 <sub>h</sub>
<b>Selection list</b>		
0	No response	
1	Error	
3	Quick stop by trouble	
4	Warning locked	
6	Information	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00615/1	0: No response	Reserved
C00615/2	1: Error	Resp. to imp. module in MXI1
C00615/3	1: Error	Resp. to imp. module in MXI2
C00615/4	0: No response	Reserved
C00615/5	0: No response	Reserved
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00618

C00618

Parameter   Name: <b>C00618   Number of CRC cycles</b>		Data type: UNSIGNED_32 Index: 23957 <sub>d</sub> = 5D95 <sub>h</sub>
Display range (min. value   unit   max. value)		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00619

Parameter   Name: <b>C00619   Resp. to max. motor current</b>		Data type: UNSIGNED_32 Index: 23956 <sub>d</sub> = 5D94 <sub>h</sub>
Response if the adjustable maximum motor current threshold ( <a href="#">C00620</a> ) is exceeded.		
Selection list (Lenze setting printed in bold)		
0	No response	
<b>1</b>	<b>Error</b>	
2	Trouble	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

C00620

Parameter   Name: <b>C00620   Max. motor current threshold</b>		Data type: UNSIGNED_32 Index: 23955 <sub>d</sub> = 5D93 <sub>h</sub>
Threshold for maximum motor current monitoring		
<ul style="list-style-type: none"> <li>The response when reaching the threshold can be selected in <a href="#">C00619</a>.</li> </ul>		
Setting range (min. value   unit   max. value)		Lenze setting
0.0	A	3000.0 <b>3000.0 A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                   Scaling factor: 10		

C00625

Parameter   Name: <b>C00625   CAN behaviour in the case of error</b>		Data type: UNSIGNED_8 Index: 23950 <sub>d</sub> = 5D8E <sub>h</sub>
Selection list (Lenze setting printed in bold)		
<b>0</b>	<b>Pre-operational state</b>	
1	No state change	
2	"Stopped" state	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00635

Parameter   Name: <b>C00635   Resp. to new firmware of drive</b>		Data type: UNSIGNED_32 Index: 23940 <sub>d</sub> = 5D84 <sub>h</sub>
Selection list (Lenze setting printed in bold)		
0	No response	
<b>1</b>	<b>Error</b>	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00636

Parameter   Name: <b>C00636   Resp. to new module in MX1</b>		Data type: UNSIGNED_32 Index: 23939 <sub>d</sub> = 5D83 <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)		
0	No response	
1	Error	
3	Quick stop by trouble	
4	<b>Warning locked</b>	
5	Warning	
6	Information	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00637

Parameter   Name: <b>C00637   Resp. to new module in MX12</b>		Data type: UNSIGNED_32 Index: 23938 <sub>d</sub> = 5D82 <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)		
0	No response	
1	Error	
3	Quick stop by trouble	
4	<b>Warning locked</b>	
5	Warning	
6	Information	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00691

Parameter   Name: <b>C00691   Total speed setpoint</b>		Data type: INTEGER_32 Index: 23884 <sub>d</sub> = 5D4C <sub>h</sub>
<b>Display range</b> (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

## C00692

Parameter   Name: <b>C00692   Speed setpoint</b>		Data type: INTEGER_32 Index: 23883 <sub>d</sub> = 5D4B <sub>h</sub>
<b>Display range</b> (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

## C00693

Parameter   Name: <b>C00693   Actual speed</b>		Data type: INTEGER_32 Index: 23882 <sub>d</sub> = 5D4A <sub>h</sub>
<b>Display range</b> (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

## C00694

Parameter   Name: <b>C00694   Speed controller output</b>		Data type: INTEGER_32 Index: 23881 <sub>d</sub> = 5D49 <sub>h</sub>
<b>Display range</b> (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00695

C00695

Parameter   Name:	<b>C00695   Total torque setpoint</b>		Data type: INTEGER_32 Index: 23880 <sub>d</sub> = 5D48 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100			

C00696

Parameter   Name:	<b>C00696   Torque setpoint</b>		Data type: INTEGER_32 Index: 23879 <sub>d</sub> = 5D47 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100			

C00697

Parameter   Name:	<b>C00697   Filtered torque setpoint</b>		Data type: INTEGER_32 Index: 23878 <sub>d</sub> = 5D46 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100			

C00698

Parameter   Name:	<b>C00698   Actual torque</b>		Data type: INTEGER_32 Index: 23877 <sub>d</sub> = 5D45 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>			
-200.00	%	200.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100			

C00730

Parameter   Name:	<b>C00730   GDO common parameter</b>		Data type: INTEGER_32 Index: 23845 <sub>d</sub> = 5D25 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>			

C00731

Parameter   Name:	<b>C00731   GDO channel 1/trigger 1</b>		Data type: INTEGER_32 Index: 23844 <sub>d</sub> = 5D24 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>			

C00732

Parameter   Name:	<b>C00732   GDO channel 2/trigger 2</b>		Data type: INTEGER_32 Index: 23843 <sub>d</sub> = 5D23 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>			

C00733

Parameter   Name:	<b>C00733   GDO channel 3</b>		Data type: INTEGER_32 Index: 23842 <sub>d</sub> = 5D22 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>			

C00734

Parameter   Name:	<b>C00734   GDO channel 4</b>		Data type: INTEGER_32 Index: 23841 <sub>d</sub> = 5D21 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>			

C00735

Parameter   Name:	<b>C00735   GDO channel 5</b>		Data type: INTEGER_32 Index: 23840 <sub>d</sub> = 5D20 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>			

C00736

Parameter | Name: **C00736 | GDO channel 6** Data type: INTEGER\_32  
Index: 23839<sub>d</sub> = 5D1F<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00737

Parameter | Name: **C00737 | GDO channel 7** Data type: INTEGER\_32  
Index: 23838<sub>d</sub> = 5D1E<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00738

Parameter | Name: **C00738 | GDO channel 8** Data type: INTEGER\_32  
Index: 23837<sub>d</sub> = 5D1D<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00739

Parameter | Name: **C00739 | GDO status information** Data type: INTEGER\_32  
Index: 23836<sub>d</sub> = 5D1C<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C00770

Parameter | Name: **C00770 | MCTRL\_dnMotorPosAct** Data type: UNSIGNED\_32  
Index: 23805<sub>d</sub> = 5CFD<sub>h</sub>

Internal motor control (MCTRL) signal

Display range (min. value   unit   max. value)		
0	Incr.	4294967295

Subcodes	Information
C00770/1	Low Word
C00770/2	High Word

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C00771

Parameter | Name: **C00771 | MCTRL\_dnLoadPosAct** Data type: UNSIGNED\_32  
Index: 23804<sub>d</sub> = 5CFC<sub>h</sub>

Internal motor control (MCTRL) signal

Display range (min. value   unit   max. value)		
0	Incr.	4294967295

Subcodes	Information
C00771/1	Low Word
C00771/2	High Word

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C00772

Parameter | Name: **C00772 | MCTRL\_dnMotorSpeedAct** Data type: INTEGER\_32  
Index: 23803<sub>d</sub> = 5CFB<sub>h</sub>

Internal motor control (MCTRL) signal

Display range (min. value   unit   max. value)		
-480000	rpm	480000

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00773

C00773

Parameter   Name: <b>C00773   MCTRL_dnLoadSpeedAct</b>		Data type: INTEGER_32 Index: 23802 <sub>d</sub> = 5CF <sub>Ah</sub>
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-480000	rpm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00774

Parameter   Name: <b>C00774   MCTRL_dnTorqueAct</b>		Data type: INTEGER_32 Index: 23801 <sub>d</sub> = 5CF <sub>9h</sub>
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

C00775

Parameter   Name: <b>C00775   MCTRL_dnOutputSpeedCtrl</b>		Data type: INTEGER_32 Index: 23800 <sub>d</sub> = 5CF <sub>8h</sub>
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

C00776

Parameter   Name: <b>C00776   MCTRL_dnInputJerkCtrl</b>		Data type: INTEGER_32 Index: 23799 <sub>d</sub> = 5CF <sub>7h</sub>
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

C00777

Parameter   Name: <b>C00777   MCTRL_dnInputTorqueCtrl</b>		Data type: INTEGER_32 Index: 23798 <sub>d</sub> = 5CF <sub>6h</sub>
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

C00778

Parameter   Name: <b>C00778   MCTRL_dnFluxAct</b>		Data type: INTEGER_32 Index: 23797 <sub>d</sub> = 5CF <sub>5h</sub>
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		



C00779

Parameter   Name:	<b>C00779   MCTRL_dnDCBusVoltage</b>		Data type: INTEGER_32 Index: 23796 <sub>d</sub> = 5CF4 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0	V	1000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00780

Parameter   Name:	<b>C00780   MCTRL_dnImotAct</b>		Data type: INTEGER_32 Index: 23795 <sub>d</sub> = 5CF3 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-500.00	A	500.00	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT         Scaling factor: 100			

C00781

Parameter   Name:	<b>C00781   MCTRL_dwMaxMotorSpeed</b>		Data type: UNSIGNED_32 Index: 23794 <sub>d</sub> = 5CF2 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0	rpm	480000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00782

Parameter   Name:	<b>C00782   MCTRL_dwMaxMotorTorque</b>		Data type: UNSIGNED_32 Index: 23793 <sub>d</sub> = 5CF1 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0.000	Nm	2147483.647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT         Scaling factor: 1000			

C00783

Parameter   Name:	<b>C00783   MCTRL_dwMotorVoltageAct</b>		Data type: UNSIGNED_32 Index: 23792 <sub>d</sub> = 5CF0 <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
0	V	2000	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C00784

Parameter   Name:	<b>C00784   MCTRL_dnMotorFreqAct</b>		Data type: INTEGER_32 Index: 23791 <sub>d</sub> = 5CEF <sub>h</sub>
Internal motor control (MCTRL) signal			
<b>Display range (min. value   unit   max. value)</b>			
-800.0	Hz	800.0	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT         Scaling factor: 10			

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00786

C00786

Parameter   Name: <b>C00786   MCTRL_dnlxtLoad</b>		Data type: INTEGER_32 Index: 23789 <sub>d</sub> = 5CE <sub>d</sub> h
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

C00787

Parameter   Name: <b>C00787   MCTRL_dnFlyingSpeedAct</b>		Data type: INTEGER_32 Index: 23788 <sub>d</sub> = 5CE <sub>d</sub> h
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-480000	rpm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00788

Parameter   Name: <b>C00788   MCTRL_dwMaxEffMotorTorque</b>		Data type: INTEGER_32 Index: 23787 <sub>d</sub> = 5CE <sub>d</sub> h
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
0.000	Nm	2147483.647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 1000		

C00789

Parameter   Name: <b>C00789   MCTRL_dwMaxDeviceCurrent</b>		Data type: INTEGER_32 Index: 23786 <sub>d</sub> = 5CE <sub>d</sub> h
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
0.00	A	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

C00790

Parameter   Name: <b>C00790   MCTRL_dnl2xtLoad</b>		Data type: INTEGER_32 Index: 23785 <sub>d</sub> = 5CE <sub>d</sub> h
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

C00791

Parameter   Name: <b>C00791   MCTRL_dnDeltaMotorPos_p</b>		Data type: INTEGER_32 Index: 23784 <sub>d</sub> = 5CE <sub>d</sub> h
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-2147483647	Incr.	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00792

Parameter   Name: <b>C00792   MCTRL_dnOutputPosCtrlMotor_s</b>		Data type: INTEGER_32 Index: 23783 <sub>d</sub> = 5CE7 <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-200	%	200
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00800

Parameter   Name: <b>C00800   MCTRL_dnPosSet</b>		Data type: UNSIGNED_32 Index: 23775 <sub>d</sub> = 5CDF <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
0	Incr.	4294967295
<b>Subcodes</b>		<b>Information</b>
C00800/1		Low Word
C00800/2		High Word
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00802

Parameter   Name: <b>C00802   MCTRL_dnSpeedAdd</b>		Data type: INTEGER_32 Index: 23773 <sub>d</sub> = 5CDD <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-480000	rpm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C00803

Parameter   Name: <b>C00803   MCTRL_dnTorqueAdd</b>		Data type: INTEGER_32 Index: 23772 <sub>d</sub> = 5CDC <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-2147483.647	Nm	2147483.647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 1000		

## C00804

Parameter   Name: <b>C00804   MCTRL_dnAccelerationAdd</b>		Data type: INTEGER_32 Index: 23771 <sub>d</sub> = 5CDB <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-2147483.647	1/s <sup>2</sup>	2147483.647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 1000		

## C00805

Parameter   Name: <b>C00805   MCTRL_dnSpeedLowLimit</b>		Data type: INTEGER_32 Index: 23770 <sub>d</sub> = 5CDA <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-480000	rpm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00806

C00806

Parameter   Name:		Data type: INTEGER_32 Index: 23769 <sub>d</sub> = 5CD9 <sub>h</sub>
<b>C00806   MCTRL_dnTorqueLowLimit</b>		
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

C00807

Parameter   Name:		Data type: INTEGER_32 Index: 23768 <sub>d</sub> = 5CD8 <sub>h</sub>
<b>C00807   MCTRL_dnTorqueHighLimit</b>		
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-21474836.47	Nm	21474836.47
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

C00808

Parameter   Name:		Data type: INTEGER_32 Index: 23767 <sub>d</sub> = 5CD7 <sub>h</sub>
<b>C00808   MCTRL_dnPosCtrlOutLimit</b>		
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-480000	rpm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00809

Parameter   Name:		Data type: INTEGER_32 Index: 23766 <sub>d</sub> = 5CD6 <sub>h</sub>
<b>C00809   MCTRL_dnTorqueCtrlAdapt</b>		
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

C00810

Parameter   Name:		Data type: INTEGER_32 Index: 23765 <sub>d</sub> = 5CD5 <sub>h</sub>
<b>C00810   MCTRL_dnSpeedCtrlAdapt</b>		
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

C00811

Parameter   Name:		Data type: INTEGER_32 Index: 23764 <sub>d</sub> = 5CD4 <sub>h</sub>
<b>C00811   MCTRL_dnPosCtrlAdapt</b>		
Internal motor control (MCTRL) signal		
Display range (min. value   unit   max. value)		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100		

#### C00812

Parameter   Name: <b>C00812   MCTRL_dnMotorPosRefValue</b>		Data type: UNSIGNED_32 Index: 23763 <sub>d</sub> = 5CD3 <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
0	Incr.	4294967295
<b>Subcodes</b>		<b>Information</b>
C00812/1		Low Word
C00812/2		High Word
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

#### C00813

Parameter   Name: <b>C00813   MCTRL_dnLoadPosRefValue</b>		Data type: UNSIGNED_32 Index: 23762 <sub>d</sub> = 5CD2 <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
0	Incr.	4294967295
<b>Subcodes</b>		<b>Information</b>
C00813/1		Low Word
C00813/2		High Word
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

#### C00814

Parameter   Name: <b>C00814   MCTRL_dnBoost</b>		Data type: INTEGER_32 Index: 23761 <sub>d</sub> = 5CD1 <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-1000	V	1000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

#### C00815

Parameter   Name: <b>C00815   MCTRL_dnSpeedCtrlIntegrator</b>		Data type: INTEGER_32 Index: 23760 <sub>d</sub> = 5CD0 <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-480000	Nm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

#### C00816

Parameter   Name: <b>C00816   MCTRL_dnFieldWeak</b>		Data type: INTEGER_32 Index: 23759 <sub>d</sub> = 5CCF <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

#### C00817

Parameter   Name: <b>C00817   MCTRL_dnSpeedSet_s</b>		Data type: INTEGER_32 Index: 23758 <sub>d</sub> = 5CCF <sub>h</sub>
Internal motor control (MCTRL) signal		
<b>Display range (min. value   unit   max. value)</b>		
-480000	rpm	480000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C00854

C00854

Parameter   Name: <b>C00854   ID status</b>		Data type: UNSIGNED_32 Index: 23721 <sub>d</sub> = 5CA9 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0		100
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00878

Parameter   Name: <b>C00878   Status DCTRL control input</b>		Data type: UNSIGNED_8 Index: 23697 <sub>d</sub> = 5C91 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0		1
<b>Subcodes</b>	<b>Information</b>	
C00878/1		
C00878/2		
C00878/3		
C00878/4		
C00878/5		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C00909

Parameter   Name: <b>C00909   Speed limitation</b>		Data type: INTEGER_16 Index: 23666 <sub>d</sub> = 5C72 <sub>h</sub>
Speed limitation for speed setpoint		
<b>Setting range (min. value   unit   max. value)</b>		
-175.0	%	175.0
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C00909/1	175.0 %	Upper speed limit value
C00909/2	-175.0 %	Lower speed limit value
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10		

C01120

Parameter   Name: <b>C01120   Sync source</b>		Data type: UNSIGNED_8 Index: 23455 <sub>d</sub> = 5B9F <sub>h</sub>
<b>Selection list (Lenze setting printed in bold)</b>		
<b>0</b>	<b>Off</b>	
1	CAN on-board	
2	CAN module	
4	Module in MXI1	
5	Module in MXI2	
6	Digital input 1	
7	Digital input 2	
8	Digital input 3	
9	Digital input 4	
10	Digital input 5	
11	Digital input 6	
12	Digital input 7	
13	Digital input 8	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C01121

Parameter   Name: <b>C01121   Sync cycle time</b>		Data type: UNSIGNED_32 Index: 23454 <sub>d</sub> = 5B9E <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
250	μs	13000 <b>1000 μs</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C01122

Parameter   Name: <b>C01122   Sync phase position</b>		Data type: UNSIGNED_32 Index: 23453 <sub>d</sub> = 5B9D <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	μs	64000 <b>0 μs</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C01123

Parameter   Name: <b>C01123   Sync window</b>		Data type: UNSIGNED_32 Index: 23452 <sub>d</sub> = 5B9C <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0	μs	1000 <b>0 μs</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C01124

## C01124

Parameter   Name:		Data type: UNSIGNED_8 Index: 23451 <sub>d</sub> = 5B9B <sub>h</sub>
<b>C01124   Sync PLL increment</b>		
<b>Selection list</b> (Lenze setting printed in bold)		
1	<b>10 ns</b>	
2	21 ns	
3	31 ns	
4	41 ns	
5	52 ns	
6	63 ns	
7	73 ns	
8	83 ns	
9	94 ns	
10	104 ns	
11	115 ns	
12	125 ns	
13	135 ns	
14	146 ns	
15	156 ns	
16	167 ns	
17	174 ns	
18	182 ns	
19	190 ns	
20	198 ns	
21	206 ns	
22	213 ns	
23	221 ns	
24	229 ns	
25	237 ns	
26	245 ns	
27	252 ns	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C01190

Parameter   Name:		Data type: UNSIGNED_32 Index: 23385 <sub>d</sub> = 5B59 <sub>h</sub>
<b>C01190   Motor thermal sensor</b>		
<b>Selection list</b> (Lenze setting printed in bold)		<b>Information</b>
0	<b>KTY83-110</b>	Lenze standard KTY83-110 (MDSKX, MCS06)
1	Spec. characteristic	Characteristic defined via <a href="#">C01191</a> and <a href="#">C01192</a> .
2	KTY83-110 + 2 x PTC	Lenze standard KTY83-110 + 2 x PTC 150°C (MCS09-MCS19)
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		



## C01191

Parameter   Name: <b>C01191   Temperature for spec. characteristic</b>		Data type: UNSIGNED_32 Index: 23384 <sub>d</sub> = 5B58 <sub>h</sub>
The special thermal sensor characteristic is selected by setting <a href="#">C01190</a> ="1"		
<b>Setting range</b> (min. value   unit   max. value)		
0	°C	255
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C01191/1	25 °C	Value 1 for spec. thermal sensor characteristic
C01191/2	150 °C	Value 2 for spec. thermal sensor characteristic
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C01192

Parameter   Name: <b>C01192   Resistor for spec. characteristic</b>		Data type: UNSIGNED_32 Index: 23383 <sub>d</sub> = 5B57 <sub>h</sub>
The special thermal sensor characteristic is selected by setting <a href="#">C01190</a> ="1"		
<b>Setting range</b> (min. value   unit   max. value)		
0	Ohm	30000
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C01192/1	1000 Ohm	Value 1 for spec. thermal sensor characteristic
C01192/2	2225 Ohm	Value 2 for spec. thermal sensor characteristic
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C01193

Parameter   Name: <b>C01193   Motor temp. feedback system</b>		Data type: UNSIGNED_16 Index: 23382 <sub>d</sub> = 5B56 <sub>h</sub>
Selection of feedback system for motor temperature detection.		
<b>Selection list</b> (Lenze setting printed in bold)		
	<b>0</b> Speed feedback	
	1 Resolver X7	
	2 Encoder X8	
	3 Encoder module in MXI1	
	4 Encoder module in MXI2	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C01194

Parameter   Name: <b>C01194   Motor operating temperature</b>		Data type: INTEGER_32 Index: 23381 <sub>d</sub> = 5B55 <sub>h</sub>
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
1	°C	200 <b>140 °C</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

## C01195

Parameter   Name: <b>C01195   Influence winding I<sup>2</sup>xt mon.</b>		Data type: UNSIGNED_32 Index: 23380 <sub>d</sub> = 5B54 <sub>h</sub>
I <sup>2</sup> xt motor monitoring: Influence of the winding temperature		
<ul style="list-style-type: none"> <li>By setting "0 %" the time constant for the winding is not considered and the thermal model is only calculated with the time constant set for the housing/steel plates.</li> </ul>		
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
0	%	100 <b>0 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C01196

C01196

Parameter   Name:		Data type: UNSIGNED_32 Index: 23379 <sub>d</sub> = 5B53 <sub>h</sub>
<b>C01196   S1 torque characteristic I<sup>2</sup>xt mon.</b>		
I <sup>2</sup> xt motor monitoring: Speed-dependent evaluation of the motor current		
<ul style="list-style-type: none"> <li>By selecting a characteristic the permissible motor current is evaluated depending on speed for calculating the thermal motor utilisation.</li> </ul>		
<b>Setting range (min. value   unit   max. value)</b>		
0	%	600
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C01196/1	0 %	S1 torque characteristic n1/nn
C01196/2	100 %	S1 torque characteristic I1/In
C01196/3	0 %	S1 torque characteristic n2/nn
C01196/4	100 %	S1 torque characteristic I2/In
C01196/5	100 %	S1 torque characteristic n3/nn
C01196/6	100 %	S1 torque characteristic I3/In
C01196/7	100 %	S1 torque characteristic n4/nn
C01196/8	100 %	S1 torque characteristic I4/In
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

C01203

Parameter   Name:		Data type: UNSIGNED_16 Index: 23372 <sub>d</sub> = 5B4C <sub>h</sub>
<b>C01203   Counter: Brake chopper overload</b>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C01204

Parameter   Name:		Data type: UNSIGNED_16 Index: 23371 <sub>d</sub> = 5B4B <sub>h</sub>
<b>C01204   Counter: Ixt overload</b>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C01205

Parameter   Name:		Data type: UNSIGNED_16 Index: 23370 <sub>d</sub> = 5B4A <sub>h</sub>
<b>C01205   Counter: DC bus overvoltage</b>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C01206

Parameter   Name:		Data type: UNSIGNED_16 Index: 23369 <sub>d</sub> = 5B49 <sub>h</sub>
<b>C01206   Counter: Mains switching</b>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C01208

Parameter   Name:		Data type: UNSIGNED_16 Index: 23367 <sub>d</sub> = 5B47 <sub>h</sub>
<b>C01208   Counter: heatsink overtemp.</b>		
<b>Display range (min. value   unit   max. value)</b>		
0		65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C01209

Parameter   Name:	<b>C01209   Counter: housing overtemp.</b>		Data type: UNSIGNED_16 Index: 23366 <sub>d</sub> = 5B46 <sub>h</sub>
Display range (min. value   unit   max. value)			
0		65535	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C01210

Parameter   Name:	<b>C01210   Electrolyt. capacitor av. temp.</b>		Data type: UNSIGNED_8 Index: 23365 <sub>d</sub> = 5B45 <sub>h</sub>
Display range (min. value   unit   max. value)			
0		255	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C01211

Parameter   Name:	<b>C01211   Service code</b>		Data type: UNSIGNED_32 Index: 23364 <sub>d</sub> = 5B44 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>			

## C01212

Parameter   Name:	<b>C01212   Counter: power section overload</b>		Data type: UNSIGNED_16 Index: 23363 <sub>d</sub> = 5B43 <sub>h</sub>
Display range (min. value   unit   max. value)			
0		65535	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C01213

Parameter   Name:	<b>C01213   Service code DataFlash</b>		Data type: UNSIGNED_32 Index: 23362 <sub>d</sub> = 5B42 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>			

## C01214

Parameter   Name:	<b>C01214   Internal clock</b>		Data type: VISIBLE_STRING Index: 23361 <sub>d</sub> = 5B41 <sub>h</sub>
System time of the controller in the format "dd/mm/yyyy hh:mm:ss"			
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C01501

Parameter   Name:	<b>C01501   Resp. to comm. error with MXI1</b>		Data type: UNSIGNED_32 Index: 23074 <sub>d</sub> = 5A22 <sub>h</sub>
Response to communication error between "intelligent" module in module slot 1 and basic device			
<b>Selection list (Lenze setting printed in bold)</b>			
	<b>0</b>	No response	
	1	Error	
	3	Quick stop by trouble	
	4	Warning locked	
	5	Warning	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C01502

## C01502

Parameter   Name:	Data type: UNSIGNED_32 Index: 23073 <sub>d</sub> = 5A21 <sub>h</sub>
<b>C01502   Resp. to comm. error with MXI2</b>	
Response to communication error between "intelligent" module in module slot 2 and basic device	
<b>Selection list</b> (Lenze setting printed in bold)	
0	<b>No response</b>
1	Error
3	Quick stop by trouble
4	Warning locked
5	Warning
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C01510

Parameter   Name:	Data type: VISIBLE_STRING Index: 23065 <sub>d</sub> = 5A19 <sub>h</sub>
<b>C01510   Ethernet IP address client x</b>	
Display of the five possible server channels	
<ul style="list-style-type: none"><li>• If a client is connected via one of these server channels, the IP address and the port of the client will be indicated in the form of "xxx.xxx.xxx.xxx : yyyy".</li><li>• If no client is connected via the server channel, "---.---.---.--- : ---" will be indicated.</li></ul>	
<b>Subcodes</b>	<b>Information</b>
C01510/1	Server channel 1 ... 5
C01510/...	
C01510/5	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C01511

Parameter   Name:	Data type: UNSIGNED_8 Index: 23064 <sub>d</sub> = 5A18 <sub>h</sub>
<b>C01511   Ethernet status client x</b>	
Status of the five possible server channels	
<b>Selection list</b>	
0	Not connected
1	Connected
2	Stop
3	Unknown status
<b>Subcodes</b>	<b>Information</b>
C01511/1	Status of server channel 1 ... 5
C01511/...	
C01511/5	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C01902

Parameter   Name: <b>C01902   Diagnostics X6: Max. baud rate</b>	Data type: UNSIGNED_32 Index: 22673 <sub>d</sub> = 5891 <sub>h</sub>
<p>Maximum permissible baud rate of the basic device after determination of the baud rate at the diagnostics interface X6</p> <ul style="list-style-type: none"> <li>• Communication starts with the default baud rate 19200 of the basic device.</li> </ul>	
<b>Selection list</b> (Lenze setting printed in bold)	
9600	9600 baud
19200	19.200 baud
38400	38.400 baud
57600	57.600 baud
115200	115.200 baud
230400	230.400 baud
375000	375.000 baud
750000	750.000 baud
1500000	1.500.000 baud
<b>3000000</b>	<b>3.000.000 baud</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input checked="" type="checkbox"/> COM <input type="checkbox"/> MOT	

## C01903

Parameter   Name: <b>C01903   Diagnostics X6: Change baud rate</b>	Data type: UNSIGNED_32 Index: 22672 <sub>d</sub> = 5890 <sub>h</sub>
<p>New Determination of the baud rate at the diagnostics interface X6</p>	
<b>Selection list</b> (Lenze setting printed in bold)	
<b>0</b>	<b>Ignore changes</b>
1	Set a higher baud rate
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input checked="" type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C01905

Parameter   Name: <b>C01905   Diagnostics X6: Curr. baud rate</b>	Data type: UNSIGNED_32 Index: 22670 <sub>d</sub> = 588E <sub>h</sub>
<p>Current baud rate at diagnostics interface X6</p>	
<b>Display range</b> (min. value   unit   max. value)	
0	3000000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C02104

Parameter   Name: <b>C02104   Program auto-start</b>	Data type: UNSIGNED_32 Index: 22471 <sub>d</sub> = 57C7 <sub>h</sub>
<b>Selection list</b> (Lenze setting printed in bold)	
0	Off
<b>1</b>	<b>Autom. after mains connection</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C02108

Parameter   Name: <b>C02108   Program status</b>	Data type: UNSIGNED_8 Index: 22467 <sub>d</sub> = 57C3 <sub>h</sub>
<b>Selection list</b> (display only)	
0	Program is running
1	Program stopped
2	Program stopped at breakpoint
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02109

C02109

Parameter   Name: <b>C02109   Program runtime</b>		Data type: UNSIGNED_16 Index: 22466 <sub>d</sub> = 57C2 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0	μs	65535
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02113

Parameter   Name: <b>C02113   Program name</b>		Data type: VISIBLE_STRING Index: 22462 <sub>d</sub> = 57BE <sub>h</sub>
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02121

Parameter   Name: <b>C02121   Runtime task 1</b>		Data type: UNSIGNED_32 Index: 22454 <sub>d</sub> = 57B6 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0	μs	3600000000
<b>Subcodes</b>		<b>Information</b>
C02121/1		Curr. runtime task 1
C02121/2		max. runtime task 1
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02122

Parameter   Name: <b>C02122   Runtime task 2</b>		Data type: UNSIGNED_32 Index: 22453 <sub>d</sub> = 57B5 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0	μs	3600000000
<b>Subcodes</b>		<b>Information</b>
C02122/1		Curr. runtime task 2
C02122/2		max. runtime task 2
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02123

Parameter   Name: <b>C02123   Runtime task 3</b>		Data type: UNSIGNED_32 Index: 22452 <sub>d</sub> = 57B4 <sub>h</sub>
<b>Display range (min. value   unit   max. value)</b>		
0	μs	3600000000
<b>Subcodes</b>		<b>Information</b>
C02123/1		Curr. runtime task 3
C02123/2		max. runtime task 3
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02520

Parameter   Name: <b>C02520   Gearbox fact. numer. motor</b>		Data type: INTEGER_32 Index: 22055 <sub>d</sub> = 5627 <sub>h</sub>
<a href="#">▶ Drive interface</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
1		2147483647 <b>1</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02521

Parameter   Name: <b>C02521   Gearbox fact. denom. motor</b>	Data type: INTEGER_32 Index: 22054 <sub>d</sub> = 5626 <sub>h</sub>
<a href="#">▶ Drive interface</a>	
<b>Setting range (min. value   unit   max. value)</b>	<b>Lenze setting</b>
1     2147483647	<b>1</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C02522

Parameter   Name: <b>C02522   Gearbox fact. numer. load</b>	Data type: INTEGER_32 Index: 22053 <sub>d</sub> = 5625 <sub>h</sub>
<a href="#">▶ Drive interface</a>	
<b>Setting range (min. value   unit   max. value)</b>	<b>Lenze setting</b>
1     2147483647	<b>1</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C02523

Parameter   Name: <b>C02523   Gearbox fact. denom. load</b>	Data type: INTEGER_32 Index: 22052 <sub>d</sub> = 5624 <sub>h</sub>
<a href="#">▶ Drive interface</a>	
<b>Setting range (min. value   unit   max. value)</b>	<b>Lenze setting</b>
1     2147483647	<b>1</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C02524

Parameter   Name: <b>C02524   Feed constant</b>	Data type: UNSIGNED_32 Index: 22051 <sub>d</sub> = 5623 <sub>h</sub>
<a href="#">▶ Drive interface</a>	
<b>Setting range (min. value   unit   max. value)</b>	<b>Lenze setting</b>
0.0001   Unit/rev.   214748.3647	<b>360.0000 Unit/rev.</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000	

## C02525

Parameter   Name: <b>C02525   Unit</b>	Data type: UNSIGNED_32 Index: 22050 <sub>d</sub> = 5622 <sub>h</sub>
<a href="#">▶ Drive interface</a>	
<b>Selection list (Lenze setting printed in bold)</b>	<b>Information</b>
0 User-defined	The text entered in <a href="#">C02526</a> is displayed for the unit.
1 <b>Incr.</b>	
2 <b>µm</b>	
3 <b>mm</b>	
4 <b>M</b>	
5 <b>inch</b>	
6 <b>yard</b>	
7 <b>°</b>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C02526

Parameter   Name: <b>C02526   User-defined unit</b>	Data type: VISIBLE_STRING Index: 22049 <sub>d</sub> = 5621 <sub>h</sub>
User-defined unit which is displayed when <a href="#">C02525</a> ="0" is selected.	
<a href="#">▶ Drive interface</a>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02527

## C02527

Parameter | Name: **C02527 | Motor mounting direction** Data type: UNSIGNED\_32  
Index: 22048<sub>d</sub> = 5620<sub>h</sub>

[▶ Drive interface](#)

Selection list (Lenze setting printed in bold)	
<b>0</b>	<b>Motor rotating CW</b>
1	Motor rotating CCW

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

## C02528

Parameter | Name: **C02528 | Traversing range** Data type: UNSIGNED\_32  
Index: 22047<sub>d</sub> = 561F<sub>h</sub>

[▶ Drive interface](#)

Selection list (Lenze setting printed in bold)	
<b>0</b>	<b>Unlimited</b>
1	Limited
2	Modulo

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

## C02529

Parameter | Name: **C02529 | Load sensor mounting direction** Data type: UNSIGNED\_32  
Index: 22046<sub>d</sub> = 561E<sub>h</sub>

[▶ Drive interface](#)

Selection list (Lenze setting printed in bold)	
<b>0</b>	<b>Sensor rotating CW</b>
1	Encoder rotating CCW

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT



## C02530

Parameter | Name: **C02530 | Active function state** Data type: INTEGER\_32  
Index: 22045<sub>d</sub> = 561D<sub>h</sub>

Displays the basic drive function that currently controls the drive.

► [Basic drive functions: Internal state machine](#)

Selection list (display only)	
0	Program stopped
1	Initial/boot state active
2	Torque follower active
3	Speed follower active
4	Position follower active
5	Setpoint follower active
6	Positioning active
7	Homing active
8	Manual jog active
9	Brake test active
10	Drive at standstill
11	Drive is stopped
12	Quick stop active
13	Reserve 1
14	Controller is not ready
15	Initialisation
16	Error

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

## C02531

Parameter | Name: **C02531 | Resulting gearbox factors** Data type: UNSIGNED\_32  
Index: 22044<sub>d</sub> = 561C<sub>h</sub>

Note: In subcode 3 the resulting gearbox factor between the motor and the load is displayed if a separate position encoder is configured and the position control is activated (C02570="2"). For a different encoder configuration (without a separate position encoder) the value "1" is shown in subcode 3.

► [Drive interface](#)

Display range (min. value   unit   max. value)		
0.001		2147483.647
Subcodes	Information	
C02531/1	Res. gearbox fact. motor end	
C02531/2	Res. gearbox fact. load end	
C02531/3	Res. gearbox fact. motor/load	

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT Scaling factor: 1000

## C02532

Parameter | Name: **C02532 | Resolution of a unit** Data type: UNSIGNED\_32  
Index: 22043<sub>d</sub> = 561B<sub>h</sub>

► [Drive interface](#)

Display range (min. value   unit   max. value)		
0.0000	Incr./Unit	214748.3647

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT Scaling factor: 10000

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02533

C02533

Parameter | Name: **C02533 | Time unit** Data type: UNSIGNED\_32  
Index: 22042<sub>d</sub> = 561A<sub>h</sub>

[▶ Drive interface](#)

Selection list (display only)	
2	s

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C02534

Parameter | Name: **C02534 | User-defined time unit** Data type: VISIBLE\_STRING  
Index: 22041<sub>d</sub> = 5619<sub>h</sub>

[▶ Drive interface](#)

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C02535

Parameter | Name: **C02535 | User-defined unit** Data type: VISIBLE\_STRING  
Index: 22040<sub>d</sub> = 5618<sub>h</sub>

[▶ Drive interface](#)

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C02536

Parameter | Name: **C02536 | Cycle** Data type: UNSIGNED\_32  
Index: 22039<sub>d</sub> = 5617<sub>h</sub>

[▶ Drive interface](#)

Setting range (min. value   unit   max. value)		Lenze setting
0.0000	Unit	214748.3647 <b>360.0000 Unit</b>

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT Scaling factor: 10000

C02537

Parameter | Name: **C02537 | Speed unit** Data type: VISIBLE\_STRING  
Index: 22038<sub>d</sub> = 5616<sub>h</sub>

[▶ Drive interface](#)

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C02538

Parameter | Name: **C02538 | Acceleration unit** Data type: VISIBLE\_STRING  
Index: 22037<sub>d</sub> = 5615<sub>h</sub>

[▶ Drive interface](#)

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C02539

Parameter | Name: **C02539 | Maximum position to be displayed** Data type: INTEGER\_32  
Index: 22036<sub>d</sub> = 5614<sub>h</sub>

[▶ Drive interface](#)

Display range (min. value   unit   max. value)	
-214748.3647	Unit

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT Scaling factor: 10000

C02540

Parameter | Name: **C02540 | Max. speed to be displayed** Data type: INTEGER\_32  
Index: 22035<sub>d</sub> = 5613<sub>h</sub>

[▶ Drive interface](#)

Display range (min. value   unit   max. value)	
-214748.3647	Unit/s

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT Scaling factor: 10000

## C02541

Parameter   Name: <b>C02541   Max. accel. to be displayed</b>		Data type: INTEGER_32 Index: 22034 <sub>d</sub> = 5612 <sub>h</sub>
<a href="#">▶ Drive interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit/s <sup>2</sup>	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000		

## C02542

Parameter   Name: <b>C02542   Load reference speed</b>		Data type: UNSIGNED_32 Index: 22033 <sub>d</sub> = 5611 <sub>h</sub>
<a href="#">▶ Drive interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
0.000	rpm	4294967.295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 1000		

## C02543

Parameter   Name: <b>C02543   Load reference torque</b>		Data type: UNSIGNED_32 Index: 22032 <sub>d</sub> = 5610 <sub>h</sub>
<a href="#">▶ Drive interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
0.000	Nm	4294967.295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 1000		

## C02547

Parameter   Name: <b>C02547   DI_dnState</b>		Data type: INTEGER_32 Index: 22028 <sub>d</sub> = 560C <sub>h</sub>
Status of the <a href="#">drive interface</a> (LS_DriveInterface).		
<b>Display range (min. value   unit   max. value)</b>		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02548

Parameter   Name: <b>C02548   DI_bErrors</b>		Data type: UNSIGNED_32 Index: 22027 <sub>d</sub> = 560B <sub>h</sub>
Display of the boolean error signals of the <a href="#">drive interface</a> (LS_DriveInterface).		
<b>Selection list</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>		<b>Information</b>
C02548/1		DI_bResetError1
C02548/2		DI_bResetError2
C02548/3		DI_bResetError3
C02548/4		DI_bSetExternError
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02549

C02549

Parameter   Name: <b>C02549   Drive interface: Signals</b>		Data type: UNSIGNED_32 Index: 22026 <sub>d</sub> = 560A <sub>h</sub>
Display of the boolean signals of the <a href="#">drive interface</a> (LS_DriveInterface).		
<b>Selection list</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>		<b>Information</b>
C02549/1		DI_bSetCInh
C02549/2		Reserved
C02549/3		Reserved
C02549/4		DI_bSwitchOn
C02549/5		Reserved
C02549/6		DI_bReady
C02549/7		DI_bFailActive
C02549/8		DI_bImpActive
C02549/9		DI_bCInhActive
C02549/10		DI_bWarningActive
C02549/11		DI_bUVDetected
C02549/12		DI_bOVDetected
C02549/13		DI_bMainSupplyOk
C02549/14		DI_bReadyToSwitchOn
C02549/15		DI_bOperationEnabled
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02550

Parameter   Name: <b>C02550   Setpoint interpolation</b>		Data type: UNSIGNED_32 Index: 22025 <sub>d</sub> = 5609 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
<b>Selection list</b>		
0	Off	
1	ON	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02550/1	0: Off	Position setpoint interpolat.
C02550/2	0: Off	Speed setpoint interpolat.
C02550/3	0: Off	Torque setpoint interpolat.
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02552

Parameter   Name: <b>C02552   Position setpoint</b>		Data type: INTEGER_32 Index: 22023 <sub>d</sub> = 5607 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000		

C02553

Parameter   Name: <b>C02553   Position controller gain</b>		Data type: UNSIGNED_32 Index: 22022 <sub>d</sub> = 5606 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.00	1/s	1000.00
		<b>20.00 1/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

C02554

Parameter   Name: <b>C02554   Int.-act. time of position controller</b>		Data type: UNSIGNED_32 Index: 22021 <sub>d</sub> = 5605 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.001	s	60.000
		<b>60.000 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 1000		

C02555

Parameter   Name: <b>C02555   Pos. contr. D comp.</b>		Data type: UNSIGNED_32 Index: 22020 <sub>d</sub> = 5604 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.000		100.000
		<b>0.000</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 1000		

C02556

Parameter   Name: <b>C02556   Pos. contr. limitation</b>		Data type: INTEGER_32 Index: 22019 <sub>d</sub> = 5603 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.0000	Unit/s	214748.3647
		<b>214748.3647 Unit/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000		

C02557

Parameter   Name: <b>C02557   Motor pos. contr. output</b>		Data type: INTEGER_32 Index: 22018 <sub>d</sub> = 5602 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit/s	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000		

C02558

Parameter   Name: <b>C02558   Pos. contr. output</b>		Data type: INTEGER_32 Index: 22017 <sub>d</sub> = 5601 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit/s	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02559

C02559

Parameter   Name: <b>C02559   Internal torque limits</b>		Data type: INTEGER_32 Index: 22016 <sub>d</sub> = 5600 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>		<b>Information</b>
C02559/1		Upper int. torque limit
C02559/2		Lower int. torque limit
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

C02560

Parameter   Name: <b>C02560   Messages - motor interface</b>		Data type: UNSIGNED_32 Index: 22015 <sub>d</sub> = 55FF <sub>h</sub>
<a href="#">▶ Motor interface</a>		
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02567

Parameter   Name: <b>C02567   Control mode</b>		Data type: UNSIGNED_32 Index: 22008 <sub>d</sub> = 55F8 <sub>h</sub>
<a href="#">▶ Motor interface</a>		
<b>Selection list (display only)</b>		
0	Position control	
1	Speed control	
2	Torque control	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02568

Parameter   Name: <b>C02568   Motor interface: % signals</b>		Data type: INTEGER_32 Index: 22007 <sub>d</sub> = 55F7 <sub>h</sub>
Display of the scaled signals of the <a href="#">motor interface</a> (LS_MotorInterface).		
<b>Display range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>		<b>Information</b>
C02568/1		MI_dnPosCtrlAdaptLoad_n
C02568/2		MI_dnPosCtrlAdaptMotor_n
C02568/3		MI_dnSpeedCtrlAdapt_n
C02568/4		MI_dnTorqueHighLimit_n
C02568/5		MI_dnTorqueLowLimit_n
C02568/6		Reserved
C02568/7		MI_dnFluxSetpoint_n
C02568/8		Reserved
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

## C02569

Parameter   Name: <b>C02569   Motor interface: Dig. signals</b>		Data type: UNSIGNED_32 Index: 22006 <sub>d</sub> = 55F6 <sub>h</sub>
Display of the boolean signals of the <a href="#">motor interface</a> (LS_MotorInterface).		
<b>Selection list</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>		<b>Information</b>
C02569/1		Reserved
C02569/2		MI_bResetSpeedCtrlIntegrator
C02569/3		MI_bLimitationActive
C02569/4		MI_bPosCtrlLimited
C02569/5		MI_bSpeedSetPointLimited
C02569/6		MI_bSpeedCtrlLimited
C02569/7		MI_bTorqueSetpointLimited
C02569/8		MI_bCurrentSetpointLimited
C02569/9		MI_bSpeedBelowC19
C02569/10		MI_bSpeedFollowingError
C02569/11		MI_bMotorOverloadWarning
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02570

Parameter   Name: <b>C02570   Controller configuration</b>		Data type: UNSIGNED_32 Index: 22005 <sub>d</sub> = 55F5 <sub>h</sub>
<a href="#">▶ Encoder evaluation</a>		
<b>Selection list (Lenze setting printed in bold)</b>		<b>Information</b>
<b>1</b>	<b>Phase control</b>	Motor encoder selection is effected in <a href="#">C00495</a> .
2	Position control	Position controller selection is effected in <a href="#">C00490</a> .
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02572

Parameter   Name: <b>C02572   Speed setpoint</b>		Data type: INTEGER_32 Index: 22003 <sub>d</sub> = 55F3 <sub>h</sub>
<a href="#">▶ Encoder evaluation</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit/s	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000		

## C02573

Parameter   Name: <b>C02573   Position setpoint</b>		Data type: INTEGER_32 Index: 22002 <sub>d</sub> = 55F2 <sub>h</sub>
<a href="#">▶ Encoder evaluation</a>		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02574

C02574

Parameter   Name: <b>C02574   Actual speed</b>	Data type: INTEGER_32 Index: 22001 <sub>d</sub> = 55F1 <sub>h</sub>
<a href="#">Encoder evaluation</a>	
<b>Display range (min. value   unit   max. value)</b>	
-214748.3647	Unit/s      214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000	

C02575

Parameter   Name: <b>C02575   Actual position</b>	Data type: INTEGER_32 Index: 22000 <sub>d</sub> = 55F0 <sub>h</sub>
<a href="#">Encoder evaluation</a>	
<b>Display range (min. value   unit   max. value)</b>	
-214748.3647	Unit      214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000	

C02576

Parameter   Name: <b>C02576   Following error</b>	Data type: INTEGER_32 Index: 21999 <sub>d</sub> = 55EF <sub>h</sub>
<a href="#">Encoder evaluation</a>	
<b>Display range (min. value   unit   max. value)</b>	
-214748.3647	Unit      214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000	

C02577

Parameter   Name: <b>C02577   External actual position</b>	Data type: INTEGER_32 Index: 21998 <sub>d</sub> = 55EE <sub>h</sub>
<a href="#">Encoder evaluation</a>	
<b>Display range (min. value   unit   max. value)</b>	
-214748.3647	Unit      214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000	

C02578

Parameter   Name: <b>C02578   Offset actual pos. value/setp.</b>	Data type: INTEGER_32 Index: 21997 <sub>d</sub> = 55ED <sub>h</sub>
<a href="#">Encoder evaluation</a>	
<b>Display range (min. value   unit   max. value)</b>	
-214748.3647	Unit      214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000	

C02579

Parameter   Name: <b>C02579   Encoder eval.: Dig. signals</b>	Data type: UNSIGNED_32 Index: 21996 <sub>d</sub> = 55EC <sub>h</sub>
Display of the boolean signals of the <a href="#">encoder evaluation</a> (LS_Feedback).	
<b>Selection list</b>	
0	FALSE
1	TRUE
<b>Subcodes</b>	<b>Information</b>
C02579/1	FDB_bResolverError
C02579/2	FDB_bSinCosSignalError
C02579/3	FDB_bEncoderComError
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	



## C02580

Parameter   Name: <b>C02580   Brake operating mode</b>	Data type: UNSIGNED_32 Index: 21995 <sub>d</sub> = 55EB <sub>h</sub>
▶ Basic function " <a href="#">Brake control</a> "	
<b>Selection list</b> (Lenze setting printed in bold)	
0	<b>Brake control off</b>
1	Directly with brake module
2	Autom. with brake module
11	Direct - external switching
12	Autom. - external switching
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C02581

Parameter   Name: <b>C02581   Brake activation threshold</b>	Data type: INTEGER_32 Index: 21994 <sub>d</sub> = 55EA <sub>h</sub>
▶ Basic function " <a href="#">Brake control</a> "	
<b>Setting range</b> (min. value   unit   max. value)	
0	rpm
50000	<b>50 rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C02582

Parameter   Name: <b>C02582   Brake resp. to pulse inhibit</b>	Data type: UNSIGNED_32 Index: 21993 <sub>d</sub> = 55E9 <sub>h</sub>
▶ Basic function " <a href="#">Brake control</a> "	
<b>Selection list</b> (Lenze setting printed in bold)	
0	<b>Activate the brake immediately</b>
1	Acivate brake when n < nmin
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C02583

Parameter   Name: <b>C02583   Status input monitoring</b>	Data type: UNSIGNED_32 Index: 21992 <sub>d</sub> = 55E8 <sub>h</sub>
▶ Basic function " <a href="#">Brake control</a> "	
<b>Selection list</b> (Lenze setting printed in bold)	
0	<b>Not active</b>
1	active
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C02585

Parameter   Name: <b>C02585   Brake control polarity</b>	Data type: UNSIGNED_32 Index: 21990 <sub>d</sub> = 55E6 <sub>h</sub>
▶ Basic function " <a href="#">Brake control</a> "	
<b>Selection list</b> (Lenze setting printed in bold)	
0	<b>Not inverted</b>
1	Inverted
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02586

C02586

Parameter   Name: <b>C02586   Starting torque 1</b>		Data type: INTEGER_32 Index: 21989 <sub>d</sub> = 55E5 <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
-21474836.47	Nm	21474836.47	<b>0.00 Nm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100			

C02587

Parameter   Name: <b>C02587   Starting torque 2</b>		Data type: INTEGER_32 Index: 21988 <sub>d</sub> = 55E4 <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
-21474836.47	Nm	21474836.47	<b>0.00 Nm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 100			

C02588

Parameter   Name: <b>C02588   Starting torque source</b>		Data type: UNSIGNED_32 Index: 21987 <sub>d</sub> = 55E3 <sub>h</sub>
▶ Basic function " <a href="#">Brake control</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Starting torque 1/2</b>	
1	Stopping value	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02589

Parameter   Name: <b>C02589   Brake closing time</b>		Data type: UNSIGNED_32 Index: 21986 <sub>d</sub> = 55E2 <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	ms	60000	<b>100 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C02590

Parameter   Name: <b>C02590   Brake opening time</b>		Data type: UNSIGNED_32 Index: 21985 <sub>d</sub> = 55E1 <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	ms	60000	<b>100 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C02591

Parameter   Name: <b>C02591   Waiting time- status monitoring</b>		Data type: UNSIGNED_32 Index: 21984 <sub>d</sub> = 55E0 <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	ms	60000	<b>100 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C02593

Parameter   Name: <b>C02593   Waiting time - brake activation</b>		Data type: UNSIGNED_32 Index: 21982 <sub>d</sub> = 55DE <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0.000	s	1000.000	<b>0.000 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 1000			

C02594

Parameter   Name: <b>C02594   Test torque</b>		Data type: INTEGER_32 Index: 21981 <sub>d</sub> = 55DD <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
-21474836.47	Nm	21474836.47	<b>0.00 Nm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100			

C02595

Parameter   Name: <b>C02595   Permissible angle of rotation</b>		Data type: INTEGER_32 Index: 21980 <sub>d</sub> = 55DC <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0	°	360	<b>5 °</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C02596

Parameter   Name: <b>C02596   Grinding speed</b>		Data type: INTEGER_32 Index: 21979 <sub>d</sub> = 55DB <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0	rpm	300	<b>100 rpm</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

C02597

Parameter   Name: <b>C02597   Acc./dec. time - grinding</b>		Data type: UNSIGNED_32 Index: 21978 <sub>d</sub> = 55DA <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0.000	s	60.000	<b>1.000 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 1000			

C02598

Parameter   Name: <b>C02598   Grinding ON time</b>		Data type: UNSIGNED_32 Index: 21977 <sub>d</sub> = 55D9 <sub>h</sub>	
▶ Basic function " <a href="#">Brake control</a> "			
<b>Setting range (min. value   unit   max. value)</b>			<b>Lenze setting</b>
0.2	s	2.0	<b>0.5 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10			

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02599

C02599

Parameter   Name: <b>C02599   Grinding OFF time</b>		Data type: UNSIGNED_32 Index: 21976 <sub>d</sub> = 55D8 <sub>h</sub>
▶ Basic function " <a href="#">Brake control</a> "		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.2	s	2.0 <b>0.5 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 10		

C02607

Parameter   Name: <b>C02607   BRK_dnState</b>		Data type: INTEGER_32 Index: 21968 <sub>d</sub> = 55D0 <sub>h</sub>
Status of the " <a href="#">brake control</a> " basic function (LS_Brake).		
<b>Display range (min. value   unit   max. value)</b>		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02608

Parameter   Name: <b>C02608   BRK_dnTorqueAdd_n</b>		Data type: INTEGER_32 Index: 21967 <sub>d</sub> = 55CF <sub>h</sub>
Display of the additive torque value of the " <a href="#">brake control</a> " basic function (LS_Brake).		
<b>Display range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 100		

C02609

Parameter   Name: <b>C02609   Brake control: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21966 <sub>d</sub> = 55CE <sub>h</sub>
Display of the boolean signals of the " <a href="#">brake control</a> " basic function (LS_Brake).		
<b>Selection list</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>		<b>Information</b>
C02609/1		BRK_bReleaseBrake
C02609/2		BRK_bStartingTorque2
C02609/3		BRK_bBrakeApplied
C02609/4		BRK_bBrakeTest
C02609/5		BRK_bBrakeGrindIn
C02609/6		BRK_bReleaseBrakeOut
C02609/7		BRK_bBrakeReleased
C02609/8		BRK_bError
C02609/9		BRK_bCInhActive
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02610

Parameter   Name: <b>C02610   Decel. time - stop function</b>		Data type: UNSIGNED_32 Index: 21965 <sub>d</sub> = 55CD <sub>h</sub>
▶ Basic function " <a href="#">Stop</a> "		
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>
0.000	s	1000.000 <b>1.000 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 1000		

## C02611

Parameter   Name: <b>C02611   S-ramp time - stop function</b>		Data type: UNSIGNED_32 Index: 21964 <sub>d</sub> = 55C <sub>h</sub>
<a href="#">▶ Basic function "Stop"</a>		
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
0.000	s	10.000 <b>0.100 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 1000		

## C02612

Parameter   Name: <b>C02612   Ref. for decel. time - stop</b>		Data type: UNSIGNED_32 Index: 21963 <sub>d</sub> = 55C <sub>h</sub>
<a href="#">▶ Basic function "Stop"</a>		
<b>Selection list</b> (Lenze setting printed in bold)		
0	<b>Reference speed (C00011)</b>	
1	Current speed	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02616

Parameter   Name: <b>C02616   STP_dnState</b>		Data type: INTEGER_32 Index: 21959 <sub>d</sub> = 55C <sub>h</sub>
Status of the basic function " <a href="#">Stop</a> " (LS_Stop).		
<b>Display range</b> (min. value   unit   max. value)		
-2147483648		2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02617

Parameter   Name: <b>C02617   STP_bStopActive</b>		Data type: UNSIGNED_32 Index: 21958 <sub>d</sub> = 55C <sub>h</sub>
Display of the boolean signals of the basic function " <a href="#">Stop</a> " (LS_Stop).		
<b>Selection list</b> (display only)		
0	<b>Stop not active</b>	
1	Stop active	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02619

Parameter   Name: <b>C02619   Quick stop: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21956 <sub>d</sub> = 55C <sub>h</sub>
Display of the boolean signals of the basic function " <a href="#">quick stop</a> " (LS_quick stop).		
<b>Selection list</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>		<b>Information</b>
C02619/1		QSP_bActivate1
C02619/2		QSP_bActivate2
C02619/3		QSP_bActivate3
C02619/4		QSP_bActive
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02620

C02620

Parameter   Name: <b>C02620   Manual control speed 1</b>		Data type: INTEGER_32 Index: 21955 <sub>d</sub> = 55C3 <sub>h</sub>	
▶ Basic function " <a href="#">Manual jog</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Unit/s	214748.3647	<b>360.0000 Unit/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 10000			

C02621

Parameter   Name: <b>C02621   Manual control speed 2</b>		Data type: INTEGER_32 Index: 21954 <sub>d</sub> = 55C2 <sub>h</sub>	
▶ Basic function " <a href="#">Manual jog</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Unit/s	214748.3647	<b>720.0000 Unit/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 10000			

C02622

Parameter   Name: <b>C02622   Manual control acceleration</b>		Data type: INTEGER_32 Index: 21953 <sub>d</sub> = 55C1 <sub>h</sub>	
▶ Basic function " <a href="#">Manual jog</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Unit/s <sup>2</sup>	214748.3647	<b>360.0000 Unit/s<sup>2</sup></b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 10000			

C02623

Parameter   Name: <b>C02623   Manual control deceleration</b>		Data type: INTEGER_32 Index: 21952 <sub>d</sub> = 55C0 <sub>h</sub>	
▶ Basic function " <a href="#">Manual jog</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Unit/s <sup>2</sup>	214748.3647	<b>1440.0000 Unit/s<sup>2</sup></b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 10000			

C02624

Parameter   Name: <b>C02624   Manual control S-ramp time</b>		Data type: UNSIGNED_32 Index: 21951 <sub>d</sub> = 55BF <sub>h</sub>	
▶ Basic function " <a href="#">Manual jog</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.000	s	10.000	<b>0.100 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 1000			

C02638

Parameter   Name: <b>C02638   Manual control status</b>		Data type: INTEGER_32 Index: 21937 <sub>d</sub> = 55B1 <sub>h</sub>	
Status of the basic function " <a href="#">Manual jog</a> " (LS_ManualJog).			
<b>Display range (min. value   unit   max. value)</b>			
0		8	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C02639

Parameter   Name: <b>C02639   Manual control: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21936 <sub>d</sub> = 55B0 <sub>h</sub>
Display of the boolean signals of the basic function " <a href="#">Manual jog</a> " (LS_ManualJog).		
<b>Selection list</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>		<b>Information</b>
C02639/1		MAN_bEnable
C02639/2		MAN_bJogPositive
C02639/3		MAN_bJogNegative
C02639/4		MAN_bActivateJogSpeed2
C02639/5		MAN_bReleaseLimitSwitch
C02639/6		MAN_bEnabled
C02639/7		MAN_bActive
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02640

Parameter   Name: <b>C02640   Ref. mode</b>		Data type: UNSIGNED_32 Index: 21935 <sub>d</sub> = 55AF <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
<b>Selection list</b> (Lenze setting printed in bold)		
0	cw_Rn_TP	
1	ccw_Rn_TP	
2	cw_Lp_ccw_Rn_TP	
3	ccw_Ln_cw_Rn_TP	
4	cw_Rp_ccw_Rn_TP	
5	ccw_Rp_cw_Rn_TP	
8	cw_TP	
9	ccw_TP	
10	cw_Lp_ccw_TP	
11	ccw_Ln_cw_TP	
12	cw_Lp	
13	ccw_Ln	
14	cw_Trq_Lim	
15	ccw_Trq_Lim	
<b>100</b>	<b>Set home pos. directly</b>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02642

Parameter   Name: <b>C02642   Home position</b>		Data type: INTEGER_32 Index: 21933 <sub>d</sub> = 55AD <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
-214748.3647	Unit	214748.3647
		<b>0.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02643

C02643

Parameter   Name: <b>C02643   Ref. target position</b>		Data type: INTEGER_32 Index: 21932 <sub>d</sub> = 55AC <sub>h</sub>	
▶ Basic function " <a href="#">Homing</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
-214748.3647	Unit	214748.3647	<b>0.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 10000			

C02644

Parameter   Name: <b>C02644   Ref. speed 1</b>		Data type: INTEGER_32 Index: 21931 <sub>d</sub> = 55AB <sub>h</sub>	
▶ Basic function " <a href="#">Homing</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Unit/s	214748.3647	<b>360.0000 Unit/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 10000			

C02645

Parameter   Name: <b>C02645   Ref. acceleration 1</b>		Data type: INTEGER_32 Index: 21930 <sub>d</sub> = 55AA <sub>h</sub>	
▶ Basic function " <a href="#">Homing</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Unit/s <sup>2</sup>	214748.3647	<b>720.0000 Unit/s<sup>2</sup></b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 10000			

C02646

Parameter   Name: <b>C02646   Ref. speed 2</b>		Data type: INTEGER_32 Index: 21929 <sub>d</sub> = 55A9 <sub>h</sub>	
▶ Basic function " <a href="#">Homing</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Unit/s	214748.3647	<b>180.0000 Unit/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 10000			

C02647

Parameter   Name: <b>C02647   Ref. acceleration 2</b>		Data type: INTEGER_32 Index: 21928 <sub>d</sub> = 55A8 <sub>h</sub>	
▶ Basic function " <a href="#">Homing</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Unit/s <sup>2</sup>	214748.3647	<b>360.0000 Unit/s<sup>2</sup></b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT Scaling factor: 10000			

C02648

Parameter   Name: <b>C02648   Ref. S-ramp time</b>		Data type: INTEGER_32 Index: 21927 <sub>d</sub> = 55A7 <sub>h</sub>	
▶ Basic function " <a href="#">Homing</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	ms	10000	<b>100 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			



C02649

Parameter   Name: <b>C02649   Ref. torque limit</b>		Data type: INTEGER_32 Index: 21926 <sub>d</sub> = 55A6 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
0.00	%	200.00
		<b>10.00 %</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 100		

C02650

Parameter   Name: <b>C02650   Ref. blocking time</b>		Data type: UNSIGNED_32 Index: 21925 <sub>d</sub> = 55A5 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
0.000	s	120.000
		<b>1.000 s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 1000		

C02651

Parameter   Name: <b>C02651   Ref. touch probe configuration</b>		Data type: UNSIGNED_32 Index: 21924 <sub>d</sub> = 55A4 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
0		4294967295
		<b>16</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02652

Parameter   Name: <b>C02652   Home pos. after mains switching</b>		Data type: UNSIGNED_32 Index: 21923 <sub>d</sub> = 55A3 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
<b>Selection list</b> (Lenze setting printed in bold)		
0	Delete	
1	Received	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02653

Parameter   Name: <b>C02653   Max. angle of after mains switch.</b>		Data type: INTEGER_32 Index: 21922 <sub>d</sub> = 55A2 <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
<b>Setting range</b> (min. value   unit   max. value)		<b>Lenze setting</b>
0	°	1000000
		<b>180 °</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02656

Parameter   Name: <b>C02656   Current position</b>		Data type: INTEGER_32 Index: 21919 <sub>d</sub> = 559F <sub>h</sub>
▶ Basic function " <a href="#">Homing</a> "		
<b>Display range</b> (min. value   unit   max. value)		
-214748.3647	Unit	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 10000		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02657

C02657

Parameter   Name: <b>C02657   HM_dnState</b>	Data type: INTEGER_32 Index: 21918 <sub>d</sub> = 559E <sub>h</sub>
Status of the basic function " <a href="#">Homing</a> " (LS_Homing).	
<b>Display range</b> (min. value   unit   max. value)	
-2147483648	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

C02658

Parameter   Name: <b>C02658   HM_dnHomePos_p</b>	Data type: INTEGER_32 Index: 21917 <sub>d</sub> = 559D <sub>h</sub>
Display of the position signals of the basic function " <a href="#">Homing</a> " (LS_Homing).	
<b>Display range</b> (min. value   unit   max. value)	
-214748.3647	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000	

C02659

Parameter   Name: <b>C02659   Homing: Dig. signals</b>	Data type: UNSIGNED_32 Index: 21916 <sub>d</sub> = 559C <sub>h</sub>
Display of the boolean signals of the basic function " <a href="#">Homing</a> " (LS_Homing).	
<b>Selection list</b>	
0	FALSE
1	TRUE
<b>Subcodes</b>	<b>Information</b>
C02659/1	HM_bEnable
C02659/2	HM_bActivateHoming
C02659/3	HM_bHomingMark
C02659/4	HM_bLoadHomePos
C02659/5	HM_bResetHomePos
C02659/6	HM_bEnabled
C02659/7	HM_bActive
C02659/8	HM_bDone
C02659/9	HM_bHomePosAvailable
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

C02674

Parameter   Name: <b>C02674   POS_dwActualProfileNumber</b>	Data type: UNSIGNED_32 Index: 21901 <sub>d</sub> = 558D <sub>h</sub>
Current profile of the basic function " <a href="#">Positioning</a> " (LS_Positioner).	
<b>Display range</b> (min. value   unit   max. value)	
0	1000
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

C02675

Parameter   Name: <b>C02675   POS_dnState</b>	Data type: INTEGER_32 Index: 21900 <sub>d</sub> = 558C <sub>h</sub>
Status of the basic function " <a href="#">Positioning</a> " (LS_Positioner).	
<b>Display range</b> (min. value   unit   max. value)	
-2147483648	2147483647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

## C02676

Parameter   Name: <b>C02676   POS_dnProfileSpeed_s</b>		Data type: INTEGER_32 Index: 21899 <sub>d</sub> = 558B <sub>h</sub>
Display of the max. speed of the current profile of the basic function " <a href="#">Positioning</a> " (LS_Positioner).		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647		214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000		

## C02677

Parameter   Name: <b>C02677   Positioning: % signals</b>		Data type: INTEGER_32 Index: 21898 <sub>d</sub> = 558A <sub>h</sub>
Display of the scaled signals of the basic function " <a href="#">Positioning</a> " (LS_Positioner).		
<b>Display range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>		<b>Information</b>
C02677/1		POS_dnSpeedOverride_n
C02677/2		POS_dnAccOverride_n
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

## C02678

Parameter   Name: <b>C02678   Positioning: Pos. signals</b>		Data type: INTEGER_32 Index: 21897 <sub>d</sub> = 5589 <sub>h</sub>
Display of the position signals of the basic function " <a href="#">Positioning</a> " (LS_Positioner).		
<b>Display range (min. value   unit   max. value)</b>		
-214748.3647		214748.3647
<b>Subcodes</b>		<b>Information</b>
C02678/1		POS_dnSetPos_p
C02678/2		POS_dnProfileTarget_p
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000		

## C02679

Parameter   Name: <b>C02679   Positioning: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21896 <sub>d</sub> = 5588 <sub>h</sub>
Display of the boolean signals of the basic function " <a href="#">Positioning</a> " (LS_Positioner).		
<b>Selection list</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>		<b>Information</b>
C02679/1		POS_bEnable
C02679/2		POS_bStart
C02679/3		POS_bAbort
C02679/4		POS_bRestart
C02679/5		POS_bEnableOverride
C02679/6		POS_bDisableTP
C02679/7		POS_bEnabled
C02679/8		POS_bActive
C02679/9		POS_bDone
C02679/10		POS_bInTarget
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02680

C02680

Parameter   Name: <b>C02680   Source position setpoint</b>	Data type: UNSIGNED_32 Index: 21895 <sub>d</sub> = 5587 <sub>h</sub>
▶ Basic function " <a href="#">Positioning</a> "	
<b>Selection list</b> (Lenze setting printed in bold)	
0	<b>Position setpoint input</b>
1	From add. speed
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

C02681

Parameter   Name: <b>C02681   Additional speed source</b>	Data type: UNSIGNED_32 Index: 21894 <sub>d</sub> = 5586 <sub>h</sub>
▶ Basic function " <a href="#">Positioning</a> "	
<b>Selection list</b> (Lenze setting printed in bold)	
0	<b>Additional speed input</b>
1	From position setpoint
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT	

C02685

Parameter   Name: <b>C02685   PF_dnMotorAcc_x</b>	Data type: INTEGER_32 Index: 21890 <sub>d</sub> = 5582 <sub>h</sub>
Display of the motor acceleration of the basic function " <a href="#">Position follower</a> " (LS_PositionFollower).	
<b>Display range</b> (min. value   unit   max. value)	
-7680000.0	7680000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10	

C02686

Parameter   Name: <b>C02686   PF_dnSpeedAdd1_s</b>	Data type: INTEGER_32 Index: 21889 <sub>d</sub> = 5581 <sub>h</sub>
Display of the speed precontrol value of the basic function " <a href="#">Position follower</a> " (LS_PositionFollower).	
<b>Display range</b> (min. value   unit   max. value)	
-480000.0	480000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10	

C02687

Parameter   Name: <b>C02687   Position follower: % signals</b>	Data type: INTEGER_32 Index: 21888 <sub>d</sub> = 5580 <sub>h</sub>
Display of the scaled signals of the basic function " <a href="#">Position follower</a> " (LS_PositionFollower).	
<b>Display range</b> (min. value   unit   max. value)	
-200.00	200.00
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100	
<b>Subcodes</b>	<b>Information</b>
C02687/1	PF_dnSpeedAdd2_n
C02687/2	PF_dnTorqueAdd_n

C02688

Parameter   Name: <b>C02688   Position follower: Pos. signal</b>	Data type: INTEGER_32 Index: 21887 <sub>d</sub> = 557F <sub>h</sub>
Display of the position signals of the basic function " <a href="#">Position follower</a> " (LS_PositionFollower).	
<b>Display range</b> (min. value   unit   max. value)	
-214748.3648	214748.3647
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000	

#### C02689

Parameter   Name: <b>C02689   Position follower: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21886 <sub>d</sub> = 557E <sub>h</sub>
Display of the boolean signals of the basic function " <a href="#">Position follower</a> " (LS_PositionFollower).		
<b>Selection list</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>		<b>Information</b>
C02689/1		PF_bEnable
C02689/2		PF_bEnabled
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

#### C02692

Parameter   Name: <b>C02692   SF_dnMotorAcc_x</b>		Data type: INTEGER_32 Index: 21883 <sub>d</sub> = 557B <sub>h</sub>
Display of the motor acceleration of the basic function " <a href="#">Speed follower</a> " (LS_SpeedFollower).		
<b>Display range (min. value   unit   max. value)</b>		
-7680000.0		7680000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10		

#### C02693

Parameter   Name: <b>C02693   SF_dnSpeedAdd_s</b>		Data type: INTEGER_32 Index: 21882 <sub>d</sub> = 557A <sub>h</sub>
Display of the additive speed setpoint of the basic function " <a href="#">Speed follower</a> " (LS_SpeedFollower).		
<b>Display range (min. value   unit   max. value)</b>		
-480000.0	rpm	480000.0
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10		

#### C02694

Parameter   Name: <b>C02694   Speed follower: % signals</b>		Data type: INTEGER_32 Index: 21881 <sub>d</sub> = 5579 <sub>h</sub>
Display of the scaled signals of the basic function " <a href="#">Speed follower</a> " (LS_SpeedFollower).		
<b>Display range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>		<b>Information</b>
C02694/1		SF_dnSpeedSet_n
C02694/2		SF_dnTorqueAdd_n
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

#### C02695

Parameter   Name: <b>C02695   Speed follower: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21880 <sub>d</sub> = 5578 <sub>h</sub>
Display of the boolean signals of the basic function " <a href="#">Speed follower</a> " (LS_SpeedFollower).		
<b>Selection list</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>		<b>Information</b>
C02695/1		SF_bEnable
C02695/2		SF_bEnabled
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02698

C02698

Parameter   Name: <b>C02698   Torque follower: % signals</b>		Data type: INTEGER_32 Index: 21877 <sub>d</sub> = 5575 <sub>h</sub>
Display of the boolean input/output signals of the basic function " <a href="#">Torque follower</a> " (LS_TorqueFollower).		
<b>Display range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>	<b>Information</b>	
C02698/1	TF_TorqueSet_n	
C02698/2	TF_dnSpeedHighLimit_n	
C02698/3	TF_dnSpeedLowLimit_n	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

C02699

Parameter   Name: <b>C02699   Torque follower: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21876 <sub>d</sub> = 5574 <sub>h</sub>
Display of the boolean input/output signals of the basic function " <a href="#">Torque follower</a> " (LS_TorqueFollower).		
<b>Selection list</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>	<b>Information</b>	
C02699/1	TF_bEnable	
C02699/2	TF_bEnabled	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02700

Parameter   Name: <b>C02700   Software limit pos. effective</b>		Data type: UNSIGNED_32 Index: 21875 <sub>d</sub> = 5573 <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Deactivated</b>	
1	Activated	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

C02701

Parameter   Name: <b>C02701   Software limit positions</b>		Data type: INTEGER_32 Index: 21874 <sub>d</sub> = 5572 <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Setting range (min. value   unit   max. value)</b>		
-214748.3647	Unit	214748.3647
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02701/1	0.0000 Unit	Positive software limit position
C02701/2	0.0000 Unit	Negative software limit position
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000		

C02702

Parameter   Name: <b>C02702   Limitations effective</b>		Data type: UNSIGNED_32 Index: 21873 <sub>d</sub> = 5571 <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Selection list (Lenze setting printed in bold)</b>		
0	<b>Deactivated</b>	
1	Activated	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02703

Parameter   Name: <b>C02703   Max. speed</b>		Data type: INTEGER_32 Index: 21872 <sub>d</sub> = 5570 <sub>h</sub>	
▶ Basic function " <a href="#">Limiter</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Unit/s	214748.3647	<b>3600.0000 Unit/s</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 10000			

## C02704

Parameter   Name: <b>C02704   Max. speed [rpm]</b>		Data type: INTEGER_32 Index: 21871 <sub>d</sub> = 556F <sub>h</sub>	
▶ Basic function " <a href="#">Limiter</a> "			
<b>Display range (min. value   unit   max. value)</b>			
0.0	rpm	214748364.7	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 10			

## C02705

Parameter   Name: <b>C02705   Max. acceleration</b>		Data type: INTEGER_32 Index: 21870 <sub>d</sub> = 556E <sub>h</sub>	
▶ Basic function " <a href="#">Limiter</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Unit/s <sup>2</sup>	214748.3647	<b>3600.0000 Unit/s<sup>2</sup></b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 10000			

## C02706

Parameter   Name: <b>C02706   Min. S-ramp time</b>		Data type: UNSIGNED_32 Index: 21869 <sub>d</sub> = 556D <sub>h</sub>	
▶ Basic function " <a href="#">Limiter</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0	ms	10000	<b>100 ms</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C02707

Parameter   Name: <b>C02707   Permissible direction of rot.</b>		Data type: UNSIGNED_32 Index: 21868 <sub>d</sub> = 556C <sub>h</sub>	
▶ Basic function " <a href="#">Limiter</a> "			
<b>Selection list (Lenze setting printed in bold)</b>			
0	<b>Positive and negative</b>		
1	Positive only		
2	Negative only		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02708

## C02708

Parameter   Name: <b>C02708   Limited speed</b>		Data type: INTEGER_32 Index: 21867 <sub>d</sub> = 556B <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
<b>Setting range (min. value   unit   max. value)</b>		
0.0000	Unit/s	214748.3647
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02708/1	3600.0000 Unit/s	Limited speed 1 ... 4
C02708/2	7200.0000 Unit/s	
C02708/3	14400.0000 Unit/s	
C02708/4	28800.0000 Unit/s	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 10000		

## C02709

Parameter   Name: <b>C02709   Limited speed</b>		Data type: INTEGER_32 Index: 21866 <sub>d</sub> = 556A <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
<b>Display range (min. value   unit   max. value)</b>		
0.0	rpm	214748364.7
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02709/1		Limited speed 1 ... 4
C02709/2		
C02709/3		
C02709/4		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 10		

## C02710

Parameter   Name: <b>C02710   Delay lim. speed</b>		Data type: UNSIGNED_32 Index: 21865 <sub>d</sub> = 5569 <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
<b>Setting range (min. value   unit   max. value)</b>		
0.0000	Unit/s <sup>2</sup>	214748.3647
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02710/1	0.0100 Unit/s <sup>2</sup>	Delays for limited speed 1 ... 4
C02710/2	0.0100 Unit/s <sup>2</sup>	
C02710/3	0.0100 Unit/s <sup>2</sup>	
C02710/4	0.0100 Unit/s <sup>2</sup>	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                 Scaling factor: 10000		

## C02711

Parameter   Name: <b>C02711   S-ramp time lim. speed</b>		Data type: UNSIGNED_32 Index: 21864 <sub>d</sub> = 5568 <sub>h</sub>
▶ Basic function " <a href="#">"Limiter"</a> "		
<b>Setting range (min. value   unit   max. value)</b>		
0	ms	10000
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02711/1	100 ms	S-ramp times for limited speed 1 ... 4
C02711/2	100 ms	
C02711/3	100 ms	
C02711/4	100 ms	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		



## C02712

Parameter   Name: <b>C02712   Decel. time lim. speed</b>		Data type: UNSIGNED_32 Index: 21863 <sub>d</sub> = 5567 <sub>h</sub>	
▶ Basic function " <a href="#">Limiter</a> "			
<b>Display range (min. value   unit   max. value)</b>			
0	ms	10000	
<b>Subcodes</b>		<b>Information</b>	
C02712/1		Deceleration times for limited speed 1 ... 4	
C02712/2			
C02712/3			
C02712/4			
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C02713

Parameter   Name: <b>C02713   Max. dist. manual control</b>		Data type: UNSIGNED_32 Index: 21862 <sub>d</sub> = 5566 <sub>h</sub>	
▶ Basic function " <a href="#">Limiter</a> "			
<b>Setting range (min. value   unit   max. value)</b>		<b>Lenze setting</b>	
0.0000	Unit	214748.3647	<b>360.0000 Unit</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 10000			

## C02714

Parameter   Name: <b>C02714   Max. dist. manual control</b>		Data type: UNSIGNED_32 Index: 21861 <sub>d</sub> = 5565 <sub>h</sub>	
▶ Basic function " <a href="#">Limiter</a> "			
<b>Display range (min. value   unit   max. value)</b>			
0	Incr.	2147483647	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

## C02715

Parameter   Name: <b>C02715   Limitation active</b>		Data type: UNSIGNED_32 Index: 21860 <sub>d</sub> = 5564 <sub>h</sub>	
▶ Basic function " <a href="#">Limiter</a> "			
<b>Selection list (display only)</b>			
0	Deactivated		
1	Activated		
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT			

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02716

## C02716

Parameter   Name: <b>C02716   Resp. to limitation</b>		Data type: UNSIGNED_32 Index: 21859 <sub>d</sub> = 5563 <sub>h</sub>
▶ Basic function " <a href="#">Limiter</a> "		
<b>Selection list</b>		
0	No response	
1	Error	
2	Trouble	
3	Quick stop by trouble	
4	Warning locked	
5	Warning	
6	Information	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02716/1	0: No response	Resp. to rotation limitation
C02716/2	3: Quick stop by trouble	Resp. to SW limit pos. excess
C02716/3	0: No response	Resp. to max. value excess
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02717

Parameter   Name: <b>C02717   LIM_dwControl</b>		Data type: UNSIGNED_32 Index: 21858 <sub>d</sub> = 5562 <sub>h</sub>
Control word of the basic function " <a href="#">Limiter</a> " (LS_Limiter).		
<b>Display range (min. value   unit   max. value)</b>		
0		4294967295
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02718

Parameter   Name: <b>C02718   LIM_dnState</b>		Data type: INTEGER_32 Index: 21857 <sub>d</sub> = 5561 <sub>h</sub>
Status of the basic function " <a href="#">Limiter</a> " (LS_Limiter).		
<b>Display range (min. value   unit   max. value)</b>		
0		1
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02719

Parameter   Name: <b>C02719   Limiter: Dig. signals</b>		Data type: UNSIGNED_32 Index: 21856 <sub>d</sub> = 5560 <sub>h</sub>
Display of the boolean input signals of the basic function " <a href="#">Limiter</a> " (LS_Limiter).		
<b>Selection list</b>		
0	FALSE	
1	TRUE	
<b>Subcodes</b>	<b>Information</b>	
C02719/1	LIM_bLimitSwitchPositive	
C02719/2	LIM_bLimitSwitchNegative	
C02719/3	LIM_bActivateLimitedSpeed1	
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

#### C02730

Parameter   Name: <b>C02730   AINx: Gain</b>		Data type: INTEGER_32 Index: 21845 <sub>d</sub> = 5555 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02730/1	100.00 %	Gain of analog input 1
C02730/2	100.00 %	Gain of analog input 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

#### C02731

Parameter   Name: <b>C02731   AINx: Offset</b>		Data type: INTEGER_32 Index: 21844 <sub>d</sub> = 5554 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02731/1	0.00 %	Offset of analog input 1
C02731/2	0.00 %	Offset of analog input 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

#### C02732

Parameter   Name: <b>C02732   AINx: Dead band</b>		Data type: INTEGER_32 Index: 21843 <sub>d</sub> = 5553 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
0.00	%	100.00
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02732/1	0.00 %	Dead band of analog input 1
C02732/2	0.00 %	Dead band of analog input 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

#### C02733

Parameter   Name: <b>C02733   AOUTx: Gain</b>		Data type: INTEGER_32 Index: 21842 <sub>d</sub> = 5552 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02733/1	100.00 %	Gain of analog output 1
C02733/2	100.00 %	Gain of analog output 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

#### C02734

Parameter   Name: <b>C02734   AOUTx: Offset</b>		Data type: INTEGER_32 Index: 21841 <sub>d</sub> = 5551 <sub>h</sub>
<b>Setting range (min. value   unit   max. value)</b>		
-200.00	%	200.00
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02734/1	0.00 %	Offset of analog output 1
C02734/2	0.00 %	Offset of analog output 2
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT                   Scaling factor: 100		

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02800

## C02800

Parameter   Name: <b>C02800   AINx: Input signal</b>		Data type: INTEGER_16 Index: 21775 <sub>d</sub> = 550F <sub>h</sub>
Scaling: -16384 ≙ -100 %, +16383 ≙ +100 %		
<b>Display range (min. value   unit   max. value)</b>		
-16384		16383
<b>Subcodes</b>		<b>Information</b>
C02800/1		Input signal of analog input 1
C02800/2		Input signal of analog input 2
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02801

Parameter   Name: <b>C02801   AOUTx: Output signal</b>		Data type: INTEGER_16 Index: 21774 <sub>d</sub> = 550E <sub>h</sub>
Scaling: -16384 ≙ -100 %, +16383 ≙ +100 %		
<b>Display range (min. value   unit   max. value)</b>		
-16384		16383
<b>Subcodes</b>		<b>Information</b>
C02801/1		Output signal of analog output 1
C02801/2		Output signal of analog output 2
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02802

Parameter   Name: <b>C02802   Status word dig. outputs</b>		Data type: BITFIELD_32 Index: 21773 <sub>d</sub> = 550D <sub>h</sub>
Display of the hexadecimal value of the digital output port		
• Important: All digital levels are indicated without considering the level logic. Internal signals are displayed as well.		
<b>Display range (min. value   unit   max. value)</b>		
0x00000000		0xFFFFFFFF
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02803

Parameter   Name: <b>C02803   Status word dig. inputs</b>		Data type: BITFIELD_32 Index: 21772 <sub>d</sub> = 550C <sub>h</sub>
Display of the hexadecimal value of the digital input port		
• Important: All digital levels are indicated without considering the level logic. Internal signals are displayed as well.		
<b>Display range (min. value   unit   max. value)</b>		
0x00000000		0xFFFFFFFF
<input checked="" type="checkbox"/> Read access <input type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02810

Parameter   Name: <b>C02810   Delay time for TPx</b>		Data type: UNSIGNED_32 Index: 21765 <sub>d</sub> = 5505 <sub>h</sub>
<p>The set delay time will be considered when the position is determined at the touch probe time and will be used to compensate for dead times, if necessary.</p> <ul style="list-style-type: none"> <li>• Please observe the setting of the input filter for the digital inputs (<a href="#">C02830</a>).</li> </ul>		
<b>Setting range</b> (min. value   unit   max. value)		
0	us	7000
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02810/1	0 us	Delay for touch probe 1 ... 8
C02810/...		
C02810/10		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02830

Parameter   Name: <b>C02830   Dlx delay time</b>		Data type: UNSIGNED_8 Index: 21745 <sub>d</sub> = 54F1 <sub>h</sub>
<p>Input filter for digital inputs</p> <ul style="list-style-type: none"> <li>• Can be used to filter "spikes" at the digital inputs, if necessary.</li> <li>• Each digital input is assigned to a subcode.</li> <li>• Since the filter is a "counting" filter, the indicated times are only approximate values.</li> </ul>		
<b>Selection list</b>		<b>Information</b>
0	2 µs	Filter time
1	4 µs	
2	8 µs	
3	16 µs	
4	32 µs	
5	64 µs	
6	128 µs	
7	256 µs	
8	512 µs	
9	1024 µs	
10	2048 µs	
11	4096 µs	
12	8192 µs	
13	16384 µs	
14	32768 µs	
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02830/1	0: 2 µs	Setting of digital input 1 ... 8
C02830/...		
C02830/8		
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input type="checkbox"/> MOT		

## C02850

Parameter   Name: <b>C02850   Service code</b>	Data type: UNSIGNED_32 Index: 21725 <sub>d</sub> = 54DD <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

## C02851

Parameter   Name: <b>C02851   Service code</b>	Data type: UNSIGNED_32 Index: 21724 <sub>d</sub> = 54DC <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

# 9400 HighLine | Parameter setting & configuration

Parameter reference

Parameter list | C02852

C02852

Parameter   Name: <b>C02852   Service code</b>	Data type: UNSIGNED_16 Index: 21723 <sub>d</sub> = 54DB <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C02853

Parameter   Name: <b>C02853   Vp Lss saturat. characteristic</b>	Data type: UNSIGNED_16 Index: 21722 <sub>d</sub> = 54DA <sub>h</sub>	
<b>Setting range (min. value   unit   max. value)</b>		
0	%	400
<b>Subcodes</b>	<b>Lenze setting</b>	<b>Information</b>
C02853/1	100 %	Saturation characteristic to correct the leakage inductance and the current controller parameters. <ul style="list-style-type: none"> <li>The saturation characteristic is displayed by 17 points which are distributed linearly on the X axis.</li> <li>The point 17 represents 100 % of the maximum motor current in the process (<a href="#">C02855</a>).</li> <li>The values to be entered in the subcodes represent the y values of the grid points 1 ... 17.</li> </ul> ▶ <a href="#">Correction of the leakage inductance via saturation characteristic</a>
C02853/2	100 %	
C02853/3	100 %	
C02853/4	100 %	
C02853/5	100 %	
C02853/6	100 %	
C02853/7	100 %	
C02853/8	100 %	
C02853/9	100 %	
C02853/10	100 %	
C02853/11	100 %	
C02853/12	100 %	
C02853/13	100 %	
C02853/14	100 %	
C02853/15	100 %	
C02853/16	100 %	
C02853/17	100 %	
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT		

C02854

Parameter   Name: <b>C02854   Service code</b>	Data type: UNSIGNED_32 Index: 21721 <sub>d</sub> = 54D9 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C02855

Parameter   Name: <b>C02855   I<sub>max</sub> Lss saturat. characteristic</b>	Data type: UNSIGNED_32 Index: 21720 <sub>d</sub> = 54D8 <sub>h</sub>	
Maximum motor current in the process <ul style="list-style-type: none"> <li>Defines the grid point 17 of the saturation characteristic set in <a href="#">C02853</a>.</li> </ul> ▶ <a href="#">Correction of the leakage inductance via saturation characteristic</a>		
<b>Setting range (min. value   unit   max. value)</b>		
0.0	A	6000.0
		<b>Lenze setting</b>
		<b>5.4 A</b>
<input checked="" type="checkbox"/> Read access <input checked="" type="checkbox"/> Write access <input checked="" type="checkbox"/> CINH <input type="checkbox"/> PLC STOP <input type="checkbox"/> No transfer <input type="checkbox"/> COM <input checked="" type="checkbox"/> MOT                       Scaling factor: 10		

C02856

Parameter   Name: <b>C02856   Service code</b>	Data type: VISIBLE_STRING Index: 21719 <sub>d</sub> = 54D7 <sub>h</sub>
<b>This code is used internally by the controller and must not be overwritten by the user!</b>	

C02857

Parameter | Name: **C02857 | Service code** Data type: VISIBLE\_STRING  
Index: 21718<sub>d</sub> = 54D6<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C02858

Parameter | Name: **C02858 | Service code** Data type: UNSIGNED\_8  
Index: 21717<sub>d</sub> = 54D5<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C02859

Parameter | Name: **C02859 | Lss sat. characteristic** Data type: UNSIGNED\_8  
Index: 21716<sub>d</sub> = 54D4<sub>h</sub>

Selection list (Lenze setting printed in bold)	
0	<b>Deactivated</b>
1	Activated

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT

C02860

Parameter | Name: **C02860 | Rr adaptation** Data type: UNSIGNED\_32  
Index: 21715<sub>d</sub> = 54D3<sub>h</sub>

Setting range (min. value   unit   max. value)	Lenze setting
50.00   %   200.00	<b>100.00 %</b>

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT Scaling factor: 100

C02861

Parameter | Name: **C02861 | Lh adaptation** Data type: UNSIGNED\_32  
Index: 21714<sub>d</sub> = 54D2<sub>h</sub>

Setting range (min. value   unit   max. value)	Lenze setting
50.00   %   200.00	<b>100.00 %</b>

Read access  Write access  CINH  PLC STOP  No transfer  COM  MOT Scaling factor: 100

C02996

Parameter | Name: **C02996 | Service code** Data type: UNSIGNED\_32  
Index: 21579<sub>d</sub> = 544B<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C02997

Parameter | Name: **C02997 | Service code** Data type: UNSIGNED\_32  
Index: 21578<sub>d</sub> = 544A<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C02998

Parameter | Name: **C02998 | Service code** Data type: UNSIGNED\_32  
Index: 21577<sub>d</sub> = 5449<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

C02999

Parameter | Name: **C02999 | Service code** Data type: UNSIGNED\_32  
Index: 21576<sub>d</sub> = 5448<sub>h</sub>

**This code is used internally by the controller and must not be overwritten by the user!**

## 16.4 Attribute table

The Attribute table contains information required for communicating with the controller via parameters.

### How to read the table of attributes:

Column	Meaning		Entry	
Code	Parameter designation		Cxxxxx	
Name	Short parameter text (display text)		Text	
Index	dec	Index under which the parameter is addressed. The subindex of array variables corresponds to the Lenze subcode number.	24575 - Lenze code number	Only required for access via bus system.
	hex		5FFF <sub>h</sub> - Lenze code number	
Data	DS	Data structure	E	Single variable (only one parameter element)
			A	Array variable (several parameter elements)
	DA	Number of array elements (subcodes)	Number	
Data	DT	Data type	BITFIELD_8	1 byte bit-coded
			BITFIELD_16	2 bytes bit-coded
			BITFIELD_32	4 bytes bit-coded
			INTEGER_8	1 byte with sign
			INTEGER_16	2 bytes with sign
			INTEGER_32	4 bytes with sign
			UNSIGNED_8	1 byte without sign
			UNSIGNED_16	2 bytes without sign
			UNSIGNED_32	4 bytes without sign
			VISIBLE_STRING	ASCII string
	Factor	Factor for data transmission via bus system, depending on the number of decimal positions	Factor	1 = no decimal positions 10 = 1 decimal position 100 = 2 decimal positions 1000 = 3 decimal positions
Access	R	Read access	<input checked="" type="checkbox"/> Reading allowed	
	W	Write access	<input checked="" type="checkbox"/> Writing allowed	
	CINH	Controller inhibit required	<input checked="" type="checkbox"/> Writing only possible when controller is inhibited	

### Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00002</a>	Controller commands	24573	5FFD	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00003</a>	Device command status	24572	5FFC	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00004</a>	Service password	24571	5FFB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00005</a>	Application selection	24570	5FFA	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00006</a>	Motor control selection	24569	5FF9	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00007</a>	Active application	24568	5FF8	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00011</a>	Motor reference speed	24564	5FF4	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00018</a>	Chopper frequency	24557	5FED	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00019</a>	Standstill recognitionthreshold	24556	5FEC	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00022</a>	Maximum current	24553	5FE9	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00034</a>	Config. analog input 1	24541	5FDD	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00050</a>	Speed setpoint	24525	5FCD	A	2	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00051</a>	Actual speed value	24524	5FCC	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00052</a>	Motor voltage	24523	5FCB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00053</a>	DC-bus voltage	24522	5FCA	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		



Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00054</a>	Motor current	24521	5FC9	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00055</a>	Phase currents	24520	5FC8	A	4	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00056</a>	Torque setpoint	24519	5FC7	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00057</a>	Torque	24518	5FC6	A	2	UNSIGNED_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C00058</a>	Rotor displacement angle	24517	5FC5	A	3	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00059</a>	Motor - number of pole pairs	24516	5FC4	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00060</a>	Rotor position	24515	5FC3	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00061</a>	Heatsink temperature	24514	5FC2	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00062</a>	Temperature inside the controller	24513	5FC1	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00063</a>	Motor temperature	24512	5FC0	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00064</a>	Device utilisation (lxt)	24511	5FBF	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00065</a>	Ext. 24-V voltage	24510	5FBE	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C00066</a>	Thermal motor load (l*xt)	24509	5FBD	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00068</a>	Electrolytic capacitor temperature	24507	5FBB	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00069</a>	CPU temperature	24506	5FBA	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00070</a>	Speed controller gain	24505	5FB9	E	1	UNSIGNED_32	100000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00071</a>	Speed controller reset time	24504	5FB8	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00072</a>	D component - speed controller	24503	5FB7	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00074</a>	Feedfwd. ctrl. - current contr.	24501	5FB5	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00075</a>	Current controller gain	24500	5FB4	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00076</a>	Integral-action time current contr.	24499	5FB3	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00077</a>	Field controller gain	24498	5FB2	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00078</a>	Field contr. reset time	24497	5FB1	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00079</a>	Mutual motor inductance	24496	5FB0	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>		
<a href="#">C00080</a>	Resolver - pole pair number	24495	5FAF	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00081</a>	Rated motorpower	24494	5FAE	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00082</a>	Motor - rotor resistance	24493	5FAD	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C00083</a>	Motor - rotor time constant	24492	5FAC	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00084</a>	Motor stator resistance	24491	5FAB	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00085</a>	Motor stator leakage induct.	24490	5FAA	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00087</a>	Rated motor speed	24488	5FA8	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00088</a>	Rated motor current	24487	5FA7	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00089</a>	Rated motor frequency	24486	5FA6	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00090</a>	Rated motor voltage	24485	5FA5	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00091</a>	Motor - cosine phi	24484	5FA4	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00092</a>	Motor - magnetising current	24483	5FA3	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00099</a>	Firmware version	24476	5F9C	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00105</a>	Quick stop deceleration time	24470	5F96	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00106</a>	Quick stop S-ramp time	24469	5F95	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00107</a>	Ref. deceleration time quick stop	24468	5F94	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00114</a>	Dix terminal polarity	24461	5F8D	A	8	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00118</a>	DOx terminal polarity	24457	5F89	A	4	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00120</a>	Mot. overload protection (l*xt)	24455	5F87	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00121</a>	Warning threshold - motor temperature	24454	5F86	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00122</a>	Warning threshold heatsink temp.	24453	5F85	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00123</a>	Warning threshold - device utilisation	24452	5F84	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00126</a>	Warning threshold - CPU temperature	24449	5F81	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00127</a>	Warning threshold - motor overload	24448	5F80	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00128</a>	Therm. motor time constant	24447	5F7F	A	2	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00129</a>	Brake resistor value	24446	5F7E	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

# 9400 HighLine | Parameter setting & configuration

## Parameter reference

### Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00130</a>	Max. power brake resistor	24445	5F7D	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00131</a>	Therm. capacity brake resistor	24444	5F7C	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00132</a>	Max. temp. of brake resistor	24443	5F7B	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00142</a>	Autom. restart after power on	24433	5F71	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00150</a>	Status word 1	24425	5F69	E	1	BITFIELD_16	1	<input checked="" type="checkbox"/>		
<a href="#">C00155</a>	Status word 2	24420	5F64	E	1	BITFIELD_16	1	<input checked="" type="checkbox"/>		
<a href="#">C00156</a>	Status/Control word MCTRL	24419	5F63	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00158</a>	Controller inhibit by (source)	24417	5F61	E	1	BITFIELD_16	1	<input checked="" type="checkbox"/>		
<a href="#">C00159</a>	Quick stop by (source)	24416	5F60	E	1	BITFIELD_16	1	<input checked="" type="checkbox"/>		
<a href="#">C00166</a>	Error status	24409	5F59	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00168</a>	Error number	24407	5F57	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00169</a>	Logbook event filter	24406	5F56	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00173</a>	Mains - voltage	24402	5F52	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00174</a>	Threshold undervoltage (LU)	24401	5F51	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00178</a>	Elapsed hour meter	24397	5F4D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00179</a>	Power-on time meter	24396	5F4C	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00180</a>	Service code	24395	5F4B	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00181</a>	Red. brake chopper threshold	24394	5F4A	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00183</a>	Device state	24392	5F48	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00185</a>	Threshold mains recovery detect.	24390	5F46	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00186</a>	ENP: detected motor type	24389	5F45	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00187</a>	ETS: Identified serial number	24388	5F44	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00188</a>	ETS: Status	24387	5F43	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00199</a>	Device name	24376	5F38	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00200</a>	Firmware product type	24375	5F37	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00201</a>	Firmware - compile date	24374	5F36	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00203</a>	HW product types	24372	5F34	A	9	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00204</a>	HW serial number	24371	5F33	A	9	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00205</a>	HW descriptions	24370	5F32	A	6	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00206</a>	HW manufacturing data	24369	5F31	A	8	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00208</a>	HW manufacturer	24367	5F2F	A	6	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00209</a>	HW countries of origin	24366	5F2E	A	6	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00210</a>	HW versions	24365	5F2D	A	6	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00211</a>	Application: Version	24364	5F2C	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00212</a>	Application: Type code	24363	5F2B	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00213</a>	Application: Compiler date	24362	5F2A	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C00214</a>	Required safety module	24361	5F29	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00218</a>	Application: ID number	24357	5F25	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00254</a>	Phase controller gain	24321	5F01	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00270</a>	Freq. current setpoint filter	24305	5EF1	A	2	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00271</a>	Width - current setp. filter	24304	5EF0	A	2	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00272</a>	Depth - current setp. filter	24303	5EEF	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00273</a>	Moment of inertia	24302	5EEE	A	2	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00274</a>	Max. change in acceleration	24301	5EED	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00275</a>	Signal source speed setpoint	24300	5EEC	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00276</a>	Signal source torque setpoint	24299	5EEB	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00280</a>	Filter time const. DC detection	24295	5EE7	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00311</a>	CAN TPDO1 mask byte x	24264	5EC8	A	8	BITFIELD_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00312</a>	CAN TPDO2 mask byte x	24263	5EC7	A	8	BITFIELD_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00313</a>	CAN TPDO3 mask byte x	24262	5EC6	A	8	BITFIELD_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00314</a>	CAN TPDO4 mask byte x	24261	5EC5	A	8	BITFIELD_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00320</a>	CAN TPDOx identifier	24255	5EBF	A	4	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00321</a>	CAN RPDOx identifier	24254	5EBE	A	4	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00322</a>	CAN TPDOx Tx mode	24253	5EBD	A	4	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00323</a>	CAN RPDOx Rx mode	24252	5EBC	A	4	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00324</a>	CAN TPDOx delay time	24251	5EBB	A	4	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00345</a>	CAN error	24230	5EA6	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00346</a>	CAN heartbeat activity	24229	5EA5	E	1	BITFIELD_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00347</a>	CAN heartbeat status	24228	5EA4	A	32	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00348</a>	CAN status DIP switch	24227	5EA3	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00349</a>	CAN setting of DIP switch	24226	5EA2	A	2	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00350</a>	CAN node address	24225	5EA1	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00351</a>	CAN baud rate	24224	5EA0	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00352</a>	CAN slave/master	24223	5E9F	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00356</a>	CAN TPDOx cycle time	24219	5E9B	A	4	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00357</a>	CAN RPDOx monitoring time	24218	5E9A	A	4	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00359</a>	CAN status	24216	5E98	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00360</a>	CAN telegram and error counter	24215	5E97	A	8	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C00361</a>	CAN bus load	24214	5E96	A	6	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00367</a>	CAN SYNC Rx identifier	24208	5E90	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00368</a>	CAN SYNC Tx identifier	24207	5E8F	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00369</a>	CAN SYNC transmit cycle time	24206	5E8E	A	3	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00372</a>	CAN SDO server Rx identifier	24203	5E8B	A	10	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00373</a>	CAN SDO server Tx identifier	24202	5E8A	A	10	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00374</a>	CAN SDO client node address	24201	5E89	A	10	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00375</a>	CAN SDO client Rx identifier	24200	5E88	A	10	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00376</a>	CAN SDO client Tx identifier	24199	5E87	A	10	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00377</a>	CAN SDO server node address	24198	5E86	A	10	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00378</a>	CAN delay boot-up - Operational	24197	5E85	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00381</a>	CAN Heartbeat Producer Time	24194	5E82	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00382</a>	CAN Guard Time	24193	5E81	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00383</a>	CAN Life Time Factor	24192	5E80	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00385</a>	CAN Heartbeat Consumer Time	24190	5E7E	A	32	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00386</a>	CAN Node Guarding	24189	5E7D	A	32	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00387</a>	CAN Node Guarding Activity	24188	5E7C	E	1	BITFIELD_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00388</a>	CAN Node Guarding Status	24187	5E7B	A	32	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00390</a>	CAN error register (DS301V402)	24185	5E79	E	1	BITFIELD_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00391</a>	CAN emergency object	24184	5E78	E	1	BITFIELD_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00392</a>	CAN emergency delay time	24183	5E77	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00393</a>	CAN event bus scan	24182	5E76	A	128	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00398</a>	Test mode motor control	24177	5E71	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00399</a>	Settings for test mode	24176	5E70	A	2	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00416</a>	Resolver error compensation	24159	5E5F	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00420</a>	Encoder - PPR	24155	5E5B	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00421</a>	Encoder voltage	24154	5E5A	E	1	UNSIGNED_16	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00422</a>	Encoder - type	24153	5E59	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00427</a>	TTL encoder signal evaluation	24148	5E54	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00443</a>	Dlx status	24132	5E44	A	12	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00444</a>	DOx status	24131	5E43	A	18	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00465</a>	Keypad: Welcome screen time-out	24110	5E2E	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00466</a>	Keypad: Default parameters	24109	5E2D	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00467</a>	Keypad: Def. welcome screen	24108	5E2C	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

# 9400 HighLine | Parameter setting & configuration

## Parameter reference

### Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00469</a>	Keypad: Fct. STOP key	24106	5E2A	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00490</a>	Position encoder	24085	5E15	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00494</a>	Motor standstill time constant	24081	5E11	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00495</a>	Motor encoder	24080	5E10	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C00497</a>	Speed act. val. time const.	24078	5E0E	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00573</a>	Resp. to overload brake chopper	24002	5DC2	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00574</a>	Resp. to overtemp. brake resist.	24001	5DC1	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00576</a>	Window - speed monitoring	23999	5DBF	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00577</a>	Gain field weakening controller	23998	5DBE	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00578</a>	Integr.-act. time field weak. contr.	23997	5DBD	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00579</a>	React. speed monitoring	23996	5DBC	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00580</a>	Resp. to encoder open circuit	23995	5DBB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00581</a>	Resp. to external fault	23994	5DBA	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00582</a>	Resp. to heatsink temp. > C00122	23993	5DB9	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00583</a>	Resp. to motor overtemp. KTY	23992	5DB8	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00584</a>	Resp. to motor temp. > C00121	23991	5DB7	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00585</a>	Resp. to motor overtemp. PTC	23990	5DB6	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00586</a>	Resp. to resolver open circuit	23989	5DB5	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00587</a>	Status fan control	23988	5DB4	E	1	BITFIELD_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00588</a>	Resp. to t. sensor drive failure	23987	5DB3	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00589</a>	Resp. to CPU temp. > C00126	23986	5DB2	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00591</a>	Resp. to CAN-RPDOx error	23984	5DB0	A	4	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00594</a>	Resp. to t. sensor motor failure	23981	5DAD	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00595</a>	Resp. to CAN bus OFF	23980	5DAC	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00596</a>	Threshold max. speed reached	23979	5DAB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00597</a>	Resp. to motor phase failure	23978	5DAA	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00598</a>	Resp. to open circuit AIN1	23977	5DA9	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00599</a>	Threshold - motor phase failure	23976	5DA8	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00600</a>	Resp. to DC bus overvoltage	23975	5DA7	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00601</a>	Resp. to comm. encoder error	23974	5DA6	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00604</a>	Resp. to device overload	23971	5DA3	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00606</a>	Resp. to motor overload	23969	5DA1	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00607</a>	Resp. to max. speed reached	23968	5DA0	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00610</a>	Resp. to heatsink fan failure	23965	5D9D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00611</a>	Resp. to integral fan failure	23964	5D9C	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00612</a>	Resp. to CAN node guarding error	23963	5D9B	A	32	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00613</a>	Resp. to CAN heartbeat error	23962	5D9A	A	32	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00614</a>	Resp. to CAN life guarding error	23961	5D99	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00615</a>	Resp. to imp. device config.	23960	5D98	A	5	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00618</a>	No. of CRC cycles	23957	5D95	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00619</a>	Resp. to max. motor current	23956	5D94	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00620</a>	Threshold max. motor current	23955	5D93	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00625</a>	CAN behaviour in case of fault	23950	5D8E	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00635</a>	Resp. to new firmw. standard dev.	23940	5D84	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00636</a>	Resp. to new module in MXI1	23939	5D83	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00637</a>	Resp. to new module in MXI2	23938	5D82	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C00691</a>	Total speed setpoint	23884	5D4C	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00692</a>	Speed setpoint	23883	5D4B	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00693</a>	Actual speed value	23882	5D4A	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00694</a>	Speed controller output	23881	5D49	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00695</a>	Total torque setpoint	23880	5D48	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C00696</a>	Torque setpoint	23879	5D47	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00697</a>	Filtered torque setpoint	23878	5D46	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00698</a>	Actual torque	23877	5D45	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00770</a>	MCTRL_dnMotorPosAct	23805	5CFD	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00771</a>	MCTRL_dnLoadPosAct	23804	5CFC	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00772</a>	MCTRL_dnMotorSpeedAct	23803	5CFB	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00773</a>	MCTRL_dnLoadSpeedAct	23802	5CFA	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00774</a>	MCTRL_dnTorqueAct	23801	5CF9	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00775</a>	MCTRL_dnOutputSpeedCtrl	23800	5CF8	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00776</a>	MCTRL_dnInputJerkCtrl	23799	5CF7	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00777</a>	MCTRL_dnInputTorqueCtrl	23798	5CF6	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00778</a>	MCTRL_dnFluxAct	23797	5CF5	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00779</a>	MCTRL_dnDCBusVoltage	23796	5CF4	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00780</a>	MCTRL_dnImotAct	23795	5CF3	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00781</a>	MCTRL_dwMaxMotorSpeed	23794	5CF2	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00782</a>	MCTRL_dwMaxMotorTorque	23793	5CF1	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C00783</a>	MCTRL_dwMotorVoltageAct	23792	5CF0	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00784</a>	MCTRL_dnMotorFreqAct	23791	5CEF	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C00786</a>	MCTRL_dnIxtLoad	23789	5CED	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00787</a>	MCTRL_dnFlyingSpeedAct	23788	5CEC	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00788</a>	MCTRL_dwMaxEffMotorTorque	23787	5CEB	E	1	INTEGER_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C00789</a>	MCTRL_dwMaxDeviceCurrent	23786	5CEA	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00790</a>	MCTRL_dnl2xtLoad	23785	5CE9	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00791</a>	MCTRL_dnDeltaMotorPos_p	23784	5CE8	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00792</a>	MCTRL_dnOutputPosCtrlMotor_s	23783	5CE7	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00800</a>	MCTRL_dnPosSet	23775	5CDF	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00802</a>	MCTRL_dnSpeedAdd	23773	5CDD	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00803</a>	MCTRL_dnTorqueAdd	23772	5CDC	E	1	INTEGER_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C00804</a>	MCTRL_dnAccelerationAdd	23771	5CDB	E	1	INTEGER_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C00805</a>	MCTRL_dnSpeedLowLimit	23770	5CDA	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00806</a>	MCTRL_dnTorqueLowLimit	23769	5CD9	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00807</a>	MCTRL_dnTorqueHighLimit	23768	5CD8	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00808</a>	MCTRL_dnPosCtrlOutLimit	23767	5CD7	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00809</a>	MCTRL_dnTorqueCtrlAdapt	23766	5CD6	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00810</a>	MCTRL_dnSpeedCtrlAdapt	23765	5CD5	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00811</a>	MCTRL_dnPosCtrlAdapt	23764	5CD4	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00812</a>	MCTRL_dnMotorPosRefValue	23763	5CD3	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00813</a>	MCTRL_dnLoadPosRefValue	23762	5CD2	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00814</a>	MCTRL_dnBoost	23761	5CD1	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00815</a>	MCTRL_dnSpeedCtrlIntegrator	23760	5CD0	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00816</a>	MCTRL_dnFieldWeak	23759	5CCF	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C00817</a>	MCTRL_dnSpeedSet_s	23758	5CCE	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00854</a>	ID status	23721	5CA9	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C00878</a>	Status DCTRL control input	23697	5C91	A	5	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C00909</a>	Speed limitation	23666	5C72	A	2	INTEGER_16	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01120</a>	Sync source	23455	5B9F	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01121</a>	Sync cycle time	23454	5B9E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01122</a>	Sync phase position	23453	5B9D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01123</a>	Sync window	23452	5B9C	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01124</a>	Sync PLL increment	23451	5B9B	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01190</a>	Motor thermal sensor	23385	5B59	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

# 9400 HighLine | Parameter setting & configuration

## Parameter reference

### Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C01191</a>	Temperature for spec. characteristic	23384	5B58	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01192</a>	Resistor for spec. characteristic	23383	5B57	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01193</a>	Motor temp. feedback system	23382	5B56	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C01194</a>	Motor operating temperature	23381	5B55	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01195</a>	Influence winding l'xt mon.	23380	5B54	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01196</a>	S1 torque characteristic l'xt mon.	23379	5B53	A	8	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01203</a>	Counter: Brake chopper overload	23372	5B4C	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01204</a>	Counter: lxt overload	23371	5B4B	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01205</a>	Counter: DC bus overvoltage	23370	5B4A	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01206</a>	Counter: Mains switching	23369	5B49	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01208</a>	Counter: Heatsink overtemp.	23367	5B47	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01209</a>	Counter: Housing overtemp.	23366	5B46	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01210</a>	Electrolytic capacitor av. temp.	23365	5B45	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C01212</a>	Counter: Power section overload	23363	5B43	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C01214</a>	Internal clock	23361	5B41	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C01501</a>	Resp. to comm. error with MX11	23074	5A22	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01502</a>	Resp. to comm. error with MX12	23073	5A21	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01510</a>	Ethernet IP address client x	23065	5A19	A	5	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C01511</a>	Ethernet status client x	23064	5A18	A	5	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C01902</a>	Diagnostics X6: Max. baud rate	22673	5891	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01903</a>	Diagnostics X6: Change baud rate	22672	5890	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C01905</a>	Diagnostics X6: Curr. baud rate	22670	588E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02104</a>	Program auto-start	22471	57C7	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02108</a>	Program status	22467	57C3	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>		
<a href="#">C02109</a>	Program runtime	22466	57C2	E	1	UNSIGNED_16	1	<input checked="" type="checkbox"/>		
<a href="#">C02113</a>	Program name	22462	57BE	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>		
<a href="#">C02121</a>	Runtime task 1	22454	57B6	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02122</a>	Runtime task 2	22453	57B5	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02123</a>	Runtime task 3	22452	57B4	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02520</a>	Gearbox fact. numer. motor	22055	5627	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02521</a>	Gearbox fact. denom. motor	22054	5626	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02522</a>	Gearbox fact. numer. load	22053	5625	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02523</a>	Gearbox fact. denom. load	22052	5624	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02524</a>	Feed constant	22051	5623	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02525</a>	Unit	22050	5622	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02526</a>	User-defined unit	22049	5621	E	1	VISIBLE_STRING	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02527</a>	Motor mounting direction	22048	5620	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02528</a>	Traversing range	22047	561F	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02529</a>	Mounting direction of position encoder	22046	561E	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02530</a>	Active function state	22045	561D	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02531</a>	Resulting gearbox factors	22044	561C	A	3	UNSIGNED_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C02532</a>	Resolution of a unit	22043	561B	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02533</a>	Time unit	22042	561A	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02534</a>	User-defined time unit	22041	5619	E	1	VISIBLE_STRING	0	<input checked="" type="checkbox"/>		
<a href="#">C02535</a>	User-defined unit	22040	5618	E	1	VISIBLE_STRING	0	<input checked="" type="checkbox"/>		
<a href="#">C02536</a>	Cycle	22039	5617	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02537</a>	Speed unit	22038	5616	E	1	VISIBLE_STRING	0	<input checked="" type="checkbox"/>		
<a href="#">C02538</a>	Acceleration unit	22037	5615	E	1	VISIBLE_STRING	0	<input checked="" type="checkbox"/>		
<a href="#">C02539</a>	Max. presentable position	22036	5614	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02540</a>	Max. speed to be shown	22035	5613	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C02541</a>	Max. acceleration to be shown	22034	5612	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02542</a>	Load reference speed	22033	5611	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C02543</a>	Load reference torque	22032	5610	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>		
<a href="#">C02547</a>	DI_dnState	22028	560C	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02548</a>	DI_bErrors	22027	560B	A	4	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02549</a>	Drive interface: Signals	22026	560 A	A	15	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02550</a>	Setpoint interpolation	22025	5609	A	3	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02552</a>	Position setpoint	22023	5607	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02553</a>	Position controller gain	22022	5606	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02554</a>	Integral-actoin time of position controller	22021	5605	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02555</a>	D component of position controller	22020	5604	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02556</a>	Pos. contr. limitation	22019	5603	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02557</a>	Motor pos. contr. output	22018	5602	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02558</a>	Pos. contr. output	22017	5601	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02559</a>	Internal torque limit	22016	5600	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02560</a>	Motor interface messages	22015	55FF	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02567</a>	Control mode	22008	55F8	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02568</a>	Motor interface: % signals	22007	55F7	A	8	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02569</a>	Motor interface.: Dig. signals	22006	55F6	A	11	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02570</a>	Controller configuration	22005	55F5	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02572</a>	Speed setpoint	22003	55F3	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02573</a>	Position setpoint	22002	55F2	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02574</a>	Actual speed value	22001	55F1	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02575</a>	Actual position	22000	55F0	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02576</a>	Following error	21999	55EF	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02577</a>	External actual position	21998	55EE	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02578</a>	Offset actual pos. value/setp.	21997	55ED	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02579</a>	Encoder eval.: Dig. signals	21996	55EC	A	3	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02580</a>	Operating mode - brake	21995	55EB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02581</a>	Brake activation threshold	21994	55EA	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02582</a>	Brake resp. to pulse inhibit	21993	55E9	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02583</a>	Status input monitoring	21992	55E8	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02585</a>	Brake control polarity	21990	55E6	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02586</a>	Starting torque 1	21989	55E5	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02587</a>	Starting torque 2	21988	55E4	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02588</a>	Source of starting torque	21987	55E3	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02589</a>	Brake closing time	21986	55E2	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02590</a>	Brake opening time	21985	55E1	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02591</a>	Waiting time - status monit.	21984	55E0	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02593</a>	Waiting time - brake active.	21982	55DE	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02594</a>	Test torque	21981	55DD	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02595</a>	Permissible angle of rotation	21980	55DC	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02596</a>	Grinding speed	21979	55 db	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02597</a>	Accel./decel. time - grinding	21978	55DA	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02598</a>	Grinding ON time	21977	55D9	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02599</a>	Grinding OFF time	21976	55D8	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02607</a>	BRK_dnState	21968	55D0	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02608</a>	BRK_dnTorqueAdd_n	21967	55CF	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02609</a>	Brake control: Dig. signals	21966	55CE	A	9	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02610</a>	Deceleration time for stop	21965	55CD	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

# 9400 HighLine | Parameter setting & configuration

## Parameter reference

### Attribute table

Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C02611</a>	S-ramp time for stop	21964	55CC	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02612</a>	Ref. for decel. time of stop	21963	55CB	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02616</a>	STP_dnState	21959	55C7	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02617</a>	STP_bStopActive	21958	55C6	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02619</a>	Quick stop: Dig. signals	21956	55C4	A	4	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02620</a>	Manual jog speed 1	21955	55C3	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02621</a>	Manual jog speed 2	21954	55C2	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02622</a>	Manual acceleration	21953	55C1	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02623</a>	Manual deceleration	21952	55C0	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02624</a>	Inaccuracy time of manual traversing	21951	55BF	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02638</a>	Manual jog status	21937	55B1	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02639</a>	Manual control: Dig. signals	21936	55B0	A	7	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02640</a>	Ref. mode	21935	55AF	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02642</a>	HM position	21933	55AD	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02643</a>	HM target position	21932	55AC	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02644</a>	Ref. speed 1	21931	55AB	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02645</a>	Home acceleration 1	21930	55AA	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02646</a>	Ref. speed 2	21929	55A9	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02647</a>	Ref. acceleration 2	21928	55A8	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02648</a>	Home S-ramp time	21927	55A7	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02649</a>	HM torque limit	21926	55A6	E	1	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02650</a>	Homing inhibit time	21925	55A5	E	1	UNSIGNED_32	1000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02651</a>	HM touch probe configuration	21924	55A4	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02652</a>	Home position after mains switching	21923	55A3	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02653</a>	Max. rot. angle after mains sw.	21922	55A2	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02656</a>	Current position	21919	559F	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02657</a>	HM_dnState	21918	559E	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02658</a>	HM_dnHomePos_p	21917	559D	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02659</a>	Homing: Dig. signals	21916	559C	A	9	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02674</a>	POS_dwActualProfileNumber	21901	558D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02675</a>	POS_dnState	21900	558C	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02676</a>	POS_dnProfileSpeed_s	21899	558B	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02677</a>	Positioning: % signals	21898	558 A	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02678</a>	Positioning: Pos. signals	21897	5589	A	2	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02679</a>	Positioning: Dig. signals	21896	5588	A	10	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02680</a>	Source position setpoint	21895	5587	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02681</a>	Source add. speed	21894	5586	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02685</a>	PF_dnMotorAcc_x	21890	5582	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02686</a>	PF_dnSpeedAdd1_s	21889	5581	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02687</a>	Position follower: % signals	21888	5580	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02688</a>	Position follower: Pos. signal	21887	557F	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>		
<a href="#">C02689</a>	Position follower: Dig. signals	21886	557E	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02692</a>	SF_dnMotorAcc_x	21883	557B	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02693</a>	SF_dnSpeedAdd_s	21882	557 A	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02694</a>	Speed follower: % signals	21881	5579	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02695</a>	Speed follower: Dig. signals	21880	5578	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02698</a>	Torque follower: % signals	21877	5575	A	3	INTEGER_32	100	<input checked="" type="checkbox"/>		
<a href="#">C02699</a>	Torque follower: Dig. signals	21876	5574	A	2	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02700</a>	Software limit positions are active	21875	5573	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02701</a>	Software limit positions	21874	5572	A	2	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02702</a>	Limitations effective	21873	5571	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	



Code	Name	Index		Data				Access		
		dec	hex	DS	DA	DT	Factor	R	W	CINH
<a href="#">C02703</a>	Max. speed	21872	5570	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02704</a>	Max. speed [rpm]	21871	556F	E	1	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02705</a>	Max. acceleration	21870	556E	E	1	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02706</a>	Min. S-ramp time	21869	556D	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02707</a>	Permissible direction of rotation	21868	556C	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02708</a>	Limited speed	21867	556B	A	4	INTEGER_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02709</a>	Limited speed	21866	556 A	A	4	INTEGER_32	10	<input checked="" type="checkbox"/>		
<a href="#">C02710</a>	Delay lim. speed	21865	5569	A	4	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02711</a>	S-ramp time lim. speed	21864	5568	A	4	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02712</a>	Decel. time lim. speed	21863	5567	A	4	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02713</a>	Max. Strecke Handfahren	21862	5566	E	1	UNSIGNED_32	10000	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02714</a>	Max. Strecke Handfahren	21861	5565	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02715</a>	Limitation active	21860	5564	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02716</a>	Resp. to limitation	21859	5563	A	3	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02717</a>	LIM_dwControl	21858	5562	E	1	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02718</a>	LIM_dnState	21857	5561	E	1	INTEGER_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02719</a>	Limitier: Dig. signals	21856	5560	A	3	UNSIGNED_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02730</a>	AINx: Gain	21845	5555	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02731</a>	AINx: Offset	21844	5554	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02732</a>	AINx: Dead band	21843	5553	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02733</a>	AOUTx: Gain	21842	5552	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02734</a>	AOUTx: Offset	21841	5551	A	2	INTEGER_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02800</a>	AINx: Input signal	21775	550F	A	2	INTEGER_16	1	<input checked="" type="checkbox"/>		
<a href="#">C02801</a>	AOUTx: Output signal	21774	550E	A	2	INTEGER_16	1	<input checked="" type="checkbox"/>		
<a href="#">C02802</a>	Status word dig. outputs	21773	550D	E	1	BITFIELD_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02803</a>	Status word dig. inputs	21772	550C	E	1	BITFIELD_32	1	<input checked="" type="checkbox"/>		
<a href="#">C02810</a>	Delay time for TPx	21765	5505	A	10	UNSIGNED_32	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02830</a>	Dlx delay time	21745	54F1	A	8	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02853</a>	Vp Lss sat. characteristic	21722	54DA	A	17	UNSIGNED_16	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02855</a>	Imax Lss saturat. characteristic	21720	54D8	E	1	UNSIGNED_32	10	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02859</a>	Lss sat. characteristic	21716	54D4	E	1	UNSIGNED_8	1	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>
<a href="#">C02860</a>	Rr adjustment	21715	54D3	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	
<a href="#">C02861</a>	Lh adaptation	21714	54D2	E	1	UNSIGNED_32	100	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	

### 17 Index

#### A

Absolute value encoder  
     Communication error [472](#)  
 Acc./dec. time - grinding (C2597) [627](#)  
 Acceleration has been limited [535](#)  
 Acceleration unit (C2538) [618](#)  
 Action types [379](#)  
 Active application (C7) [547](#)  
 Active function state (C2530) [617](#)  
 Actual position (C2575) [624](#)  
 Actual speed (C2574) [624](#)  
 Actual speed (C693) [597](#)  
 Actual speed value (C51) [548](#)  
 Actual speed value outside the monitoring window  
 C00576 [471](#)  
 Actual torque (C698) [598](#)  
 Additional speed source (C2681) [636](#)  
 AINx  
     Dead band (C2732) [643](#)  
     Gain (C2730) [643](#)  
     Input signal (C2800) [644](#)  
     Offset (C2731) [643](#)  
 Analog input 1  
     Master current [477](#)  
 Analog inputs [117](#)  
 Analog outputs [120](#)  
 AOUTx  
     Gain (C2733) [643](#)  
     Offset (C2734) [643](#)  
     Output signal (C2801) [644](#)  
 Application  
     Compile date (C213) [565](#)  
     ID number (C218) [565](#)  
     Type code (C212) [565](#)  
     Version (C211) [565](#)  
 Application has started [460](#)  
 Application has stopped [460](#), [461](#)  
 Application notes [18](#)  
 Application selection (C5) [547](#)  
 Application unit [39](#)  
 Automatic chopper frequency reduction [80](#)  
 Automatic restart after mains ON (C142) [556](#)

#### B

Basic drive functions [140](#)  
 Basic functions [140](#)  
 Blocking function in MEC task [500](#)  
 Brake activation threshold (C2581) [625](#)  
 Brake chopper  
     Ixt overload [472](#)  
     Overcurrent [473](#)  
 Brake closing time (C2589) [626](#)

Brake control

    Dig. signals (C2609) [628](#)  
 Brake control polarity (C2585) [625](#)  
 Brake opening time (C2590) [626](#)  
 Brake resistance value (C129) [556](#)  
 Brake resistor  
     Ixt overload [472](#)  
 Brake resistor - thermal capacity (C131) [556](#)  
 Brake resp. to pulse inhibit (C2582) [625](#)  
 Breakpoint has been reached [460](#)  
 BRK\_dnState (C2607) [628](#)  
 BRK\_dnTorqueAdd\_n (C2608) [628](#)

#### C

C100 [553](#)  
 C105 [554](#)  
 C106 [554](#)  
 C107 [554](#)  
 C11 [547](#)  
 C1120 [606](#)  
 C1121 [607](#)  
 C1122 [607](#)  
 C1123 [607](#)  
 C1124 [608](#)  
 C114 [554](#)  
 C118 [554](#)  
 C1190 [608](#)  
 C1191 [609](#)  
 C1192 [609](#)  
 C1193 [609](#)  
 C1194 [609](#)  
 C1195 [609](#)  
 C1196 [610](#)  
 C120 [555](#)  
 C1203 [610](#)  
 C1204 [610](#)  
 C1205 [610](#)  
 C1206 [610](#)  
 C1208 [610](#)  
 C1209 [611](#)  
 C121 [555](#)  
 C1210 [611](#)  
 C1211 [611](#)  
 C1212 [611](#)  
 C1213 [611](#)  
 C1214 [611](#)  
 C122 [555](#)  
 C123 [555](#)  
 C126 [555](#)  
 C127 [555](#)  
 C128 [556](#)

C129	<a href="#">556</a>	C2113	<a href="#">614</a>
C130	<a href="#">556</a>	C212	<a href="#">565</a>
C131	<a href="#">556</a>	C2121	<a href="#">614</a>
C132	<a href="#">556</a>	C2122	<a href="#">614</a>
C142	<a href="#">556</a>	C2123	<a href="#">614</a>
C150	<a href="#">557</a>	C213	<a href="#">565</a>
C1501	<a href="#">611</a>	C214	<a href="#">565</a>
C1502	<a href="#">612</a>	C217	<a href="#">565</a>
C1510	<a href="#">612</a>	C218	<a href="#">565</a>
C1511	<a href="#">612</a>	C22	<a href="#">548</a>
C155	<a href="#">557</a>	C225	<a href="#">565</a>
C156	<a href="#">558</a>	C2520	<a href="#">614</a>
C158	<a href="#">558</a>	C2521	<a href="#">615</a>
C159	<a href="#">559</a>	C2522	<a href="#">615</a>
C166	<a href="#">559</a>	C2523	<a href="#">615</a>
C167	<a href="#">559</a>	C2524	<a href="#">615</a>
C168	<a href="#">559</a>	C2525	<a href="#">615</a>
C169	<a href="#">559</a>	C2526	<a href="#">615</a>
C171	<a href="#">559</a>	C2527	<a href="#">616</a>
C173	<a href="#">560</a>	C2528	<a href="#">616</a>
C174	<a href="#">560</a>	C2529	<a href="#">616</a>
C175	<a href="#">560</a>	C2530	<a href="#">617</a>
C176	<a href="#">560</a>	C2531	<a href="#">617</a>
C177	<a href="#">561</a>	C2532	<a href="#">617</a>
C178	<a href="#">561</a>	C2533	<a href="#">618</a>
C179	<a href="#">561</a>	C2534	<a href="#">618</a>
C18	<a href="#">547</a>	C2535	<a href="#">618</a>
C180	<a href="#">561</a>	C2536	<a href="#">618</a>
C181	<a href="#">561</a>	C2537	<a href="#">618</a>
C183	<a href="#">561</a>	C2538	<a href="#">618</a>
C185	<a href="#">562</a>	C2539	<a href="#">618</a>
C186	<a href="#">562</a>	C254	<a href="#">565</a>
C187	<a href="#">562</a>	C2540	<a href="#">618</a>
C188	<a href="#">562</a>	C2541	<a href="#">619</a>
C19	<a href="#">547</a>	C2542	<a href="#">619</a>
C1902	<a href="#">613</a>	C2543	<a href="#">619</a>
C1903	<a href="#">613</a>	C2547	<a href="#">619</a>
C1905	<a href="#">613</a>	C2548	<a href="#">619</a>
C199	<a href="#">562</a>	C2549	<a href="#">620</a>
C2	<a href="#">544</a>	C2550	<a href="#">620</a>
C200	<a href="#">562</a>	C2552	<a href="#">620</a>
C201	<a href="#">562</a>	C2553	<a href="#">621</a>
C203	<a href="#">563</a>	C2554	<a href="#">621</a>
C204	<a href="#">563</a>	C2555	<a href="#">621</a>
C205	<a href="#">563</a>	C2556	<a href="#">621</a>
C206	<a href="#">564</a>	C2557	<a href="#">621</a>
C208	<a href="#">564</a>	C2558	<a href="#">621</a>
C209	<a href="#">564</a>	C2559	<a href="#">622</a>
C210	<a href="#">564</a>	C2560	<a href="#">622</a>
C2104	<a href="#">613</a>	C2567	<a href="#">622</a>
C2108	<a href="#">613</a>	C2568	<a href="#">622</a>
C2109	<a href="#">614</a>	C2569	<a href="#">623</a>
C211	<a href="#">565</a>	C2570	<a href="#">623</a>

C2572	<a href="#">623</a>	C2652	<a href="#">633</a>
C2573	<a href="#">623</a>	C2653	<a href="#">633</a>
C2574	<a href="#">624</a>	C2656	<a href="#">633</a>
C2575	<a href="#">624</a>	C2657	<a href="#">634</a>
C2576	<a href="#">624</a>	C2658	<a href="#">634</a>
C2577	<a href="#">624</a>	C2659	<a href="#">634</a>
C2578	<a href="#">624</a>	C2674	<a href="#">634</a>
C2579	<a href="#">624</a>	C2675	<a href="#">634</a>
C2580	<a href="#">625</a>	C2676	<a href="#">635</a>
C2581	<a href="#">625</a>	C2677	<a href="#">635</a>
C2582	<a href="#">625</a>	C2678	<a href="#">635</a>
C2583	<a href="#">625</a>	C2679	<a href="#">635</a>
C2585	<a href="#">625</a>	C2680	<a href="#">636</a>
C2586	<a href="#">626</a>	C2681	<a href="#">636</a>
C2587	<a href="#">626</a>	C2685	<a href="#">636</a>
C2588	<a href="#">626</a>	C2686	<a href="#">636</a>
C2589	<a href="#">626</a>	C2687	<a href="#">636</a>
C2590	<a href="#">626</a>	C2688	<a href="#">636</a>
C2591	<a href="#">626</a>	C2689	<a href="#">637</a>
C2593	<a href="#">627</a>	C2692	<a href="#">637</a>
C2594	<a href="#">627</a>	C2693	<a href="#">637</a>
C2595	<a href="#">627</a>	C2694	<a href="#">637</a>
C2596	<a href="#">627</a>	C2695	<a href="#">637</a>
C2597	<a href="#">627</a>	C2698	<a href="#">638</a>
C2598	<a href="#">627</a>	C2699	<a href="#">638</a>
C2599	<a href="#">628</a>	C270	<a href="#">566</a>
C2607	<a href="#">628</a>	C2700	<a href="#">638</a>
C2608	<a href="#">628</a>	C2701	<a href="#">638</a>
C2609	<a href="#">628</a>	C2702	<a href="#">638</a>
C2610	<a href="#">628</a>	C2703	<a href="#">639</a>
C2611	<a href="#">629</a>	C2704	<a href="#">639</a>
C2612	<a href="#">629</a>	C2705	<a href="#">639</a>
C2616	<a href="#">629</a>	C2706	<a href="#">639</a>
C2617	<a href="#">629</a>	C2707	<a href="#">639</a>
C2619	<a href="#">629</a>	C2708	<a href="#">640</a>
C2620	<a href="#">630</a>	C2709	<a href="#">640</a>
C2621	<a href="#">630</a>	C271	<a href="#">566</a>
C2622	<a href="#">630</a>	C2710	<a href="#">640</a>
C2623	<a href="#">630</a>	C2711	<a href="#">640</a>
C2624	<a href="#">630</a>	C2712	<a href="#">641</a>
C2638	<a href="#">630</a>	C2713	<a href="#">641</a>
C2639	<a href="#">631</a>	C2714	<a href="#">641</a>
C2640	<a href="#">631</a>	C2715	<a href="#">641</a>
C2642	<a href="#">631</a>	C2716	<a href="#">642</a>
C2643	<a href="#">632</a>	C2717	<a href="#">642</a>
C2644	<a href="#">632</a>	C2718	<a href="#">642</a>
C2645	<a href="#">632</a>	C2719	<a href="#">642</a>
C2646	<a href="#">632</a>	C272	<a href="#">566</a>
C2647	<a href="#">632</a>	C273	<a href="#">566</a>
C2648	<a href="#">632</a>	C2730	<a href="#">643</a>
C2649	<a href="#">633</a>	C2731	<a href="#">643</a>
C2650	<a href="#">633</a>	C2732	<a href="#">643</a>
C2651	<a href="#">633</a>	C2733	<a href="#">643</a>

C2734	<a href="#">643</a>	C347	<a href="#">572</a>
C274	<a href="#">566</a>	C348	<a href="#">572</a>
C275	<a href="#">567</a>	C349	<a href="#">572</a>
C276	<a href="#">567</a>	C350	<a href="#">573</a>
C280	<a href="#">567</a>	C351	<a href="#">573</a>
C2800	<a href="#">644</a>	C352	<a href="#">573</a>
C2801	<a href="#">644</a>	C356	<a href="#">574</a>
C2802	<a href="#">644</a>	C357	<a href="#">574</a>
C2803	<a href="#">644</a>	C359	<a href="#">574</a>
C2810	<a href="#">645</a>	C360	<a href="#">575</a>
C2830	<a href="#">645</a>	C361	<a href="#">575</a>
C2850	<a href="#">645</a>	C367	<a href="#">575</a>
C2851	<a href="#">645</a>	C368	<a href="#">576</a>
C2852	<a href="#">646</a>	C369	<a href="#">576</a>
C2853	<a href="#">646</a>	C372	<a href="#">576</a>
C2854	<a href="#">646</a>	C373	<a href="#">577</a>
C2855	<a href="#">646</a>	C374	<a href="#">577</a>
C2856	<a href="#">646</a>	C375	<a href="#">578</a>
C2857	<a href="#">647</a>	C376	<a href="#">578</a>
C2858	<a href="#">647</a>	C377	<a href="#">578</a>
C2859	<a href="#">647</a>	C378	<a href="#">579</a>
C2860	<a href="#">647</a>	C379	<a href="#">579</a>
C2861	<a href="#">647</a>	C381	<a href="#">579</a>
C2996	<a href="#">647</a>	C382	<a href="#">579</a>
C2997	<a href="#">647</a>	C383	<a href="#">579</a>
C2998	<a href="#">647</a>	C385	<a href="#">580</a>
C2999	<a href="#">647</a>	C386	<a href="#">580</a>
C3	<a href="#">546</a>	C387	<a href="#">580</a>
C308	<a href="#">567</a>	C388	<a href="#">581</a>
C309	<a href="#">567</a>	C390	<a href="#">581</a>
C310	<a href="#">567</a>	C391	<a href="#">581</a>
C311	<a href="#">567</a>	C392	<a href="#">581</a>
C312	<a href="#">568</a>	C393	<a href="#">582</a>
C313	<a href="#">568</a>	C395	<a href="#">582</a>
C314	<a href="#">568</a>	C396	<a href="#">582</a>
C320	<a href="#">569</a>	C397	<a href="#">582</a>
C321	<a href="#">569</a>	C398	<a href="#">582</a>
C322	<a href="#">570</a>	C399	<a href="#">582</a>
C323	<a href="#">570</a>	C4	<a href="#">546</a>
C324	<a href="#">570</a>	C416	<a href="#">583</a>
C325	<a href="#">570</a>	C420	<a href="#">583</a>
C326	<a href="#">570</a>	C421	<a href="#">583</a>
C327	<a href="#">571</a>	C422	<a href="#">583</a>
C328	<a href="#">571</a>	C427	<a href="#">583</a>
C329	<a href="#">571</a>	C443	<a href="#">584</a>
C330	<a href="#">571</a>	C444	<a href="#">584</a>
C335	<a href="#">571</a>	C465	<a href="#">585</a>
C336	<a href="#">571</a>	C466	<a href="#">585</a>
C337	<a href="#">571</a>	C467	<a href="#">585</a>
C338	<a href="#">571</a>	C468	<a href="#">585</a>
C34	<a href="#">548</a>	C469	<a href="#">585</a>
C345	<a href="#">571</a>	C490	<a href="#">585</a>
C346	<a href="#">572</a>	C494	<a href="#">586</a>

C495	<a href="#">586</a>	C614	<a href="#">595</a>
C497	<a href="#">586</a>	C615	<a href="#">595</a>
C5	<a href="#">547</a>	C618	<a href="#">596</a>
C50	<a href="#">548</a>	C619	<a href="#">596</a>
C51	<a href="#">548</a>	C62	<a href="#">550</a>
C512	<a href="#">586</a>	C620	<a href="#">596</a>
C513	<a href="#">586</a>	C625	<a href="#">596</a>
C514	<a href="#">586</a>	C63	<a href="#">550</a>
C515	<a href="#">586</a>	C635	<a href="#">596</a>
C516	<a href="#">586</a>	C636	<a href="#">597</a>
C52	<a href="#">548</a>	C637	<a href="#">597</a>
C53	<a href="#">548</a>	C64	<a href="#">550</a>
C54	<a href="#">548</a>	C65	<a href="#">550</a>
C55	<a href="#">549</a>	C66	<a href="#">550</a>
C56	<a href="#">549</a>	C68	<a href="#">550</a>
C57	<a href="#">549</a>	C69	<a href="#">551</a>
C573	<a href="#">587</a>	C691	<a href="#">597</a>
C574	<a href="#">587</a>	C692	<a href="#">597</a>
C576	<a href="#">587</a>	C693	<a href="#">597</a>
C577	<a href="#">587</a>	C694	<a href="#">597</a>
C578	<a href="#">587</a>	C695	<a href="#">598</a>
C579	<a href="#">588</a>	C696	<a href="#">598</a>
C58	<a href="#">549</a>	C697	<a href="#">598</a>
C580	<a href="#">588</a>	C698	<a href="#">598</a>
C581	<a href="#">588</a>	C7	<a href="#">547</a>
C582	<a href="#">589</a>	C70	<a href="#">551</a>
C583	<a href="#">589</a>	C71	<a href="#">551</a>
C584	<a href="#">589</a>	C72	<a href="#">551</a>
C585	<a href="#">589</a>	C730	<a href="#">598</a>
C586	<a href="#">590</a>	C731	<a href="#">598</a>
C587	<a href="#">590</a>	C732	<a href="#">598</a>
C588	<a href="#">590</a>	C733	<a href="#">598</a>
C589	<a href="#">590</a>	C734	<a href="#">598</a>
C59	<a href="#">549</a>	C735	<a href="#">598</a>
C591	<a href="#">591</a>	C736	<a href="#">599</a>
C594	<a href="#">591</a>	C737	<a href="#">599</a>
C595	<a href="#">591</a>	C738	<a href="#">599</a>
C596	<a href="#">591</a>	C739	<a href="#">599</a>
C597	<a href="#">592</a>	C74	<a href="#">551</a>
C598	<a href="#">592</a>	C75	<a href="#">551</a>
C599	<a href="#">592</a>	C76	<a href="#">551</a>
C6	<a href="#">547</a>	C77	<a href="#">551</a>
C60	<a href="#">549</a>	C770	<a href="#">599</a>
C600	<a href="#">592</a>	C771	<a href="#">599</a>
C601	<a href="#">593</a>	C772	<a href="#">599</a>
C604	<a href="#">593</a>	C773	<a href="#">600</a>
C606	<a href="#">593</a>	C774	<a href="#">600</a>
C607	<a href="#">593</a>	C775	<a href="#">600</a>
C61	<a href="#">550</a>	C776	<a href="#">600</a>
C610	<a href="#">594</a>	C777	<a href="#">600</a>
C611	<a href="#">594</a>	C778	<a href="#">600</a>
C612	<a href="#">594</a>	C779	<a href="#">601</a>
C613	<a href="#">595</a>	C78	<a href="#">552</a>

- C780 [601](#)
- C781 [601](#)
- C782 [601](#)
- C783 [601](#)
- C784 [601](#)
- C786 [602](#)
- C787 [602](#)
- C788 [602](#)
- C789 [602](#)
- C79 [552](#)
- C790 [602](#)
- C791 [602](#)
- C792 [603](#)
- C80 [552](#)
- C800 [603](#)
- C802 [603](#)
- C803 [603](#)
- C804 [603](#)
- C805 [603](#)
- C806 [604](#)
- C807 [604](#)
- C808 [604](#)
- C809 [604](#)
- C81 [552](#)
- C810 [604](#)
- C811 [604](#)
- C812 [605](#)
- C813 [605](#)
- C814 [605](#)
- C815 [605](#)
- C816 [605](#)
- C817 [605](#)
- C82 [552](#)
- C83 [552](#)
- C84 [552](#)
- C85 [552](#)
- C854 [606](#)
- C87 [553](#)
- C878 [606](#)
- C88 [553](#)
- C89 [553](#)
- C90 [553](#)
- C909 [606](#)
- C91 [553](#)
- C92 [553](#)
- C99 [553](#)
- CAN - DIP switch setting (C349) [572](#)
- CAN baud rate (C351) [573](#)
- CAN behaviour in the case of fault (C625) [596](#)
- CAN bus load (C361) [575](#)
- CAN delay boot-up - operational (C378) [579](#)
- CAN emergency delay time (C392) [581](#)
- CAN emergency object (C391) [581](#)
- CAN error (C345) [571](#)
- CAN error register (DS301V402) (C390) [581](#)
- CAN guard time (C382) [579](#)
- CAN Heartbeat activity (C346) [572](#)
- CAN heartbeat consumer time (C385) [580](#)
- CAN heartbeat producer time (C381) [579](#)
- CAN Heartbeat status (C347) [572](#)
- CAN life time factor (C383) [579](#)
- CAN module (MX11)
  - Bus off [501](#)
  - Faulty emergency configuration [508](#)
  - Faulty NMT master configuration [514](#)
  - Faulty NMT slave configuration [508](#)
  - Heartbeat error index 1 [502](#)
  - Heartbeat error index 10 [504](#)
  - Heartbeat error index 11 [504](#)
  - Heartbeat error index 12 [504](#)
  - Heartbeat error index 13 [504](#)
  - Heartbeat error index 14 [504](#)
  - Heartbeat error index 15 [504](#)
  - Heartbeat error index 16 [505](#)
  - Heartbeat error index 17 [505](#)
  - Heartbeat error index 18 [505](#)
  - Heartbeat error index 19 [505](#)
  - Heartbeat error index 2 [502](#)
  - Heartbeat error index 20 [505](#)
  - Heartbeat error index 21 [505](#)
  - Heartbeat error index 22 [506](#)
  - Heartbeat error index 23 [506](#)
  - Heartbeat error index 24 [506](#)
  - Heartbeat error index 25 [506](#)
  - Heartbeat error index 26 [506](#)
  - Heartbeat error index 27 [506](#)
  - Heartbeat error index 28 [507](#)
  - Heartbeat error index 29 [507](#)
  - Heartbeat error index 3 [502](#)
  - Heartbeat error index 30 [507](#)
  - Heartbeat error index 31 [507](#)
  - Heartbeat error index 32 [507](#)
  - Heartbeat error index 4 [503](#)
  - Heartbeat error index 5 [503](#)
  - Heartbeat error index 6 [503](#)
  - Heartbeat error index 7 [503](#)
  - Heartbeat error index 8 [503](#)
  - Heartbeat error index 9 [503](#)
  - Invalid basic configuration [502](#)
  - Invalid node address 0 [502](#)
  - Life guarding error [507](#)
  - Node guarding error 1 [508](#)
  - Node guarding error 10 [510](#)
  - Node guarding error 11 [510](#)
  - Node guarding error 12 [510](#)
  - Node guarding error 13 [510](#)
  - Node guarding error 14 [510](#)
  - Node guarding error 15 [511](#)
  - Node guarding error 16 [511](#)
  - Node guarding error 17 [511](#)

- Node guarding error 18 [511](#)
- Node guarding error 19 [511](#)
- Node guarding error 2 [508](#)
- Node guarding error 20 [511](#)
- Node guarding error 21 [512](#)
- Node guarding error 22 [512](#)
- Node guarding error 23 [512](#)
- Node guarding error 24 [512](#)
- Node guarding error 25 [512](#)
- Node guarding error 26 [512](#)
- Node guarding error 27 [513](#)
- Node guarding error 28 [513](#)
- Node guarding error 29 [513](#)
- Node guarding error 3 [509](#)
- Node guarding error 30 [513](#)
- Node guarding error 31 [513](#)
- Node guarding error 32 [513](#)
- Node guarding error 4 [509](#)
- Node guarding error 5 [509](#)
- Node guarding error 6 [509](#)
- Node guarding error 7 [509](#)
- Node guarding error 8 [509](#)
- Node guarding error 9 [510](#)
- CAN module (MXI1) PDO manager
  - Faulty configuration [516](#)
- CAN module (MXI1) RPDO1
  - Telegram not received or faulty [514](#)
- CAN module (MXI1) RPDO2
  - Telegram not received or faulty [514](#)
- CAN module (MXI1) RPDO3
  - Telegram not received or faulty [514](#)
- CAN module (MXI1) RPDO4
  - Telegram not received or faulty [515](#)
- CAN module (MXI1) RPDO5
  - Telegram not received or faulty [515](#)
- CAN module (MXI1) RPDO6
  - Telegram not received or faulty [515](#)
- CAN module (MXI1) RPDO7
  - Telegram not received or faulty [515](#)
- CAN module (MXI1) RPDO8
  - Telegram not received or faulty [515](#)
- CAN module (MXI1) SDO client
  - Faulty configuration [516](#)
- CAN module (MXI1) SDO server
  - Faulty configuration [516](#)
- CAN module (MXI2)
  - Bus off [517](#)
  - Faulty emergency configuration [524](#)
  - Faulty NMT master configuration [530](#)
  - Faulty NMT slave configuration [524](#)
  - Heartbeat error index 1 [518](#)
  - Heartbeat error index 10 [520](#)
  - Heartbeat error index 11 [520](#)
  - Heartbeat error index 12 [520](#)
  - Heartbeat error index 13 [520](#)
  - Heartbeat error index 14 [520](#)
  - Heartbeat error index 15 [520](#)
  - Heartbeat error index 16 [521](#)
  - Heartbeat error index 17 [521](#)
  - Heartbeat error index 18 [521](#)
  - Heartbeat error index 19 [521](#)
  - Heartbeat error index 2 [518](#)
  - Heartbeat error index 20 [521](#)
  - Heartbeat error index 21 [521](#)
  - Heartbeat error index 22 [522](#)
  - Heartbeat error index 23 [522](#)
  - Heartbeat error index 24 [522](#)
  - Heartbeat error index 25 [522](#)
  - Heartbeat error index 26 [522](#)
  - Heartbeat error index 27 [522](#)
  - Heartbeat error index 28 [523](#)
  - Heartbeat error index 29 [523](#)
  - Heartbeat error index 3 [518](#)
  - Heartbeat error index 30 [523](#)
  - Heartbeat error index 31 [523](#)
  - Heartbeat error index 32 [523](#)
  - Heartbeat error index 4 [519](#)
  - Heartbeat error index 5 [519](#)
  - Heartbeat error index 6 [519](#)
  - Heartbeat error index 7 [519](#)
  - Heartbeat error index 8 [519](#)
  - Heartbeat error index 9 [519](#)
  - Invalid basic configuration [518](#)
  - Invalid node address 0 [518](#)
  - Life guarding error [523](#)
  - Node guarding error 1 [524](#)
  - Node guarding error 10 [526](#)
  - Node guarding error 11 [526](#)
  - Node guarding error 12 [526](#)
  - Node guarding error 13 [526](#)
  - Node guarding error 14 [526](#)
  - Node guarding error 15 [527](#)
  - Node guarding error 16 [527](#)
  - Node guarding error 17 [527](#)
  - Node guarding error 18 [527](#)
  - Node guarding error 19 [527](#)
  - Node guarding error 2 [524](#)
  - Node guarding error 20 [527](#)
  - Node guarding error 21 [528](#)
  - Node guarding error 22 [528](#)
  - Node guarding error 23 [528](#)
  - Node guarding error 24 [528](#)
  - Node guarding error 25 [528](#)
  - Node guarding error 26 [528](#)
  - Node guarding error 27 [529](#)
  - Node guarding error 28 [529](#)
  - Node guarding error 29 [529](#)
  - Node guarding error 3 [525](#)
  - Node guarding error 30 [529](#)
  - Node guarding error 31 [529](#)
  - Node guarding error 32 [529](#)
  - Node guarding error 4 [525](#)
  - Node guarding error 5 [525](#)
  - Node guarding error 6 [525](#)
  - Node guarding error 7 [525](#)



- Node guarding error 8 [525](#)
- Node guarding error 9 [526](#)
- CAN module (MXI2) PDO manager
  - Faulty configuration [532](#)
- CAN module (MXI2) RPDO1
  - Telegram not received or faulty [530](#)
- CAN module (MXI2) RPDO2
  - Telegram not received or faulty [530](#)
- CAN module (MXI2) RPDO3
  - Telegram not received or faulty [530](#)
- CAN module (MXI2) RPDO4
  - Telegram not received or faulty [531](#)
- CAN module (MXI2) RPDO5
  - Telegram not received or faulty [531](#)
- CAN module (MXI2) RPDO6
  - Telegram not received or faulty [531](#)
- CAN module (MXI2) RPDO7
  - Telegram not received or faulty [531](#)
- CAN module (MXI2) RPDO8
  - Telegram not received or faulty [531](#)
- CAN module (MXI2) SDO client
  - Faulty configuration [532](#)
- CAN module (MXI2) SDO server
  - Faulty configuration [532](#)
- CAN node address (C350) [573](#)
- CAN node guarding (C386) [580](#)
- CAN node guarding activity (C387) [580](#)
- CAN node guarding status (C388) [581](#)
- CAN on board
  - Bus off [477](#)
  - Faulty emergency configuration [484](#)
  - Faulty NMT master configuration [489](#)
  - Faulty NMT slave configuration [484](#)
  - Heartbeat error index 1 [478](#)
  - Heartbeat error index 10 [480](#)
  - Heartbeat error index 11 [480](#)
  - Heartbeat error index 12 [480](#)
  - Heartbeat error index 13 [480](#)
  - Heartbeat error index 14 [480](#)
  - Heartbeat error index 15 [480](#)
  - Heartbeat error index 16 [481](#)
  - Heartbeat error index 17 [481](#)
  - Heartbeat error index 18 [481](#)
  - Heartbeat error index 19 [481](#)
  - Heartbeat error index 2 [478](#)
  - Heartbeat error index 20 [481](#)
  - Heartbeat error index 21 [481](#)
  - Heartbeat error index 22 [482](#)
  - Heartbeat error index 23 [482](#)
  - Heartbeat error index 24 [482](#)
  - Heartbeat error index 25 [482](#)
  - Heartbeat error index 26 [482](#)
  - Heartbeat error index 27 [482](#)
  - Heartbeat error index 28 [483](#)
  - Heartbeat error index 29 [483](#)
  - Heartbeat error index 3 [478](#)
  - Heartbeat error index 30 [483](#)
- Heartbeat error index 31 [483](#)
- Heartbeat error index 32 [483](#)
- Heartbeat error index 4 [479](#)
- Heartbeat error index 5 [479](#)
- Heartbeat error index 6 [479](#)
- Heartbeat error index 7 [479](#)
- Heartbeat error index 8 [479](#)
- Heartbeat error index 9 [479](#)
- Invalid basic configuration [478](#)
- Invalid node address 0 [478](#)
- Life guarding error [483](#)
- Node guarding error 1 [484](#)
- Node guarding error 10 [486](#)
- Node guarding error 11 [486](#)
- Node guarding error 12 [486](#)
- Node guarding error 13 [486](#)
- Node guarding error 14 [486](#)
- Node guarding error 15 [486](#)
- Node guarding error 16 [487](#)
- Node guarding error 17 [487](#)
- Node guarding error 18 [487](#)
- Node guarding error 19 [487](#)
- Node guarding error 2 [484](#)
- Node guarding error 20 [487](#)
- Node guarding error 21 [487](#)
- Node guarding error 22 [488](#)
- Node guarding error 23 [488](#)
- Node guarding error 24 [488](#)
- Node guarding error 25 [488](#)
- Node guarding error 26 [488](#)
- Node guarding error 27 [488](#)
- Node guarding error 28 [489](#)
- Node guarding error 29 [489](#)
- Node guarding error 3 [484](#)
- Node guarding error 30 [489](#)
- Node guarding error 31 [489](#)
- Node guarding error 32 [489](#)
- Node guarding error 4 [485](#)
- Node guarding error 5 [485](#)
- Node guarding error 6 [485](#)
- Node guarding error 7 [485](#)
- Node guarding error 8 [485](#)
- Node guarding error 9 [485](#)
- CAN on board PDO manager
  - Faulty configuration [490](#)
- CAN on board RPDO1
  - Telegram not received or faulty [490](#)
- CAN on board RPDO2
  - Telegram not received or faulty [490](#)
- CAN on board RPDO3
  - Telegram not received or faulty [490](#)
- CAN on board RPDO4
  - Telegram not received or faulty [490](#)
- CAN on board SDO client
  - Faulty configuration [491](#)
- CAN on board SDO server
  - Faulty configuration [491](#)

- CAN on-board [134](#)
  - CAN result - bus scan (C393) [582](#)
  - CAN RPDOx identifier (C321) [569](#)
  - CAN RPDOx monitoring time (C357) [574](#)
  - CAN RPDOx Rx mode (C323) [570](#)
  - CAN SDO client node address (C374) [577](#)
  - CAN SDO client Rx identifier (C375) [578](#)
  - CAN SDO client Tx identifier (C376) [578](#)
  - CAN SDO server node address (C377) [578](#)
  - CAN SDO server Rx identifier (C372) [576](#)
  - CAN SDO server Tx identifier (C373) [577](#)
  - CAN slave/master (C352) [573](#)
  - CAN status (C359) [574](#)
  - CAN status DIP switch (C348) [572](#)
  - CAN sync transmission cycle time (C369) [576](#)
  - CAN sync-Rx identifier (C367) [575](#)
  - CAN sync-Tx identifier (C368) [576](#)
  - CAN telegram and error counter (C360) [575](#)
  - CAN TPDO1 mask byte x (C311) [567](#)
  - CAN TPDO2 mask byte x (C312) [568](#)
  - CAN TPDO3 mask byte x (C313) [568](#)
  - CAN TPDO4 mask byte x (C314) [568](#)
  - CAN TPDOx cycle time (C356) [574](#)
  - CAN TPDOx delay time (C324) [570](#)
  - CAN TPDOx identifier (C320) [569](#)
  - CAN TPDOx Tx mode (C322) [570](#)
  - Capacitor temperature (C68) [550](#)
  - Check configuration (C225) [565](#)
  - Code number has been assigned twice [497](#)
  - Combination Memory module/device not possible [455](#)
  - Combination MXI1/MXI2 not possible [454](#)
  - Combination of module in MXI1/device not possible [455](#)
  - Combination of module in MXI2/device not possible [455](#)
  - Communication error between device and device module [477](#)
  - Communication task
    - Standstill > 3 s [499](#)
  - Config. analog input 1 (C34) [548](#)
  - Connection table in use [495](#)
  - Control card
    - Supply voltage (24 V DC) too low [461](#)
  - Control card is defective [449](#), [451](#)
  - Control card is defective (UB18 neg.) [468](#)
  - Control card is defective (UB24) [467](#)
  - Control card is defective (UB8) [467](#)
  - Control card is defective (VCC15 neg.) [467](#)
  - Control card is defective (VCC15) [467](#)
  - Control card is defective (VCC5) [468](#)
  - Control card is not compatible [452](#)
  - Control mode (C2567) [622](#)
  - Controller
    - Pulse inhibit is active [462](#)
  - Controller command status (C3) [546](#)
  - Controller commands (C2) [544](#)
  - Controller configuration (C2570) [623](#)
  - Controller in STO state [462](#)
  - Controller inhibit by (source) (C158) [558](#)
  - Controller initialised [462](#)
  - Controller is enabled [462](#)
  - Controller load (lxt) (C64) [550](#)
  - Conventions used [16](#)
  - Copyright [2](#)
  - Copyright information [2](#)
  - Correction of the leakage inductance [82](#)
  - Counter
    - Brake chopper overload (C1203) [610](#)
    - DC bus overvoltage (C1205) [610](#)
    - Heatsink overtemp. (C1208) [610](#)
    - Housing overtemp. (C1209) [611](#)
    - lxt overload (C1204) [610](#)
    - Mains switching (C1206) [610](#)
    - Power section overload (C1212) [611](#)
  - CPU
    - Overtemperature [465](#)
    - Temperature > C00126 [464](#)
    - Temperature sensor defective [466](#)
  - CPU temperature (C69) [551](#)
  - Current controller feedforward control (C74) [551](#)
  - Current controller gain (C75) [551](#)
  - Current controller reset time (C76) [551](#)
  - Current position (C2656) [633](#)
  - Cycle (C2536) [618](#)
  - Cyclic task
    - Standstill > 60 s [499](#)
- ## D
- Data type [537](#)
  - DC bus overvoltage [470](#)
  - DC bus undervoltage [470](#)
  - DC bus voltage (C53) [548](#)
  - DC-bus capacitor
    - Overtemperature [464](#)
    - Temperature > CXXXXX [464](#)
    - Temperature sensor defective [465](#)
  - Decel. time - stop function (C2610) [628](#)
  - Decel. time lim. speed (C2712) [641](#)
  - Deceleration has been limited [535](#)
  - Delay lim. speed (C2710) [640](#)
  - Delay time for TPx (C2810) [645](#)
  - Depth - current setpoint filter (C272) [566](#)
  - Device name (C199) [562](#)
  - Device state (C183) [561](#)
  - Device util. warning threshold (C123) [555](#)
  - Device utilisation lxt > 100 % [466](#)
  - Device utilisation lxt > C00123 [466](#)
  - DeviceCFG.dat file is faulty [491](#)
  - DeviceCFG.dat file is invalid [492](#)
  - DeviceCFG.dat file is missing [492](#)
  - DFIN (MXI1)

- A-/A track error [500](#)
- B-/B track error [500](#)
- Enable/lamp control signal error [501](#)
- Supply cannot be corrected anymore [501](#)
- Z-/Z track error [501](#)
- DFIN (MXI2)
  - A-/A track error [516](#)
  - B-/B track error [516](#)
  - Enable/lamp control signal error [517](#)
  - Supply cannot be corrected anymore [517](#)
  - Z-/Z track error [517](#)
- DFOUT (MXI1)
  - Maximum frequency reached [501](#)
- DFOUT (MXI2)
  - Maximum frequency reached [517](#)
- DI\_bErrors (C2548) [619](#)
- DI\_dnState (C2547) [619](#)
- Diagnostics X6
  - Change baud rate (C1903) [613](#)
  - curr. baud rate (C1905) [613](#)
  - max. baud rate (C1902) [613](#)
- Digital inputs [123](#)
- Digital outputs [125](#)
- Division by zero [460](#)
- Dlx delay time (C2830) [645](#)
- Dlx status (C443) [584](#)
- Dlx terminal polarity (C114) [554](#)
- DOx status (C444) [584](#)
- DOx terminal polarity (C118) [554](#)
- Drive interface [34](#)
  - Signals (C2549) [620](#)
- DRIVE-ERROR LED [34](#)
- DRIVE-READY LED [34](#)
- E**
- Earth fault detected [471](#)
- Elapsed-time meter (C178) [561](#)
- Electrolytic capacitor av. temp. (C1210) [611](#)
- Electronic nameplate
  - Checksum error [454](#)
  - Communication error [454](#)
  - Data incompatible [468](#)
  - Data loaded [475](#)
  - Data out of parameter limits [476](#)
  - Not found [475](#)
  - Unknown encoder protocol [475](#)
  - Unknown encoder signal [476](#)
- E-mail to Lenze [679](#)
- Encoder
  - Open circuit [472](#)
- Encoder - PPR (C420) [583](#)
- Encoder - type (C422) [583](#)
- Encoder - voltage (C421) [583](#)
- Encoder evaluation [108](#)
  - Dig. signals (C2579) [624](#)
- EnDat encoder
  - Flat battery [474](#)
  - Lamp error [474](#)
  - Overcurrent [474](#)
  - Overvoltage [474](#)
  - Position error [474](#)
  - Signal error [474](#)
  - Undervoltage [474](#)
- ENP
  - detected motor type (C186) [562](#)
  - detected serial number (C187) [562](#)
  - Status (C188) [562](#)
- Error during initialisation [500](#)
- Error during the update of inputs and outputs [458](#)
- Error messages [443](#)
- Error number [443](#)
  - 0x00650000 [449](#)
  - 0x00650001 [449](#)
  - 0x00650002 [449](#)
  - 0x00650003 [449](#)
  - 0x00680000 [449](#)
  - 0x00680001 [449](#)
  - 0x00680002 [450](#)
  - 0x00680003 [450](#)
  - 0x00680004 [450](#)
  - 0x00680005 [450](#)
  - 0x00680006 [450](#)
  - 0x00680007 [451](#)
  - 0x00680008 [451](#)
  - 0x00680009 [451](#)
  - 0x0068000a [451](#)
  - 0x0068000b [451](#)
  - 0x0068000c [451](#)
  - 0x0068000d [452](#)
  - 0x0068000e [452](#)
  - 0x0068000f [452](#)
  - 0x00680010 [452](#)
  - 0x00680011 [452](#)
  - 0x00680012 [452](#)
  - 0x00680013 [453](#)
  - 0x00680014 [453](#)
  - 0x00680015 [453](#)
  - 0x00680016 [453](#)
  - 0x00680017 [453](#)
  - 0x00680018 [453](#)
  - 0x00680019 [454](#)
  - 0x0068001a [454](#)
  - 0x0068001b [454](#)
  - 0x0068001c [454](#)
  - 0x0068001d [454](#)
  - 0x0068001e [454](#)
  - 0x0068001f [455](#)
  - 0x00680020 [455](#)
  - 0x00680021 [455](#)
  - 0x00690000 [455](#)
  - 0x00690001 [455](#)
  - 0x00690002 [455](#)

0x00690003	<a href="#">456</a>	0x00770010	<a href="#">466</a>
0x00690004	<a href="#">456</a>	0x00770011	<a href="#">466</a>
0x00690005	<a href="#">456</a>	0x00780000	<a href="#">466</a>
0x00690006	<a href="#">456</a>	0x00780001	<a href="#">466</a>
0x00690007	<a href="#">456</a>	0x00780002	<a href="#">467</a>
0x00690008	<a href="#">456</a>	0x00780003	<a href="#">467</a>
0x00690009	<a href="#">457</a>	0x00780004	<a href="#">467</a>
0x0069000a	<a href="#">457</a>	0x00780005	<a href="#">467</a>
0x0069000b	<a href="#">457</a>	0x00780006	<a href="#">467</a>
0x0069000c	<a href="#">457</a>	0x00780007	<a href="#">467</a>
0x0069000d	<a href="#">457</a>	0x00780008	<a href="#">468</a>
0x006a0000	<a href="#">457</a>	0x00780009	<a href="#">468</a>
0x006a0001	<a href="#">458</a>	0x0078000a	<a href="#">468</a>
0x006a0002	<a href="#">458</a>	0x00790000	<a href="#">468</a>
0x006a0003	<a href="#">458</a>	0x00790001	<a href="#">468</a>
0x006a0004	<a href="#">458</a>	0x00790002	<a href="#">468</a>
0x006a0005	<a href="#">458</a>	0x007b0001	<a href="#">468</a>
0x006a0006	<a href="#">458</a>	0x007b0002	<a href="#">469</a>
0x006a0007	<a href="#">459</a>	0x007b0003	<a href="#">469</a>
0x006a0008	<a href="#">459</a>	0x007b0004	<a href="#">469</a>
0x006a0009	<a href="#">459</a>	0x007b0006	<a href="#">469</a>
0x006a000a	<a href="#">459</a>	0x007b0007	<a href="#">469</a>
0x006a000b	<a href="#">459</a>	0x007b0009	<a href="#">469</a>
0x006a000c	<a href="#">459</a>	0x007b000a	<a href="#">469</a>
0x006a000d	<a href="#">459</a>	0x007b000b	<a href="#">470</a>
0x006a000e	<a href="#">460</a>	0x007b000c	<a href="#">470</a>
0x006a000f	<a href="#">460</a>	0x007b000d	<a href="#">470</a>
0x006a0010	<a href="#">460</a>	0x007b000e	<a href="#">470</a>
0x006a0011	<a href="#">460</a>	0x007b000f	<a href="#">470</a>
0x006a0012	<a href="#">460</a>	0x007b0010	<a href="#">470</a>
0x006a0013	<a href="#">460</a>	0x007b0011	<a href="#">471</a>
0x006a0014	<a href="#">461</a>	0x007b0012	<a href="#">471</a>
0x006a0015	<a href="#">461</a>	0x007b0013	<a href="#">471</a>
0x006a0016	<a href="#">461</a>	0x007b0014	<a href="#">471</a>
0x006f0000	<a href="#">461</a>	0x007b0017	<a href="#">471</a>
0x00720000	<a href="#">462</a>	0x007b0018	<a href="#">471</a>
0x00750000	<a href="#">462</a>	0x007b0019	<a href="#">472</a>
0x00750001	<a href="#">462</a>	0x007b001a	<a href="#">472</a>
0x00750002	<a href="#">462</a>	0x007b001b	<a href="#">472</a>
0x00750003	<a href="#">462</a>	0x007b001c	<a href="#">472</a>
0x00750005	<a href="#">462</a>	0x007b001d	<a href="#">472</a>
0x00750006	<a href="#">463</a>	0x007b001e	<a href="#">472</a>
0x00770000	<a href="#">463</a>	0x007b001f	<a href="#">473</a>
0x00770001	<a href="#">463</a>	0x007b0020	<a href="#">473</a>
0x00770002	<a href="#">463</a>	0x007b0021	<a href="#">473</a>
0x00770003	<a href="#">463</a>	0x007b0023	<a href="#">473</a>
0x00770004	<a href="#">464</a>	0x007b0024	<a href="#">473</a>
0x00770005	<a href="#">464</a>	0x007b0025	<a href="#">473</a>
0x00770006	<a href="#">464</a>	0x007b0026	<a href="#">474</a>
0x00770007	<a href="#">464</a>	0x007b0027	<a href="#">474</a>
0x00770008	<a href="#">464</a>	0x007b0028	<a href="#">474</a>
0x00770009	<a href="#">465</a>	0x007b0029	<a href="#">474</a>
0x0077000a	<a href="#">465</a>	0x007b002a	<a href="#">474</a>
0x0077000b	<a href="#">465</a>	0x007b002b	<a href="#">474</a>
0x0077000c	<a href="#">465</a>	0x007b002c	<a href="#">474</a>
0x0077000d	<a href="#">465</a>	0x007b002d	<a href="#">475</a>
0x0077000e	<a href="#">466</a>	0x007b002e	<a href="#">475</a>
0x0077000f	<a href="#">466</a>	0x007b002f	<a href="#">475</a>

0x007b0030	<a href="#">475</a>	0x00860006	<a href="#">485</a>
0x007b0031	<a href="#">475</a>	0x00860007	<a href="#">485</a>
0x007b0032	<a href="#">475</a>	0x00860008	<a href="#">485</a>
0x007b0033	<a href="#">476</a>	0x00860009	<a href="#">486</a>
0x007b0034	<a href="#">476</a>	0x0086000a	<a href="#">486</a>
0x007b0036	<a href="#">476</a>	0x0086000b	<a href="#">486</a>
0x007b0037	<a href="#">476</a>	0x0086000c	<a href="#">486</a>
0x007b0038	<a href="#">476</a>	0x0086000d	<a href="#">486</a>
0x007b0039	<a href="#">476</a>	0x0086000e	<a href="#">486</a>
0x007c0000	<a href="#">477</a>	0x0086000f	<a href="#">487</a>
0x007c0001	<a href="#">477</a>	0x00860010	<a href="#">487</a>
0x007d0000	<a href="#">477</a>	0x00860011	<a href="#">487</a>
0x007d0001	<a href="#">477</a>	0x00860012	<a href="#">487</a>
0x007f0002	<a href="#">477</a>	0x00860013	<a href="#">487</a>
0x00830000	<a href="#">477</a>	0x00860014	<a href="#">487</a>
0x00830001	<a href="#">478</a>	0x00860015	<a href="#">488</a>
0x00830002	<a href="#">478</a>	0x00860016	<a href="#">488</a>
0x00840000	<a href="#">478</a>	0x00860017	<a href="#">488</a>
0x00840001	<a href="#">478</a>	0x00860018	<a href="#">488</a>
0x00840002	<a href="#">478</a>	0x00860019	<a href="#">488</a>
0x00840003	<a href="#">479</a>	0x0086001a	<a href="#">488</a>
0x00840004	<a href="#">479</a>	0x0086001b	<a href="#">489</a>
0x00840005	<a href="#">479</a>	0x0086001c	<a href="#">489</a>
0x00840006	<a href="#">479</a>	0x0086001d	<a href="#">489</a>
0x00840007	<a href="#">479</a>	0x0086001e	<a href="#">489</a>
0x00840008	<a href="#">479</a>	0x0086001f	<a href="#">489</a>
0x00840009	<a href="#">480</a>	0x00860020	<a href="#">489</a>
0x0084000a	<a href="#">480</a>	0x00870000	<a href="#">490</a>
0x0084000b	<a href="#">480</a>	0x00870001	<a href="#">490</a>
0x0084000c	<a href="#">480</a>	0x00870002	<a href="#">490</a>
0x0084000d	<a href="#">480</a>	0x00870003	<a href="#">490</a>
0x0084000e	<a href="#">480</a>	0x00870008	<a href="#">490</a>
0x0084000f	<a href="#">481</a>	0x00880000	<a href="#">491</a>
0x00840010	<a href="#">481</a>	0x00890000	<a href="#">491</a>
0x00840011	<a href="#">481</a>	0x008c0000	<a href="#">491</a>
0x00840012	<a href="#">481</a>	0x008c0001	<a href="#">491</a>
0x00840013	<a href="#">481</a>	0x008c0002	<a href="#">491</a>
0x00840014	<a href="#">481</a>	0x008c0003	<a href="#">491</a>
0x00840015	<a href="#">482</a>	0x008c0004	<a href="#">492</a>
0x00840016	<a href="#">482</a>	0x008c0005	<a href="#">492</a>
0x00840017	<a href="#">482</a>	0x008c0006	<a href="#">492</a>
0x00840018	<a href="#">482</a>	0x008c0007	<a href="#">492</a>
0x00840019	<a href="#">482</a>	0x008c0008	<a href="#">492</a>
0x0084001a	<a href="#">482</a>	0x008c0009	<a href="#">492</a>
0x0084001b	<a href="#">483</a>	0x008c000a	<a href="#">493</a>
0x0084001c	<a href="#">483</a>	0x008c000b	<a href="#">493</a>
0x0084001d	<a href="#">483</a>	0x008c000d	<a href="#">493</a>
0x0084001e	<a href="#">483</a>	0x008c000e	<a href="#">493</a>
0x0084001f	<a href="#">483</a>	0x008c000f	<a href="#">493</a>
0x00840020	<a href="#">483</a>	0x008c0010	<a href="#">493</a>
0x00840021	<a href="#">484</a>	0x008c0011	<a href="#">494</a>
0x00850000	<a href="#">484</a>	0x008c0012	<a href="#">494</a>
0x00860000	<a href="#">484</a>	0x008c0013	<a href="#">494</a>
0x00860001	<a href="#">484</a>	0x008c0014	<a href="#">494</a>
0x00860002	<a href="#">484</a>	0x008c0015	<a href="#">494</a>
0x00860003	<a href="#">485</a>	0x008c0016	<a href="#">494</a>
0x00860004	<a href="#">485</a>	0x008c0017	<a href="#">495</a>
0x00860005	<a href="#">485</a>	0x008c0018	<a href="#">495</a>

0x008c001a	<a href="#">495</a>	0x009e0010	<a href="#">505</a>
0x008c001d	<a href="#">495</a>	0x009e0011	<a href="#">505</a>
0x00900000	<a href="#">495</a>	0x009e0012	<a href="#">505</a>
0x00900001	<a href="#">495</a>	0x009e0013	<a href="#">505</a>
0x00900002	<a href="#">496</a>	0x009e0014	<a href="#">505</a>
0x00900003	<a href="#">496</a>	0x009e0015	<a href="#">506</a>
0x00900004	<a href="#">496</a>	0x009e0016	<a href="#">506</a>
0x00900005	<a href="#">496</a>	0x009e0017	<a href="#">506</a>
0x00900006	<a href="#">496</a>	0x009e0018	<a href="#">506</a>
0x00900007	<a href="#">496</a>	0x009e0019	<a href="#">506</a>
0x00900008	<a href="#">497</a>	0x009e001a	<a href="#">506</a>
0x00900009	<a href="#">497</a>	0x009e001b	<a href="#">507</a>
0x0090000a	<a href="#">497</a>	0x009e001c	<a href="#">507</a>
0x0090000b	<a href="#">497</a>	0x009e001d	<a href="#">507</a>
0x00910000	<a href="#">497</a>	0x009e001e	<a href="#">507</a>
0x00910001	<a href="#">497</a>	0x009e001f	<a href="#">507</a>
0x00910002	<a href="#">498</a>	0x009e0020	<a href="#">507</a>
0x00910003	<a href="#">498</a>	0x009e0021	<a href="#">508</a>
0x00910004	<a href="#">498</a>	0x009f0000	<a href="#">508</a>
0x00910005	<a href="#">498</a>	0x00a00000	<a href="#">508</a>
0x00910006	<a href="#">498</a>	0x00a00001	<a href="#">508</a>
0x00910008	<a href="#">498</a>	0x00a00002	<a href="#">509</a>
0x00910009	<a href="#">498</a>	0x00a00003	<a href="#">509</a>
0x0091000a	<a href="#">499</a>	0x00a00004	<a href="#">509</a>
0x0091000b	<a href="#">499</a>	0x00a00005	<a href="#">509</a>
0x0091000c	<a href="#">499</a>	0x00a00006	<a href="#">509</a>
0x0091000d	<a href="#">499</a>	0x00a00007	<a href="#">509</a>
0x0091000e	<a href="#">499</a>	0x00a00008	<a href="#">510</a>
0x0091000f	<a href="#">499</a>	0x00a00009	<a href="#">510</a>
0x00910010	<a href="#">500</a>	0x00a0000a	<a href="#">510</a>
0x00910011	<a href="#">500</a>	0x00a0000b	<a href="#">510</a>
0x00910012	<a href="#">500</a>	0x00a0000c	<a href="#">510</a>
0x00920000	<a href="#">500</a>	0x00a0000d	<a href="#">510</a>
0x00990000	<a href="#">500</a>	0x00a0000e	<a href="#">511</a>
0x00990001	<a href="#">500</a>	0x00a0000f	<a href="#">511</a>
0x00990002	<a href="#">501</a>	0x00a00010	<a href="#">511</a>
0x00990003	<a href="#">501</a>	0x00a00011	<a href="#">511</a>
0x00990004	<a href="#">501</a>	0x00a00012	<a href="#">511</a>
0x00990005	<a href="#">501</a>	0x00a00013	<a href="#">511</a>
0x009d0000	<a href="#">501</a>	0x00a00014	<a href="#">512</a>
0x009d0001	<a href="#">502</a>	0x00a00015	<a href="#">512</a>
0x009d0002	<a href="#">502</a>	0x00a00016	<a href="#">512</a>
0x009e0000	<a href="#">502</a>	0x00a00017	<a href="#">512</a>
0x009e0001	<a href="#">502</a>	0x00a00018	<a href="#">512</a>
0x009e0002	<a href="#">502</a>	0x00a00019	<a href="#">512</a>
0x009e0003	<a href="#">503</a>	0x00a0001a	<a href="#">513</a>
0x009e0004	<a href="#">503</a>	0x00a0001b	<a href="#">513</a>
0x009e0005	<a href="#">503</a>	0x00a0001c	<a href="#">513</a>
0x009e0006	<a href="#">503</a>	0x00a0001d	<a href="#">513</a>
0x009e0007	<a href="#">503</a>	0x00a0001e	<a href="#">513</a>
0x009e0008	<a href="#">503</a>	0x00a0001f	<a href="#">513</a>
0x009e0009	<a href="#">504</a>	0x00a00020	<a href="#">514</a>
0x009e000a	<a href="#">504</a>	0x00a10000	<a href="#">514</a>
0x009e000b	<a href="#">504</a>	0x00a10001	<a href="#">514</a>
0x009e000c	<a href="#">504</a>	0x00a10002	<a href="#">514</a>
0x009e000d	<a href="#">504</a>	0x00a10003	<a href="#">515</a>
0x009e000e	<a href="#">504</a>	0x00a10004	<a href="#">515</a>
0x009e000f	<a href="#">505</a>	0x00a10005	<a href="#">515</a>

0x00a10006	<a href="#">515</a>	0x00af0009	<a href="#">526</a>
0x00a10007	<a href="#">515</a>	0x00af000a	<a href="#">526</a>
0x00a10008	<a href="#">516</a>	0x00af000b	<a href="#">526</a>
0x00a20000	<a href="#">516</a>	0x00af000c	<a href="#">526</a>
0x00a30000	<a href="#">516</a>	0x00af000d	<a href="#">526</a>
0x00aa0000	<a href="#">516</a>	0x00af000e	<a href="#">527</a>
0x00aa0001	<a href="#">516</a>	0x00af000f	<a href="#">527</a>
0x00aa0002	<a href="#">517</a>	0x00af0010	<a href="#">527</a>
0x00aa0003	<a href="#">517</a>	0x00af0011	<a href="#">527</a>
0x00aa0004	<a href="#">517</a>	0x00af0012	<a href="#">527</a>
0x00aa0005	<a href="#">517</a>	0x00af0013	<a href="#">527</a>
0x00ac0000	<a href="#">517</a>	0x00af0014	<a href="#">528</a>
0x00ac0001	<a href="#">518</a>	0x00af0015	<a href="#">528</a>
0x00ac0002	<a href="#">518</a>	0x00af0016	<a href="#">528</a>
0x00ad0000	<a href="#">518</a>	0x00af0017	<a href="#">528</a>
0x00ad0001	<a href="#">518</a>	0x00af0018	<a href="#">528</a>
0x00ad0002	<a href="#">518</a>	0x00af0019	<a href="#">528</a>
0x00ad0003	<a href="#">519</a>	0x00af001a	<a href="#">529</a>
0x00ad0004	<a href="#">519</a>	0x00af001b	<a href="#">529</a>
0x00ad0005	<a href="#">519</a>	0x00af001c	<a href="#">529</a>
0x00ad0006	<a href="#">519</a>	0x00af001d	<a href="#">529</a>
0x00ad0007	<a href="#">519</a>	0x00af001e	<a href="#">529</a>
0x00ad0008	<a href="#">519</a>	0x00af001f	<a href="#">529</a>
0x00ad0009	<a href="#">520</a>	0x00af0020	<a href="#">530</a>
0x00ad000a	<a href="#">520</a>	0x00b00000	<a href="#">530</a>
0x00ad000b	<a href="#">520</a>	0x00b00001	<a href="#">530</a>
0x00ad000c	<a href="#">520</a>	0x00b00002	<a href="#">530</a>
0x00ad000d	<a href="#">520</a>	0x00b00003	<a href="#">531</a>
0x00ad000e	<a href="#">520</a>	0x00b00004	<a href="#">531</a>
0x00ad000f	<a href="#">521</a>	0x00b00005	<a href="#">531</a>
0x00ad0010	<a href="#">521</a>	0x00b00006	<a href="#">531</a>
0x00ad0011	<a href="#">521</a>	0x00b00007	<a href="#">531</a>
0x00ad0012	<a href="#">521</a>	0x00b00008	<a href="#">532</a>
0x00ad0013	<a href="#">521</a>	0x00b10000	<a href="#">532</a>
0x00ad0014	<a href="#">521</a>	0x00b20000	<a href="#">532</a>
0x00ad0015	<a href="#">522</a>	0x00b80000	<a href="#">532</a>
0x00ad0016	<a href="#">522</a>	0x00b80001	<a href="#">532</a>
0x00ad0017	<a href="#">522</a>	0x00b80002	<a href="#">533</a>
0x00ad0018	<a href="#">522</a>	0x00b80003	<a href="#">533</a>
0x00ad0019	<a href="#">522</a>	0x00b80004	<a href="#">533</a>
0x00ad001a	<a href="#">522</a>	0x00b80005	<a href="#">533</a>
0x00ad001b	<a href="#">523</a>	0x00b80007	<a href="#">534</a>
0x00ad001c	<a href="#">523</a>	0x00b80008	<a href="#">534</a>
0x00ad001d	<a href="#">523</a>	0x00b80009	<a href="#">534</a>
0x00ad001e	<a href="#">523</a>	0x00b8000a	<a href="#">534</a>
0x00ad001f	<a href="#">523</a>	0x00b8000b	<a href="#">534</a>
0x00ad0020	<a href="#">523</a>	0x00b8000c	<a href="#">535</a>
0x00ad0021	<a href="#">524</a>	0x00b8000d	<a href="#">535</a>
0x00ae0000	<a href="#">524</a>	0x00b8000e	<a href="#">535</a>
0x00af0000	<a href="#">524</a>	0x00b8000f	<a href="#">535</a>
0x00af0001	<a href="#">524</a>	0x00b80010	<a href="#">536</a>
0x00af0002	<a href="#">525</a>	0x00b80011	<a href="#">536</a>
0x00af0003	<a href="#">525</a>	Error number (C168)	<a href="#">559</a>
0x00af0004	<a href="#">525</a>	Error status (C166)	<a href="#">559</a>
0x00af0005	<a href="#">525</a>	Ethernet IP address client x (C1510)	<a href="#">612</a>
0x00af0006	<a href="#">525</a>	Ethernet status client x (C1511)	<a href="#">612</a>
0x00af0007	<a href="#">525</a>	Ext. 24-V voltage (C65)	<a href="#">550</a>
0x00af0008	<a href="#">526</a>		

External actual position (C2577) [624](#)  
External error [462](#)

### F

Failure of motor phase U [475](#)  
Failure of motor phase V [475](#)  
Failure of motor phase W [475](#)  
Faulty application parameter [460](#)  
Faulty device command transmission [468](#)  
Faulty program download [458](#)  
Feed constant (C2524) [615](#)  
Feedback [38](#)  
Feedback system motor temperature (C1193) [609](#)  
Feedback to Lenze [679](#)  
Feedforward control of torque [93](#)  
Field controller gain (C77) [551](#)  
Field controller reset time (C78) [552](#)  
Field weak. contr. reset time (C578) [587](#)  
Field weakening controller gain (C577) [587](#)  
Filter time const. DC detection (C280) [567](#)  
Filtered torque setpoint (C697) [598](#)  
Firmware - compile date (C201) [562](#)  
Firmware - version (C99) [553](#)  
Firmware has been changed [454](#)  
Firmware is not compatible [454](#)  
Firmware product type (C200) [562](#)  
Following error (C2576) [624](#)  
Frequency - current setpoint filter (C270) [566](#)

### G

GDO channel 1/trigger 1 (C731) [598](#)  
GDO channel 2/trigger 2 (C732) [598](#)  
GDO channel 3 (C733) [598](#)  
GDO channel 4 (C734) [598](#)  
GDO channel 5 (C735) [598](#)  
GDO channel 6 (C736) [599](#)  
GDO channel 7 (C737) [599](#)  
GDO channel 8 (C738) [599](#)  
GDO common parameter (C730) [598](#)  
GDO status information (C739) [599](#)  
Gearbox fact. denom. load (C2523) [615](#)  
Gearbox fact. denom. motor (C2521) [615](#)  
Gearbox fact. numer. load (C2522) [615](#)  
Gearbox fact. numer. motor (C2520) [614](#)  
General error in the application [457](#)  
Grinding OFF time (C2599) [628](#)  
Grinding ON time (C2598) [627](#)  
Grinding speed (C2596) [627](#)

### H

Heartbeat not periodic [498](#)  
Heatsink  
Fan is defective [466](#)  
Overtemperature [463](#)

Temperature > C00122 [463](#)  
Temperature sensor defective [465](#)  
Heatsink temp. warn. threshold (C122) [555](#)  
Heatsink temperature (C61) [550](#)  
HM\_dnHomePos\_p (C2658) [634](#)  
HM\_dnState (C2657) [634](#)  
Home pos. after mains switching (C2652) [633](#)  
Home position (C2642) [631](#)  
Home target position (C2643) [632](#)  
Homing  
Dig. signals (C2659) [634](#)  
HW countries of origin (C209) [564](#)  
HW descriptions (C205) [563](#)  
HW manufacturer (C208) [564](#)  
HW manufacturing data (C206) [564](#)  
HW product types (C203) [563](#)  
HW serial numbers (C204) [563](#)  
HW versions (C210) [564](#)

### I

Identification status (C854) [606](#)  
Imax Lss saturat. characteristic (C2855) [646](#)  
Imprint [2](#)  
Incorrect memory module [452](#)  
Influence winding I'xt mon. (C1195) [609](#)  
Inside the device  
Fan is defective [466](#)  
Overtemperature [464](#)  
Temperature > CXXXXX [464](#)  
Temperature sensor defective [465](#)  
Integral-action time of position controller (C2554) [621](#)  
Internal clock (C1214) [611](#)  
Internal communication error (DMA) [476](#)  
Internal communication error (host MCTRL) [471](#)  
Internal communication error (MCTRL host) [476](#)  
Internal error  
see C00180 [498](#)  
Internal error (CRC application) [495](#)  
Internal error (CRC code RAM) [455](#)  
Internal error (event mechanism) [457](#)  
Internal error (faulty binary semaphores) [457](#)  
Internal error (file system) [457](#)  
Internal error (LDS instance data) [455](#)  
Internal error (LDS tasks) [456](#)  
Internal error (memory area - logbook) [455](#)  
Internal error (message memory) [456](#)  
Internal error (message queue) [456](#)  
Internal error (name data base) [456](#)  
Internal error (semaphores) [457](#)  
Internal error (storage blocks) [456](#)  
Internal error (task queue) [456](#)  
Internal torque limits (C2559) [622](#)  
Invalid PLC configuration [463](#), [476](#), [477](#), [532](#)



**J**

Jerk has been limited [535](#)

**K**

## Keypad

Default parameter (C466) [585](#)

Default welcome screen (C467) [585](#)

Fct. STOP key (C469) [585](#)

Welcome screen time-out (C465) [585](#)

Keypad LCD display [434](#)

**L**

Layout of the safety information [18](#)

LCD display (keypad) [434](#)

LED status displays [34](#)

Lenze setting loaded [495](#)

Lh adaptation (C2861) [647](#)

Liability [2](#)

LIM\_dnState (C2718) [642](#)

LIM\_dwControl (C2717) [642](#)

Limitation active (C2715) [641](#)

Limitations effective (C2702) [638](#)

Limited speed (C2708) [640](#)

Limited speed (C2709) [640](#)

## Limiter

Dig. signals (C2719) [642](#)

Load reference speed (C2542) [619](#)

Load reference torque (C2543) [619](#)

Loading of Lenze setting failed [496](#)

Log file - event filter (C169) [559](#)

## LOGFILE

Overflow [449](#)

Reset (read error) [449](#)

Reset (version error) [449](#)

LS\_AnalogInput [119](#)

LS\_AnalogOutput [122](#)

LS\_Brake [231](#)

LS\_DigitalInput [124](#)

LS\_DigitalOutput [126](#)

LS\_DriveInterface [60](#)

LS\_Feedback [115](#)

LS\_Homing [174](#)

LS\_Limiter [209](#)

LS\_ManualJog [162](#)

LS\_MotorInterface [104](#)

LS\_Positioner [180](#)

LS\_PositionFollower [189](#)

LS\_quick stop [155](#)

LS\_SafetyModule [139](#)

LS\_SpeedFollower [195](#)

LS\_Stop [151](#)

LS\_TorqueFollower [199](#)

LS\_TouchProbe1 [132](#)

LS\_TouchProbe2 [132](#)

LS\_TouchProbe3 [132](#)

LS\_TouchProbe4 [132](#)

LS\_TouchProbe5 [132](#)

LS\_TouchProbe6 [132](#)

LS\_TouchProbe7 [132](#)

LS\_TouchProbe8 [132](#)

LS\_TouchProbeLoad [133](#)

LS\_TouchProbeMotor [133](#)

Lss sat. characteristic (C2859) [647](#)

**M**

Machine parameters [35](#)

Mains - voltage (C173) [560](#)

Mains voltage switched off [497](#)

Mains voltage switched on [497](#)

Manual acceleration (C2622) [630](#)

Manual deceleration (C2623) [630](#)

## Manual jog

Dig. signals (C2639) [631](#)

Manual jog to software limit position [160](#)

Manual speed 1 (C2620) [630](#)

Manual speed 2 (C2621) [630](#)

Manual S-ramp time (C2624) [630](#)

Max. accel. to be displayed (C2541) [619](#)

Max. acceleration (C2705) [639](#)

Max. acceleration change (C274) [566](#)

Max. angle of rotation after mains switching (C2653) [633](#)

Max. dist. manual jog (C2713) [641](#)

Max. dist. manual jog (C2714) [641](#)

Max. power of brake resistor (C130) [556](#)

Max. speed (C2703) [639](#)

Max. speed [rpm] (C2704) [639](#)

Max. speed to be displayed (C2540) [618](#)

Max. temperature of brake resistor (C132) [556](#)

Maximum acceleration exceeded [536](#)

Maximum current (C22) [548](#)

Maximum position to be displayed (C2539) [618](#)

Maximum speed exceeded [536](#)

MCTRL\_dnAccelerationAdd (C804) [603](#)

MCTRL\_dnBoost (C814) [605](#)

MCTRL\_dnDCBusVoltage (C779) [601](#)

MCTRL\_dnDeltaMotorPos\_p (C791) [602](#)

MCTRL\_dnFieldWeak (C816) [605](#)

MCTRL\_dnFluxAct (C778) [600](#)

MCTRL\_dnFlyingSpeedAct (C787) [602](#)

MCTRL\_dnI2xtLoad (C790) [602](#)

MCTRL\_dnImotAct (C780) [601](#)

MCTRL\_dnInputJerkCtrl (C776) [600](#)

MCTRL\_dnInputTorqueCtrl (C777) [600](#)

MCTRL\_dnIxtLoad (C786) [602](#)

MCTRL\_dnLoadPosAct (C771) [599](#)

MCTRL\_dnLoadPosRefValue (C813) [605](#)

MCTRL\_dnLoadSpeedAct (C773) [600](#)

- MCTRL\_dnMotorFreqAct (C784) [601](#)
- MCTRL\_dnMotorPosAct (C770) [599](#)
- MCTRL\_dnMotorPosRefValue (C812) [605](#)
- MCTRL\_dnMotorSpeedAct (C772) [599](#)
- MCTRL\_dnOutputPosCtrlMotor\_s (C792) [603](#)
- MCTRL\_dnOutputSpeedCtrl (C775) [600](#)
- MCTRL\_dnPosCtrlAdapt (C811) [604](#)
- MCTRL\_dnPosCtrlOutLimit (C808) [604](#)
- MCTRL\_dnPosSet (C800) [603](#)
- MCTRL\_dnSpeedAdd (C802) [603](#)
- MCTRL\_dnSpeedCtrlAdapt (C810) [604](#)
- MCTRL\_dnSpeedCtrlIntegrator (C815) [605](#)
- MCTRL\_dnSpeedLowLimit (C805) [603](#)
- MCTRL\_dnSpeedSet\_s (C817) [605](#)
- MCTRL\_dnTorqueAct (C774) [600](#)
- MCTRL\_dnTorqueAdd (C803) [603](#)
- MCTRL\_dnTorqueCtrlAdapt (C809) [604](#)
- MCTRL\_dnTorqueHighLimit (C807) [604](#)
- MCTRL\_dnTorqueLowLimit (C806) [604](#)
- MCTRL\_dwMaxDeviceCurrent (C789) [602](#)
- MCTRL\_dwMaxEffMotorTorque (C788) [602](#)
- MCTRL\_dwMaxMotorSpeed (C781) [601](#)
- MCTRL\_dwMaxMotorTorque (C782) [601](#)
- MCTRL\_dwMotorVoltageAct (C783) [601](#)
- Memory module
  - File system has been formatted [477](#)
  - File system has been restored [477](#)
  - File system is faulty [454](#)
- Memory module has been changed [453](#)
- Memory module has been removed [450](#)
- Memory module is defective or missing [450](#), [451](#)
- Memory module is missing [449](#)
- Messages motor interface (C2560) [622](#)
- Min. S-ramp time (C2706) [639](#)
- Modulation modes [80](#)
- Moment of inertia (C273) [566](#)
- Monitoring [439](#)
- Motor
  - Actual current value > C00620 [472](#)
  - Actual speed value > C00596 [473](#)
  - Calculated electromotive force factor unrealistic [470](#)
  - Calculated flux factor unrealistic [470](#)
  - Calculated leakage inductance unrealistic [472](#)
  - Calculated motor impedance unrealistic [468](#)
  - Calculated mutual inductance unrealistic [469](#)
  - Calculated rotor resistance unrealistic [469](#)
  - Calculated rotor time constant unrealistic [470](#)
  - Device current is too low for rated magnetisation [469](#)
  - Overtemperature [463](#)
  - Phase resistance is too high [469](#)
  - PTC has triggered [466](#)
  - Rated current [469](#)
  - Temperature > C00121 [463](#)
  - Temperature sensor defective [465](#)
- Motor - cosine phi (C91) [553](#)
- Motor - magnetising current (C92) [553](#)
- Motor - mutual inductance (C79) [552](#)
- Motor - pole pair number (C59) [549](#)
- Motor - rated current (C88) [553](#)
- Motor - rated frequency (C89) [553](#)
- Motor - rated speed (C87) [553](#)
- Motor - rated voltage (C90) [553](#)
- Motor - rotor resistance (C82) [552](#)
- Motor - rotor time constant (C83) [552](#)
- Motor brake
  - Angular drift with closed brake is too large [533](#)
  - Automatically activated when the waiting time has elapsed [533](#)
  - Status monitoring error [533](#)
- Motor control
  - Task overflow [471](#)
- Motor control selection (C6) [547](#)
- Motor current (C54) [548](#)
- Motor data are inconsistent [469](#), [471](#)
- Motor encoder [112](#)
  - Module selected under C00495 not available [473](#)
- Motor encoder (C495) [586](#)
- Motor interface [64](#)
  - % signals (C2568) [622](#)
  - Dig. signals (C2569) [623](#)
- Motor load I<sup>2</sup>t > C00120 [467](#)
- Motor load I<sup>2</sup>t > C00127 [467](#)
- Motor mounting direction (C2527) [616](#)
- Motor operating temperature (C1194) [609](#)
- Motor overload protection (I<sup>2</sup>t) (C120) [555](#)
- Motor parameter identification cancelled [476](#)
- Motor pos. contr. output (C2557) [621](#)
- Motor reference speed (C11) [547](#)
- Motor standstill time constant (C494) [586](#)
- Motor stator leakage inductance (C85) [552](#)
- Motor stator resistance (C84) [552](#)
- Motor temp. warning threshold (C121) [555](#)
- Motor temperature
  - Module selected under C01193 not available [473](#)
- Motor temperature (C63) [550](#)
- Motor thermal sensor (C1190) [608](#)
- Motor voltage (C52) [548](#)
- MXI1
  - CAN module is missing or incompatible [495](#)
  - Digital frequency module is missing or incompatible [494](#)
  - Ethernet module is missing or incompatible [494](#)
  - ICM module missing or incompatible [494](#)
  - Module changed during operation [450](#)
  - Module has been changed [453](#)
  - Module is defective or missing [451](#)
  - Module is missing or incompatible [493](#)
  - PROFIBUS module is missing or incompatible [493](#)
  - Wrong module [452](#)
- MXI2

- CAN module is missing or incompatible [495](#)
  - Digital frequency module is missing or incompatible [494](#)
  - Ethernet module is missing or incompatible [494](#)
  - ICM module missing or incompatible [494](#)
  - Module changed during operation [450](#)
  - Module has been changed [453](#)
  - Module is defective or missing [451](#)
  - Module is missing or incompatible [493](#)
  - PROFIBUS module is missing or incompatible [493](#)
  - Wrong module [452](#)
- N**
- Negative direction of rotation limited [534](#)
  - Negative limit switch has triggered [533](#)
  - Negative software limit switch overtravelled [534](#)
  - New applications loaded [458](#)
  - No heartbeat signal detected [498](#)
  - No parameters for module in MXI1 [497](#)
  - No parameters for module in MXI2 [497](#)
  - Number of CRC cycles (C618) [596](#)
- O**
- Offset actual pos. value/setp. (C2578) [624](#)
  - Operating mode brake (C2580) [625](#)
  - Optimise response to setpoint changes [93](#)
  - Overchange [392](#)
  - Overcurrent detected [470](#)
- P**
- Parameter error information (C217) [565](#)
  - Parameter set
    - Variant conflict [497](#)
    - Version conflict [496](#)
  - Parameter set faulty [495](#)
  - Parameter set loaded [496](#)
  - Parameter set restored [496](#)
  - Parameter set saved [496](#)
  - PDO mapping (MXI1)
    - Faulty configuration [461](#)
  - PDO mapping (MXI2)
    - Faulty configuration [461](#)
  - Permissible angle of rotation (C2595) [627](#)
  - Permissible direction of rot. (C2707) [639](#)
  - PF\_dnMotorAcc\_x (C2685) [636](#)
  - PF\_dnSpeedAdd1\_s (C2686) [636](#)
  - Phase controller gain (C254) [565](#)
  - Phase currents (C55) [549](#)
  - Pointer access in impermissible memory area [460](#)
  - Pos. contr D comp.(C2555) [621](#)
  - Pos. contr. limitation (C2556) [621](#)
  - Pos. contr. output (C2558) [621](#)
  - POS\_dnProfileSpeed\_s (C2676) [635](#)
  - POS\_dnState (C2675) [634](#)
  - POS\_dwActualProfileNumber (C2674) [634](#)
  - Position controller gain (C2553) [621](#)
  - Position encoder [113](#)
    - Module selected under C00490 not available [473](#)
  - Position encoder (C490) [585](#)
  - Position encoder mounting direction (C2529) [616](#)
  - Position follower
    - % signals (C2687) [636](#)
    - Dig. signals (C2689) [637](#)
    - Pos. signal (C2688) [636](#)
  - Position setpoint (C2552) [620](#)
  - Position setpoint (C2573) [623](#)
  - Position target outside the software limit positions [535](#)
  - Position value faulty [500](#)
  - Positioning
    - % signals (C2677) [635](#)
    - Dig. signals (C2679) [635](#)
    - Pos. signals (C2678) [635](#)
  - Positioning modes [395](#)
  - Positive direction of rotation limited [534](#)
  - Positive limit switch has triggered [532](#)
  - Positive software limit switch overtravelled [534](#)
  - Power section is defective [449](#), [451](#)
  - Power section is not compatible [452](#)
  - Power stage has been changed [453](#)
  - Power-on time meter (C179) [561](#)
  - Profile chaining with velocity changeover (overchange) [392](#)
  - Program auto-start (C2104) [613](#)
  - Program name (C2113) [614](#)
  - Program runtime (C2109) [614](#)
  - Program status (C2108) [613](#)
  - Project not available [493](#)
  - Project not loaded [492](#)
  - ProjectList.dat file is faulty [491](#)
  - ProjectList.dat file is invalid [492](#)
  - ProjectList.dat file is missing [492](#)
  - ProjectSelection.dat file is faulty [491](#)
  - ProjectSelection.dat file is invalid [492](#)
  - ProjectSelection.dat file is missing [491](#)
- Q**
- Quick stop
    - Dig. signals (C2619) [629](#)
  - Quick stop by (source) (C159) [559](#)
  - Quick stop deceleration time (C105) [554](#)
  - Quick stop S-ramp time (C106) [554](#)
- R**
- Rated motor power (C81) [552](#)
  - Read error - service register [462](#)
  - Red. brake chopper threshold (C181) [561](#)
  - Ref. acceleration 1 (C2645) [632](#)
  - Ref. acceleration 2 (C2647) [632](#)
  - Ref. blocking time (C2650) [633](#)

- Ref. deceleration time quick stop (C107) [554](#)
  - Ref. for dec. time of stop (C2612) [629](#)
  - Ref. mode (C2640) [631](#)
  - Ref. speed 1 (C2644) [632](#)
  - Ref. speed 2 (C2646) [632](#)
  - Ref. S-ramp time (C2648) [632](#)
  - Ref. torque limit (C2649) [633](#)
  - Ref. touch probe configuration (C2651) [633](#)
  - Reference search [165](#)
  - Reference setting [165](#)
  - Required license missing [493](#)
  - Required safety module (C214) [565](#)
  - Reset of error message [44](#), [447](#)
  - Resistor for spec. characteristic (C1192) [609](#)
  - Resolution of a unit (C2532) [617](#)
  - Resolver
    - Calculated acceleration unrealistic [473](#)
    - Open circuit [471](#)
  - Resolver - pole pair number (C80) [552](#)
  - Resolver error correction (C416) [583](#)
  - Resp. CAN life guarding error (C614) [595](#)
  - Resp. DC bus overvoltage (C600) [592](#)
  - Resp. to CAN bus off (C595) [591](#)
  - Resp. to CAN heartbeat error (C613) [595](#)
  - Resp. to CAN node guarding error (C612) [594](#)
  - Resp. to CAN-RPDOx error (C591) [591](#)
  - Resp. to comm. encoder error (C601) [593](#)
  - Resp. to comm. error with MXI1 (C1501) [611](#)
  - Resp. to comm. error with MXI2 (C1502) [612](#)
  - Resp. to CPU temp. > C00126 (C589) [590](#)
  - Resp. to device overload (C604) [593](#)
  - Resp. to encoder open circuit (C580) [588](#)
  - Resp. to external fault (C581) [588](#)
  - Resp. to failure t. sensor motor (C594) [591](#)
  - Resp. to heatsink fan failure (C610) [594](#)
  - Resp. to heatsink temp. > C00122 (C582) [589](#)
  - Resp. to imp. device config. (C615) [595](#)
  - Resp. to integral fan failure (C611) [594](#)
  - Resp. to limitation (C2716) [642](#)
  - Resp. to max. motor current (C619) [596](#)
  - Resp. to max. speed reached (C607) [593](#)
  - Resp. to motor overload (C606) [593](#)
  - Resp. to motor overtemp. KTY (C583) [589](#)
  - Resp. to motor overtemp. PTC (C585) [589](#)
  - Resp. to motor phase failure (C597) [592](#)
  - Resp. to motor temp. > C00121 (C584) [589](#)
  - Resp. to new firmware of drive (C635) [596](#)
  - Resp. to new module in MXI1 (C636) [597](#)
  - Resp. to new module in MXI2 (C637) [597](#)
  - Resp. to open circuit AIN1 (C598) [592](#)
  - Resp. to overload brake chopper (C573) [587](#)
  - Resp. to resolver open circuit (C586) [590](#)
  - Resp. to speed monitoring (C579) [588](#)
  - Resp. to t. sensor drive failure (C588) [590](#)
  - Resp. to overtemp. brake resist. (C574) [587](#)
  - Resulting gearbox factors (C2531) [617](#)
  - Rotor angle (C58) [549](#)
  - Rotor position (C60) [549](#)
  - Rr adaptation (C2860) [647](#)
  - Run-time error [459](#)
  - Runtime task 1 (C2121) [614](#)
  - Runtime task 2 (C2122) [614](#)
  - Runtime task 3 (C2123) [614](#)
- ## S
- S1 torque characteristic l'xt mon. (C1196) [610](#)
  - Safety engineering [135](#)
  - Safety instructions [18](#)
  - Safety module [135](#)
    - Incompatible to setting under C00214 [500](#)
  - Safety module has been changed [453](#)
  - Safety module has been removed [451](#)
  - Safety module is defective or missing [450](#), [452](#)
  - Saturation characteristic [82](#)
  - Saving of parameters failed [496](#)
  - Service code (C100) [553](#)
  - Service code (C1211) [611](#)
  - Service code (C167) [559](#)
  - Service code (C171) [559](#)
  - Service code (C175) [560](#)
  - Service code (C176) [560](#)
  - Service code (C177) [561](#)
  - Service code (C180) [561](#)
  - Service code (C2850) [645](#)
  - Service code (C2851) [645](#)
  - Service code (C2852) [646](#)
  - Service code (C2854) [646](#)
  - Service code (C2856) [646](#)
  - Service code (C2857) [647](#)
  - Service code (C2858) [647](#)
  - Service code (C2996) [647](#)
  - Service code (C2997) [647](#)
  - Service code (C2998) [647](#)
  - Service code (C2999) [647](#)
  - Service code (C308) [567](#)
  - Service code (C309) [567](#)
  - Service code (C310) [567](#)
  - Service code (C325) [570](#)
  - Service code (C326) [570](#)
  - Service code (C327) [571](#)
  - Service code (C328) [571](#)
  - Service code (C329) [571](#)
  - Service code (C330) [571](#)
  - Service code (C335) [571](#)
  - Service code (C336) [571](#)
  - Service code (C337) [571](#)

- Service code (C338) [571](#)
  - Service code (C379) [579](#)
  - Service code (C395) [582](#)
  - Service code (C396) [582](#)
  - Service code (C397) [582](#)
  - Service code (C468) [585](#)
  - Service code (C512) [586](#)
  - Service code (C513) [586](#)
  - Service code (C514) [586](#)
  - Service code (C515) [586](#)
  - Service code (C516) [586](#)
  - Service code DataFlash (C1213) [611](#)
  - Service password (C4) [546](#)
  - Setpoint interpolation (C2550) [620](#)
  - Setting for test mode (C399) [582](#)
  - Setting the error response [439](#)
  - SF\_dnMotorAcc\_x (C2692) [637](#)
  - SF\_dnSpeedAdd\_s (C2693) [637](#)
  - Signal source - speed setpoint (C275) [567](#)
  - Signal source - torque setpoint (C276) [567](#)
  - Software limit pos. effective (C2700) [638](#)
  - Software limit positions (C2701) [638](#)
  - Source position setpoint (C2680) [636](#)
  - Speed act. val. time const. (C497) [586](#)
  - Speed controller D component (C72) [551](#)
  - Speed controller gain (C70) [551](#)
  - Speed controller output (C694) [597](#)
  - Speed controller reset time (C71) [551](#)
  - Speed follower
    - % signals (C2694) [637](#)
    - Dig. signals (C2695) [637](#)
  - Speed has been limited [534](#)
  - Speed limitation (C909) [606](#)
  - Speed setpoint (C2572) [623](#)
  - Speed setpoint (C50) [548](#)
  - Speed setpoint (C692) [597](#)
  - Speed unit (C2537) [618](#)
  - S-ramp time - stop function (C2611) [629](#)
  - S-ramp time lim. speed (C2711) [640](#)
  - Starting torque 1 (C2586) [626](#)
  - Starting torque 2 (C2587) [626](#)
  - Starting torque source (C2588) [626](#)
  - State bus [127](#)
  - Status - fan control (C587) [590](#)
  - Status DCTRL control input (C878) [606](#)
  - Status displays [34](#)
  - Status input monitoring (C2583) [625](#)
  - Status manual jog (C2638) [630](#)
  - Status word 1 (C150) [557](#)
  - Status word 2 (C155) [557](#)
  - Status word dig. inputs (C2803) [644](#)
  - Status word dig. outputs (C2802) [644](#)
  - Status/control word MCTRL (C156) [558](#)
  - STP\_bStopActive (C2617) [629](#)
  - STP\_dnState (C2616) [629](#)
  - Structure of safety instructions [18](#)
  - Switching frequency (C18) [547](#)
  - Switching frequency reduction [79](#)
  - Sync- cycle time (C1121) [607](#)
  - Sync phase position (C1122) [607](#)
  - Sync source (C1120) [606](#)
  - Sync window (C1123) [607](#)
  - Sync-PLL increment (C1124) [608](#)
  - System bus [134](#)
  - System error messages [443](#)
  - System task
    - Task overflow [499](#)
  - System task 1
    - Task overflow [499](#)
  - System task 2
    - Task overflow [499](#)
  - System task 3
    - Task overflow [499](#)
- ## T
- Technology applications [233](#), [241](#), [287](#), [367](#)
  - Temperature for spec. characteristic (C1191) [609](#)
  - Temperature inside the controller (C62) [550](#)
  - Test mode - motor control (C398) [582](#)
  - Test torque (C2594) [627](#)
  - Therm. motor time constant (C128) [556](#)
  - Thermal motor load (I<sup>2</sup>t) (C66) [550](#)
  - Threshold - mains recov. detect. (C185) [562](#)
  - Threshold - undervoltage (LU) (C174) [560](#)
  - Threshold for max. motor current (C620) [596](#)
  - Threshold max. speed reached (C596) [591](#)
  - Threshold motor phase failure (C599) [592](#)
  - Time error - controller interface [468](#)
  - Time unit (C2533) [618](#)
  - Torque (C57) [549](#)
  - Torque feedforward control [93](#)
  - Torque follower
    - % signals (C2698) [638](#)
    - Dig. signals (C2699) [638](#)
  - Torque setpoint (C56) [549](#)
  - Torque setpoint (C696) [598](#)
  - Total speed setpoint (C691) [597](#)
  - Total torque setpoint (C695) [598](#)
  - Touch probe detection [129](#)
  - Traversing range (C2528) [616](#)
  - TTL encoder signal evaluation (C427) [583](#)
- ## U
- Unit [39](#)
  - Unit (C2525) [615](#)
  - User task 1
    - Overflow [458](#)

User task 2  
  Overflow [458](#)  
User task 3  
  Overflow [458](#)  
User task 4  
  Overflow [459](#)  
User task 5  
  Overflow [459](#)  
User task 6  
  Overflow [459](#)  
User task 7  
  Overflow [459](#)  
User task 8  
  Overflow [459](#)  
User task 9  
  Overflow [459](#)  
User-defined time unit (C2534) [618](#)  
User-defined unit (C2526) [615](#)  
User-defined unit (C2535) [618](#)

### V

Violation of the time dial [468](#)  
Vp Lss saturat. characteristic (C2853) [646](#)

### W

Waiting time - brake activation (C2593) [627](#)  
Waiting time - status monitoring (C2591) [626](#)  
Warning threshold - CPU temperature (C126) [555](#)  
Warning threshold - motor overload (C127) [555](#)  
Width - current setpoint filter (C271) [566](#)  
Window speed monitoring (C576) [587](#)  
Wrong safety module [453](#)

### Z

Zero speed detection threshold (C19) [547](#)

# FEEDBACK



## Your opinion is important to us

These Instructions were created to the best of our knowledge and belief to give you the best possible support for handling our product.

If you have suggestions for improvement, please e-mail us to:

[feedback-docu@Lenze.de](mailto:feedback-docu@Lenze.de)

Thank you for your support.

*Your Lenze documentation team*